

**libximc**

2.8.9

Generated by Doxygen 1.8.1.2

Mon Jul 4 2016 20:33:21

# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	About . . . . .	1
1.2	System requirements . . . . .	1
1.2.1	For rebuilding library . . . . .	1
1.2.2	For using library . . . . .	2
<b>2</b>	<b>How to rebuild library</b>	<b>3</b>
2.1	Building on generic UNIX . . . . .	3
2.2	Building on debian-based linux systems . . . . .	3
2.3	Building on redhat-based linux systems . . . . .	3
2.4	Buliding on Mac OS X . . . . .	4
2.5	Buliding on Windows . . . . .	4
2.6	Source code access . . . . .	4
<b>3</b>	<b>How to use with...</b>	<b>5</b>
3.1	Usage with C . . . . .	5
3.1.1	Visual C++ . . . . .	5
3.1.2	MinGW . . . . .	5
3.1.3	C++ Builder . . . . .	5
3.1.4	XCode . . . . .	6
3.1.5	GCC . . . . .	6
3.2	.NET . . . . .	6
3.3	Delphi . . . . .	6
3.4	Java . . . . .	6
3.5	Python . . . . .	7
3.6	MATLAB . . . . .	7
3.7	Generic logging facility . . . . .	8
3.8	Required permissions . . . . .	8
<b>4</b>	<b>Data Structure Documentation</b>	<b>9</b>
4.1	accessories_settings.t Struct Reference . . . . .	9
4.1.1	Detailed Description . . . . .	9

4.1.2	Field Documentation	10
4.1.2.1	LimitSwitchesSettings	10
4.1.2.2	MagneticBrakeInfo	10
4.1.2.3	MBRatedCurrent	10
4.1.2.4	MBRatedVoltage	10
4.1.2.5	MBSettings	10
4.1.2.6	MBTorque	10
4.1.2.7	TemperatureSensorInfo	10
4.1.2.8	TSGrad	10
4.1.2.9	TSMax	10
4.1.2.10	TSMin	10
4.1.2.11	TSSettings	10
4.2	analog_data.t Struct Reference	11
4.2.1	Detailed Description	12
4.2.2	Field Documentation	12
4.2.2.1	A1Voltage	12
4.2.2.2	A1Voltage_ADC	12
4.2.2.3	A2Voltage	12
4.2.2.4	A2Voltage_ADC	12
4.2.2.5	ACurrent	12
4.2.2.6	ACurrent_ADC	12
4.2.2.7	B1Voltage	13
4.2.2.8	B1Voltage_ADC	13
4.2.2.9	B2Voltage	13
4.2.2.10	B2Voltage_ADC	13
4.2.2.11	BCurrent	13
4.2.2.12	BCurrent_ADC	13
4.2.2.13	FullCurrent	13
4.2.2.14	FullCurrent_ADC	13
4.2.2.15	Joy	13
4.2.2.16	Joy_ADC	13
4.2.2.17	L	13
4.2.2.18	L5	13
4.2.2.19	L5_ADC	14
4.2.2.20	Pot	14
4.2.2.21	R	14
4.2.2.22	SupVoltage	14
4.2.2.23	SupVoltage_ADC	14
4.2.2.24	Temp	14
4.2.2.25	Temp_ADC	14

4.3	brake_settings_t Struct Reference . . . . .	14
4.3.1	Detailed Description . . . . .	15
4.3.2	Field Documentation . . . . .	15
4.3.2.1	BrakeFlags . . . . .	15
4.3.2.2	t1 . . . . .	15
4.3.2.3	t2 . . . . .	15
4.3.2.4	t3 . . . . .	15
4.3.2.5	t4 . . . . .	15
4.4	calibration_t Struct Reference . . . . .	15
4.4.1	Detailed Description . . . . .	15
4.5	chart_data_t Struct Reference . . . . .	16
4.5.1	Detailed Description . . . . .	16
4.5.2	Field Documentation . . . . .	16
4.5.2.1	DutyCycle . . . . .	16
4.5.2.2	Joy . . . . .	16
4.5.2.3	Pot . . . . .	17
4.5.2.4	WindingCurrentA . . . . .	17
4.5.2.5	WindingCurrentB . . . . .	17
4.5.2.6	WindingCurrentC . . . . .	17
4.5.2.7	WindingVoltageA . . . . .	17
4.5.2.8	WindingVoltageB . . . . .	17
4.5.2.9	WindingVoltageC . . . . .	17
4.6	command_add_sync_in_action_calb_t Struct Reference . . . . .	17
4.6.1	Field Documentation . . . . .	17
4.6.1.1	Position . . . . .	17
4.6.1.2	Time . . . . .	18
4.7	command_add_sync_in_action_t Struct Reference . . . . .	18
4.7.1	Detailed Description . . . . .	18
4.7.2	Field Documentation . . . . .	18
4.7.2.1	Time . . . . .	18
4.7.2.2	uPosition . . . . .	18
4.8	control_settings_calb_t Struct Reference . . . . .	18
4.8.1	Field Documentation . . . . .	19
4.8.1.1	Flags . . . . .	19
4.8.1.2	MaxClickTime . . . . .	19
4.8.1.3	MaxSpeed . . . . .	19
4.8.1.4	Timeout . . . . .	19
4.9	control_settings_t Struct Reference . . . . .	19
4.9.1	Detailed Description . . . . .	19
4.9.2	Field Documentation . . . . .	20

4.9.2.1	Flags	20
4.9.2.2	MaxClickTime	20
4.9.2.3	MaxSpeed	20
4.9.2.4	Timeout	20
4.9.2.5	uDeltaPosition	20
4.9.2.6	uMaxSpeed	20
4.10	controller.name.t Struct Reference	20
4.10.1	Detailed Description	21
4.10.2	Field Documentation	21
4.10.2.1	ControllerName	21
4.10.2.2	CtrlFlags	21
4.11	ctp.settings.t Struct Reference	21
4.11.1	Detailed Description	21
4.11.2	Field Documentation	21
4.11.2.1	CTPFlags	21
4.11.2.2	CTPMinError	22
4.12	debug.read.t Struct Reference	22
4.12.1	Detailed Description	22
4.12.2	Field Documentation	22
4.12.2.1	DebugData	22
4.13	debug.write.t Struct Reference	22
4.13.1	Detailed Description	22
4.13.2	Field Documentation	23
4.13.2.1	DebugData	23
4.14	device.information.t Struct Reference	23
4.14.1	Detailed Description	23
4.14.2	Field Documentation	23
4.14.2.1	Major	23
4.14.2.2	Minor	23
4.14.2.3	Release	23
4.15	device.network.information.t Struct Reference	24
4.15.1	Detailed Description	24
4.16	edges.settings.calb.t Struct Reference	24
4.16.1	Field Documentation	24
4.16.1.1	BorderFlags	24
4.16.1.2	EnderFlags	24
4.16.1.3	LeftBorder	24
4.16.1.4	RightBorder	25
4.17	edges.settings.t Struct Reference	25
4.17.1	Detailed Description	25

4.17.2 Field Documentation . . . . .	25
4.17.2.1 BorderFlags . . . . .	25
4.17.2.2 EnderFlags . . . . .	25
4.17.2.3 LeftBorder . . . . .	25
4.17.2.4 RightBorder . . . . .	26
4.17.2.5 uLeftBorder . . . . .	26
4.17.2.6 uRightBorder . . . . .	26
4.18 encoder_information_t Struct Reference . . . . .	26
4.18.1 Detailed Description . . . . .	26
4.18.2 Field Documentation . . . . .	26
4.18.2.1 Manufacturer . . . . .	26
4.18.2.2 PartNumber . . . . .	26
4.19 encoder_settings_t Struct Reference . . . . .	27
4.19.1 Detailed Description . . . . .	27
4.19.2 Field Documentation . . . . .	27
4.19.2.1 EncoderSettings . . . . .	27
4.19.2.2 MaxCurrentConsumption . . . . .	27
4.19.2.3 MaxOperatingFrequency . . . . .	27
4.19.2.4 SupplyVoltageMax . . . . .	27
4.19.2.5 SupplyVoltageMin . . . . .	28
4.20 engine_settings_calb_t Struct Reference . . . . .	28
4.20.1 Field Documentation . . . . .	28
4.20.1.1 Antiplay . . . . .	28
4.20.1.2 EngineFlags . . . . .	28
4.20.1.3 MicrostepMode . . . . .	28
4.20.1.4 NomCurrent . . . . .	28
4.20.1.5 NomSpeed . . . . .	28
4.20.1.6 NomVoltage . . . . .	29
4.20.1.7 StepsPerRev . . . . .	29
4.21 engine_settings_t Struct Reference . . . . .	29
4.21.1 Detailed Description . . . . .	29
4.21.2 Field Documentation . . . . .	30
4.21.2.1 Antiplay . . . . .	30
4.21.2.2 EngineFlags . . . . .	30
4.21.2.3 MicrostepMode . . . . .	30
4.21.2.4 NomCurrent . . . . .	30
4.21.2.5 NomSpeed . . . . .	30
4.21.2.6 NomVoltage . . . . .	30
4.21.2.7 StepsPerRev . . . . .	30
4.21.2.8 uNomSpeed . . . . .	30

4.22	entytype_settings_t Struct Reference	30
4.22.1	Detailed Description	31
4.22.2	Field Documentation	31
4.22.2.1	DriverType	31
4.22.2.2	EngineType	31
4.23	extio_settings.t Struct Reference	31
4.23.1	Detailed Description	31
4.23.2	Field Documentation	32
4.23.2.1	EXTIOModeFlags	32
4.23.2.2	EXTIOSetupFlags	32
4.24	feedback_settings.t Struct Reference	32
4.24.1	Detailed Description	32
4.24.2	Field Documentation	32
4.24.2.1	FeedbackFlags	32
4.24.2.2	FeedbackType	33
4.24.2.3	HallShift	33
4.24.2.4	HallSPR	33
4.25	gear_information.t Struct Reference	33
4.25.1	Detailed Description	33
4.25.2	Field Documentation	33
4.25.2.1	Manufacturer	33
4.25.2.2	PartNumber	33
4.26	gear_settings.t Struct Reference	33
4.26.1	Detailed Description	34
4.26.2	Field Documentation	34
4.26.2.1	Efficiency	34
4.26.2.2	InputInertia	34
4.26.2.3	MaxOutputBacklash	34
4.26.2.4	RatedInputSpeed	34
4.26.2.5	RatedInputTorque	35
4.26.2.6	ReductionIn	35
4.26.2.7	ReductionOut	35
4.27	get_position_calb_t Struct Reference	35
4.27.1	Field Documentation	35
4.27.1.1	EncPosition	35
4.27.1.2	Position	35
4.28	get_position.t Struct Reference	35
4.28.1	Detailed Description	36
4.28.2	Field Documentation	36
4.28.2.1	EncPosition	36

4.29 hallsensor.information_t Struct Reference . . . . .	36
4.29.1 Detailed Description . . . . .	36
4.29.2 Field Documentation . . . . .	36
4.29.2.1 Manufacturer . . . . .	36
4.29.2.2 PartNumber . . . . .	36
4.30 hallsensor.settings_t Struct Reference . . . . .	36
4.30.1 Detailed Description . . . . .	37
4.30.2 Field Documentation . . . . .	37
4.30.2.1 MaxCurrentConsumption . . . . .	37
4.30.2.2 MaxOperatingFrequency . . . . .	37
4.30.2.3 SupplyVoltageMax . . . . .	37
4.30.2.4 SupplyVoltageMin . . . . .	37
4.31 home_settings.calb_t Struct Reference . . . . .	37
4.31.1 Field Documentation . . . . .	38
4.31.1.1 FastHome . . . . .	38
4.31.1.2 HomeDelta . . . . .	38
4.31.1.3 HomeFlags . . . . .	38
4.31.1.4 SlowHome . . . . .	38
4.32 home_settings.t Struct Reference . . . . .	38
4.32.1 Detailed Description . . . . .	39
4.32.2 Field Documentation . . . . .	39
4.32.2.1 FastHome . . . . .	39
4.32.2.2 HomeDelta . . . . .	39
4.32.2.3 HomeFlags . . . . .	39
4.32.2.4 SlowHome . . . . .	39
4.32.2.5 uFastHome . . . . .	39
4.32.2.6 uHomeDelta . . . . .	39
4.32.2.7 uSlowHome . . . . .	39
4.33 init_random.t Struct Reference . . . . .	39
4.33.1 Detailed Description . . . . .	40
4.33.2 Field Documentation . . . . .	40
4.33.2.1 key . . . . .	40
4.34 joystick_settings.t Struct Reference . . . . .	40
4.34.1 Detailed Description . . . . .	40
4.34.2 Field Documentation . . . . .	41
4.34.2.1 DeadZone . . . . .	41
4.34.2.2 ExpFactor . . . . .	41
4.34.2.3 JoyCenter . . . . .	41
4.34.2.4 JoyFlags . . . . .	41
4.34.2.5 JoyHighEnd . . . . .	41

4.34.2.6 JoyLowEnd . . . . .	41
4.35 motor_information_t Struct Reference . . . . .	41
4.35.1 Detailed Description . . . . .	42
4.35.2 Field Documentation . . . . .	42
4.35.2.1 Manufacturer . . . . .	42
4.35.2.2 PartNumber . . . . .	42
4.36 motor_settings.t Struct Reference . . . . .	42
4.36.1 Detailed Description . . . . .	43
4.36.2 Field Documentation . . . . .	43
4.36.2.1 DetentTorque . . . . .	43
4.36.2.2 MaxCurrent . . . . .	43
4.36.2.3 MaxCurrentTime . . . . .	44
4.36.2.4 MaxSpeed . . . . .	44
4.36.2.5 MechanicalTimeConstant . . . . .	44
4.36.2.6 MotorType . . . . .	44
4.36.2.7 NoLoadCurrent . . . . .	44
4.36.2.8 NoLoadSpeed . . . . .	44
4.36.2.9 NominalCurrent . . . . .	44
4.36.2.10 NominalPower . . . . .	44
4.36.2.11 NominalSpeed . . . . .	44
4.36.2.12 NominalTorque . . . . .	45
4.36.2.13 NominalVoltage . . . . .	45
4.36.2.14 Phases . . . . .	45
4.36.2.15 Poles . . . . .	45
4.36.2.16 RotorInertia . . . . .	45
4.36.2.17 SpeedConstant . . . . .	45
4.36.2.18 SpeedTorqueGradient . . . . .	45
4.36.2.19 StallTorque . . . . .	45
4.36.2.20 TorqueConstant . . . . .	45
4.36.2.21 WindingInductance . . . . .	46
4.36.2.22 WindingResistance . . . . .	46
4.37 move_settings_calb_t Struct Reference . . . . .	46
4.37.1 Field Documentation . . . . .	46
4.37.1.1 Accel . . . . .	46
4.37.1.2 AntiplaySpeed . . . . .	46
4.37.1.3 Decel . . . . .	46
4.37.1.4 Speed . . . . .	46
4.38 move_settings.t Struct Reference . . . . .	46
4.38.1 Detailed Description . . . . .	47
4.38.2 Field Documentation . . . . .	47

4.38.2.1	Accel . . . . .	47
4.38.2.2	AntiplaySpeed . . . . .	47
4.38.2.3	Decel . . . . .	47
4.38.2.4	Speed . . . . .	47
4.38.2.5	uAntiplaySpeed . . . . .	47
4.38.2.6	uSpeed . . . . .	48
4.39	pid_settings.t Struct Reference . . . . .	48
4.39.1	Detailed Description . . . . .	48
4.40	power_settings.t Struct Reference . . . . .	48
4.40.1	Detailed Description . . . . .	49
4.40.2	Field Documentation . . . . .	49
4.40.2.1	CurrentSetTime . . . . .	49
4.40.2.2	CurrReductDelay . . . . .	49
4.40.2.3	HoldCurrent . . . . .	49
4.40.2.4	PowerFlags . . . . .	49
4.40.2.5	PowerOffDelay . . . . .	49
4.41	secure_settings.t Struct Reference . . . . .	49
4.41.1	Detailed Description . . . . .	50
4.41.2	Field Documentation . . . . .	50
4.41.2.1	CriticalAllPwr . . . . .	50
4.41.2.2	CriticalAllUsb . . . . .	50
4.41.2.3	CriticalT . . . . .	50
4.41.2.4	CriticalUpwr . . . . .	50
4.41.2.5	CriticalUusb . . . . .	50
4.41.2.6	Flags . . . . .	50
4.41.2.7	LowUpwrOff . . . . .	50
4.41.2.8	MinimumUusb . . . . .	50
4.42	serial_number.t Struct Reference . . . . .	51
4.42.1	Detailed Description . . . . .	51
4.42.2	Field Documentation . . . . .	51
4.42.2.1	Key . . . . .	51
4.42.2.2	Major . . . . .	51
4.42.2.3	Minor . . . . .	51
4.42.2.4	Release . . . . .	51
4.42.2.5	SN . . . . .	51
4.43	set_position_calb.t Struct Reference . . . . .	52
4.43.1	Field Documentation . . . . .	52
4.43.1.1	EncPosition . . . . .	52
4.43.1.2	PosFlags . . . . .	52
4.43.1.3	Position . . . . .	52

4.44 set_position.t Struct Reference . . . . .	52
4.44.1 Detailed Description . . . . .	52
4.44.2 Field Documentation . . . . .	53
4.44.2.1 EncPosition . . . . .	53
4.44.2.2 PosFlags . . . . .	53
4.45 stage_information.t Struct Reference . . . . .	53
4.45.1 Detailed Description . . . . .	53
4.45.2 Field Documentation . . . . .	53
4.45.2.1 Manufacturer . . . . .	53
4.45.2.2 PartNumber . . . . .	53
4.46 stage_name.t Struct Reference . . . . .	53
4.46.1 Detailed Description . . . . .	54
4.46.2 Field Documentation . . . . .	54
4.46.2.1 PositionerName . . . . .	54
4.47 stage_settings.t Struct Reference . . . . .	54
4.47.1 Detailed Description . . . . .	55
4.47.2 Field Documentation . . . . .	55
4.47.2.1 HorizontalLoadCapacity . . . . .	55
4.47.2.2 LeadScrewPitch . . . . .	55
4.47.2.3 MaxCurrentConsumption . . . . .	55
4.47.2.4 MaxSpeed . . . . .	55
4.47.2.5 SupplyVoltageMax . . . . .	55
4.47.2.6 SupplyVoltageMin . . . . .	55
4.47.2.7 TravelRange . . . . .	55
4.47.2.8 Units . . . . .	56
4.47.2.9 VerticalLoadCapacity . . . . .	56
4.48 status_calb.t Struct Reference . . . . .	56
4.48.1 Field Documentation . . . . .	57
4.48.1.1 CmdBufFreeSpace . . . . .	57
4.48.1.2 CurPosition . . . . .	57
4.48.1.3 CurSpeed . . . . .	57
4.48.1.4 CurT . . . . .	57
4.48.1.5 EncPosition . . . . .	57
4.48.1.6 EncSts . . . . .	57
4.48.1.7 Flags . . . . .	57
4.48.1.8 GPIOFlags . . . . .	57
4.48.1.9 Ipwr . . . . .	57
4.48.1.10 Iusb . . . . .	57
4.48.1.11 MoveSts . . . . .	57
4.48.1.12 MvCmdSts . . . . .	57

4.48.1.13 PWRSts . . . . .	58
4.48.1.14 Upwr . . . . .	58
4.48.1.15 Uusb . . . . .	58
4.48.1.16 WindSts . . . . .	58
4.49 status_t Struct Reference . . . . .	58
4.49.1 Detailed Description . . . . .	59
4.49.2 Field Documentation . . . . .	59
4.49.2.1 CmdBufFreeSpace . . . . .	59
4.49.2.2 CurPosition . . . . .	59
4.49.2.3 CurSpeed . . . . .	59
4.49.2.4 CurT . . . . .	59
4.49.2.5 EncPosition . . . . .	59
4.49.2.6 EncSts . . . . .	59
4.49.2.7 Flags . . . . .	59
4.49.2.8 GPIOFlags . . . . .	60
4.49.2.9 Ipwr . . . . .	60
4.49.2.10 Iusb . . . . .	60
4.49.2.11 MoveSts . . . . .	60
4.49.2.12 MvCmdSts . . . . .	60
4.49.2.13 PWRSts . . . . .	60
4.49.2.14 uCurPosition . . . . .	60
4.49.2.15 uCurSpeed . . . . .	60
4.49.2.16 Upwr . . . . .	60
4.49.2.17 Uusb . . . . .	60
4.49.2.18 WindSts . . . . .	60
4.50 sync_in_settings.calb.t Struct Reference . . . . .	61
4.50.1 Field Documentation . . . . .	61
4.50.1.1 ClutterTime . . . . .	61
4.50.1.2 Position . . . . .	61
4.50.1.3 Speed . . . . .	61
4.50.1.4 SyncInFlags . . . . .	61
4.51 sync_in_settings.t Struct Reference . . . . .	61
4.51.1 Detailed Description . . . . .	62
4.51.2 Field Documentation . . . . .	62
4.51.2.1 ClutterTime . . . . .	62
4.51.2.2 Speed . . . . .	62
4.51.2.3 SyncInFlags . . . . .	62
4.51.2.4 uPosition . . . . .	62
4.51.2.5 uSpeed . . . . .	62
4.52 sync_out_settings.calb.t Struct Reference . . . . .	62

4.52.1	Field Documentation . . . . .	63
4.52.1.1	Accuracy . . . . .	63
4.52.1.2	SyncOutFlags . . . . .	63
4.52.1.3	SyncOutPeriod . . . . .	63
4.52.1.4	SyncOutPulseSteps . . . . .	63
4.53	sync.out.settings.t Struct Reference . . . . .	63
4.53.1	Detailed Description . . . . .	63
4.53.2	Field Documentation . . . . .	64
4.53.2.1	Accuracy . . . . .	64
4.53.2.2	SyncOutFlags . . . . .	64
4.53.2.3	SyncOutPeriod . . . . .	64
4.53.2.4	SyncOutPulseSteps . . . . .	64
4.53.2.5	uAccuracy . . . . .	64
4.54	uart.settings.t Struct Reference . . . . .	64
4.54.1	Detailed Description . . . . .	64
4.54.2	Field Documentation . . . . .	65
4.54.2.1	UARTSetupFlags . . . . .	65
<b>5</b>	<b>File Documentation</b> . . . . .	<b>66</b>
5.1	ximc.h File Reference . . . . .	66
5.1.1	Detailed Description . . . . .	86
5.1.2	Macro Definition Documentation . . . . .	87
5.1.2.1	ALARM_ON_DRIVER_OVERHEATING . . . . .	87
5.1.2.2	BORDER_IS_ENCODER . . . . .	87
5.1.2.3	BORDER_STOP_LEFT . . . . .	87
5.1.2.4	BORDER_STOP_RIGHT . . . . .	87
5.1.2.5	BORDERS_SWAP_MISSET_DETECTION . . . . .	87
5.1.2.6	BRAKE_ENABLED . . . . .	87
5.1.2.7	BRAKE_ENG_PWROFF . . . . .	87
5.1.2.8	CONTROL_BTN_LEFT_PUSHED_OPEN . . . . .	87
5.1.2.9	CONTROL_BTN_RIGHT_PUSHED_OPEN . . . . .	87
5.1.2.10	CONTROL_MODE_BITS . . . . .	87
5.1.2.11	CONTROL_MODE_JOY . . . . .	87
5.1.2.12	CONTROL_MODE_LR . . . . .	88
5.1.2.13	CONTROL_MODE_OFF . . . . .	88
5.1.2.14	CTP_ALARM_ON_ERROR . . . . .	88
5.1.2.15	CTP_BASE . . . . .	88
5.1.2.16	CTP_ENABLED . . . . .	88
5.1.2.17	CTP_ERROR_CORRECTION . . . . .	88
5.1.2.18	DRIVER_TYPE_DISCRETE_FET . . . . .	88

5.1.2.19	DRIVER_TYPE_EXTERNAL . . . . .	88
5.1.2.20	DRIVER_TYPE_INTEGRATE . . . . .	88
5.1.2.21	EEPROM_PRECEDENCE . . . . .	88
5.1.2.22	ENC_STATE_ABSENT . . . . .	88
5.1.2.23	ENC_STATE_MALFUNC . . . . .	88
5.1.2.24	ENC_STATE_OK . . . . .	89
5.1.2.25	ENC_STATE_REVERS . . . . .	89
5.1.2.26	ENC_STATE_UNKNOWN . . . . .	89
5.1.2.27	ENDER_SW1_ACTIVE_LOW . . . . .	89
5.1.2.28	ENDER_SW2_ACTIVE_LOW . . . . .	89
5.1.2.29	ENDER_SWAP . . . . .	89
5.1.2.30	ENGINE_ACCEL_ON . . . . .	89
5.1.2.31	ENGINE_ANTIPLAY . . . . .	89
5.1.2.32	ENGINE_LIMIT_CURR . . . . .	89
5.1.2.33	ENGINE_LIMIT_RPM . . . . .	89
5.1.2.34	ENGINE_LIMIT_VOLT . . . . .	89
5.1.2.35	ENGINE_MAX_SPEED . . . . .	90
5.1.2.36	ENGINE_REVERSE . . . . .	90
5.1.2.37	ENGINE_TYPE_2DC . . . . .	90
5.1.2.38	ENGINE_TYPE_BRUSHLESS . . . . .	90
5.1.2.39	ENGINE_TYPE_DC . . . . .	90
5.1.2.40	ENGINE_TYPE_NONE . . . . .	90
5.1.2.41	ENGINE_TYPE_STEP . . . . .	90
5.1.2.42	ENGINE_TYPE_TEST . . . . .	90
5.1.2.43	ENUMERATE_PROBE . . . . .	90
5.1.2.44	EXTIO_SETUP_INVERT . . . . .	90
5.1.2.45	EXTIO_SETUP_MODE_IN_ALARM . . . . .	91
5.1.2.46	EXTIO_SETUP_MODE_IN_BITS . . . . .	91
5.1.2.47	EXTIO_SETUP_MODE_IN_HOME . . . . .	91
5.1.2.48	EXTIO_SETUP_MODE_IN_MOVR . . . . .	91
5.1.2.49	EXTIO_SETUP_MODE_IN_NOP . . . . .	91
5.1.2.50	EXTIO_SETUP_MODE_IN_PWOF . . . . .	91
5.1.2.51	EXTIO_SETUP_MODE_IN_STOP . . . . .	91
5.1.2.52	EXTIO_SETUP_MODE_OUT_ALARM . . . . .	91
5.1.2.53	EXTIO_SETUP_MODE_OUT_BITS . . . . .	91
5.1.2.54	EXTIO_SETUP_MODE_OUT_MOTOR_FOUND . . . . .	91
5.1.2.55	EXTIO_SETUP_MODE_OUT_MOTOR_ON . . . . .	91
5.1.2.56	EXTIO_SETUP_MODE_OUT_MOVING . . . . .	91
5.1.2.57	EXTIO_SETUP_MODE_OUT_OFF . . . . .	92
5.1.2.58	EXTIO_SETUP_MODE_OUT_ON . . . . .	92

5.1.2.59	EXTIO_SETUP_OUTPUT	92
5.1.2.60	FEEDBACK_EMF	92
5.1.2.61	FEEDBACK_ENC_REVERSE	92
5.1.2.62	FEEDBACK_ENCODER	92
5.1.2.63	FEEDBACK_ENCODERHALL	92
5.1.2.64	FEEDBACK_HALL_REVERSE	92
5.1.2.65	FEEDBACK_NONE	92
5.1.2.66	H_BRIDGE_ALERT	92
5.1.2.67	HOME_DIR_FIRST	92
5.1.2.68	HOME_DIR_SECOND	92
5.1.2.69	HOME_HALF_MV	93
5.1.2.70	HOME_MV_SEC_EN	93
5.1.2.71	HOME_STOP_FIRST_BITS	93
5.1.2.72	HOME_STOP_FIRST_LIM	93
5.1.2.73	HOME_STOP_FIRST_REV	93
5.1.2.74	HOME_STOP_FIRST_SYN	93
5.1.2.75	HOME_STOP_SECOND_BITS	93
5.1.2.76	HOME_STOP_SECOND_LIM	93
5.1.2.77	HOME_STOP_SECOND_REV	93
5.1.2.78	HOME_STOP_SECOND_SYN	93
5.1.2.79	JOY_REVERSE	93
5.1.2.80	LOW_UPWR_PROTECTION	93
5.1.2.81	MICROSTEP_MODE_FRAC_128	94
5.1.2.82	MICROSTEP_MODE_FRAC_16	94
5.1.2.83	MICROSTEP_MODE_FRAC_2	94
5.1.2.84	MICROSTEP_MODE_FRAC_256	94
5.1.2.85	MICROSTEP_MODE_FRAC_32	94
5.1.2.86	MICROSTEP_MODE_FRAC_4	94
5.1.2.87	MICROSTEP_MODE_FRAC_64	94
5.1.2.88	MICROSTEP_MODE_FRAC_8	94
5.1.2.89	MICROSTEP_MODE_FULL	94
5.1.2.90	MOVE_STATE_ANTIPLAY	94
5.1.2.91	MOVE_STATE_MOVING	94
5.1.2.92	MOVE_STATE_TARGET_SPEED	94
5.1.2.93	MVCMD_ERROR	95
5.1.2.94	MVCMD_HOME	95
5.1.2.95	MVCMD_LEFT	95
5.1.2.96	MVCMD_LOFT	95
5.1.2.97	MVCMD_MOVE	95
5.1.2.98	MVCMD_MOVR	95

5.1.2.99 MVCMD_NAME_BITS . . . . .	95
5.1.2.100 MVCMD_RIGHT . . . . .	95
5.1.2.101 MVCMD_RUNNING . . . . .	95
5.1.2.102 MVCMD_SSTP . . . . .	95
5.1.2.103 MVCMD_STOP . . . . .	95
5.1.2.104 MVCMD_UKNWN . . . . .	95
5.1.2.105 POWER_OFF_ENABLED . . . . .	96
5.1.2.106 POWER_REDUCt_ENABLED . . . . .	96
5.1.2.107 POWER_SMOOTH_CURRENT . . . . .	96
5.1.2.108 PWR_STATE_MAX . . . . .	96
5.1.2.109 PWR_STATE_NORM . . . . .	96
5.1.2.110 PWR_STATE_OFF . . . . .	96
5.1.2.111 PWR_STATE_REDUCt . . . . .	96
5.1.2.112 PWR_STATE_UNKNOWN . . . . .	96
5.1.2.113 REV_SENS_INV . . . . .	96
5.1.2.114 SETPOS_IGNORE_ENCODER . . . . .	96
5.1.2.115 SETPOS_IGNORE_POSITION . . . . .	96
5.1.2.116 STATE_ALARM . . . . .	96
5.1.2.117 STATE_BORDERS_SWAP_MISSET . . . . .	97
5.1.2.118 STATE_BRAKE . . . . .	97
5.1.2.119 STATE_BUTTON_LEFT . . . . .	97
5.1.2.120 STATE_BUTTON_RIGHT . . . . .	97
5.1.2.121 STATE CONTR . . . . .	97
5.1.2.122 STATE_CONTROLLER_OVERHEAT . . . . .	97
5.1.2.123 STATE_CTP_ERROR . . . . .	97
5.1.2.124 STATE_DIG_SIGNAL . . . . .	97
5.1.2.125 STATE_EEPROM_CONNECTED . . . . .	97
5.1.2.126 STATE_ENC_A . . . . .	97
5.1.2.127 STATE_ENC_B . . . . .	97
5.1.2.128 STATE_ERRC . . . . .	97
5.1.2.129 STATE_ERRD . . . . .	98
5.1.2.130 STATE_ERRV . . . . .	98
5.1.2.131 STATE_GPIO_LEVEL . . . . .	98
5.1.2.132 STATE_GPIO_PINOUT . . . . .	98
5.1.2.133 STATE_HALL_A . . . . .	98
5.1.2.134 STATE_HALL_B . . . . .	98
5.1.2.135 STATE_HALL_C . . . . .	98
5.1.2.136 STATE_LEFT_EDGE . . . . .	98
5.1.2.137 STATE_LOW_USB_VOLTAGE . . . . .	98
5.1.2.138 STATE_OVERLOAD_POWER_CURRENT . . . . .	98

5.1.2.139 STATE_OVERLOAD_POWER_VOLTAGE . . . . .	98
5.1.2.140 STATE_OVERLOAD_USB_CURRENT . . . . .	98
5.1.2.141 STATE_OVERLOAD_USB_VOLTAGE . . . . .	99
5.1.2.142 STATE_POWER_OVERHEAT . . . . .	99
5.1.2.143 STATE_REV_SENSOR . . . . .	99
5.1.2.144 STATE_RIGHT_EDGE . . . . .	99
5.1.2.145 STATE_SECUR . . . . .	99
5.1.2.146 STATE_SYNC_INPUT . . . . .	99
5.1.2.147 STATE_SYNC_OUTPUT . . . . .	99
5.1.2.148 SYNCIN_ENABLED . . . . .	99
5.1.2.149 SYNCIN_GOTOPOSITION . . . . .	99
5.1.2.150 SYNCIN_INVERT . . . . .	99
5.1.2.151 SYNCOUT_ENABLED . . . . .	99
5.1.2.152 SYNCOUT_IN_STEPS . . . . .	99
5.1.2.153 SYNCOUT_INVERT . . . . .	100
5.1.2.154 SYNCOUT_ONPERIOD . . . . .	100
5.1.2.155 SYNCOUT_ONSTART . . . . .	100
5.1.2.156 SYNCOUT_ONSTOP . . . . .	100
5.1.2.157 SYNCOUT_STATE . . . . .	100
5.1.2.158 UART_PARITY_BITS . . . . .	100
5.1.2.159 WIND_A_STATE_ABSENT . . . . .	100
5.1.2.160 WIND_A_STATE_MALFUNC . . . . .	100
5.1.2.161 WIND_A_STATE_OK . . . . .	100
5.1.2.162 WIND_A_STATE_UNKNOWN . . . . .	100
5.1.2.163 WIND_B_STATE_ABSENT . . . . .	100
5.1.2.164 WIND_B_STATE_MALFUNC . . . . .	100
5.1.2.165 WIND_B_STATE_OK . . . . .	101
5.1.2.166 WIND_B_STATE_UNKNOWN . . . . .	101
5.1.2.167 XIMC_API . . . . .	101
5.1.3    Typedef Documentation . . . . .	101
5.1.3.1    logging_callback_t . . . . .	101
5.1.4    Function Documentation . . . . .	101
5.1.4.1    close_device . . . . .	101
5.1.4.2    command_add_sync_in_action . . . . .	101
5.1.4.3    command_clear_fram . . . . .	101
5.1.4.4    command_eeread_settings . . . . .	102
5.1.4.5    command_eesave_settings . . . . .	102
5.1.4.6    command_home . . . . .	102
5.1.4.7    command_homezero . . . . .	102
5.1.4.8    command_left . . . . .	103

5.1.4.9	command_loft	103
5.1.4.10	command_move	103
5.1.4.11	command_movr	103
5.1.4.12	command_power_off	103
5.1.4.13	command_read_settings	104
5.1.4.14	command_reset	104
5.1.4.15	command_right	104
5.1.4.16	command_save_settings	104
5.1.4.17	command_sstp	104
5.1.4.18	command_stop	105
5.1.4.19	command_update_firmware	105
5.1.4.20	command_wait_for_stop	105
5.1.4.21	command_zero	105
5.1.4.22	enumerate_devices	106
5.1.4.23	free_enumerate_devices	106
5.1.4.24	get_accessories_settings	106
5.1.4.25	get_analog_data	106
5.1.4.26	get_bootloader_version	106
5.1.4.27	get_brake_settings	107
5.1.4.28	get_chart_data	107
5.1.4.29	get_control_settings	107
5.1.4.30	get_controller_name	107
5.1.4.31	get_ctp_settings	107
5.1.4.32	get_debug_read	108
5.1.4.33	get_device_count	108
5.1.4.34	get_device_information	108
5.1.4.35	get_device_name	108
5.1.4.36	get_edges_settings	109
5.1.4.37	get_encoder_information	109
5.1.4.38	get_encoder_settings	109
5.1.4.39	get_engine_settings	109
5.1.4.40	get_entype_settings	110
5.1.4.41	get_enumerate_device_controller_name	110
5.1.4.42	get_enumerate_device_information	110
5.1.4.43	get_enumerate_device_network_information	110
5.1.4.44	get_enumerate_device_serial	111
5.1.4.45	get_enumerate_device_stage_name	111
5.1.4.46	get_extio_settings	111
5.1.4.47	get_feedback_settings	111
5.1.4.48	get_firmware_version	112

5.1.4.49	get_gear_information . . . . .	112
5.1.4.50	get_gear_settings . . . . .	112
5.1.4.51	get_hallsensor_information . . . . .	112
5.1.4.52	get_hallsensor_settings . . . . .	112
5.1.4.53	get_home_settings . . . . .	113
5.1.4.54	get_init_random . . . . .	113
5.1.4.55	get_joystick_settings . . . . .	113
5.1.4.56	get_motor_information . . . . .	113
5.1.4.57	get_motor_settings . . . . .	114
5.1.4.58	get_move_settings . . . . .	114
5.1.4.59	get_pid_settings . . . . .	114
5.1.4.60	get_position . . . . .	114
5.1.4.61	get_power_settings . . . . .	114
5.1.4.62	get_secure_settings . . . . .	115
5.1.4.63	get_serial_number . . . . .	115
5.1.4.64	get_stage_information . . . . .	115
5.1.4.65	get_stage_name . . . . .	115
5.1.4.66	get_stage_settings . . . . .	115
5.1.4.67	get_status . . . . .	116
5.1.4.68	get_status_calb . . . . .	116
5.1.4.69	get_sync_in_settings . . . . .	116
5.1.4.70	get_sync_out_settings . . . . .	116
5.1.4.71	get_uart_settings . . . . .	117
5.1.4.72	goto_firmware . . . . .	117
5.1.4.73	has_firmware . . . . .	117
5.1.4.74	logging_callback_stderr_narrow . . . . .	117
5.1.4.75	logging_callback_stderr_wide . . . . .	117
5.1.4.76	msec_sleep . . . . .	118
5.1.4.77	open_device . . . . .	118
5.1.4.78	probe_device . . . . .	118
5.1.4.79	service_command_updf . . . . .	118
5.1.4.80	set_accessories_settings . . . . .	118
5.1.4.81	set_brake_settings . . . . .	119
5.1.4.82	set_control_settings . . . . .	119
5.1.4.83	set_controller_name . . . . .	119
5.1.4.84	set_ctp_settings . . . . .	119
5.1.4.85	set_debug_write . . . . .	120
5.1.4.86	set_edges_settings . . . . .	120
5.1.4.87	set_encoder_information . . . . .	120
5.1.4.88	set_encoder_settings . . . . .	120

5.1.4.89 set_engine_settings . . . . .	120
5.1.4.90 set_entype_settings . . . . .	121
5.1.4.91 set_extio_settings . . . . .	121
5.1.4.92 set_feedback_settings . . . . .	121
5.1.4.93 set_gear_information . . . . .	121
5.1.4.94 set_gear_settings . . . . .	122
5.1.4.95 set_hallsensor_information . . . . .	122
5.1.4.96 set_hallsensor_settings . . . . .	122
5.1.4.97 set_home_settings . . . . .	122
5.1.4.98 set_joystick_settings . . . . .	123
5.1.4.99 set_logging_callback . . . . .	123
5.1.4.100 set_motor_information . . . . .	123
5.1.4.101 set_motor_settings . . . . .	123
5.1.4.102 set_move_settings . . . . .	124
5.1.4.103 set_pid_settings . . . . .	124
5.1.4.104 set_position . . . . .	124
5.1.4.105 set_power_settings . . . . .	124
5.1.4.106 set_secure_settings . . . . .	124
5.1.4.107 set_serial_number . . . . .	125
5.1.4.108 set_stage_information . . . . .	125
5.1.4.109 set_stage_name . . . . .	125
5.1.4.110 set_stage_settings . . . . .	125
5.1.4.111 set_sync_in_settings . . . . .	126
5.1.4.112 set_sync_out_settings . . . . .	126
5.1.4.113 set_uart_settings . . . . .	126
5.1.4.114 write_key . . . . .	126
5.1.4.115 ximc_fix_usbser_sys . . . . .	127
5.1.4.116 ximc_version . . . . .	127

# Chapter 1

## Introduction

### 1.1 About

Congratulations on choosing XIMC multi-platform programming library! This document contains all information about XIMC library. It utilizes well known virtual COM-port interface, so you can use it on Windows 7, Windows Vista, Windows XP, Windows Server 2003, Windows 2000, Linux, Mac OS X. XIMC multi-platform programing library supports plug/unplug on the fly. Each device can be controlled only by one program at once. Multiple processes (programs) that control one device simultaneously are not allowed.

### 1.2 System requirements

#### 1.2.1 For rebuilding library

On Windows:

- Windows 2000 or later, 64-bit system (if compiling both architectures) or 32-bit system.
- Microsoft Visual C++ 2013 or later
- cygwin with tar, bison, flex, curl installed
- 7z

On Linux:

- 64-bit or/and 32-bit system system
- gcc 4 or later
- common autotools: autoconf, autoheader, aclocal, automake, autoreconf, libtool
- gmake
- doxygen - for building docs
- LaTeX distribution (teTeX or texlive) - for building docs
- flex 2.5.30+
- bison
- mercurial (for building developer version from hg)

On Mac OS X:

- XCode 4
- doxygen
- mactex
- autotools
- mercurial (for building developer version from hg)

If mercurial is used, please enable 'purge' extension by adding to `~/.hgrc` following lines:

```
[extensions]
hgext.purge=
```

### 1.2.2 For using library

Supported operating systems (32 or 64 bit) and environment requirements:

- Mac OS X 10.6
- Windows 2000 or later
- Autotools-compatible unix. Package is installed from sources.
- Linux debian-based 32 and 64 bit. DEB package is built against Debian Squeeze 7
- Linux debian-based ARM. DEB package is built on Ubuntu 14.04
- Linux rpm-based. RPM is built against OpenSUSE 12
- Java 7 64-bit or (only Linux) 32-bit
- .NET 2.0 (32-bit only)
- Delphi (32-bit only)

Build requirements:

- Windows: Microsoft Visual C++ 2013 or mingw (currently not supported)
- UNIX: gcc 4, gmake
- Mac OS X: XCode 4
- JDK 7

# Chapter 2

## How to rebuild library

### 2.1 Building on generic UNIX

Generic version could be built with standard autotools.

```
./build.sh lib
```

Built files (library, headers, documentation) are installed to ./dist/local directory. It is a generic developer build. Sometimes you need to specify additional parameters to command line for your machine. Please look to following OS sections.

### 2.2 Building on debian-based linux systems

Requirement: 64-bit and 32-bit debian system, ubuntu Typical set of packages: gcc, autotools, autoconf, libtool, dpkg-dev, flex, bison, doxygen, texlive, mercurial Full set of packages: apt-get install ruby1.9.1 debhelper vim sudo g++ mercurial git curl make cmake autotools-dev automake autoconf libtool default-jre-headless default-jdk openjdk-6-jdk dpkg-dev lintian texlive texlive-latex-extra texlive-lang-cyrillic dh-autoreconf hardening-wrapper bison flex doxygen lsb-release pkg-config check For ARM cross-compiling install gcc-arm-linux-gnueabihf from your ARM toolchain.

It's required to match library and host architecture: 64-bit library can be built only at 64-bit host, 32-bit library - only at 32-bit host. ARM library is built with armhf cross-compiler gcc-arm-linux-gnueabihf.

To build library and package invoke a script:

```
$ ./build.sh libdeb
```

For ARM library replace 'libdeb' with 'libdebarm'.

Grab packages from ./ximc/deb and locally installed binaries from ./dist/local.

### 2.3 Building on redhat-based linux systems

Requirement: 64-bit redhat-based system (Fedora, Red Hat, SUSE) Typical set of packages: gcc, autotools, autoconf, libtool, flex, bison, doxygen, texlive, mercurial Full set of packages: autoconf automake bison doxygen flex gcc gcc-32bit gcc-c++ gcc-c++-32bit java-1\_7\_0-openjdk java-1\_7\_0-openjdk-devel libtool lsb-release make mercurial rpm-build rpm-devel rpmlint texlive texlive-fonts-extra texlive-latex

It's possible to build both 32- and 64-bit libraries on 64-bit host system. 64-bit library can't be built on 32-bit system.

To build library and package invoke a script:

```
$ ./build.sh librpm
```

Grab packages from ./ximc/rpm and locally installed binaries from ./dist/local.

## 2.4 Buliding on Mac OS X

To build and package a script invoke a script:

```
$ ./build.sh libosx
```

Built library (classical and framework), examples (classical and .app), documentation are located at ./ximc/macosx, locally installed binaries from ./dist/local.

## 2.5 Buliding on Windows

Requirements: 64-bit windows (build script builds both architectures), cygwin (must be installed to a default path), mercurial.

Invoke a script:

```
$ ./build.bat
```

Grab packages from ./deb/win32 and ./deb/win64

To build debug version of the library set environment variable "DEBUG" to "true" before running the build script.

## 2.6 Source code access

XIMC source codes are given under special request.

# Chapter 3

## How to use with...

Library usage can be examined from test application testapp. Non-C languages are supported because library supports stdcall calling convention and so can be used with a variety of languages.

C test project is located at 'examples/testapp' directory, C# test project - at 'examples/testcs', VB.NET - 'examples/testvbnet', Delphi 6 - 'examples/testdelphi', sample bindings for MATLAB - 'examples/testmatlab', for Java - 'examples/testjava', for Python - 'examples/testpython'. Development kit also contains precompiled examples: testapp and testappeasy as 32 and 64-bit applications for Windows and 64-bit application for osx, testcs, testvbnet, testdelphi - 32-bit only, testjava is architecture-independent, testmatlab and testpython are runtime-interpreted.

NOTE: SDK requires Microsoft Visual C++ Redistributable Package (provided with SDK - vcredist\_x86 or vcredist\_x64)

### 3.1 Usage with C

#### 3.1.1 Visual C++

Testapp can be built using testapp.sln. Library must be compiled with MS Visual C++ too, mingw-library isn't supported. Make sure that Microsoft Visual C++ Redistributable Package is installed.

Open solution examples/testapp/testapp.sln, build and run from the IDE.

#### 3.1.2 MinGW

MinGW is a port of GCC to win32 platform. It's required to install MinGW package. Currently not supported

MinGW-compiled testapp can be built with MS Visual C++ or mingw library.

```
$ mingw32-make -f Makefile.mingw all
```

Then copy library libximc.dll to current directory and launch testapp.exe.

#### 3.1.3 C++ Builder

First of all you should create C++ Builder-style import library. Visual C++ library is not compatible with BCB. Invoke:

```
$ implib libximc.lib libximc.def
```

Then compile test application:

```
$ bcc32 -I..\\..\\ximc\\win32 -L..\\..\\ximc\\win32 -DWIN32 -DNDEBUG -D_WINDOWS  
testapp.c libximc.lib
```

### 3.1.4 XCode

Test app should be built with XCode project testapp.xcodeproj. Library is a Mac OS X framework, and at example application it's bundled inside testapp.app

Then launch application testapp.app and check activity output in Console.app.

### 3.1.5 GCC

Make sure that libximc (rpm, deb, freebsd package or tarball) is installed at your system. Installation of package should be performed with a package manager of operating system. On OS X a framework is provided.

Note that user should belong to system group which allows access to a serial port (dip or serial, for example).

Test application can be built with the installed library with the following script:

```
$ make
```

In case of cross-compilation (target architecture differs from the current system architecture) feed -m64 or -m32 flag to compiler. On OS X it's needed to use -arch flag instead to build an universal binary. Please consult a compiler documentation.

Then launch the application as:

```
$ make run
```

Note: make run on OS X copies a library to the current directory. If you want to use library from the custom directory please be sure to specify LD\_LIBRARY\_PATH or DYLD\_LIBRARY\_PATH to the directory with the library.

## 3.2 .NET

Wrapper assembly for libximc.dll is wrappers/csharp/ximcnet.dll. It is provided with two different architectures and depends on .NET 2.0.

Test .NET applications for Visual Studio 2013 is located at testcs (for C#) and testvbnet (for VB.NET) respectively. Copy ximcnet.dll, libximc.dll, xiwrapper.dll, bindy.dll from the ximc-2.x.x/ximc/win64 or ximc-2.x.x/ximc/win32 accordingly to your system to the current directory. Open solutions, build and run.

## 3.3 Delphi

Wrapper for libximc.dll is a unit wrappers/delphi/ximc.pas

Console test application for is located at testdelphi. Tested with Delphi 6 and only 32-bit version.

Just compile, place DLL near the executable and run program.

## 3.4 Java

How to run example on Linux. Navigate to ximc-2.x.x./examples/testjava/compiled/ and run:

```
$ java -classpath /usr/share/java/libjximc.jar -classpath testjava.jar ru.ximc.  
TestJava
```

How to run example on Windows or Mac. Navigate to ximc-2.x.x./examples/testjava/compiled/. Copy contents of ximc-2.x.x/ximc/win64 or ximc-2.x.x/ximc/macosx accordingly to the current directory. Then run:

---

```
$ java -classpath libjximc.jar -classpath testjava.jar ru.ximc.TestJava
```

How to modify and recompile an example. Navigate to examples/testjava/compiled. Sources are embedded in a testjava.jar. Extract them:

```
$ jar xvf testjava.jar ru META-INF
```

Then rebuild sources:

```
$ javac -classpath /usr/share/java/libjximc.jar -Xlint ru/ximc/TestJava.java
```

or for windows or mac

```
$ javac -classpath libjximc.jar -Xlint ru/ximc/TestJava.java
```

Then build a jar:

```
$ jar cmf META-INF/MANIFEST.MF testjava.jar ru
```

## 3.5 Python

1. Change current directory to the examples/python.
1. On OS X copy library ximc/macosx/libximc.framework to the current directory. On Windows copy libraries from ximc/win32 or ximc/win64 to the current directory. Note: the Python architecture you are using to run the example (32/64 bit) must match that of Windows and libximc.
1. Copy contents of ximc/crossplatform/wrappers/python/ to the current directory or just set env variable PYTHONPATH:

```
export PYTHONPATH=$PYTHONPATH:'pwd'../../ximc/crossplatform/wrappers/python
```

1. On Linux you may need to set LD\_LIBRARY\_PATH so Python can locate libraries with RPATH. For example, you may need:

```
export LD_LIBRARY_PATH=$LD_LIBRARY_PATH:'pwd'
```

1. Then launch Python 2 or Python 3:

```
python testpython.py
```

## 3.6 MATLAB

Sample MATLAB program testximc.m is provided at the directory examples/testmatlab. Change current directory to the examples/matlab. On windows copy [ximc.h](#), libximc.dll, bindy.dll, xiwrapper.dll and contents of ximc/(win32,win64)/wrappers/matlab/ directory to the current directory.

On Mac install Apple's "Command Line Tools for XCode" and then copy ximc/macosx/libximc.framework and contents of ximc/macosx/wrappers/matlab to the the current directory.

Then launch in MATLAB prompt:

```
testximc
```

### 3.7 Generic logging facility

If you want to turn on file logging, you should run the program that uses libximc library with the "XILOG" environment variable set to desired file name. This file will be opened for writing on the first log event and will be closed when the program which uses libximc terminates. Data which is sent to/received from the controller is logged along with port open and close events.

### 3.8 Required permissions

libximc generally does not require special permissions to work, it only needs read/write access to USB-serial ports on the system. An exception to this rule is a Windows-only "fix\_usbser.sys()" function - it needs elevation and will produce null result if run as a regular user.

vim: ft=doxygen

## Chapter 4

# Data Structure Documentation

### 4.1 accessories\_settings\_t Struct Reference

Additional accessories information.

#### Data Fields

- char [MagneticBrakeInfo](#) [25]  
*The manufacturer and the part number of magnetic brake, the maximum string length is 24 characters.*
- float [MBRatedVoltage](#)  
*Rated voltage for controlling the magnetic brake (B).*
- float [MBRatedCurrent](#)  
*Rated current for controlling the magnetic brake (A).*
- float [MBTorque](#)  
*Retention moment (mN m).*
- unsigned int [MBSettings](#)  
*Magnetic brake settings flags.*
- char [TemperatureSensorInfo](#) [25]  
*The manufacturer and the part number of the temperature sensor, the maximum string length: 24 characters.*
- float [TMin](#)  
*The minimum measured temperature (degrees Celsius) Data type: float.*
- float [TMax](#)  
*The maximum measured temperature (degrees Celsius) Data type: float.*
- float [TGrad](#)  
*The temperature gradient (V/degrees Celsius).*
- unsigned int [TSSettings](#)  
*Temperature sensor settings flags.*
- unsigned int [LimitSwitchesSettings](#)  
*Temperature sensor settings flags.*

#### 4.1.1 Detailed Description

Additional accessories information.

#### See Also

[set\\_accessories\\_settings](#)  
[get\\_accessories\\_settings](#)  
[get\\_accessories\\_settings, set.accessories.settings](#)

## 4.1.2 Field Documentation

4.1.2.1 unsigned int LimitSwitchesSettings

[Temperature sensor settings flags.](#)

4.1.2.2 char MagneticBrakeInfo[25]

The manufacturer and the part number of magnetic brake, the maximum string length is 24 characters.

4.1.2.3 float MBRatedCurrent

Rated current for controlling the magnetic brake (A).

Data type: float.

4.1.2.4 float MBRatedVoltage

Rated voltage for controlling the magnetic brake (B).

Data type: float.

4.1.2.5 unsigned int MBSettings

[Magnetic brake settings flags.](#)

4.1.2.6 float MBTorque

Retention moment (mN m).

Data type: float.

4.1.2.7 char TemperatureSensorInfo[25]

The manufacturer and the part number of the temperature sensor, the maximum string length: 24 characters.

4.1.2.8 float TSGrad

The temperature gradient (V/degrees Celsius).

Data type: float.

4.1.2.9 float TSMax

The maximum measured temperature (degrees Celsius) Data type: float.

4.1.2.10 float TSMin

The minimum measured temperature (degrees Celsius) Data type: float.

4.1.2.11 unsigned int TSSettings

[Temperature sensor settings flags.](#)

---

## 4.2 analog\_data\_t Struct Reference

Analog data.

### Data Fields

- unsigned int **A1Voltage\_ADC**  
*"Voltage on pin 1 winding A" raw data from ADC.*
- unsigned int **A2Voltage\_ADC**  
*"Voltage on pin 2 winding A" raw data from ADC.*
- unsigned int **B1Voltage\_ADC**  
*"Voltage on pin 1 winding B" raw data from ADC.*
- unsigned int **B2Voltage\_ADC**  
*"Voltage on pin 2 winding B" raw data from ADC.*
- unsigned int **SupVoltage\_ADC**  
*"Voltage on the top of MOSFET full bridge" raw data from ADC.*
- unsigned int **ACurrent\_ADC**  
*"Winding A current" raw data from ADC.*
- unsigned int **BCurrent\_ADC**  
*"Winding B current" raw data from ADC.*
- unsigned int **FullCurrent\_ADC**  
*"Full current" raw data from ADC.*
- unsigned int **Temp\_ADC**  
*Voltage from temperature sensor, raw data from ADC.*
- unsigned int **Joy\_ADC**  
*Joystick raw data from ADC.*
- unsigned int **Pot\_ADC**  
*Voltage on analog input, raw data from ADC.*
- unsigned int **L5\_ADC**  
*USB supply voltage after the current sense resistor, from ADC.*
- unsigned int **H5\_ADC**  
*Power supply USB from ADC.*
- int **A1Voltage**  
*"Voltage on pin 1 winding A" calibrated data.*
- int **A2Voltage**  
*"Voltage on pin 2 winding A" calibrated data.*
- int **B1Voltage**  
*"Voltage on pin 1 winding B" calibrated data.*
- int **B2Voltage**  
*"Voltage on pin 2 winding B" calibrated data.*
- int **SupVoltage**  
*"Voltage on the top of MOSFET full bridge" calibrated data.*
- int **ACurrent**  
*"Winding A current" calibrated data.*
- int **BCurrent**  
*"Winding B current" calibrated data.*
- int **FullCurrent**  
*"Full current" calibrated data.*
- int **Temp**  
*Temperature, calibrated data.*

- int **Joy**  
*Joystick, calibrated data.*
- int **Pot**  
*Analog input, calibrated data.*
- int **L5**  
*USB supply voltage after the current sense resistor.*
- int **H5**  
*Power supply USB.*
- unsigned int **deprecated**
- int **R**  
*Motor winding resistance in mOhms(is only used with stepper motor).*
- int **L**  
*Motor winding pseudo inductance in uHn(is only used with stepper motor).*

#### 4.2.1 Detailed Description

Analog data.

This structure contains raw analog data from ADC embedded on board. These data used for device testing and deep recalibration by manufacturer only.

See Also

[get\\_analog\\_data](#)  
[get\\_analog\\_data](#)

#### 4.2.2 Field Documentation

##### 4.2.2.1 int A1Voltage

"Voltage on pin 1 winding A" calibrated data.

##### 4.2.2.2 unsigned int A1Voltage\_ADC

"Voltage on pin 1 winding A" raw data from ADC.

##### 4.2.2.3 int A2Voltage

"Voltage on pin 2 winding A" calibrated data.

##### 4.2.2.4 unsigned int A2Voltage\_ADC

"Voltage on pin 2 winding A" raw data from ADC.

##### 4.2.2.5 int ACurrent

"Winding A current" calibrated data.

##### 4.2.2.6 unsigned int ACurrent\_ADC

"Winding A current" raw data from ADC.

4.2.2.7 int B1Voltage

"Voltage on pin 1 winding B" calibrated data.

4.2.2.8 unsigned int B1Voltage\_ADC

"Voltage on pin 1 winding B" raw data from ADC.

4.2.2.9 int B2Voltage

"Voltage on pin 2 winding B" calibrated data.

4.2.2.10 unsigned int B2Voltage\_ADC

"Voltage on pin 2 winding B" raw data from ADC.

4.2.2.11 int BCurrent

"Winding B current" calibrated data.

4.2.2.12 unsigned int BCurrent\_ADC

"Winding B current" raw data from ADC.

4.2.2.13 int FullCurrent

"Full current" calibrated data.

4.2.2.14 unsigned int FullCurrent\_ADC

"Full current" raw data from ADC.

4.2.2.15 int Joy

Joystick, calibrated data.

Range: 0..10000

4.2.2.16 unsigned int Joy\_ADC

Joystick raw data from ADC.

4.2.2.17 int L

Motor winding pseudo inductance in uHn(is only used with stepper motor).

4.2.2.18 int L5

USB supply voltage after the current sense resistor.

4.2.2.19 unsigned int L5\_ADC

USB supply voltage after the current sense resistor, from ADC.

4.2.2.20 int Pot

Analog input, calibrated data.

Range: 0..10000

4.2.2.21 int R

Motor winding resistance in mOhms(is only used with stepper motor).

4.2.2.22 int SupVoltage

"Voltage on the top of MOSFET full bridge" calibrated data.

4.2.2.23 unsigned int SupVoltage\_ADC

"Voltage on the top of MOSFET full bridge" raw data from ADC.

4.2.2.24 int Temp

Temperature, calibrated data.

4.2.2.25 unsigned int Temp\_ADC

Voltage from temperature sensor, raw data from ADC.

## 4.3 brake\_settings\_t Struct Reference

Brake settings.

### Data Fields

- unsigned int [t1](#)  
*Time in ms between turn on motor power and turn off brake.*
- unsigned int [t2](#)  
*Time in ms between turn off brake and moving readiness.*
- unsigned int [t3](#)  
*Time in ms between motor stop and turn on brake.*
- unsigned int [t4](#)  
*Time in ms between turn on brake and turn off motor power.*
- unsigned int [BrakeFlags](#)  
*Brake settings flags.*

### 4.3.1 Detailed Description

Brake settings.

This structure contains parameters of brake control.

See Also

[set\\_brake\\_settings](#)  
[get\\_brake\\_settings](#)  
[get\\_brake\\_settings, set\\_brake\\_settings](#)

### 4.3.2 Field Documentation

#### 4.3.2.1 unsigned int BrakeFlags

Brake settings flags.

#### 4.3.2.2 unsigned int t1

Time in ms between turn on motor power and turn off brake.

#### 4.3.2.3 unsigned int t2

Time in ms between turn off brake and moving readiness.

All moving commands will execute after this interval.

#### 4.3.2.4 unsigned int t3

Time in ms between motor stop and turn on brake.

#### 4.3.2.5 unsigned int t4

Time in ms between turn on brake and turn off motor power.

## 4.4 calibration\_t Struct Reference

Calibration companion structure.

### Data Fields

- double A  
*Mulitiplier.*
- unsigned int MicrostepMode  
*Microstep mode.*

### 4.4.1 Detailed Description

Calibration companion structure.

## 4.5 chart\_data\_t Struct Reference

Additional device state.

### Data Fields

- int [WindingVoltageA](#)  
*In the case step motor, the voltage across the winding A; in the case of a brushless, the voltage on the first coil, in the case of the only DC.*
- int [WindingVoltageB](#)  
*In the case step motor, the voltage across the winding B; in case of a brushless, the voltage on the second winding, and in the case of DC is not used.*
- int [WindingVoltageC](#)  
*In the case of a brushless, the voltage on the third winding, in the case step motor and DC is not used.*
- int [WindingCurrentA](#)  
*In the case step motor, the current in the coil A; brushless if the current in the first coil, and in the case of a single DC.*
- int [WindingCurrentB](#)  
*In the case step motor, the current in the coil B; brushless if the current in the second coil, and in the case of DC is not used.*
- int [WindingCurrentC](#)  
*In the case of a brushless, the current in the third winding, in the case step motor and DC is not used.*
- unsigned int [Pot](#)  
*Analog input value in ten-thousandths.*
- unsigned int [Joy](#)  
*The joystick position in the ten-thousandths.*
- int [DutyCycle](#)  
*Duty cycle of PWM.*

### 4.5.1 Detailed Description

Additional device state.

This structure contains additional values such as winding's voltages, currents and temperature.

#### See Also

[get\\_chart\\_data](#)  
[get\\_chart\\_data](#)

### 4.5.2 Field Documentation

#### 4.5.2.1 int DutyCycle

Duty cycle of PWM.

#### 4.5.2.2 unsigned int Joy

The joystick position in the ten-thousandths.

Range: 0..10000

## 4.5.2.3 unsigned int Pot

Analog input value in ten-thousandths.

Range: 0..10000

## 4.5.2.4 int WindingCurrentA

In the case step motor, the current in the coil A; brushless if the current in the first coil, and in the case of a single DC.

## 4.5.2.5 int WindingCurrentB

In the case step motor, the current in the coil B; brushless if the current in the second coil, and in the case of DC is not used.

## 4.5.2.6 int WindingCurrentC

In the case of a brushless, the current in the third winding, in the case step motor and DC is not used.

## 4.5.2.7 int WindingVoltageA

In the case step motor, the voltage across the winding A; in the case of a brushless, the voltage on the first coil, in the case of the only DC.

## 4.5.2.8 int WindingVoltageB

In the case step motor, the voltage across the winding B; in case of a brushless, the voltage on the second winding, and in the case of DC is not used.

## 4.5.2.9 int WindingVoltageC

In the case of a brushless, the voltage on the third winding, in the case step motor and DC is not used.

## 4.6 command\_add\_sync\_in\_action\_calb\_t Struct Reference

## Data Fields

- float [Position](#)  
*Desired position or shift.*
- unsigned int [Time](#)  
*Time for which you want to achieve the desired position in microseconds.*

## 4.6.1 Field Documentation

## 4.6.1.1 float Position

Desired position or shift.

## 4.6.1.2 unsigned int Time

Time for which you want to achieve the desired position in microseconds.

## 4.7 command\_add\_sync\_in\_action\_t Struct Reference

This command adds one element of the FIFO commands.

### Data Fields

- int [Position](#)  
*Desired position or shift (whole steps)*
- int [uPosition](#)  
*The fractional part of a position or shift in microsteps.*
- unsigned int [Time](#)  
*Time for which you want to achieve the desired position in microseconds.*

### 4.7.1 Detailed Description

This command adds one element of the FIFO commands.

#### See Also

[command\\_add\\_sync\\_in\\_action](#)

### 4.7.2 Field Documentation

#### 4.7.2.1 unsigned int Time

Time for which you want to achieve the desired position in microseconds.

#### 4.7.2.2 int uPosition

The fractional part of a position or shift in microsteps.

Is only used with stepper motor. Range: -255..255.

## 4.8 control\_settings\_calb\_t Struct Reference

### Data Fields

- float [MaxSpeed](#) [10]  
*Array of speeds using with joystick and button control.*
- unsigned int [Timeout](#) [9]  
*timeout[i] is time in ms, after that max\_speed[i+1] is applying.*
- unsigned int [MaxClickTime](#)  
*Maximum click time.*
- unsigned int [Flags](#)  
*Control flags.*
- float [DeltaPosition](#)  
*Shift (delta) of position.*

## 4.8.1 Field Documentation

### 4.8.1.1 unsigned int Flags

*Control flags.*

### 4.8.1.2 unsigned int MaxClickTime

Maximum click time.

Prior to the expiration of this time the first speed isn't enabled.

### 4.8.1.3 float MaxSpeed[10]

Array of speeds using with joystick and button control.

### 4.8.1.4 unsigned int Timeout[9]

timeout[i] is time in ms, after that max\_speed[i+1] is applying.

It is using with buttons control only.

## 4.9 control\_settings\_t Struct Reference

Control settings.

### Data Fields

- unsigned int **MaxSpeed** [10]
 

*Array of speeds (full step) using with joystick and button control.*
- unsigned int **uMaxSpeed** [10]
 

*Array of speeds (1/256 microstep) using with joystick and button control.*
- unsigned int **Timeout** [9]
 

*timeout[i] is time in ms, after that max\_speed[i+1] is applying.*
- unsigned int **MaxClickTime**

*Maximum click time.*
- unsigned int **Flags**

*Control flags.*
- int **DeltaPosition**

*Shift (delta) of position.*
- int **uDeltaPosition**

*Fractional part of the shift in micro steps.*

## 4.9.1 Detailed Description

Control settings.

This structure contains control parameters. When choosing CTL\_MODE=1 switches motor control with the joystick. In this mode, the joystick to the maximum engine tends Move at MaxSpeed [i], where i=0 if the previous use This mode is not selected another i. Buttons switch the room rate i. When CTL\_MODE=2 is switched on motor control using the Left / right. When you click on the button motor starts to move in the appropriate direction at a speed MaxSpeed [0], at the end of time Timeout[i] motor move at a speed MaxSpeed [i+1]. at Transition from MaxSpeed

[i] on MaxSpeed [i+1] to acceleration, as usual. The figure above shows the sensitivity of the joystick feature on its position.

See Also

[set\\_control\\_settings](#)  
[get\\_control\\_settings](#)  
[get\\_control\\_settings, set\\_control\\_settings](#)

## 4.9.2 Field Documentation

### 4.9.2.1 unsigned int Flags

[Control flags.](#)

### 4.9.2.2 unsigned int MaxClickTime

Maximum click time.

Prior to the expiration of this time the first speed isn't enabled.

### 4.9.2.3 unsigned int MaxSpeed[10]

Array of speeds (full step) using with joystick and button control.

Range: 0..100000.

### 4.9.2.4 unsigned int Timeout[9]

timeout[i] is time in ms, after that max\_speed[i+1] is applying.

It is using with buttons control only.

### 4.9.2.5 int uDeltaPosition

Fractional part of the shift in micro steps.

Is only used with stepper motor. Range: -255..255.

### 4.9.2.6 unsigned int uMaxSpeed[10]

Array of speeds (1/256 microstep) using with joystick and button control.

## 4.10 controller\_name\_t Struct Reference

Controller user name and flags of setting.

### Data Fields

- char [ControllerName](#) [17]  
*User controller name.*
- unsigned int [CtrlFlags](#)  
*Flags of internal controller settings.*

#### 4.10.1 Detailed Description

Controller user name and flags of setting.

See Also

[get\\_controller\\_name](#), [set\\_controller\\_name](#)

#### 4.10.2 Field Documentation

##### 4.10.2.1 char ControllerName[17]

User controller name.

Can be set by user for his/her convenience. Max string length: 16 chars.

##### 4.10.2.2 unsigned int CtrlFlags

Flags of internal controller settings.

## 4.11 ctp\_settings\_t Struct Reference

Control position settings(is only used with stepper motor).

### Data Fields

- unsigned int [CTPMinError](#)  
*Minimum contrast steps from step motor encoder position, which set STATE\_CTP\_ERROR flag.*
- unsigned int [CTPFlags](#)  
*Position control flags.*

#### 4.11.1 Detailed Description

Control position settings(is only used with stepper motor).

When controlling the step motor with encoder (CTP\_BASE 0) it is possible to detect the loss of steps. The controller knows the number of steps per revolution (GENG :: StepsPerRev) and the encoder resolution (GFBS :: IPT). When the control (flag CTP\_ENABLED), the controller stores the current position in the footsteps of SM and the current position of the encoder. Further, at each step of the position encoder is converted into steps and if the difference is greater CTPMinError, a flag STATE\_CTP\_ERROR and set ALARM state. When controlling the step motor with speed sensor (CTP\_BASE 1), the position is controlled by him. The active edge of input clock controller stores the current value of steps. Further, at each turn checks how many steps shifted. When a mismatch CTPMinError a flag STATE\_CTP\_ERROR and set ALARM state.

See Also

[set\\_ctp\\_settings](#)  
[get\\_ctp\\_settings](#)  
[get\\_ctp\\_settings](#), [set\\_ctp\\_settings](#)

#### 4.11.2 Field Documentation

##### 4.11.2.1 unsigned int CTPFlags

Position control flags.

4.11.2.2 unsigned int CTPMinError

Minimum contrast steps from step motor encoder position, which set STATE\_CTP\_ERROR flag.

Measured in steps step motor.

## 4.12 debug\_read\_t Struct Reference

Debug data.

### Data Fields

- unsigned int [DebugData](#) [128]  
*Arbitrary debug data.*

### 4.12.1 Detailed Description

Debug data.

These data are used for device debugging by manufacturer only.

See Also

[get\\_debug\\_read](#)

### 4.12.2 Field Documentation

#### 4.12.2.1 unsigned int DebugData[128]

Arbitrary debug data.

## 4.13 debug\_write\_t Struct Reference

Debug data.

### Data Fields

- unsigned int [DebugData](#) [128]  
*Arbitrary debug data.*

### 4.13.1 Detailed Description

Debug data.

These data are used for device debugging by manufacturer only.

See Also

[set\\_debug\\_write](#)

### 4.13.2 Field Documentation

#### 4.13.2.1 unsigned int DebugData[128]

Arbitrary debug data.

## 4.14 device\_information\_t Struct Reference

Read command controller information.

### Data Fields

- char [Manufacturer](#) [5]  
*Manufacturer.*
- char [ManufacturerId](#) [3]  
*Manufacturer id.*
- char [ProductDescription](#) [9]  
*Product description.*
- unsigned int [Major](#)  
*The major number of the hardware version.*
- unsigned int [Minor](#)  
*Minor number of the hardware version.*
- unsigned int [Release](#)  
*Number of edits this release of hardware.*

### 4.14.1 Detailed Description

Read command controller information.

The controller responds to this command in any state. Manufacturer field for all XI \*\* devices should contain the string "XIMC" (validation is performed on it) The remaining fields contain information about the device.

### See Also

[get\\_device\\_information](#)  
[get\\_device\\_information\\_impl](#)

### 4.14.2 Field Documentation

#### 4.14.2.1 unsigned int Major

The major number of the hardware version.

#### 4.14.2.2 unsigned int Minor

Minor number of the hardware version.

#### 4.14.2.3 unsigned int Release

Number of edits this release of hardware.

## 4.15 device\_network\_information\_t Struct Reference

Device network information structure.

### Data Fields

- `uint32_t ipv4`  
*IPv4 address, passed in network byte order (big-endian byte order)*
- `char nodename [16]`  
*Name of the Bindy node which hosts the device.*
- `uint32_t axis_state`  
*Flags representing device state.*
- `char locker_username [16]`  
*Name of the user who locked the device (if any)*
- `char locker_nodename [16]`  
*Bindy node name, which was used to lock the device (if any)*
- `time_t locked_time`  
*Time the lock was acquired at (UTC, microseconds since the epoch)*

### 4.15.1 Detailed Description

Device network information structure.

## 4.16 edges\_settings\_calb\_t Struct Reference

### Data Fields

- `unsigned int BorderFlags`  
*Border flags.*
- `unsigned int EnderFlags`  
*Limit switches flags.*
- `float LeftBorder`  
*Left border position, used if BORDER\_IS\_ENCODER flag is set.*
- `float RightBorder`  
*Right border position, used if BORDER\_IS\_ENCODER flag is set.*

### 4.16.1 Field Documentation

#### 4.16.1.1 `unsigned int BorderFlags`

*Border flags.*

#### 4.16.1.2 `unsigned int EnderFlags`

*Limit switches flags.*

#### 4.16.1.3 `float LeftBorder`

*Left border position, used if BORDER\_IS\_ENCODER flag is set.*

## 4.16.1.4 float RightBorder

Right border position, used if BORDER\_IS\_ENCODER flag is set.

## 4.17 edges\_settings\_t Struct Reference

Edges settings.

## Data Fields

- unsigned int [BorderFlags](#)  
*Border flags.*
- unsigned int [EnderFlags](#)  
*Limit switches flags.*
- int [LeftBorder](#)  
*Left border position, used if BORDER\_IS\_ENCODER flag is set.*
- int [uLeftBorder](#)  
*Left border position in 1/256 microsteps(used with stepper motor only).*
- int [RightBorder](#)  
*Right border position, used if BORDER\_IS\_ENCODER flag is set.*
- int [uRightBorder](#)  
*Right border position in 1/256 microsteps.*

## 4.17.1 Detailed Description

Edges settings.

This structure contains border and limit switches settings. Please load new engine settings when you change positioner etc. Please note that wrong engine settings lead to device malfunction, can lead to irreversible damage of board.

## See Also

[set\\_edges\\_settings](#)  
[get\\_edges\\_settings](#)  
[get\\_edges\\_settings](#), [set\\_edges\\_settings](#)

## 4.17.2 Field Documentation

## 4.17.2.1 unsigned int BorderFlags

[Border flags.](#)

## 4.17.2.2 unsigned int EnderFlags

[Limit switches flags.](#)

## 4.17.2.3 int LeftBorder

Left border position, used if BORDER\_IS\_ENCODER flag is set.

## 4.17.2.4 int RightBorder

Right border position, used if BORDER\_IS\_ENCODER flag is set.

## 4.17.2.5 int uLeftBorder

Left border position in 1/256 microsteps(used with stepper motor only).

Range: -255..255.

## 4.17.2.6 int uRightBorder

Right border position in 1/256 microsteps.

Used with stepper motor only. Range: -255..255.

## 4.18 encoder\_information\_t Struct Reference

Encoder information.

### Data Fields

- char [Manufacturer](#) [17]  
*Manufacturer.*
- char [PartNumber](#) [25]  
*Series and PartNumber.*

### 4.18.1 Detailed Description

Encoder information.

#### See Also

[set\\_encoder\\_information](#)  
[get\\_encoder\\_information](#)  
[get\\_encoder\\_information](#), [set\\_encoder\\_information](#)

### 4.18.2 Field Documentation

#### 4.18.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

#### 4.18.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

## 4.19 encoder\_settings\_t Struct Reference

Encoder settings.

### Data Fields

- float [MaxOperatingFrequency](#)  
*Max operation frequency (kHz).*
- float [SupplyVoltageMin](#)  
*Minimum supply voltage (V).*
- float [SupplyVoltageMax](#)  
*Maximum supply voltage (V).*
- float [MaxCurrentConsumption](#)  
*Max current consumption (mA).*
- unsigned int [PPR](#)  
*The number of counts per revolution.*
- unsigned int [EncoderSettings](#)  
*Encoder settings flags.*

### 4.19.1 Detailed Description

Encoder settings.

#### See Also

[set\\_encoder\\_settings](#)  
[get\\_encoder\\_settings](#)  
[get\\_encoder\\_settings](#), [set\\_encoder\\_settings](#)

### 4.19.2 Field Documentation

#### 4.19.2.1 unsigned int EncoderSettings

[Encoder settings flags.](#)

#### 4.19.2.2 float MaxCurrentConsumption

Max current consumption (mA).

Data type: float.

#### 4.19.2.3 float MaxOperatingFrequency

Max operation frequency (kHz).

Data type: float.

#### 4.19.2.4 float SupplyVoltageMax

Maximum supply voltage (V).

Data type: float.

## 4.19.2.5 float SupplyVoltageMin

Minimum supply voltage (V).

Data type: float.

## 4.20 engine\_settings\_calb\_t Struct Reference

## Data Fields

- unsigned int [NomVoltage](#)  
*Rated voltage.*
- unsigned int [NomCurrent](#)  
*Rated current.*
- float [NomSpeed](#)  
*Nominal speed.*
- unsigned int [EngineFlags](#)  
*Flags of engine settings.*
- float [Antiplay](#)  
*Number of pulses or steps for backlash (play) compensation procedure.*
- unsigned int [MicrostepMode](#)  
*Flags of microstep mode.*
- unsigned int [StepsPerRev](#)  
*Number of full steps per revolution(Used with steper motor only).*

## 4.20.1 Field Documentation

## 4.20.1.1 float Antiplay

Number of pulses or steps for backlash (play) compensation procedure.

Used if ENGINE\_ANTIPLAY flag is set.

## 4.20.1.2 unsigned int EngineFlags

[Flags of engine settings.](#)

## 4.20.1.3 unsigned int MicrostepMode

[Flags of microstep mode.](#)

## 4.20.1.4 unsigned int NomCurrent

Rated current.

Controller will keep current consumed by motor below this value if ENGINE\_LIMIT\_CURR flag is set. Range: 15..8000

## 4.20.1.5 float NomSpeed

Nominal speed.

Controller will keep motor speed below this value if ENGINE\_LIMIT\_RPM flag is set.

## 4.20.1.6 unsigned int NomVoltage

Rated voltage.

Controller will keep the voltage drop on motor below this value if ENGINE\_LIMIT\_VOLT flag is set(Used with DC only). Range: 1..65535

## 4.20.1.7 unsigned int StepsPerRev

Number of full steps per revolution(Used with steper motor only).

Range: 1..65535.

## 4.21 engine\_settings\_t Struct Reference

Engine settings.

## Data Fields

- unsigned int [NomVoltage](#)  
*Rated voltage.*
- unsigned int [NomCurrent](#)  
*Rated current.*
- unsigned int [NomSpeed](#)  
*Nominal speed (in whole steps/s or rpm for DC and stepper motor as a master encoder).*
- unsigned int [uNomSpeed](#)  
*The fractional part of a nominal speed in microsteps (is only used with stepper motor).*
- unsigned int [EngineFlags](#)  
*Flags of engine settings.*
- int [Antiplay](#)  
*Number of pulses or steps for backlash (play) compensation procedure.*
- unsigned int [MicrostepMode](#)  
*Flags of microstep mode.*
- unsigned int [StepsPerRev](#)  
*Number of full steps per revolution(Used with steper motor only).*

## 4.21.1 Detailed Description

Engine settings.

This structure contains useful motor settings. These settings specify motor shaft movement algorithm, list of limitations and rated characteristics. All boards are supplied with standart set of engine setting on controller's flash memory. Please load new engine settings when you change motor, encoder, positioner etc. Please note that wrong engine settings lead to device malfunction, can lead to irreversible damage of board.

## See Also

[set\\_engine\\_settings](#)  
[get\\_engine\\_settings](#)  
[get\\_engine\\_settings, set\\_engine\\_settings](#)

## 4.21.2 Field Documentation

### 4.21.2.1 int Antiplay

Number of pulses or steps for backlash (play) compensation procedure.

Used if ENGINE\_ANTIPLAY flag is set.

### 4.21.2.2 unsigned int EngineFlags

[Flags of engine settings.](#)

### 4.21.2.3 unsigned int MicrostepMode

[Flags of microstep mode.](#)

### 4.21.2.4 unsigned int NomCurrent

Rated current.

Controller will keep current consumed by motor below this value if ENGINE\_LIMIT\_CURR flag is set. Range: 15..8000

### 4.21.2.5 unsigned int NomSpeed

Nominal speed (in whole steps/s or rpm for DC and stepper motor as a master encoder).

Controller will keep motor shaft RPM below this value if ENGINE\_LIMIT\_RPM flag is set. Range: 1..100000.

### 4.21.2.6 unsigned int NomVoltage

Rated voltage.

Controller will keep the voltage drop on motor below this value if ENGINE\_LIMIT\_VOLT flag is set(Used with DC only). Range: 1..65535

### 4.21.2.7 unsigned int StepsPerRev

Number of full steps per revolution(Used with steper motor only).

Range: 1..65535.

### 4.21.2.8 unsigned int uNomSpeed

The fractional part of a nominal speed in microsteps (is only used with stepper motor).

## 4.22 entype\_settings\_t Struct Reference

Engine type and driver type settings.

## Data Fields

- unsigned int [EngineType](#)  
*Flags of engine type.*
- unsigned int [DriverType](#)  
*Flags of driver type.*

### 4.22.1 Detailed Description

Engine type and driver type settings.

#### Parameters

<i>id</i>	an identifier of device
<i>EngineType</i>	engine type
<i>DriverType</i>	driver type

#### See Also

[get\\_entype\\_settings](#), [set\\_entype\\_settings](#)

### 4.22.2 Field Documentation

#### 4.22.2.1 unsigned int DriverType

*Flags of driver type.*

#### 4.22.2.2 unsigned int EngineType

*Flags of engine type.*

## 4.23 extio\_settings\_t Struct Reference

EXTIO settings.

## Data Fields

- unsigned int [EXTIOTSetupFlags](#)  
*External IO setup flags.*
- unsigned int [EXTIOModeFlags](#)  
*External IO mode flags.*

### 4.23.1 Detailed Description

EXTIO settings.

This structure contains all EXTIO settings. By default input event are signalled through rising front and output states are signalled by high logic state.

See Also

[get\\_extio\\_settings](#)  
[set\\_extio\\_settings](#)  
[get\\_extio\\_settings, set\\_extio\\_settings](#)

#### 4.23.2 Field Documentation

##### 4.23.2.1 unsigned int EXTIOModeFlags

External IO mode flags.

##### 4.23.2.2 unsigned int EXTIOSetupFlags

External IO setup flags.

## 4.24 feedback\_settings\_t Struct Reference

Feedback settings.

### Data Fields

- unsigned int **IPS**  
*The number of measured counts per revolution encoder.*
- unsigned int **FeedbackType**  
*Feedback type.*
- unsigned int **FeedbackFlags**  
*Describes feedback flags.*
- unsigned int **HallSPR**  
*The number of hall steps per revolution.*
- int **HallShift**  
*Phase shift between output signal on BLDC engine and hall sensor input(0 - when only active the Hall sensor, the output state is a positive voltage on the winding A and a negative voltage on the winding B).*

#### 4.24.1 Detailed Description

Feedback settings.

This structure contains feedback settings.

See Also

[get\\_feedback\\_settings, set\\_feedback\\_settings](#)

#### 4.24.2 Field Documentation

##### 4.24.2.1 unsigned int FeedbackFlags

Describes feedback flags.

4.24.2.2 unsigned int FeedbackType

Feedback type.

4.24.2.3 int HallShift

Phase shift between output signal on BLDC engine and hall sensor input(0 - when only active the Hall sensor, the output state is a positive voltage on the winding A and a negative voltage on the winding B).

4.24.2.4 unsigned int HallSPR

The number of hall steps per revolution.

## 4.25 gear\_information\_t Struct Reference

Gear information.

### Data Fields

- char [Manufacturer](#) [17]  
*Manufacturer.*
- char [PartNumber](#) [25]  
*Series and PartNumber.*

### 4.25.1 Detailed Description

Gear information.

See Also

[set\\_gear\\_information](#)  
[get\\_gear\\_information](#)  
[get\\_gear\\_information](#), [set\\_gear\\_information](#)

### 4.25.2 Field Documentation

#### 4.25.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

#### 4.25.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

## 4.26 gear\_settings\_t Struct Reference

Gear settings.

## Data Fields

- float [ReductionIn](#)  
*Input reduction coefficient.*
- float [ReductionOut](#)  
*Output reduction coefficient.*
- float [RatedInputTorque](#)  
*Max continuous torque (N m).*
- float [RatedInputSpeed](#)  
*Max speed on the input shaft (rpm).*
- float [MaxOutputBacklash](#)  
*Output backlash of the reduction gear(degree).*
- float [InputInertia](#)  
*Equivalent input gear inertia (g cm<sup>2</sup>).*
- float [Efficiency](#)  
*Reduction gear efficiency (%).*

### 4.26.1 Detailed Description

Gear settings.

See Also

[set\\_gear\\_settings](#)  
[get\\_gear\\_settings](#)  
[get\\_gear\\_settings, set\\_gear\\_settings](#)

### 4.26.2 Field Documentation

#### 4.26.2.1 float Efficiency

Reduction gear efficiency (%).

Data type: float.

#### 4.26.2.2 float InputInertia

Equivalent input gear inertia (g cm<sup>2</sup>).

Data type: float.

#### 4.26.2.3 float MaxOutputBacklash

Output backlash of the reduction gear(degree).

Data type: float.

#### 4.26.2.4 float RatedInputSpeed

Max speed on the input shaft (rpm).

Data type: float.

## 4.26.2.5 float RatedInputTorque

Max continuous torque (N m).

Data type: float.

## 4.26.2.6 float ReductionIn

Input reduction coefficient.

(Output = (ReductionOut / ReductionIn) \* Input) Data type: float.

## 4.26.2.7 float ReductionOut

Output reduction coefficient.

(Output = (ReductionOut / ReductionIn) \* Input) Data type: float.

## 4.27 get\_position\_calb\_t Struct Reference

## Data Fields

- float [Position](#)  
*The position in the engine.*
- long\_t [EncPosition](#)  
*Encoder position.*

## 4.27.1 Field Documentation

## 4.27.1.1 long\_t EncPosition

Encoder position.

## 4.27.1.2 float Position

The position in the engine.

## 4.28 get\_position\_t Struct Reference

Position information.

## Data Fields

- int [Position](#)  
*The position of the whole steps in the engine.*
- int [uPosition](#)  
*Microstep position is only used with stepper motors.*
- long\_t [EncPosition](#)  
*Encoder position.*

#### 4.28.1 Detailed Description

Position information.

Useful structure that contains position value in steps and micro for stepper motor and encoder steps of all engines.

See Also

[get\\_position](#)

#### 4.28.2 Field Documentation

##### 4.28.2.1 long\_t EncPosition

Encoder position.

### 4.29 hallsensor\_information\_t Struct Reference

Hall sensor information.

#### Data Fields

- char [Manufacturer](#) [17]  
*Manufacturer.*
- char [PartNumber](#) [25]  
*Series and PartNumber.*

#### 4.29.1 Detailed Description

Hall sensor information.

See Also

[set\\_hallsensor\\_information](#)  
[get\\_hallsensor\\_information](#)  
[get\\_hallsensor\\_information](#), [set\\_hallsensor\\_information](#)

#### 4.29.2 Field Documentation

##### 4.29.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

##### 4.29.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

### 4.30 hallsensor\_settings\_t Struct Reference

Hall sensor settings.

## Data Fields

- float [MaxOperatingFrequency](#)  
*Max operation frequency (kHz).*
- float [SupplyVoltageMin](#)  
*Minimum supply voltage (V).*
- float [SupplyVoltageMax](#)  
*Maximum supply voltage (V).*
- float [MaxCurrentConsumption](#)  
*Max current consumption (mA).*
- unsigned int [PPR](#)  
*The number of counts per revolution.*

### 4.30.1 Detailed Description

Hall sensor settings.

#### See Also

[set\\_hallsensor\\_settings](#)  
[get\\_hallsensor\\_settings](#)  
[get\\_hallsensor\\_settings](#), [set\\_hallsensor\\_settings](#)

### 4.30.2 Field Documentation

#### 4.30.2.1 float MaxCurrentConsumption

Max current consumption (mA).

Data type: float.

#### 4.30.2.2 float MaxOperatingFrequency

Max operation frequency (kHz).

Data type: float.

#### 4.30.2.3 float SupplyVoltageMax

Maximum supply voltage (V).

Data type: float.

#### 4.30.2.4 float SupplyVoltageMin

Minimum supply voltage (V).

Data type: float.

## 4.31 home\_settings\_calb\_t Struct Reference

## Data Fields

- float [FastHome](#)

- float [SlowHome](#)  
*Speed used for first motion.*
- float [HomeDelta](#)  
*Distance from break point.*
- unsigned int [HomeFlags](#)  
*Home settings flags.*

#### 4.31.1 Field Documentation

##### 4.31.1.1 float FastHome

Speed used for first motion.

##### 4.31.1.2 float HomeDelta

Distance from break point.

##### 4.31.1.3 unsigned int HomeFlags

*Home settings flags.*

##### 4.31.1.4 float SlowHome

Speed used for second motion.

## 4.32 home\_settings\_t Struct Reference

Position calibration settings.

### Data Fields

- unsigned int [FastHome](#)  
*Speed used for first motion.*
- unsigned int [uFastHome](#)  
*Part of the speed for first motion, microsteps.*
- unsigned int [SlowHome](#)  
*Speed used for second motion.*
- unsigned int [uSlowHome](#)  
*Part of the speed for second motion, microsteps.*
- int [HomeDelta](#)  
*Distance from break point.*
- int [uHomeDelta](#)  
*Part of the delta distance, microsteps.*
- unsigned int [HomeFlags](#)  
*Home settings flags.*

### 4.32.1 Detailed Description

Position calibration settings.

This structure contains settings used in position calibrating. It specify behaviour of calibrating position.

See Also

[get\\_home\\_settings](#)  
[set\\_home\\_settings](#)  
[command\\_home](#)  
[get\\_home\\_settings, set\\_home\\_settings](#)

### 4.32.2 Field Documentation

#### 4.32.2.1 unsigned int FastHome

Speed used for first motion.

Range: 0..100000.

#### 4.32.2.2 int HomeDelta

Distance from break point.

#### 4.32.2.3 unsigned int HomeFlags

**Home settings flags.**

#### 4.32.2.4 unsigned int SlowHome

Speed used for second motion.

Range: 0..100000.

#### 4.32.2.5 unsigned int uFastHome

Part of the speed for first motion, microsteps.

#### 4.32.2.6 int uHomeDelta

Part of the delta distance, microsteps.

Range: -255..255.

#### 4.32.2.7 unsigned int uSlowHome

Part of the speed for second motion, microsteps.

## 4.33 init\_random\_t Struct Reference

Random key.

## Data Fields

- unsigned int [key](#) [16]

*Random key.*

### 4.33.1 Detailed Description

Random key.

Structure that contains random key used in encryption of WKEY and SSER command contents.

#### See Also

[get\\_init\\_random](#)

### 4.33.2 Field Documentation

#### 4.33.2.1 unsigned int key[16]

Random key.

## 4.34 joystick\_settings\_t Struct Reference

Joystick settings.

## Data Fields

- unsigned int [JoyLowEnd](#)

*Joystick lower end position.*

- unsigned int [JoyCenter](#)

*Joystick center position.*

- unsigned int [JoyHighEnd](#)

*Joystick higher end position.*

- unsigned int [ExpFactor](#)

*Exponential nonlinearity factor.*

- unsigned int [DeadZone](#)

*Joystick dead zone.*

- unsigned int [JoyFlags](#)

*Joystick flags.*

### 4.34.1 Detailed Description

Joystick settings.

This structure contains joystick parameters. If joystick position is outside DeadZone limits from the central position a movement with speed, defined by the joystick DeadZone edge to 100% deviation, begins. Joystick positions inside DeadZone limits correspond to zero speed (soft stop of motion) and positions beyond Low and High limits correspond MaxSpeed [i] or -MaxSpeed [i] (see command SCTL), where i = 0 by default and can be changed with left/right buttons (see command SCTL). If next speed in list is zero (both integer and microstep parts), the button press is ignored. First speed in list shouldn't be zero. The relationship between the deviation and the rate is exponential, allowing no switching speed combine high mobility and accuracy.

See Also

[set\\_joystick\\_settings](#)  
[get\\_joystick\\_settings](#)  
[get\\_joystick\\_settings](#), [set\\_joystick\\_settings](#)

#### 4.34.2 Field Documentation

##### 4.34.2.1 unsigned int DeadZone

Joystick dead zone.

##### 4.34.2.2 unsigned int ExpFactor

Exponential nonlinearity factor.

##### 4.34.2.3 unsigned int JoyCenter

Joystick center position.

Range: 0..10000.

##### 4.34.2.4 unsigned int JoyFlags

Joystick flags.

##### 4.34.2.5 unsigned int JoyHighEnd

Joystick higher end position.

Range: 0..10000.

##### 4.34.2.6 unsigned int JoyLowEnd

Joystick lower end position.

Range: 0..10000.

## 4.35 motor\_information\_t Struct Reference

motor information.

### Data Fields

- char [Manufacturer](#) [17]  
*Manufacturer.*
- char [PartNumber](#) [25]  
*Series and PartNumber.*

### 4.35.1 Detailed Description

motor information.

See Also

[set\\_motor\\_information](#)  
[get\\_motor\\_information](#)  
[get\\_motor\\_information](#), [set\\_motor\\_information](#)

### 4.35.2 Field Documentation

#### 4.35.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

#### 4.35.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

## 4.36 motor\_settings\_t Struct Reference

motor settings.

### Data Fields

- unsigned int [MotorType](#)  
*Motor Type flags.*
- unsigned int [ReservedField](#)  
*Reserved.*
- unsigned int [Poles](#)  
*Number of pole pairs for DC or BLDC motors or number of steps per rotation for stepper motor.*
- unsigned int [Phases](#)  
*Number of phases for BLDC motors.*
- float [NominalVoltage](#)  
*Nominal voltage on winding (B).*
- float [NominalCurrent](#)  
*Maximum direct current in winding for DC and BLDC engines, nominal current in windings for stepper motor (A).*
- float [NominalSpeed](#)  
*Nominal speed(rpm).*
- float [NominalTorque](#)  
*Nominal torque(mN m).*
- float [NominalPower](#)  
*Nominal power(W).*
- float [WindingResistance](#)  
*Resistance of windings for DC engine, each of two windings for stepper motor or each of three windings for BLDC engine(Ohm).*
- float [WindingInductance](#)

*Inductance of windings for DC engine, each of two windings for stepper motor or each of three windings for BLDC engine (mH).*

- float [RotorInertia](#)

*Rotor inertia (g cm<sup>2</sup>).*

- float [StallTorque](#)

*Torque hold position for a stepper motor or torque at a motionless rotor for other types of engines (mN m).*

- float [DetentTorque](#)

*Holding torque position with un-powered coils (mN m).*

- float [TorqueConstant](#)

*Torque constant, which determines the aspect ratio of maximum moment of force from the rotor current flowing in the coil (mN m / A).*

- float [SpeedConstant](#)

*Velocity constant, which determines the value or amplitude of the induced voltage on the motion of DC or BLDC motor (rpm / V) or stepper motor (steps/s / V).*

- float [SpeedTorqueGradient](#)

*Speed torque gradient (rpm / mN m).*

- float [MechanicalTimeConstant](#)

*Mechanical time constant (ms).*

- float [MaxSpeed](#)

*The maximum speed for stepper motors (steps/s) or DC and BLDC motors (rmp).*

- float [MaxCurrent](#)

*The maximum current in the winding (A).*

- float [MaxCurrentTime](#)

*Safe duration of overcurrent in the winding (ms).*

- float [NoLoadCurrent](#)

*The current consumption in idle mode (A).*

- float [NoLoadSpeed](#)

*Idle speed (rpm).*

#### 4.36.1 Detailed Description

motor settings.

See Also

[set\\_motor\\_settings](#)

[get\\_motor\\_settings](#)

[get\\_motor\\_settings, set\\_motor\\_settings](#)

#### 4.36.2 Field Documentation

##### 4.36.2.1 float DetentTorque

Holding torque position with un-powered coils (mN m).

Data type: float.

##### 4.36.2.2 float MaxCurrent

The maximum current in the winding (A).

Data type: float.

## 4.36.2.3 float MaxCurrentTime

Safe duration of overcurrent in the winding (ms).

Data type: float.

## 4.36.2.4 float MaxSpeed

The maximum speed for stepper motors (steps/s) or DC and BLDC motors (rmp).

Data type: float.

## 4.36.2.5 float MechanicalTimeConstant

Mechanical time constant (ms).

Data type: float.

## 4.36.2.6 unsigned int MotorType

[Motor Type flags.](#)

## 4.36.2.7 float NoLoadCurrent

The current consumption in idle mode (A).

Used for DC and BLDC motors. Data type: float.

## 4.36.2.8 float NoLoadSpeed

Idle speed (rpm).

Used for DC and BLDC motors. Data type: float.

## 4.36.2.9 float NominalCurrent

Maximum direct current in winding for DC and BLDC engines, nominal current in windings for stepper motor (A).

Data type: float.

## 4.36.2.10 float NominalPower

Nominal power(W).

Used for DC and BLDC engine. Data type: float.

## 4.36.2.11 float NominalSpeed

Nominal speed(rpm).

Used for DC and BLDC engine. Data type: float.

## 4.36.2.12 float NominalTorque

Nominal torque(mN m).

Used for DC and BLDC engine. Data type: float.

## 4.36.2.13 float NominalVoltage

Nominal voltage on winding (B).

Data type: float

## 4.36.2.14 unsigned int Phases

Number of phases for BLDC motors.

## 4.36.2.15 unsigned int Poles

Number of pole pairs for DC or BLDC motors or number of steps per rotation for stepper motor.

## 4.36.2.16 float RotorInertia

Rotor inertia(g cm<sup>2</sup>).

Data type: float.

## 4.36.2.17 float SpeedConstant

Velocity constant, which determines the value or amplitude of the induced voltage on the motion of DC or BLDC motor (rpm / V) or stepper motor (steps/s / V).

Data type: float.

## 4.36.2.18 float SpeedTorqueGradient

Speed torque gradient (rpm / mN m).

Data type: float.

## 4.36.2.19 float StallTorque

Torque hold position for a stepper motor or torque at a motionless rotor for other types of engines (mN m).

Data type: float.

## 4.36.2.20 float TorqueConstant

Torque constant, which determines the aspect ratio of maximum moment of force from the rotor current flowing in the coil (mN m / A).

Used mainly for DC motors. Data type: float.

## 4.36.2.21 float WindingInductance

Inductance of windings for DC engine, each of two windings for stepper motor or each of three windings for BLDC engine(mH).

Data type: float.

## 4.36.2.22 float WindingResistance

Resistance of windings for DC engine, each of two windings for stepper motor or each of three windings for BLDC engine(Ohm).

Data type: float.

## 4.37 move\_settings\_calb\_t Struct Reference

## Data Fields

- float [Speed](#)  
*Target speed.*
- float [Accel](#)  
*Motor shaft acceleration, steps/s<sup>2</sup>(stepper motor) or RPM/s(DC).*
- float [Decel](#)  
*Motor shaft deceleration, steps/s<sup>2</sup>(stepper motor) or RPM/s(DC).*
- float [AntiplaySpeed](#)  
*Speed in antiplay mode.*

## 4.37.1 Field Documentation

## 4.37.1.1 float Accel

Motor shaft acceleration, steps/s<sup>2</sup>(stepper motor) or RPM/s(DC).

## 4.37.1.2 float AntiplaySpeed

Speed in antiplay mode.

## 4.37.1.3 float Decel

Motor shaft deceleration, steps/s<sup>2</sup>(stepper motor) or RPM/s(DC).

## 4.37.1.4 float Speed

Target speed.

## 4.38 move\_settings\_t Struct Reference

Move settings.

## Data Fields

- **unsigned int Speed**  
*Target speed (for stepper motor: steps/s, for DC: rpm).*
- **unsigned int uSpeed**  
*Target speed in microstep fractions/s.*
- **unsigned int Accel**  
*Motor shaft acceleration, steps/s<sup>2</sup>(stepper motor) or RPM/s(DC).*
- **unsigned int Decel**  
*Motor shaft deceleration, steps/s<sup>2</sup>(stepper motor) or RPM/s(DC).*
- **unsigned int AntiplaySpeed**  
*Speed in antiplay mode, full steps/s(stepper motor) or RPM(DC).*
- **unsigned int uAntiplaySpeed**  
*Speed in antiplay mode, 1/256 microsteps/s.*

### 4.38.1 Detailed Description

Move settings.

See Also

[set\\_move\\_settings](#)  
[get\\_move\\_settings](#)  
[get\\_move\\_settings, set\\_move\\_settings](#)

### 4.38.2 Field Documentation

#### 4.38.2.1 unsigned int Accel

Motor shaft acceleration, steps/s<sup>2</sup>(stepper motor) or RPM/s(DC).

Range: 1..65535.

#### 4.38.2.2 unsigned int AntiplaySpeed

Speed in antiplay mode, full steps/s(stepper motor) or RPM(DC).

Range: 0..100000.

#### 4.38.2.3 unsigned int Decel

Motor shaft deceleration, steps/s<sup>2</sup>(stepper motor) or RPM/s(DC).

Range: 1..65535.

#### 4.38.2.4 unsigned int Speed

Target speed (for stepper motor: steps/s, for DC: rpm).

Range: 0..100000.

#### 4.38.2.5 unsigned int uAntiplaySpeed

Speed in antiplay mode, 1/256 microsteps/s.

Used with stepper motor only.

## 4.38.2.6 unsigned int uSpeed

Target speed in microstep fractions/s.

Using with stepper motor only.

## 4.39 pid\_settings\_t Struct Reference

PID settings.

## Data Fields

- unsigned int [KpU](#)  
*Proportional gain for voltage PID routine.*
- unsigned int [KiU](#)  
*Integral gain for voltage PID routine.*
- unsigned int [KdU](#)  
*Differential gain for voltage PID routine.*

## 4.39.1 Detailed Description

PID settings.

This structure contains factors for PID routine. It specify behaviour of PID routine for voltage. These factors are slightly different for different positioners. All boards are supplied with standart set of PID setting on controller's flash memory. Please load new PID settings when you change positioner. Please note that wrong PID settings lead to device malfunction.

## See Also

[set\\_pid\\_settings](#)  
[get\\_pid\\_settings](#)  
[get\\_pid\\_settings, set\\_pid\\_settings](#)

## 4.40 power\_settings\_t Struct Reference

Step motor power settings.

## Data Fields

- unsigned int [HoldCurrent](#)  
*Current in holding regime, percent of nominal.*
- unsigned int [CurrReductDelay](#)  
*Time in ms from going to STOP state to reducing current.*
- unsigned int [PowerOffDelay](#)  
*Time in s from going to STOP state to turning power off.*
- unsigned int [CurrentSetTime](#)  
*Time in ms to reach nominal current.*
- unsigned int [PowerFlags](#)  
*Flags of power settings of stepper motor.*

#### 4.40.1 Detailed Description

Step motor power settings.

See Also

[set\\_move\\_settings](#)  
[get\\_move\\_settings](#)  
[get\\_power\\_settings](#), [set\\_power\\_settings](#)

#### 4.40.2 Field Documentation

##### 4.40.2.1 unsigned int CurrentSetTime

Time in ms to reach nominal current.

##### 4.40.2.2 unsigned int CurrReductDelay

Time in ms from going to STOP state to reducing current.

##### 4.40.2.3 unsigned int HoldCurrent

Current in holding regime, percent of nominal.

Range: 0..100.

##### 4.40.2.4 unsigned int PowerFlags

Flags of power settings of stepper motor.

##### 4.40.2.5 unsigned int PowerOffDelay

Time in s from going to STOP state to turning power off.

## 4.41 secure\_settings\_t Struct Reference

This structure contains raw analog data from ADC embedded on board.

### Data Fields

- unsigned int [LowUpwrOff](#)  
*Lower voltage limit to turn off the motor, in mV.*
- unsigned int [Criticalpwr](#)  
*Maximum motor current which triggers ALARM state, in mA.*
- unsigned int [CriticalUpwr](#)  
*Maximum motor voltage which triggers ALARM state, in mV.*
- unsigned int [CriticalT](#)  
*Maximum temperature, which triggers ALARM state, in tenths of degrees Celcius.*
- unsigned int [CriticalUsb](#)  
*Maximum USB current which triggers ALARM state, in mA.*
- unsigned int [CriticalUusb](#)

*Maximum USB voltage which triggers ALARM state, in mV.*

- `unsigned int MinimumUusb`  
*Minimum USB voltage which triggers ALARM state, in mV.*
- `unsigned int Flags`  
*Flags of secure settings.*

#### 4.41.1 Detailed Description

This structure contains raw analog data from ADC embedded on board.

These data used for device testing and deep recalibration by manufacturer only.

See Also

[get\\_secure\\_settings](#)  
[set\\_secure\\_settings](#)  
[get\\_secure\\_settings, set\\_secure\\_settings](#)

#### 4.41.2 Field Documentation

##### 4.41.2.1 `unsigned int CriticalIpwr`

Maximum motor current which triggers ALARM state, in mA.

##### 4.41.2.2 `unsigned int CriticalUusb`

Maximum USB current which triggers ALARM state, in mA.

##### 4.41.2.3 `unsigned int CriticalT`

Maximum temperature, which triggers ALARM state, in tenths of degrees Celcius.

##### 4.41.2.4 `unsigned int CriticalUpwr`

Maximum motor voltage which triggers ALARM state, in mV.

##### 4.41.2.5 `unsigned int CriticalUusb`

Maximum USB voltage which triggers ALARM state, in mV.

##### 4.41.2.6 `unsigned int Flags`

*Flags of secure settings.*

##### 4.41.2.7 `unsigned int LowUpwrOff`

Lower voltage limit to turn off the motor, in mV.

##### 4.41.2.8 `unsigned int MinimumUusb`

Minimum USB voltage which triggers ALARM state, in mV.

## 4.42 serial\_number\_t Struct Reference

Serial number structure and hardware version.

### Data Fields

- unsigned int **SN**  
*New board serial number.*
- unsigned int **Key** [32]  
*Protection key (256 bit).*
- unsigned int **Major**  
*The major number of the hardware version.*
- unsigned int **Minor**  
*Minor number of the hardware version.*
- unsigned int **Release**  
*Number of edits this release of hardware.*

### 4.42.1 Detailed Description

Serial number structure and hardware version.

The structure keep new serial number, hardware version and valid key. The SN and hardware version are changed and saved when transmitted key matches stored key. Can be used by manufacturer only.

#### See Also

[set\\_serial\\_number](#)

### 4.42.2 Field Documentation

#### 4.42.2.1 unsigned int Key[32]

Protection key (256 bit).

#### 4.42.2.2 unsigned int Major

The major number of the hardware version.

#### 4.42.2.3 unsigned int Minor

Minor number of the hardware version.

#### 4.42.2.4 unsigned int Release

Number of edits this release of hardware.

#### 4.42.2.5 unsigned int SN

New board serial number.

## 4.43 set\_position\_calb\_t Struct Reference

### Data Fields

- float [Position](#)  
*The position in the engine.*
- long\_t [EncPosition](#)  
*Encoder position.*
- unsigned int [PosFlags](#)  
*Position setting flags.*

### 4.43.1 Field Documentation

#### 4.43.1.1 long\_t EncPosition

Encoder position.

#### 4.43.1.2 unsigned int PosFlags

[Position setting flags.](#)

#### 4.43.1.3 float Position

The position in the engine.

## 4.44 set\_position\_t Struct Reference

Position information.

### Data Fields

- int [Position](#)  
*The position of the whole steps in the engine.*
- int [uPosition](#)  
*Microstep position is only used with stepper motors.*
- long\_t [EncPosition](#)  
*Encoder position.*
- unsigned int [PosFlags](#)  
*Position setting flags.*

### 4.44.1 Detailed Description

Position information.

Useful structure that contains position value in steps and micro for stepper motor and encoder steps of all engines.

### See Also

[set\\_position](#)

## 4.44.2 Field Documentation

### 4.44.2.1 long\_t EncPosition

Encoder position.

### 4.44.2.2 unsigned int PosFlags

[Position setting flags.](#)

## 4.45 stage\_information\_t Struct Reference

Stage information.

### Data Fields

- char [Manufacturer](#) [17]  
*Manufacturer.*
- char [PartNumber](#) [25]  
*Series and PartNumber.*

### 4.45.1 Detailed Description

Stage information.

See Also

[set\\_stage\\_information](#)  
[get\\_stage\\_information](#)  
[get\\_stage\\_information](#), [set\\_stage\\_information](#)

### 4.45.2 Field Documentation

#### 4.45.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

#### 4.45.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

## 4.46 stage\_name\_t Struct Reference

Stage user name.

## Data Fields

- char [PositionerName](#) [17]

*User positioner name.*

### 4.46.1 Detailed Description

Stage user name.

#### See Also

[get\\_stage\\_name](#), [set\\_stage\\_name](#)

### 4.46.2 Field Documentation

#### 4.46.2.1 char PositionerName[17]

User positioner name.

Can be set by user for his/her convinience. Max string length: 16 chars.

## 4.47 stage\_settings\_t Struct Reference

Stage settings.

## Data Fields

- float [LeadScrewPitch](#)

*Lead screw pitch (mm).*

- char [Units](#) [9]

*Units for MaxSpeed and TravelRange fields of the structure (steps, degrees, mm, ...).*

- float [MaxSpeed](#)

*Max speed (Units/c).*

- float [TravelRange](#)

*Travel range (Units).*

- float [SupplyVoltageMin](#)

*Supply voltage minimum (V).*

- float [SupplyVoltageMax](#)

*Supply voltage maximum (V).*

- float [MaxCurrentConsumption](#)

*Max current consumption (A).*

- float [HorizontalLoadCapacity](#)

*Horizontal load capacity (kg).*

- float [VerticalLoadCapacity](#)

*Vertical load capacity (kg).*

#### 4.47.1 Detailed Description

Stage settings.

See Also

[set\\_stage\\_settings](#)  
[get\\_stage\\_settings](#)  
[get\\_stage\\_settings, set\\_stage\\_settings](#)

#### 4.47.2 Field Documentation

##### 4.47.2.1 float HorizontalLoadCapacity

Horizontal load capacity (kg).

Data type: float.

##### 4.47.2.2 float LeadScrewPitch

Lead screw pitch (mm).

Data type: float.

##### 4.47.2.3 float MaxCurrentConsumption

Max current consumption (A).

Data type: float.

##### 4.47.2.4 float MaxSpeed

Max speed (Units/c).

Data type: float.

##### 4.47.2.5 float SupplyVoltageMax

Supply voltage maximum (V).

Data type: float.

##### 4.47.2.6 float SupplyVoltageMin

Supply voltage minimum (V).

Data type: float.

##### 4.47.2.7 float TravelRange

Travel range (Units).

Data type: float.

## 4.47.2.8 char Units[9]

Units for MaxSpeed and TravelRange fields of the structure (steps, degrees, mm, ...).

Max string length: 8 chars.

## 4.47.2.9 float VerticalLoadCapacity

Vertical load capacity (kg).

Data type: float.

## 4.48 status\_calb\_t Struct Reference

## Data Fields

- unsigned int [MoveSts](#)

*Flags of move state.*

- unsigned int [MvCmdSts](#)

*Move command state.*

- unsigned int [PWRSts](#)

*Flags of power state of stepper motor.*

- unsigned int [EncSts](#)

*Encoder state.*

- unsigned int [WindSts](#)

*Winding state.*

- float [CurPosition](#)

*Current position.*

- long\_t [EncPosition](#)

*Current encoder position.*

- float [CurSpeed](#)

*Motor shaft speed.*

- int [Ipwr](#)

*Engine current.*

- int [Upwr](#)

*Power supply voltage.*

- int [Iusb](#)

*USB current consumption.*

- int [Uusb](#)

*USB voltage.*

- int [CurT](#)

*Temperature in tenths of degrees C.*

- unsigned int [Flags](#)

*Status flags.*

- unsigned int [GPIOFlags](#)

*Status flags.*

- unsigned int [CmdBufFreeSpace](#)

*This field shows the amount of free cells buffer synchronization chain.*

## 4.48.1 Field Documentation

4.48.1.1 unsigned int CmdBufFreeSpace

This field shows the amount of free cells buffer synchronization chain.

4.48.1.2 float CurPosition

Current position.

4.48.1.3 float CurSpeed

Motor shaft speed.

4.48.1.4 int CurT

Temperature in tenths of degrees C.

4.48.1.5 long\_t EncPosition

Current encoder position.

4.48.1.6 unsigned int EncSts

Encoder state.

4.48.1.7 unsigned int Flags

Status flags.

4.48.1.8 unsigned int GPIOFlags

Status flags.

4.48.1.9 int Ipwr

Engine current.

4.48.1.10 int Iusb

USB current consumption.

4.48.1.11 unsigned int MoveSts

Flags of move state.

4.48.1.12 unsigned int MvCmdSts

Move command state.

4.48.1.13 unsigned int PWRSts

Flags of power state of stepper motor.

4.48.1.14 int Upwr

Power supply voltage.

4.48.1.15 int Uusb

USB voltage.

4.48.1.16 unsigned int Windsts

Winding state.

## 4.49 status\_t Struct Reference

Device state.

### Data Fields

- unsigned int **Movests**  
*Flags of move state.*
- unsigned int **MvCmdsts**  
*Move command state.*
- unsigned int **PWRsts**  
*Flags of power state of stepper motor.*
- unsigned int **Encsts**  
*Encoder state.*
- unsigned int **Windsts**  
*Winding state.*
- int **CurPosition**  
*Current position.*
- int **uCurPosition**  
*Step motor shaft position in 1/256 microsteps.*
- long\_t **EncPosition**  
*Current encoder position.*
- int **CurSpeed**  
*Motor shaft speed.*
- int **uCurSpeed**  
*Part of motor shaft speed in 1/256 microsteps.*
- int **Ipwr**  
*Engine current.*
- int **Upwr**  
*Power supply voltage.*
- int **Iusb**  
*USB current consumption.*
- int **Uusb**

- *USB voltage.*
- int [CurT](#)  
*Temperature in tenths of degrees C.*
- unsigned int [Flags](#)  
*Status flags.*
- unsigned int [GPIOFlags](#)  
*Status flags.*
- unsigned int [CmdBufFreeSpace](#)  
*This field shows the amount of free cells buffer synchronization chain.*

#### 4.49.1 Detailed Description

Device state.

Useful structure that contains current controller state, including speed, position and boolean flags.

See Also

[get\\_status\\_impl](#)

#### 4.49.2 Field Documentation

##### 4.49.2.1 unsigned int CmdBufFreeSpace

This field shows the amount of free cells buffer synchronization chain.

##### 4.49.2.2 int CurPosition

Current position.

##### 4.49.2.3 int CurSpeed

Motor shaft speed.

##### 4.49.2.4 int CurT

Temperature in tenths of degrees C.

##### 4.49.2.5 long\_t EncPosition

Current encoder position.

##### 4.49.2.6 unsigned int EncSts

Encoder state.

##### 4.49.2.7 unsigned int Flags

Status flags.

4.49.2.8 unsigned int GPIOFlags

Status flags.

4.49.2.9 int Ipwr

Engine current.

4.49.2.10 int Iusb

USB current consumption.

4.49.2.11 unsigned int Movests

Flags of move state.

4.49.2.12 unsigned int MvCmdsts

Move command state.

4.49.2.13 unsigned int PWRsts

Flags of power state of stepper motor.

4.49.2.14 int uCurPosition

Step motor shaft position in 1/256 microsteps.

Used only with stepper motor.

4.49.2.15 int uCurSpeed

Part of motor shaft speed in 1/256 microsteps.

Used only with stepper motor.

4.49.2.16 int Upwr

Power supply voltage.

4.49.2.17 int Uusb

USB voltage.

4.49.2.18 unsigned int Windsts

Winding state.

## 4.50 sync\_in\_settings\_calb\_t Struct Reference

### Data Fields

- unsigned int **SynclnFlags**  
*Flags for synchronization input setup.*
- unsigned int **ClutterTime**  
*Input synchronization pulse dead time (mks).*
- float **Position**  
*Desired position or shift.*
- float **Speed**  
*Target speed.*

### 4.50.1 Field Documentation

#### 4.50.1.1 unsigned int ClutterTime

Input synchronization pulse dead time (mks).

#### 4.50.1.2 float Position

Desired position or shift.

#### 4.50.1.3 float Speed

Target speed.

#### 4.50.1.4 unsigned int SynclnFlags

Flags for synchronization input setup.

## 4.51 sync\_in\_settings\_t Struct Reference

Synchronization settings.

### Data Fields

- unsigned int **SynclnFlags**  
*Flags for synchronization input setup.*
- unsigned int **ClutterTime**  
*Input synchronization pulse dead time (mks).*
- int **Position**  
*Desired position or shift (whole steps)*
- int **uPosition**  
*The fractional part of a position or shift in microsteps.*
- unsigned int **Speed**  
*Target speed (for stepper motor: steps/s, for DC: rpm).*
- unsigned int **uSpeed**  
*Target speed in microsteps/s.*

### 4.51.1 Detailed Description

Synchronization settings.

This structure contains all synchronization settings, modes, periods and flags. It specifies behaviour of input synchronization. All boards are supplied with standard set of these settings.

See Also

[get\\_sync\\_in\\_settings](#)  
[set\\_sync\\_in\\_settings](#)  
[get\\_sync\\_in\\_settings](#), [set\\_sync\\_in\\_settings](#)

### 4.51.2 Field Documentation

#### 4.51.2.1 unsigned int ClutterTime

Input synchronization pulse dead time (mks).

#### 4.51.2.2 unsigned int Speed

Target speed (for stepper motor: steps/s, for DC: rpm).

Range: 0..100000.

#### 4.51.2.3 unsigned int SyncInFlags

[Flags for synchronization input setup.](#)

#### 4.51.2.4 int uPosition

The fractional part of a position or shift in microsteps.

Is used with stepper motor. Range: -255..255.

#### 4.51.2.5 unsigned int uSpeed

Target speed in microsteps/s.

Using with stepper motor only.

## 4.52 sync\_out\_settings\_calb\_t Struct Reference

### Data Fields

- unsigned int [SyncOutFlags](#)  
*Flags of synchronization output.*
- unsigned int [SyncOutPulseSteps](#)  
*This value specifies duration of output pulse.*
- unsigned int [SyncOutPeriod](#)  
*This value specifies number of encoder pulses or steps between two output synchronization pulses when SYNCOUT\_ONPERIOD is set.*
- float [Accuracy](#)  
*This is the neighborhood around the target coordinates, which is getting hit in the target position and the momentum generated by the stop.*

### 4.52.1 Field Documentation

#### 4.52.1.1 float Accuracy

This is the neighborhood around the target coordinates, which is getting hit in the target position and the momentum generated by the stop.

#### 4.52.1.2 unsigned int SyncOutFlags

[Flags of synchronization output.](#)

#### 4.52.1.3 unsigned int SyncOutPeriod

This value specifies number of encoder pulses or steps between two output synchronization pulses when SYNCOUT\_ONPERIOD is set.

#### 4.52.1.4 unsigned int SyncOutPulseSteps

This value specifies duration of output pulse.

It is measured microseconds when SYNCOUT\_IN\_STEPS flag is cleared or in encoder pulses or motor steps when SYNCOUT\_IN\_STEPS is set.

## 4.53 sync\_out\_settings\_t Struct Reference

Synchronization settings.

### Data Fields

- unsigned int [SyncOutFlags](#)  
*Flags of synchronization output.*
- unsigned int [SyncOutPulseSteps](#)  
*This value specifies duration of output pulse.*
- unsigned int [SyncOutPeriod](#)  
*This value specifies number of encoder pulses or steps between two output synchronization pulses when SYNCOUT\_ONPERIOD is set.*
- unsigned int [Accuracy](#)  
*This is the neighborhood around the target coordinates, which is getting hit in the target position and the momentum generated by the stop.*
- unsigned int [uAccuracy](#)  
*This is the neighborhood around the target coordinates in micro steps (only used with stepper motor).*

### 4.53.1 Detailed Description

Synchronization settings.

This structure contains all synchronization settings, modes, periods and flags. It specifies behaviour of output synchronization. All boards are supplied with standard set of these settings.

### See Also

- [get\\_sync\\_out\\_settings](#)
- [set\\_sync\\_out\\_settings](#)
- [get\\_sync\\_out\\_settings, set\\_sync\\_out\\_settings](#)

### 4.53.2 Field Documentation

#### 4.53.2.1 unsigned int Accuracy

This is the neighborhood around the target coordinates, which is getting hit in the target position and the momentum generated by the stop.

#### 4.53.2.2 unsigned int SyncOutFlags

[Flags of synchronization output.](#)

#### 4.53.2.3 unsigned int SyncOutPeriod

This value specifies number of encoder pulses or steps between two output synchronization pulses when SYNCOUT\_ONPERIOD is set.

#### 4.53.2.4 unsigned int SyncOutPulseSteps

This value specifies duration of output pulse.

It is measured microseconds when SYNCOUT\_IN\_STEPS flag is cleared or in encoder pulses or motor steps when SYNCOUT\_IN\_STEPS is set.

#### 4.53.2.5 unsigned int uAccuracy

This is the neighborhood around the target coordinates in micro steps (only used with stepper motor).

## 4.54 uart\_settings\_t Struct Reference

UART settings.

### Data Fields

- [unsigned int Speed](#)  
*UART speed.*
- [unsigned int UARTSetupFlags](#)  
*UART parity flags.*

### 4.54.1 Detailed Description

UART settings.

This structure contains UART settings.

### See Also

[get\\_uart\\_settings](#)  
[set\\_uart\\_settings](#)  
[get\\_uart\\_settings](#), [set\\_uart\\_settings](#)

## 4.54.2 Field Documentation

4.54.2.1 unsigned int UARTSetupFlags

[UART parity flags.](#)

# Chapter 5

## File Documentation

### 5.1 ximc.h File Reference

Header file for libximc library.

#### Data Structures

- struct `calibration.t`  
*Calibration companion structure.*
- struct `device_network_information.t`  
*Device network information structure.*
- struct `feedback_settings.t`  
*Feedback settings.*
- struct `home_settings.t`  
*Position calibration settings.*
- struct `home_settings.calb.t`
- struct `move_settings.t`  
*Move settings.*
- struct `move_settings.calb.t`
- struct `engine_settings.t`  
*Engine settings.*
- struct `engine_settings.calb.t`
- struct `entype_settings.t`  
*Engine type and driver type settings.*
- struct `power_settings.t`  
*Step motor power settings.*
- struct `secure_settings.t`  
*This structure contains raw analog data from ADC embedded on board.*
- struct `edges_settings.t`  
*Edges settings.*
- struct `edges_settings.calb.t`
- struct `pid_settings.t`  
*PID settings.*
- struct `sync_in_settings.t`  
*Synchronization settings.*
- struct `sync_in_settings.calb.t`
- struct `sync_out_settings.t`

- struct `sync_out_settings_calb_t`
- struct `extio_settings_t`
  - EXTIO settings.*
- struct `brake_settings_t`
  - Brake settings.*
- struct `control_settings_t`
  - Control settings.*
- struct `control_settings_calb_t`
- struct `joystick_settings_t`
  - Joystick settings.*
- struct `ctp_settings_t`
  - Control position settings(is only used with stepper motor).*
- struct `uart_settings_t`
  - UART settings.*
- struct `controller_name_t`
  - Controller user name and flags of setting.*
- struct `command_add_sync_in_action_t`
  - This command adds one element of the FIFO commands.*
- struct `command_add_sync_in_action_calb_t`
- struct `get_position_t`
  - Position information.*
- struct `get_position_calb_t`
- struct `set_position_t`
  - Position information.*
- struct `set_position_calb_t`
- struct `status_t`
  - Device state.*
- struct `status_calb_t`
- struct `chart_data_t`
  - Additional device state.*
- struct `device_information_t`
  - Read command controller information.*
- struct `serial_number_t`
  - Serial number structure and hardware version.*
- struct `analog_data_t`
  - Analog data.*
- struct `debug_read_t`
  - Debug data.*
- struct `debug_write_t`
  - Debug data.*
- struct `stage_name_t`
  - Stage user name.*
- struct `stage_information_t`
  - Stage information.*
- struct `stage_settings_t`
  - Stage settings.*
- struct `motor_information_t`
  - motor information.*
- struct `motor_settings_t`
  - motor settings.*

- struct `encoder_information_t`  
*Encoder information.*
- struct `encoder_settings_t`  
*Encoder settings.*
- struct `hallsensor_information_t`  
*Hall sensor information.*
- struct `hallsensor_settings_t`  
*Hall sensor settings.*
- struct `gear_information_t`  
*Gear information.*
- struct `gear_settings_t`  
*Gear settings.*
- struct `accessories_settings_t`  
*Additional accessories information.*
- struct `init_random_t`  
*Random key.*

## Macros

- `#define XIMC_API`  
*Library import macro Macros allows to automatically import function from shared library.*
- `#define XIMC_CALLCONV`  
*Library calling convention macros.*
- `#define XIMC_RETTYPE void*`  
*Thread return type.*
- `#define device_undefined -1`  
*Handle specified undefined device.*

## Result statuses

- `#define result_ok 0`  
*success*
- `#define result_error -1`  
*generic error*
- `#define result_not_implemented -2`  
*function is not implemented*
- `#define result_value_error -3`  
*value error*
- `#define result_nodvice -4`  
*device is lost*

## Logging level

- `#define LOGLEVEL_ERROR 0x01`  
*Logging level - error.*
- `#define LOGLEVEL_WARNING 0x02`  
*Logging level - warning.*
- `#define LOGLEVEL_INFO 0x03`  
*Logging level - info.*
- `#define LOGLEVEL_DEBUG 0x04`  
*Logging level - debug.*

## Enumerate devices flags

- #define [ENUMERATE\\_PROBE](#) 0x01  
*Check if a device with OS name name is XIMC device.*
- #define [ENUMERATE\\_ALL\\_COM](#) 0x02  
*Check all COM devices.*
- #define [ENUMERATE\\_NETWORK](#) 0x04  
*Check network devices.*

### Flags of move state

*Specify move states.*

See Also

[get\\_status](#)  
[status\\_t::move\\_state](#)  
[status\\_t::MoveSts](#), [get\\_status\\_impl](#)

- #define [MOVE\\_STATE\\_MOVING](#) 0x01  
*This flag indicates that controller is trying to move the motor.*
- #define [MOVE\\_STATE\\_TARGET\\_SPEED](#) 0x02  
*Target speed is reached, if flag set.*
- #define [MOVE\\_STATE\\_ANTIPLAY](#) 0x04  
*Motor is playing compensation, if flag set.*

### Flags of internal controller settings

See Also

[set\\_controller\\_name](#)  
[get\\_controller\\_name](#)  
[controller\\_name\\_t::CtrlFlags](#), [get\\_controller\\_name](#), [set\\_controller\\_name](#)

- #define [EEPROM\\_PRECEDENCE](#) 0x01  
*If the flag is set settings from external EEPROM override controller settings.*

### Flags of power state of stepper motor

*Specify power states.*

See Also

[status\\_t::power\\_state](#)  
[get\\_status](#)  
[status\\_t::PWRSts](#), [get\\_status\\_impl](#)

- #define [PWR\\_STATE\\_UNKNOWN](#) 0x00  
*Unknown state, should never happen.*
- #define [PWR\\_STATE\\_OFF](#) 0x01  
*Motor windings are disconnected from the driver.*
- #define [PWR\\_STATE\\_NORM](#) 0x03  
*Motor windings are powered by nominal current.*
- #define [PWR\\_STATE\\_REDUC](#) 0x04  
*Motor windings are powered by reduced current to lower power consumption.*
- #define [PWR\\_STATE\\_MAX](#) 0x05  
*Motor windings are powered by maximum current driver can provide at this voltage.*

### Status flags

*GPIO state flags returned by device query. Contains boolean part of controller state. May be combined with bitwise OR.*

## See Also

- `status_t::flags`
  - `get_status`
  - `status_t::GPIOFlags`, `get_status_impl`
- `#define STATE_CONTR 0x0003F`  
*Flags of controller states.*
  - `#define STATE_ERRC 0x000001`  
*Command error encountered.*
  - `#define STATE.ERRD 0x000002`  
*Data integrity error encountered.*
  - `#define STATE.ERRV 0x000004`  
*Value error encountered.*
  - `#define STATE_EEPROM_CONNECTED 0x00010`  
*EEPROM with settings is connected.*
  - `#define STATE_IS_HOMED 0x00020`  
*Calibration performed.*
  - `#define STATE_SECUR 0x3FFC0`  
*Flags of security.*
  - `#define STATE_ALARM 0x00040`  
*Controller is in alarm state indicating that something dangerous had happened.*
  - `#define STATE_CTP_ERROR 0x00080`  
*Control position error(is only used with stepper motor).*
  - `#define STATE_POWER_OVERHEAT 0x00100`  
*Power driver overheat.*
  - `#define STATE_CONTROLLER_OVERHEAT 0x00200`  
*Controller overheat.*
  - `#define STATE_OVERLOAD_POWER_VOLTAGE 0x00400`  
*Power voltage exceeds safe limit.*
  - `#define STATE_OVERLOAD_POWER_CURRENT 0x00800`  
*Power current exceeds safe limit.*
  - `#define STATE_OVERLOAD_USB_VOLTAGE 0x01000`  
*USB voltage exceeds safe limit.*
  - `#define STATE_LOW_USB_VOLTAGE 0x02000`  
*USB voltage is insufficient for normal operation.*
  - `#define STATE_OVERLOAD_USB_CURRENT 0x04000`  
*USB current exceeds safe limit.*
  - `#define STATE_BORDERS_SWAP_MISSET 0x08000`  
*Engine stuck at the wrong edge.*
  - `#define STATE_LOW_POWER_VOLTAGE 0x10000`  
*Power voltage is lower than Low Voltage Protection limit.*
  - `#define STATE_H_BRIDGE_FAULT 0x20000`  
*Signal from the driver that fault happened.*
  - `#define STATE_DIG_SIGNAL 0xFFFF`  
*Flags of digital signals.*
  - `#define STATE_RIGHT_EDGE 0x0001`  
*Engine stuck at the right edge.*
  - `#define STATE_LEFT_EDGE 0x0002`  
*Engine stuck at the left edge.*
  - `#define STATE_BUTTON_RIGHT 0x0004`  
*Button "right" state (1 if pressed).*
  - `#define STATE_BUTTON_LEFT 0x0008`  
*Button "left" state (1 if pressed).*
  - `#define STATE_GPIO_PINOUT 0x0010`  
*External GPIO works as Out, if flag set; otherwise works as In.*
  - `#define STATE_GPIO_LEVEL 0x0020`  
*State of external GPIO pin.*
  - `#define STATE_HALL_A 0x0040`

- #define STATE\_HALL\_B 0x0080  
*State of Hall.a pin.*
- #define STATE\_HALL\_C 0x0100  
*State of Hall.b pin.*
- #define STATE\_BRAKE 0x0200  
*State of Hall.c pin.*
- #define STATE\_REV\_SENSOR 0x0400  
*State of Revolution sensor pin.*
- #define STATE\_SYNC\_INPUT 0x0800  
*State of Sync input pin.*
- #define STATE\_SYNC\_OUTPUT 0x1000  
*State of Sync output pin.*
- #define STATE\_ENC\_A 0x2000  
*State of encoder A pin.*
- #define STATE\_ENC\_B 0x4000  
*State of encoder B pin.*

### Encoder state

*Encoder state returned by device query.*

See Also

*status\_t::encsts*  
*get\_status*  
*status\_t::EncSts, get\_status\_impl*

- #define ENC\_STATE\_ABSENT 0x00  
*Encoder is absent.*
- #define ENC\_STATE\_UNKNOWN 0x01  
*Encoder state is unknown.*
- #define ENC\_STATE\_MALFUNC 0x02  
*Encoder is connected and malfunctioning.*
- #define ENC\_STATE\_REVERS 0x03  
*Encoder is connected and operational but counts in other direction.*
- #define ENC\_STATE\_OK 0x04  
*Encoder is connected and working properly.*

### Winding state

*Motor winding state returned by device query.*

See Also

*status\_t::windsts*  
*get\_status*  
*status\_t::WindSts, get\_status\_impl*

- #define WIND\_A\_STATE\_ABSENT 0x00  
*Winding A is disconnected.*
- #define WIND\_A\_STATE\_UNKNOWN 0x01  
*Winding A state is unknown.*
- #define WIND\_A\_STATE\_MALFUNC 0x02  
*Winding A is short-circuited.*
- #define WIND\_A\_STATE\_OK 0x03  
*Winding A is connected and working properly.*
- #define WIND\_B\_STATE\_ABSENT 0x00  
*Winding B is disconnected.*
- #define WIND\_B\_STATE\_UNKNOWN 0x10  
*Winding B state is unknown.*
- #define WIND\_B\_STATE\_MALFUNC 0x20

- `#define WIND_B_STATE_OK 0x30`  
*Winding B is connected and working properly.*

### Move command state

*Move command (command\_move, command\_movr, command\_left, command\_right, command\_stop, command\_home, command\_loft, command\_sstp) and its state (run, finished, error).*

See Also

- `status_t::mvcmdsts`
- `get_status`
- `status_t::MvCmdSts, get_status_impl`
- `#define MVCMD_NAME_BITS 0x3F`  
*Move command bit mask.*
- `#define MVCMD_UKNWN 0x00`  
*Unknown command.*
- `#define MVCMD_MOVE 0x01`  
*Command move.*
- `#define MVCMD_MOVR 0x02`  
*Command movr.*
- `#define MVCMD_LEFT 0x03`  
*Command left.*
- `#define MVCMD_RIGHT 0x04`  
*Command right.*
- `#define MVCMD_STOP 0x05`  
*Command stop.*
- `#define MVCMD_HOME 0x06`  
*Command home.*
- `#define MVCMD_LOFT 0x07`  
*Command loft.*
- `#define MVCMD_SSTP 0x08`  
*Command soft stop.*
- `#define MVCMD_ERROR 0x40`  
*Finish state (1 - move command have finished with an error, 0 - move command have finished correctly).*
- `#define MVCMD_RUNNING 0x80`  
*Move command state (0 - move command have finished, 1 - move command is being executed).*

### Flags of engine settings

*Specify motor shaft movement algorithm and list of limitations. Flags returned by query of engine settings. May be combined with bitwise OR.*

See Also

- `engine_settings_t::flags`
- `set_engine_settings`
- `get_engine_settings`
- `engine_settings_t::EngineFlags, get_engine_settings, set_engine_settings`
- `#define ENGINE_REVERSE 0x01`  
*Reverse flag.*
- `#define ENGINE_MAX_SPEED 0x04`  
*Max speed flag.*
- `#define ENGINE_ANTIPLAY 0x08`  
*Play compensation flag.*
- `#define ENGINE_ACCEL_ON 0x10`  
*Acceleration enable flag.*
- `#define ENGINE_LIMIT_VOLT 0x20`  
*Maximum motor voltage limit enable flag(is only used with DC motor).*

- #define `ENGINE_LIMIT_CURR` 0x40  
*Maximum motor current limit enable flag(is only used with DC motor).*
- #define `ENGINE_LIMIT_RPM` 0x80  
*Maximum motor speed limit enable flag.*

### Flags of microstep mode

*Specify settings of microstep mode. Using with step motors. Flags returned by query of engine settings. May be combined with bitwise OR*

See Also

- `engine_settings_t::flags`
- `set_engine_settings`
- `get_engine_settings`
- `engine_settings_t::MicrostepMode, get_engine_settings, set_engine_settings`
- #define `MICROSTEP_MODE_FULL` 0x01  
*Full step mode.*
- #define `MICROSTEP_MODE_FRAC_2` 0x02  
*1/2 step mode.*
- #define `MICROSTEP_MODE_FRAC_4` 0x03  
*1/4 step mode.*
- #define `MICROSTEP_MODE_FRAC_8` 0x04  
*1/8 step mode.*
- #define `MICROSTEP_MODE_FRAC_16` 0x05  
*1/16 step mode.*
- #define `MICROSTEP_MODE_FRAC_32` 0x06  
*1/32 step mode.*
- #define `MICROSTEP_MODE_FRAC_64` 0x07  
*1/64 step mode.*
- #define `MICROSTEP_MODE_FRAC_128` 0x08  
*1/128 step mode.*
- #define `MICROSTEP_MODE_FRAC_256` 0x09  
*1/256 step mode.*

### Flags of engine type

*Specify motor type. Flags returned by query of engine settings.*

See Also

- `engine_settings_t::flags`
- `set_entype_settings`
- `get_entype_settings`
- `entype_settings_t::EngineType, get_entype_settings, set_entype_settings`
- #define `ENGINE_TYPE_NONE` 0x00  
*A value that shouldn't be used.*
- #define `ENGINE_TYPE_DC` 0x01  
*DC motor.*
- #define `ENGINE_TYPE_2DC` 0x02  
*2 DC motors.*
- #define `ENGINE_TYPE_STEP` 0x03  
*Step motor.*
- #define `ENGINE_TYPE_TEST` 0x04  
*Duty cycle are fixed.*
- #define `ENGINE_TYPE_BRUSHLESS` 0x05  
*Brushless motor.*

### Flags of driver type

*Specify driver type. Flags returned by query of engine settings.*

See Also

`engine_settings_t::flags`  
`set_entype_settings`  
`get_entype_settings`  
`entype_settings_t::DriverType, get_entype_settings, set_entype_settings`

- `#define DRIVER_TYPE_DISCRETE_FET 0x01`  
*Driver with discrete FET keys.*
- `#define DRIVER_TYPE_INTEGRATE 0x02`  
*Driver with integrated IC.*
- `#define DRIVER_TYPE_EXTERNAL 0x03`  
*External driver.*

### Flags of power settings of stepper motor

*Specify power settings. Flags returned by query of power settings.*

See Also

`power_settings_t::flags`  
`get_power_settings`  
`set_power_settings`  
`power_settings_t::PowerFlags, get_power_settings, set_power_settings`

- `#define POWER_REDUCED_ENABLED 0x01`  
*Current reduction enabled after CurrReducedDelay, if this flag is set.*
- `#define POWER_OFF_ENABLED 0x02`  
*Power off enabled after PowerOffDelay, if this flag is set.*
- `#define POWER_SMOOTH_CURRENT 0x04`  
*Current ramp-up/down is performed smoothly during current\_set\_time, if this flag is set.*

### Flags of secure settings

*Specify secure settings. Flags returned by query of secure settings.*

See Also

`secure_settings_t::flags`  
`get_secure_settings`  
`set_secure_settings`  
`secure_settings_t::Flags, get_secure_settings, set_secure_settings`

- `#define ALARM_ON_DRIVER_OVERHEATING 0x01`  
*If this flag is set enter Alarm state on driver overheat signal.*
- `#define LOW_UPWR_PROTECTION 0x02`  
*If this flag is set turn off motor when voltage is lower than LowUpwrOff.*
- `#define H_BRIDGE_ALERT 0x04`  
*If this flag is set then turn off the power unit with a signal problem in one of the transistor bridge.*
- `#define ALARM_ON_BORDERS_SWAP_MISSET 0x08`  
*If this flag is set enter Alarm state on borders swap misset.*
- `#define ALARM_FLAGS_STICKING 0x10`  
*If this flag is set only a STOP command can turn all alarms to 0.*
- `#define USB_BREAK_RECONNECT 0x20`  
*If this flag is set USB brake reconnect module will be enable.*

### Position setting flags

*Flags used in setting of position.*

See Also

`get_position`  
`set_position`  
`set_position_t::PosFlags, set_position`

- `#define SETPOS_IGNORE_POSITION 0x01`  
*Will not reload position in steps/microsteps if this flag is set.*
- `#define SETPOS_IGNORE_ENCODER 0x02`  
*Will not reload encoder state if this flag is set.*

### Feedback type.

See Also

`set_feedback_settings`  
`get_feedback_settings`  
`feedback_settings_t::FeedbackType, get_feedback_settings, set_feedback_settings`

- `#define FEEDBACK_ENCODER 0x01`  
*Feedback by encoder.*
- `#define FEEDBACK_ENCODERHALL 0x03`  
*Feedback by Hall detector.*
- `#define FEEDBACK_EMF 0x04`  
*Feedback by EMF.*
- `#define FEEDBACK_NONE 0x05`  
*Feedback is absent.*

### Describes feedback flags.

See Also

`set_feedback_settings`  
`get_feedback_settings`  
`feedback_settings_t::FeedbackFlags, get_feedback_settings, set_feedback_settings`

- `#define FEEDBACK_ENC_REVERSE 0x01`  
*Reverse count of encoder.*
- `#define FEEDBACK_HALL_REVERSE 0x02`  
*Reverce count position on the Hall sensor.*

### Flags for synchronization input setup

See Also

`sync_settings_t::syncin_flags`  
`get_sync_settings`  
`set_sync_settings`  
`sync_in_settings_t::SyncInFlags, get_sync_in_settings, set_sync_in_settings`

- `#define SYNCIN_ENABLED 0x01`  
*Synchronization in mode is enabled, if this flag is set.*
- `#define SYNCIN_INVERT 0x02`  
*Trigger on falling edge if flag is set, on rising edge otherwise.*
- `#define SYNCIN_GOTOPOSITION 0x04`  
*The engine is go to position specified in Position and uPosition, if this flag is set.*

### Flags of synchronization output

See Also

- `sync_settings_t::syncout_flags`
- `get_sync_settings`
- `set_sync_settings`
- `sync_out_settings.t::SyncOutFlags, get_sync_out_settings, set_sync_out_settings`
- `#define SYNCOUT_ENABLED 0x01`

*Synchronization out pin follows the synchronization logic, if set.*
- `#define SYNCOUT_STATE 0x02`

*When output state is fixed by negative SYNCOUT\_ENABLED flag, the pin state is in accordance with this flag state.*
- `#define SYNCOUT_INVERT 0x04`

*Low level is active, if set, and high level is active otherwise.*
- `#define SYNCOUT_IN_STEPS 0x08`

*Use motor steps/encoder pulses instead of milliseconds for output pulse generation if the flag is set.*
- `#define SYNCOUT_ONSTART 0x10`

*Generate synchronization pulse when movement starts.*
- `#define SYNCOUT_ONSTOP 0x20`

*Generate synchronization pulse when movement stops.*
- `#define SYNCOUT_ONPERIOD 0x40`

*Generate synchronization pulse every SyncOutPeriod encoder pulses.*

### External IO setup flags

See Also

- `extio_settings.t::setup_flags`
- `get_extio_settings`
- `set_extio_settings`
- `extio_settings.t::EXTIOTSetupFlags, get_extio_settings, set_extio_settings`
- `#define EXTIO_SETUP_OUTPUT 0x01`

*EXTIO works as output if flag is set, works as input otherwise.*
- `#define EXTIO_SETUP_INVERT 0x02`

*Interpret EXTIO states and fronts inverted if flag is set.*

### External IO mode flags

See Also

- `extio_settings.t::extio_mode_flags`
- `get_extio_settings`
- `set_extio_settings`
- `extio_settings.t::EXTIOModeFlags, get_extio_settings, set_extio_settings`
- `#define EXTIO_SETUP_MODE_IN_BITS 0x0F`

*Bits of the behaviour selector when the signal on input goes to the active state.*
- `#define EXTIO_SETUP_MODE_IN_NOP 0x00`

*Do nothing.*
- `#define EXTIO_SETUP_MODE_IN_STOP 0x01`

*Issue STOP command, ceasing the engine movement.*
- `#define EXTIO_SETUP_MODE_IN_PWOF 0x02`

*Issue PWOF command, powering off all engine windings.*
- `#define EXTIO_SETUP_MODE_IN_MOVR 0x03`

*Issue MOVR command with last used settings.*
- `#define EXTIO_SETUP_MODE_IN_HOME 0x04`

*Issue HOME command.*
- `#define EXTIO_SETUP_MODE_IN_ALARM 0x05`

*Set Alarm when the signal goes to the active state.*
- `#define EXTIO_SETUP_MODE_OUT_BITS 0xF0`

- Bits of the output behaviour selection.
- #define [EXTIO\\_SETUP\\_MODE\\_OUT\\_OFF](#) 0x00  
EXTIO pin always set in inactive state.
- #define [EXTIO\\_SETUP\\_MODE\\_OUT\\_ON](#) 0x10  
EXTIO pin always set in active state.
- #define [EXTIO\\_SETUP\\_MODE\\_OUT\\_MOVING](#) 0x20  
EXTIO pin stays active during moving state.
- #define [EXTIO\\_SETUP\\_MODE\\_OUT\\_ALARM](#) 0x30  
EXTIO pin stays active during Alarm state.
- #define [EXTIO\\_SETUP\\_MODE\\_OUT\\_MOTOR\\_ON](#) 0x40  
EXTIO pin stays active when windings are powered.
- #define [EXTIO\\_SETUP\\_MODE\\_OUT\\_MOTOR\\_FOUND](#) 0x50  
EXTIO pin stays active when motor is connected (first winding).

### Border flags

Specify types of borders and motor behaviour on borders. May be combined with bitwise OR.

See Also

[get\\_edges\\_settings](#)  
[set\\_edges\\_settings](#)  
[edges\\_settings.t::BorderFlags](#), [get\\_edges\\_settings](#), [set\\_edges\\_settings](#)

- #define [BORDER\\_IS\\_ENCODER](#) 0x01  
Borders are fixed by predetermined encoder values, if set; borders position on limit switches, if not set.
- #define [BORDER\\_STOP\\_LEFT](#) 0x02  
Motor should stop on left border.
- #define [BORDER\\_STOP\\_RIGHT](#) 0x04  
Motor should stop on right border.
- #define [BORDERS\\_SWAP\\_MISSET\\_DETECTION](#) 0x08  
Motor should stop on both borders.

### Limit switches flags

Specify electrical behaviour of limit switches like order and pulled positions. May be combined with bitwise OR.

See Also

[get\\_edges\\_settings](#)  
[set\\_edges\\_settings](#)  
[edges\\_settings.t::EnderFlags](#), [get\\_edges\\_settings](#), [set\\_edges\\_settings](#)

- #define [ENDER\\_SWAP](#) 0x01  
First limit switch on the right side, if set; otherwise on the left side.
- #define [ENDER\\_SW1\\_ACTIVE\\_LOW](#) 0x02  
1 - Limit switch connected to pin SW1 is triggered by a low level on pin.
- #define [ENDER\\_SW2\\_ACTIVE\\_LOW](#) 0x04  
1 - Limit switch connected to pin SW2 is triggered by a low level on pin.

### Brake settings flags

Specify behaviour of brake. May be combined with bitwise OR.

See Also

[get\\_brake\\_settings](#)  
[set\\_brake\\_settings](#)  
[brake\\_settings.t::BrakeFlags](#), [get\\_brake\\_settings](#), [set\\_brake\\_settings](#)

- #define [BRAKE\\_ENABLED](#) 0x01  
Brake control is enabled, if this flag is set.
- #define [BRAKE\\_ENG\\_PWROFF](#) 0x02

*Brake turns off power of step motor, if this flag is set.*

### Control flags

*Specify motor control settings by joystick or buttons. May be combined with bitwise OR.*

See Also

[get\\_control\\_settings](#)  
[set\\_control\\_settings](#)  
[control\\_settings\\_t::Flags](#), [get\\_control\\_settings](#), [set\\_control\\_settings](#)

- #define **CONTROL\_MODE\_BITS** 0x03  
*Bits to control engine by joystick or buttons.*
- #define **CONTROL\_MODE\_OFF** 0x00  
*Control is disabled.*
- #define **CONTROL\_MODE\_JOY** 0x01  
*Control by joystick.*
- #define **CONTROL\_MODE\_LR** 0x02  
*Control by left/right buttons.*
- #define **CONTROL\_BTN\_LEFT\_PUSHED\_OPEN** 0x04  
*Pushed left button corresponds to open contact, if this flag is set.*
- #define **CONTROL\_BTN\_RIGHT\_PUSHED\_OPEN** 0x08  
*Pushed right button corresponds to open contact, if this flag is set.*

### Joystick flags

*Control joystick states.*

See Also

[set\\_joystick\\_settings](#)  
[get\\_joystick\\_settings](#)  
[joystick\\_settings\\_t::JoyFlags](#), [get\\_joystick\\_settings](#), [set\\_joystick\\_settings](#)

- #define **JOY\_REVERSE** 0x01  
*Joystick action is reversed.*

### Position control flags

*Specify settings of position control. May be combined with bitwise OR.*

See Also

[get\\_ctp\\_settings](#)  
[set\\_ctp\\_settings](#)  
[ctp\\_settings\\_t::CTPFlags](#), [get\\_ctp\\_settings](#), [set\\_ctp\\_settings](#)

- #define **CTP\_ENABLED** 0x01  
*Position control is enabled, if flag set.*
- #define **CTP\_BASE** 0x02  
*Position control is based on revolution sensor, if this flag is set; otherwise it is based on encoder.*
- #define **CTP\_ALARM\_ON\_ERROR** 0x04  
*Set ALARM on mismatch, if flag set.*
- #define **REV\_SENS\_INV** 0x08  
*Sensor is active when it 0 and invert makes active level 1.*
- #define **CTP\_ERROR\_CORRECTION** 0x10  
*Correct errors which appear when slippage if the flag is set.*

### Home settings flags

*Specify behaviour for home command. May be combined with bitwise OR.*

See Also

- `get_home_setting s`
- `set_home_settings`
- `command_home`
- `home_settings_t::HomeFlags, get_home_settings, set_home_settings`
- `#define HOME_DIR_FIRST 0x01`

*Flag defines direction of 1st motion after execution of home command.*
- `#define HOME_DIR_SECOND 0x02`

*Flag defines direction of 2nd motion.*
- `#define HOME_MV_SEC_EN 0x04`

*Use the second phase of calibration to the home position, if set; otherwise the second phase is skipped.*
- `#define HOME_HALF_MV 0x08`

*If the flag is set, the stop signals are ignored in start of second movement the first half-turn.*
- `#define HOME_STOP_FIRST_BITS 0x30`

*Bits of the first stop selector.*
- `#define HOME_STOP_FIRST_REV 0x10`

*First motion stops by revolution sensor.*
- `#define HOME_STOP_FIRST_SYN 0x20`

*First motion stops by synchronization input.*
- `#define HOME_STOP_FIRST_LIM 0x30`

*First motion stops by limit switch.*
- `#define HOME_STOP_SECOND_BITS 0xC0`

*Bits of the second stop selector.*
- `#define HOME_STOP_SECOND_REV 0x40`

*Second motion stops by revolution sensor.*
- `#define HOME_STOP_SECOND_SYN 0x80`

*Second motion stops by synchronization input.*
- `#define HOME_STOP_SECOND_LIM 0xC0`

*Second motion stops by limit switch.*

## UART parity flags

See Also

- `uart_settings_t::UARTSetupFlags, get_uart_settings, set_uart_settings`
- `#define UART_PARITY_BITS 0x03`

*Bits of the parity.*
- `#define UART_PARITY_BIT_EVEN 0x00`

*Parity bit 1, if even.*
- `#define UART_PARITY_BIT_ODD 0x01`

*Parity bit 1, if odd.*
- `#define UART_PARITY_BIT_SPACE 0x02`

*Parity bit always 0.*
- `#define UART_PARITY_BIT_MARK 0x03`

*Parity bit always 1.*
- `#define UART_PARITY_BIT_USE 0x04`

*None parity.*
- `#define UART_STOP_BIT 0x08`

*If set - one stop bit, else two stop bit.*

## Motor Type flags

See Also

`motor_settings_t::MotorType, get_motor_settings, set_motor_settings`

- `#define MOTOR_TYPE_UNKNOWN 0x00`  
*Unknown type of engine.*
- `#define MOTOR_TYPE_STEP 0x01`  
*Step engine.*
- `#define MOTOR_TYPE_DC 0x02`  
*DC engine.*
- `#define MOTOR_TYPE_BLDC 0x03`  
*BLDC engine.*

### Encoder settings flags

See Also

`encoder_settings_t::EncoderSettings, get_encoder_settings, set_encoder_settings`

- `#define ENCSET_DIFFERENTIAL_OUTPUT 0x001`  
*If flag is set the encoder has differential output, else single ended output.*
- `#define ENCSET_PUSHPULL_OUTPUT 0x004`  
*If flag is set the encoder has push-pull output, else open drain output.*
- `#define ENCSET_INDEXCHANNEL_PRESENT 0x010`  
*If flag is set the encoder has index channel, else encoder hasn't it.*
- `#define ENCSET_REVOLUTIONSENSOR_PRESENT 0x040`  
*If flag is set the encoder has revolution sensor, else encoder hasn't it.*
- `#define ENCSET_REVOLUTIONSENSOR_ACTIVE_HIGH 0x100`  
*If flag is set the revolution sensor active state is high logic state, else active state is low logic state.*

### Magnetic brake settings flags

See Also

`accessories_settings_t::MBSettings, get_accessories_settings, set_accessories_settings`

- `#define MB_AVAILABLE 0x01`  
*If flag is set the magnetic brake is available.*
- `#define MB_POWERED_HOLD 0x02`  
*If this flag is set the magnetic brake is on when powered.*

### Temperature sensor settings flags

See Also

`accessories_settings_t::LimitSwitchesSettings, get_accessories_settings, set_accessories_settings`

- `#define TS_TYPE_BITS 0x07`  
*Bits of the temperature sensor type.*
- `#define TS_TYPE_UNKNOWN 0x00`  
*Unknow type of sensor.*
- `#define TS_TYPE_THERMOCOUPLE 0x01`  
*Thermocouple.*
- `#define TS_TYPE_SEMICONDUCTOR 0x02`  
*The semiconductor temperature sensor.*
- `#define TS_AVAILABLE 0x08`  
*If flag is set the temperature sensor is available.*
- `#define LS_ON_SW1_AVAILABLE 0x01`  
*If flag is set the limit switch connnected to pin SW1 is available.*
- `#define LS_ON_SW2_AVAILABLE 0x02`  
*If flag is set the limit switch connnected to pin SW2 is available.*
- `#define LS_SW1_ACTIVE_LOW 0x04`  
*If flag is set the limit switch connnected to pin SW1 is triggered by a low level on pin.*
- `#define LS_SW2_ACTIVE_LOW 0x08`  
*If flag is set the limit switch connnected to pin SW2 is triggered by a low level on pin.*
- `#define LS_SHORTED 0x10`  
*If flag is set the Limit switches is shorted.*

## Typedefs

- `typedef unsigned long long ulong_t`
- `typedef long long long_t`
- `typedef int device_t`  
`Type describes device identifier.`
- `typedef int result_t`  
`Type specifies result of any operation.`
- `typedef uint32_t device_enumeration_t`  
`Type describes device enumeration structure.`
- `typedef struct calibration_t calibration_t`  
`Calibration companion structure.`
- `typedef struct device_network_information_t device_network_information_t`  
`Device network information structure.`

## Functions

### Controller settings setup

Functions for adjusting engine read/write almost all controller settings.

- `result_t XIMC_API set_feedback_settings (device_t id, const feedback_settings_t *feedback_settings)`  
`Set feedback settings.`
- `result_t XIMC_API get_feedback_settings (device_t id, feedback_settings_t *feedback_settings)`  
`Read feedback settings.`
- `result_t XIMC_API set_home_settings (device_t id, const home_settings_t *home_settings)`  
`Set home settings.`
- `result_t XIMC_API set_home_settings_calb (device_t id, const home_settings_calb_t *home_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API get_home_settings (device_t id, home_settings_t *home_settings)`  
`Read home settings.`
- `result_t XIMC_API get_home_settings_calb (device_t id, home_settings_calb_t *home_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API set_move_settings (device_t id, const move_settings_t *move_settings)`  
`Set command setup movement (speed, acceleration, threshold and etc).`
- `result_t XIMC_API set_move_settings_calb (device_t id, move_settings_calb_t *move_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API get_move_settings (device_t id, move_settings_t *move_settings)`  
`Read command setup movement (speed, acceleration, threshold and etc).`
- `result_t XIMC_API get_move_settings_calb (device_t id, move_settings_calb_t *move_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API set_engine_settings (device_t id, const engine_settings_t *engine_settings)`  
`Set engine settings.`
- `result_t XIMC_API set_engine_settings_calb (device_t id, const engine_settings_calb_t *engine_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API get_engine_settings (device_t id, engine_settings_t *engine_settings)`  
`Read engine settings.`
- `result_t XIMC_API get_engine_settings_calb (device_t id, engine_settings_calb_t *engine_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API set_entype_settings (device_t id, const entype_settings_t *entype_settings)`  
`Set engine type and driver type.`
- `result_t XIMC_API get_entype_settings (device_t id, entype_settings_t *entype_settings)`  
`Return engine type and driver type.`
- `result_t XIMC_API set_power_settings (device_t id, const power_settings_t *power_settings)`  
`Set settings of step motor power control.`
- `result_t XIMC_API get_power_settings (device_t id, power_settings_t *power_settings)`  
`Read settings of step motor power control.`

- `result_t XIMC_API set_secure_settings (device_t id, const secure_settings_t *secure_settings)`  
*Set protection settings.*
- `result_t XIMC_API get_secure_settings (device_t id, secure_settings_t *secure_settings)`  
*Read protection settings.*
- `result_t XIMC_API set_edges_settings (device_t id, const edges_settings_t *edges_settings)`  
*Set border and limit switches settings.*
- `result_t XIMC_API set_edges_settings_calb (device_t id, const edges_settings_calb_t *edges_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API get.edges_settings (device_t id, edges_settings_t *edges_settings)`  
*Read border and limit switches settings.*
- `result_t XIMC_API get.edges_settings_calb (device_t id, edges_settings_calb_t *edges_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API set.pid.settings (device_t id, const pid_settings_t *pid_settings)`  
*Set PID settings.*
- `result_t XIMC_API get.pid.settings (device_t id, pid_settings_t *pid_settings)`  
*Read PID settings.*
- `result_t XIMC_API set.sync.in.settings (device_t id, const sync_in_settings_t *sync_in_settings)`  
*Set input synchronization settings.*
- `result_t XIMC_API set.sync.in.settings.calb (device_t id, const sync_in_settings_calb_t *sync_in_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API get.sync.in.settings (device_t id, sync_in_settings_t *sync_in_settings)`  
*Read input synchronization settings.*
- `result_t XIMC_API get.sync.in.settings.calb (device_t id, sync_in_settings_calb_t *sync_in_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API set.sync.out.settings (device_t id, const sync_out_settings_t *sync_out_settings)`  
*Set output synchronization settings.*
- `result_t XIMC_API set.sync.out.settings.calb (device_t id, const sync_out_settings_calb_t *sync_out_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API get.sync.out.settings (device_t id, sync_out_settings_t *sync_out_settings)`  
*Read output synchronization settings.*
- `result_t XIMC_API get.sync.out.settings.calb (device_t id, sync_out_settings_calb_t *sync_out_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API set.extio.settings (device_t id, const extio_settings_t *extio_settings)`  
*Set EXTIO settings.*
- `result_t XIMC_API get.extio.settings (device_t id, extio_settings_t *extio_settings)`  
*Read EXTIO settings.*
- `result_t XIMC_API set.brake.settings (device_t id, const brake_settings_t *brake_settings)`  
*Set settings of brake control.*
- `result_t XIMC_API get.brake.settings (device_t id, brake_settings_t *brake_settings)`  
*Read settings of brake control.*
- `result_t XIMC_API set.control.settings (device_t id, const control_settings_t *control_settings)`  
*Set settings of motor control.*
- `result_t XIMC_API set.control.settings.calb (device_t id, const control_settings_calb_t *control_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API get.control.settings (device_t id, control_settings_t *control_settings)`  
*Read settings of motor control.*
- `result_t XIMC_API get.control.settings.calb (device_t id, control_settings_calb_t *control_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API set.joystick.settings (device_t id, const joystick_settings_t *joystick_settings)`  
*Set settings of joystick.*
- `result_t XIMC_API get.joystick.settings (device_t id, joystick_settings_t *joystick_settings)`  
*Read settings of joystick.*
- `result_t XIMC_API set.ctp.settings (device_t id, const ctp_settings_t *ctp_settings)`  
*Set settings of control position(is only used with stepper motor).*
- `result_t XIMC_API get.ctp.settings (device_t id, ctp_settings_t *ctp_settings)`  
*Read settings of control position(is only used with stepper motor).*
- `result_t XIMC_API set uart.settings (device_t id, const uart_settings_t *uart_settings)`  
*Set UART settings.*
- `result_t XIMC_API get uart.settings (device_t id, uart_settings_t *uart_settings)`  
*Read UART settings.*

- **result\_t XIMC\_API set\_controller\_name (device\_t id, const controller\_name\_t \*controller\_name)**  
*Write user controller name and flags of setting from FRAM.*
- **result\_t XIMC\_API get\_controller\_name (device\_t id, controller\_name\_t \*controller\_name)**  
*Read user controller name and flags of setting from FRAM.*

### Group of commands movement control

- **result\_t XIMC\_API command\_stop (device\_t id)**  
*Immediately stop the engine, the transition to the STOP mode key BREAK (winding short-circuited), the regime "retention" is deactivated for DC motors, keeping current in the windings for stepper motors (with Power management settings).*
- **result\_t XIMC\_API command\_add\_sync\_in\_action (device\_t id, const command\_add\_sync\_in\_action\_t \*the\_command\_add\_sync\_in\_action)**  
*This command adds one element of the FIFO commands that are executed when input clock pulse.*
- **result\_t XIMC\_API command\_add\_sync\_in\_action\_calb (device\_t id, const command\_add\_sync\_in\_action\_calb\_t \*the\_command\_add\_sync\_in\_action\_calb, const calibration\_t \*calibration)**
- **result\_t XIMC\_API command\_power\_off (device\_t id)**  
*Immediately power off motor regardless its state.*
- **result\_t XIMC\_API command\_move (device\_t id, int Position, int uPosition)**  
*Upon receiving the command "move" the engine starts to move with pre-set parameters (speed, acceleration, retention), to the point specified to the Position, uPosition.*
- **result\_t XIMC\_API command\_move\_calb (device\_t id, float Position, const calibration\_t \*calibration)**
- **result\_t XIMC\_API command\_movr (device\_t id, int DeltaPosition, int uDeltaPosition)**  
*Upon receiving the command "movr" engine starts to move with pre-set parameters (speed, acceleration, hold), left or right (depending on the sign of DeltaPosition) by the number of pulses specified in the fields DeltaPosition, uDeltaPosition.*
- **result\_t XIMC\_API command\_movr\_calb (device\_t id, float DeltaPosition, const calibration\_t \*calibration)**
- **result\_t XIMC\_API command\_home (device\_t id)**  
*The positive direction is to the right.*
- **result\_t XIMC\_API command\_left (device\_t id)**  
*Start continuous moving to the left.*
- **result\_t XIMC\_API command\_right (device\_t id)**  
*Start continuous moving to the right.*
- **result\_t XIMC\_API command\_loft (device\_t id)**  
*Upon receiving the command "loft" the engine is shifted from the current point to a distance GENG :: Antiplay, then move to the same point.*
- **result\_t XIMC\_API command\_sstp (device\_t id)**  
*soft stop engine.*
- **result\_t XIMC\_API get\_position (device\_t id, get\_position\_t \*the\_get\_position)**  
*Reads the value position in steps and micro for stepper motor and encoder steps all engines.*
- **result\_t XIMC\_API get\_position\_calb (device\_t id, get\_position\_calb\_t \*the\_get\_position\_calb, const calibration\_t \*calibration)**
- **result\_t XIMC\_API set\_position (device\_t id, const set\_position\_t \*the\_set\_position)**  
*Sets any position value in steps and micro for stepper motor and encoder steps of all engines.*
- **result\_t XIMC\_API set\_position\_calb (device\_t id, const set\_position\_calb\_t \*the\_set\_position\_calb, const calibration\_t \*calibration)**
- **result\_t XIMC\_API command\_zero (device\_t id)**  
*Sets the current position and the position in which the traffic moves by the move command and movr zero for all cases, except for movement to the target position.*

### Group of commands to save and load settings

- **result\_t XIMC\_API command\_save\_settings (device\_t id)**  
*Save all settings from controller's RAM to controller's flash memory, replacing previous data in controller's flash memory.*
- **result\_t XIMC\_API command\_read\_settings (device\_t id)**  
*Read all settings from controller's flash memory to controller's RAM, replacing previous data in controller's RAM.*
- **result\_t XIMC\_API command\_eesave\_settings (device\_t id)**  
*Save settings from controller's RAM to stage's EEPROM memory, which spontaneously connected to stage and it isn't change without its mechanical reconstruction.*

- `result_t XIMC_API command_eeread_settings (device_t id)`  
*Read settings from controller's RAM to stage's EEPROM memory, which spontaneously connected to stage and it isn't change without its mechanical reconstruction.*
- `result_t XIMC_API get_chart_data (device_t id, chart_data_t *chart_data)`  
*Return device electrical parameters, useful for charts.*
- `result_t XIMC_API get_serial_number (device_t id, unsigned int *SerialNumber)`  
*Read device serial number.*
- `result_t XIMC_API get_firmware_version (device_t id, unsigned int *Major, unsigned int *Minor, unsigned int *Release)`  
*Read controller's firmware version.*
- `result_t XIMC_API service_command_updf (device_t id)`  
*Command puts the controller to update the firmware.*

### Service commands

- `result_t XIMC_API set_serial_number (device_t id, const serial_number_t *serial_number)`  
*Write device serial number and hardware version to controller's flash memory.*
- `result_t XIMC_API get_analog_data (device_t id, analog_data_t *analog_data)`  
*Read analog data structure that contains raw analog data from ADC embedded on board.*
- `result_t XIMC_API get_debug_read (device_t id, debug_read_t *debug_read)`  
*Read data from firmware for debug purpose.*
- `result_t XIMC_API set_debug_write (device_t id, const debug_write_t *debug_write)`  
*Write data to firmware for debug purpose.*

### Group of commands to work with EEPROM

- `result_t XIMC_API set_stage_name (device_t id, const stage_name_t *stage_name)`  
*Write user stage name from EEPROM.*
- `result_t XIMC_API get_stage_name (device_t id, stage_name_t *stage_name)`  
*Read user stage name from EEPROM.*
- `result_t XIMC_API set_stage_information (device_t id, const stage_information_t *stage_information)`  
*Set stage information to EEPROM.*
- `result_t XIMC_API get_stage_information (device_t id, stage_information_t *stage_information)`  
*Read stage information from EEPROM.*
- `result_t XIMC_API set_stage_settings (device_t id, const stage_settings_t *stage_settings)`  
*Set stage settings to EEPROM.*
- `result_t XIMC_API get_stage_settings (device_t id, stage_settings_t *stage_settings)`  
*Read stage settings from EEPROM.*
- `result_t XIMC_API set_motor_information (device_t id, const motor_information_t *motor_information)`  
*Set motor information to EEPROM.*
- `result_t XIMC_API get_motor_information (device_t id, motor_information_t *motor_information)`  
*Read motor information from EEPROM.*
- `result_t XIMC_API set_motor_settings (device_t id, const motor_settings_t *motor_settings)`  
*Set motor settings to EEPROM.*
- `result_t XIMC_API get_motor_settings (device_t id, motor_settings_t *motor_settings)`  
*Read motor settings from EEPROM.*
- `result_t XIMC_API set_encoder_information (device_t id, const encoder_information_t *encoder_information)`  
*Set encoder information to EEPROM.*
- `result_t XIMC_API get_encoder_information (device_t id, encoder_information_t *encoder_information)`  
*Read encoder information from EEPROM.*
- `result_t XIMC_API set_encoder_settings (device_t id, const encoder_settings_t *encoder_settings)`  
*Set encoder settings to EEPROM.*
- `result_t XIMC_API get_encoder_settings (device_t id, encoder_settings_t *encoder_settings)`  
*Read encoder settings from EEPROM.*
- `result_t XIMC_API set_hallsensor_information (device_t id, const hallsensor_information_t *hallsensor_information)`  
*Set hall sensor information to EEPROM.*

- `result_t XIMC_API get_hallsensor_information (device_t id, hallsensor_information_t *hallsensor_information)`  
*Read hall sensor information from EEPROM.*
- `result_t XIMC_API set_hallsensor_settings (device_t id, const hallsensor_settings_t *hallsensor_settings)`  
*Set hall sensor settings to EEPROM.*
- `result_t XIMC_API get_hallsensor_settings (device_t id, hallsensor_settings_t *hallsensor_settings)`  
*Read hall sensor settings from EEPROM.*
- `result_t XIMC_API set_gear_information (device_t id, const gear_information_t *gear_information)`  
*Set gear information to EEPROM.*
- `result_t XIMC_API get_gear_information (device_t id, gear_information_t *gear_information)`  
*Read gear information from EEPROM.*
- `result_t XIMC_API set_gear_settings (device_t id, const gear_settings_t *gear_settings)`  
*Set gear settings to EEPROM.*
- `result_t XIMC_API get_gear_settings (device_t id, gear_settings_t *gear_settings)`  
*Read gear settings from EEPROM.*
- `result_t XIMC_API set_accessories_settings (device_t id, const accessories_settings_t *accessories_settings)`  
*Set additional accessories information to EEPROM.*
- `result_t XIMC_API get_accessories_settings (device_t id, accessories_settings_t *accessories_settings)`  
*Read additional accessories information from EEPROM.*
- `result_t XIMC_API get_bootloader_version (device_t id, unsigned int *Major, unsigned int *Minor, unsigned int *Release)`  
*Read controller's firmware version.*
- `result_t XIMC_API get_init_random (device_t id, init_random_t *init_random)`  
*Read random number from controller.*
- `result_t XIMC_API goto_firmware (device_t id, uint8_t *ret)`  
*Reboot to firmware.*
- `result_t XIMC_API has_firmware (const char *name, uint8_t *ret)`  
*Check for firmware on device.*
- `result_t XIMC_API command_update_firmware (const char *name, const uint8_t *data, uint32_t data_size)`  
*Update firmware.*
- `result_t XIMC_API write_key (const char *name, uint8_t *key)`  
*Write controller key.*
- `result_t XIMC_API command_reset (device_t id)`  
*Reset controller.*
- `result_t XIMC_API command_clear_fram (device_t id)`  
*Clear controller FRAM.*

Boards and drivers control

Functions for searching and opening/closing devices

- `typedef char * pchar`  
*Nevermind.*
- `typedef void(XIMC_CALLCONV * logging_callback_t )(int loglevel, const wchar_t *message, void *user_data)`  
*Logging callback prototype.*
- `device_t XIMC_API open_device (const char *name)`  
*Open a device with OS name name and return identifier of the device which can be used in calls.*
- `result_t XIMC_API close_device (device_t *id)`  
*Close specified device.*
- `result_t XIMC_API probe_device (const char *name)`  
*Check if a device with OS name name is XIMC device.*
- `device_enumeration_t XIMC_API enumerate_devices (int enumerate_flags, const char *hints)`  
*Enumerate all devices that looks like valid.*
- `result_t XIMC_API free_enumerate_devices (device_enumeration_t device_enumeration)`

- `int XIMC_API get_device_count (device_enumeration_t device_enumeration)`  
*Get device count.*
- `pchar XIMC_API get_device_name (device_enumeration_t device_enumeration, int device_index)`  
*Get device name from the device enumeration.*
- `result_t XIMC_API get_enumerate_device_serial (device_enumeration_t device_enumeration, int device_index, uint32_t *serial)`  
*Get device serial number from the device enumeration.*
- `result_t XIMC_API get_enumerate_device_information (device_enumeration_t device_enumeration, int device_index, device_information_t *device_information)`  
*Get device information from the device enumeration.*
- `result_t XIMC_API get_enumerate_device_controller_name (device_enumeration_t device_enumeration, int device_index, controller_name_t *controller_name)`  
*Get controller name from the device enumeration.*
- `result_t XIMC_API get_enumerate_device_stage_name (device_enumeration_t device_enumeration, int device_index, stage_name_t *stage_name)`  
*Get stage name from the device enumeration.*
- `result_t XIMC_API get_enumerate_device_network_information (device_enumeration_t device_enumeration, int device_index, device_network_information_t *device_network_information)`  
*Get device network information from the device enumeration.*
- `result_t XIMC_API reset_locks ()`  
*Reset library locks in a case of deadlock.*
- `result_t XIMC_API ximc_fix_usbser.sys (const char *device_name)`  
*Fix for errors in Windows USB driver stack.*
- `void XIMC_API msec_sleep (unsigned int msec)`  
*Sleeps for a specified amount of time.*
- `void XIMC_API ximc_version (char *version)`  
*Returns a library version.*
- `void XIMC_API logging_callback_stderr_wide (int loglevel, const wchar_t *message, void *user_data)`  
*Simple callback for logging to stderr in wide chars.*
- `void XIMC_API logging_callback_stderr_narrow (int loglevel, const wchar_t *message, void *user_data)`  
*Simple callback for logging to stderr in narrow (single byte) chars.*
- `void XIMC_API set_logging_callback (logging_callback_t logging_callback, void *user_data)`  
*Sets a logging callback.*
- `result_t XIMC_API get_status (device_t id, status_t *status)`  
*Return device state.*
- `result_t XIMC_API get_status_calb (device_t id, status_calb_t *status, const calibration_t *calibration)`  
*Calibrated device state.*
- `result_t XIMC_API get_device_information (device_t id, device_information_t *device_information)`  
*Return device information.*
- `result_t XIMC_API command_wait_for_stop (device_t id, uint32_t refresh_interval_ms)`  
*Wait for stop.*
- `result_t XIMC_API command_homezero (device_t id)`  
*Make home command, wait until it is finished and make zero command.*

### 5.1.1 Detailed Description

Header file for libximc library.

## 5.1.2 Macro Definition Documentation

5.1.2.1 `#define ALARM_ON_DRIVER_OVERHEATING 0x01`

If this flag is set enter Alarm state on driver overheat signal.

5.1.2.2 `#define BORDER_IS_ENCODER 0x01`

Borders are fixed by predetermined encoder values, if set; borders position on limit switches, if not set.

5.1.2.3 `#define BORDER_STOP_LEFT 0x02`

Motor should stop on left border.

5.1.2.4 `#define BORDER_STOP_RIGHT 0x04`

Motor should stop on right border.

5.1.2.5 `#define BORDERS_SWAP_MISSET_DETECTION 0x08`

Motor should stop on both borders.

Need to save motor then wrong border settings is set

5.1.2.6 `#define BRAKE_ENABLED 0x01`

Brake control is enabled, if this flag is set.

5.1.2.7 `#define BRAKE_ENG_PWROFF 0x02`

Brake turns off power of step motor, if this flag is set.

5.1.2.8 `#define CONTROL_BTN_LEFT_PUSHED_OPEN 0x04`

Pushed left button corresponds to open contact, if this flag is set.

5.1.2.9 `#define CONTROL_BTN_RIGHT_PUSHED_OPEN 0x08`

Pushed right button corresponds to open contact, if this flag is set.

5.1.2.10 `#define CONTROL_MODE_BITS 0x03`

Bits to control engine by joystick or buttons.

5.1.2.11 `#define CONTROL_MODE_JOY 0x01`

Control by joystick.

5.1.2.12 #define CONTROL\_MODE\_LR 0x02

Control by left/right buttons.

5.1.2.13 #define CONTROL\_MODE\_OFF 0x00

Control is disabled.

5.1.2.14 #define CTP\_ALARM\_ON\_ERROR 0x04

Set ALARM on mismatch, if flag set.

5.1.2.15 #define CTP\_BASE 0x02

Position control is based on revolution sensor, if this flag is set; otherwise it is based on encoder.

5.1.2.16 #define CTP\_ENABLED 0x01

Position control is enabled, if flag set.

5.1.2.17 #define CTP\_ERROR\_CORRECTION 0x10

Correct errors which appear when slippage if the flag is set.

It works only with the encoder. Incompatible with flag CTP\_ALARM\_ON\_ERROR.

5.1.2.18 #define DRIVER\_TYPE\_DISCRETE\_FET 0x01

Driver with discrete FET keys.

Default option.

5.1.2.19 #define DRIVER\_TYPE\_EXTERNAL 0x03

External driver.

5.1.2.20 #define DRIVER\_TYPE\_INTEGRATE 0x02

Driver with integrated IC.

5.1.2.21 #define EEPROM\_PRECEDENCE 0x01

If the flag is set settings from external EEPROM override controller settings.

5.1.2.22 #define ENC\_STATE\_ABSENT 0x00

Encoder is absent.

5.1.2.23 #define ENC\_STATE\_MALFUNC 0x02

Encoder is connected and malfunctioning.

5.1.2.24 #define ENC\_STATE\_OK 0x04

Encoder is connected and working properly.

5.1.2.25 #define ENC\_STATE\_REVERS 0x03

Encoder is connected and operational but counts in other direction.

5.1.2.26 #define ENC\_STATE\_UNKNOWN 0x01

Encoder state is unknown.

5.1.2.27 #define ENDER\_SW1\_ACTIVE\_LOW 0x02

1 - Limit switch connected to pin SW1 is triggered by a low level on pin.

5.1.2.28 #define ENDER\_SW2\_ACTIVE\_LOW 0x04

1 - Limit switch connected to pin SW2 is triggered by a low level on pin.

5.1.2.29 #define ENDER\_SWAP 0x01

First limit switch on the right side, if set; otherwise on the left side.

5.1.2.30 #define ENGINE\_ACCEL\_ON 0x10

Acceleration enable flag.

If it set, motion begins with acceleration and ends with deceleration.

5.1.2.31 #define ENGINE\_ANTIPLAY 0x08

Play compensation flag.

If it set, engine makes backlash (play) compensation procedure and reach the predetermined position accurately on low speed.

5.1.2.32 #define ENGINE\_LIMIT\_CURR 0x40

Maximum motor current limit enable flag(is only used with DC motor).

5.1.2.33 #define ENGINE\_LIMIT\_RPM 0x80

Maximum motor speed limit enable flag.

5.1.2.34 #define ENGINE\_LIMIT\_VOLT 0x20

Maximum motor voltage limit enable flag(is only used with DC motor).

5.1.2.35 #define ENGINE\_MAX\_SPEED 0x04

Max speed flag.

If it is set, engine uses maximum speed achievable with the present engine settings as nominal speed.

5.1.2.36 #define ENGINE\_REVERSE 0x01

Reverse flag.

It determines motor shaft rotation direction that corresponds to feedback counts increasing. If not set (default), motor shaft rotation direction under positive voltage corresponds to feedback counts increasing and vice versa. Change it if you see that positive directions on motor and feedback are opposite.

5.1.2.37 #define ENGINE\_TYPE\_2DC 0x02

2 DC motors.

5.1.2.38 #define ENGINE\_TYPE\_BRUSHLESS 0x05

Brushless motor.

5.1.2.39 #define ENGINE\_TYPE\_DC 0x01

DC motor.

5.1.2.40 #define ENGINE\_TYPE\_NONE 0x00

A value that shouldn't be used.

5.1.2.41 #define ENGINE\_TYPE\_STEP 0x03

Step motor.

5.1.2.42 #define ENGINE\_TYPE\_TEST 0x04

Duty cycle are fixed.

Used only manufacturer.

5.1.2.43 #define ENUMERATE\_PROBE 0x01

Check if a device with OS name name is XIMC device.

Be careful with this flag because it sends some data to the device.

5.1.2.44 #define EXTIO\_SETUP\_INVERT 0x02

Interpret EXTIO states and fronts inverted if flag is set.

Falling front as input event and low logic level as active state.

5.1.2.45 #define EXTIO\_SETUP\_MODE\_IN\_ALARM 0x05

Set Alarm when the signal goes to the active state.

5.1.2.46 #define EXTIO\_SETUP\_MODE\_IN\_BITS 0x0F

Bits of the behaviour selector when the signal on input goes to the active state.

5.1.2.47 #define EXTIO\_SETUP\_MODE\_IN\_HOME 0x04

Issue HOME command.

5.1.2.48 #define EXTIO\_SETUP\_MODE\_IN\_MOVR 0x03

Issue MOVR command with last used settings.

5.1.2.49 #define EXTIO\_SETUP\_MODE\_IN\_NOP 0x00

Do nothing.

5.1.2.50 #define EXTIO\_SETUP\_MODE\_IN\_PWOF 0x02

Issue PWOF command, powering off all engine windings.

5.1.2.51 #define EXTIO\_SETUP\_MODE\_IN\_STOP 0x01

Issue STOP command, ceasing the engine movement.

5.1.2.52 #define EXTIO\_SETUP\_MODE\_OUT\_ALARM 0x30

EXTIO pin stays active during Alarm state.

5.1.2.53 #define EXTIO\_SETUP\_MODE\_OUT\_BITS 0xF0

Bits of the output behaviour selection.

5.1.2.54 #define EXTIO\_SETUP\_MODE\_OUT\_MOTOR\_FOUND 0x50

EXTIO pin stays active when motor is connected (first winding).

5.1.2.55 #define EXTIO\_SETUP\_MODE\_OUT\_MOTOR\_ON 0x40

EXTIO pin stays active when windings are powered.

5.1.2.56 #define EXTIO\_SETUP\_MODE\_OUT\_MOVING 0x20

EXTIO pin stays active during moving state.

5.1.2.57 #define EXTIO\_SETUP\_MODE\_OUT\_OFF 0x00

EXTIO pin always set in inactive state.

5.1.2.58 #define EXTIO\_SETUP\_MODE\_OUT\_ON 0x10

EXTIO pin always set in active state.

5.1.2.59 #define EXTIO\_SETUP\_OUTPUT 0x01

EXTIO works as output if flag is set, works as input otherwise.

5.1.2.60 #define FEEDBACK\_EMF 0x04

Feedback by EMF.

5.1.2.61 #define FEEDBACK\_ENC\_REVERSE 0x01

Reverse count of encoder.

5.1.2.62 #define FEEDBACK\_ENCODER 0x01

Feedback by encoder.

5.1.2.63 #define FEEDBACK\_ENCODERHALL 0x03

Feedback by Hall detector.

5.1.2.64 #define FEEDBACK\_HALL\_REVERSE 0x02

Reverce count position on the Hall sensor.

5.1.2.65 #define FEEDBACK\_NONE 0x05

Feedback is absent.

5.1.2.66 #define H\_BRIDGE\_ALERT 0x04

If this flag is set then turn off the power unit with a signal problem in one of the transistor bridge.

5.1.2.67 #define HOME\_DIR\_FIRST 0x01

Flag defines direction of 1st motion after execution of home command.

Direction is right, if set; otherwise left.

5.1.2.68 #define HOME\_DIR\_SECOND 0x02

Flag defines direction of 2nd motion.

Direction is right, if set; otherwise left.

5.1.2.69 #define HOME\_HALF\_MV 0x08

If the flag is set, the stop signals are ignored in start of second movement the first half-turn.

5.1.2.70 #define HOME\_MV\_SEC\_EN 0x04

Use the second phase of calibration to the home position, if set; otherwise the second phase is skipped.

5.1.2.71 #define HOME\_STOP\_FIRST\_BITS 0x30

Bits of the first stop selector.

5.1.2.72 #define HOME\_STOP\_FIRST\_LIM 0x30

First motion stops by limit switch.

5.1.2.73 #define HOME\_STOP\_FIRST\_REV 0x10

First motion stops by revolution sensor.

5.1.2.74 #define HOME\_STOP\_FIRST\_SYN 0x20

First motion stops by synchronization input.

5.1.2.75 #define HOME\_STOP\_SECOND\_BITS 0xC0

Bits of the second stop selector.

5.1.2.76 #define HOME\_STOP\_SECOND\_LIM 0xC0

Second motion stops by limit switch.

5.1.2.77 #define HOME\_STOP\_SECOND\_REV 0x40

Second motion stops by revolution sensor.

5.1.2.78 #define HOME\_STOP\_SECOND\_SYN 0x80

Second motion stops by synchronization input.

5.1.2.79 #define JOY\_REVERSE 0x01

Joystick action is reversed.

Joystick deviation to the upper values correspond to negative speeds and vice versa.

5.1.2.80 #define LOW\_UPWR\_PROTECTION 0x02

If this flag is set turn off motor when voltage is lower than LowUpwrOff.

5.1.2.81 #define MICROSTEP\_MODE\_FRAC\_128 0x08

1/128 step mode.

5.1.2.82 #define MICROSTEP\_MODE\_FRAC\_16 0x05

1/16 step mode.

5.1.2.83 #define MICROSTEP\_MODE\_FRAC\_2 0x02

1/2 step mode.

5.1.2.84 #define MICROSTEP\_MODE\_FRAC\_256 0x09

1/256 step mode.

5.1.2.85 #define MICROSTEP\_MODE\_FRAC\_32 0x06

1/32 step mode.

5.1.2.86 #define MICROSTEP\_MODE\_FRAC\_4 0x03

1/4 step mode.

5.1.2.87 #define MICROSTEP\_MODE\_FRAC\_64 0x07

1/64 step mode.

5.1.2.88 #define MICROSTEP\_MODE\_FRAC\_8 0x04

1/8 step mode.

5.1.2.89 #define MICROSTEP\_MODE\_FULL 0x01

Full step mode.

5.1.2.90 #define MOVE\_STATE\_ANTIPLAY 0x04

Motor is playing compensation, if flag set.

5.1.2.91 #define MOVE\_STATE\_MOVING 0x01

This flag indicates that controller is trying to move the motor.

Don't use this flag for waiting of completion of the movement command. Use MVCMD\_RUNNING flag from the MvCmdSts field instead.

5.1.2.92 #define MOVE\_STATE\_TARGET\_SPEED 0x02

Target speed is reached, if flag set.

5.1.2.93 #define MVCMD\_ERROR 0x40

Finish state (1 - move command have finished with an error, 0 - move command have finished correctly).

This flags is actual when MVCMD\_RUNNING signals movement finish.

5.1.2.94 #define MVCMD\_HOME 0x06

Command home.

5.1.2.95 #define MVCMD\_LEFT 0x03

Command left.

5.1.2.96 #define MVCMD\_LOFT 0x07

Command loft.

5.1.2.97 #define MVCMD\_MOVE 0x01

Command move.

5.1.2.98 #define MVCMD\_MOVR 0x02

Command movr.

5.1.2.99 #define MVCMD\_NAME\_BITS 0x3F

Move command bit mask.

5.1.2.100 #define MVCMD\_RIGHT 0x04

Command right.

5.1.2.101 #define MVCMD\_RUNNING 0x80

Move command state (0 - move command have finished, 1 - move command is being executed).

5.1.2.102 #define MVCMD\_SSTP 0x08

Command soft stop.

5.1.2.103 #define MVCMD\_STOP 0x05

Command stop.

5.1.2.104 #define MVCMD\_UKNWN 0x00

Unknown command.

5.1.2.105 #define POWER\_OFF\_ENABLED 0x02

Power off enabled after PowerOffDelay, if this flag is set.

5.1.2.106 #define POWER\_REDUCT\_ENABLED 0x01

Current reduction enabled after CurrReducDelay, if this flag is set.

5.1.2.107 #define POWER\_SMOOTH\_CURRENT 0x04

Current ramp-up/down is performed smoothly during current\_set\_time, if this flag is set.

5.1.2.108 #define PWR\_STATE\_MAX 0x05

Motor windings are powered by maximum current driver can provide at this voltage.

5.1.2.109 #define PWR\_STATE\_NORM 0x03

Motor windings are powered by nominal current.

5.1.2.110 #define PWR\_STATE\_OFF 0x01

Motor windings are disconnected from the driver.

5.1.2.111 #define PWR\_STATE\_REDUCED 0x04

Motor windings are powered by reduced current to lower power consumption.

5.1.2.112 #define PWR\_STATE\_UNKNOWN 0x00

Unknown state, should never happen.

5.1.2.113 #define REV\_SENS\_INV 0x08

Sensor is active when it 0 and invert makes active level 1.

That is, if you do not invert, it is normal logic - 0 is the activation.

5.1.2.114 #define SETPOS\_IGNORE\_ENCODER 0x02

Will not reload encoder state if this flag is set.

5.1.2.115 #define SETPOS\_IGNORE\_POSITION 0x01

Will not reload position in steps/microsteps if this flag is set.

5.1.2.116 #define STATE\_ALARM 0x00040

Controller is in alarm state indicating that something dangerous had happened.

Most commands are ignored in this state. To reset the flag a STOP command must be issued.

---

5.1.2.117 #define STATE\_BORDERS\_SWAP\_MISSET 0x08000

Engine stuck at the wrong edge.

5.1.2.118 #define STATE\_BRAKE 0x0200

State of Brake pin.

5.1.2.119 #define STATE\_BUTTON\_LEFT 0x0008

Button "left" state (1 if pressed).

5.1.2.120 #define STATE\_BUTTON\_RIGHT 0x0004

Button "right" state (1 if pressed).

5.1.2.121 #define STATE\_CONTR 0x0003F

Flags of controller states.

5.1.2.122 #define STATE\_CONTROLLER\_OVERHEAT 0x00200

Controller overheat.

5.1.2.123 #define STATE\_CTP\_ERROR 0x00080

Control position error(is only used with stepper motor).

5.1.2.124 #define STATE\_DIG\_SIGNAL 0xFFFF

Flags of digital signals.

5.1.2.125 #define STATE\_EEPROM\_CONNECTED 0x00010

EEPROM with settings is connected.

5.1.2.126 #define STATE\_ENC\_A 0x2000

State of encoder A pin.

5.1.2.127 #define STATE\_ENC\_B 0x4000

State of encoder B pin.

5.1.2.128 #define STATE\_ERRC 0x00001

Command error encountered.

5.1.2.129 #define STATE\_ERRD 0x00002

Data integrity error encountered.

5.1.2.130 #define STATE\_ERRV 0x00004

Value error encountered.

5.1.2.131 #define STATE\_GPIO\_LEVEL 0x0020

State of external GPIO pin.

5.1.2.132 #define STATE\_GPIO\_PINOUT 0x0010

External GPIO works as Out, if flag set; otherwise works as In.

5.1.2.133 #define STATE\_HALL\_A 0x0040

State of Hall\_a pin.

5.1.2.134 #define STATE\_HALL\_B 0x0080

State of Hall\_b pin.

5.1.2.135 #define STATE\_HALL\_C 0x0100

State of Hall\_c pin.

5.1.2.136 #define STATE\_LEFT\_EDGE 0x0002

Engine stuck at the left edge.

5.1.2.137 #define STATE\_LOW\_USB\_VOLTAGE 0x02000

USB voltage is insufficient for normal operation.

5.1.2.138 #define STATE\_OVERLOAD\_POWER\_CURRENT 0x00800

Power current exceeds safe limit.

5.1.2.139 #define STATE\_OVERLOAD\_POWER\_VOLTAGE 0x00400

Power voltage exceeds safe limit.

5.1.2.140 #define STATE\_OVERLOAD\_USB\_CURRENT 0x04000

USB current exceeds safe limit.

5.1.2.141 #define STATE\_OVERLOAD\_USB\_VOLTAGE 0x01000

USB voltage exceeds safe limit.

5.1.2.142 #define STATE\_POWER\_OVERHEAT 0x00100

Power driver overheat.

5.1.2.143 #define STATE\_REV\_SENSOR 0x0400

State of Revolution sensor pin.

5.1.2.144 #define STATE\_RIGHT\_EDGE 0x0001

Engine stuck at the right edge.

5.1.2.145 #define STATE\_SECUR 0x3FFC0

Flags of security.

5.1.2.146 #define STATE\_SYNC\_INPUT 0x0800

State of Sync input pin.

5.1.2.147 #define STATE\_SYNC\_OUTPUT 0x1000

State of Sync output pin.

5.1.2.148 #define SYNCIN\_ENABLED 0x01

Synchronization in mode is enabled, if this flag is set.

5.1.2.149 #define SYNCIN\_GOTOPOSITION 0x04

The engine is go to position specified in Position and uPosition, if this flag is set.

And it is shift on the Position and uPosition, if this flag is unset

5.1.2.150 #define SYNCIN\_INVERT 0x02

Trigger on falling edge if flag is set, on rising edge otherwise.

5.1.2.151 #define SYNCOUT\_ENABLED 0x01

Synchronization out pin follows the synchronization logic, if set.

It governed by SYNCOUT\_STATE flag otherwise.

5.1.2.152 #define SYNCOUT\_IN\_STEPS 0x08

Use motor steps/encoder pulses instead of milliseconds for output pulse generation if the flag is set.

5.1.2.153 #define SYNCOUT\_INVERT 0x04

Low level is active, if set, and high level is active otherwise.

5.1.2.154 #define SYNCOUT\_ONPERIOD 0x40

Generate synchronization pulse every SyncOutPeriod encoder pulses.

5.1.2.155 #define SYNCOUT\_ONSTART 0x10

Generate synchronization pulse when movement starts.

5.1.2.156 #define SYNCOUT\_ONSTOP 0x20

Generate synchronization pulse when movement stops.

5.1.2.157 #define SYNCOUT\_STATE 0x02

When output state is fixed by negative SYNCOUT\_ENABLED flag, the pin state is in accordance with this flag state.

5.1.2.158 #define UART\_PARITY\_BITS 0x03

Bits of the parity.

5.1.2.159 #define WIND\_A\_STATE\_ABSENT 0x00

Winding A is disconnected.

5.1.2.160 #define WIND\_A\_STATE\_MALFUNC 0x02

Winding A is short-circuited.

5.1.2.161 #define WIND\_A\_STATE\_OK 0x03

Winding A is connected and working properly.

5.1.2.162 #define WIND\_A\_STATE\_UNKNOWN 0x01

Winding A state is unknown.

5.1.2.163 #define WIND\_B\_STATE\_ABSENT 0x00

Winding B is disconnected.

5.1.2.164 #define WIND\_B\_STATE\_MALFUNC 0x20

Winding B is short-circuited.

5.1.2.165 #define WIND\_B\_STATE\_OK 0x30

Winding B is connected and working properly.

5.1.2.166 #define WIND\_B\_STATE\_UNKNOWN 0x10

Winding B state is unknown.

5.1.2.167 #define XIMC\_API

Library import macro Macros allows to automatically import function from shared library.

It automatically expands to `dllimport` on msvc when including header file

### 5.1.3 Typedef Documentation

5.1.3.1 `typedef void(XIMC_CALLCONV * logging_callback_t)(int loglevel, const wchar_t *message, void *user_data)`

Logging callback prototype.

Parameters

<i>loglevel</i>	a loglevel
<i>message</i>	a message

### 5.1.4 Function Documentation

5.1.4.1 `result_t XIMC_API close_device ( device_t * id )`

Close specified device.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.2 `result_t XIMC_API command_add_sync_in_action ( device_t id, const command_add_sync_in_action_t * the_command_add_sync_in_action )`

This command adds one element of the FIFO commands that are executed when input clock pulse.

Each pulse synchronization or perform that action, which is described in SSNI, if the buffer is empty, or the oldest loaded into the buffer action to temporarily replace the speed and coordinate in SSNI. In the latter case this action is erased from the buffer. The number of remaining empty buffer elements can be found in the structure of GETS.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.3 `result_t XIMC_API command_clear_fram ( device_t id )`

Clear controller FRAM.

Can be used by manufacturer only

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

#### 5.1.4.4 **result\_t XIMC\_API command\_eeread\_settings ( device\_t id )**

Read settings from controller's RAM to stage's EEPROM memory, which spontaneously connected to stage and it isn't change without its mechanical reconstruction.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

#### 5.1.4.5 **result\_t XIMC\_API command\_eesave\_settings ( device\_t id )**

Save settings from controller's RAM to stage's EEPROM memory, which spontaneously connected to stage and it isn't change without its mechanical reconstruction.

Can be used by manufacturer only.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

#### 5.1.4.6 **result\_t XIMC\_API command\_home ( device\_t id )**

The positive direction is to the right.

A value of zero reverses the direction of the direction of the flag, the set speed. Restriction imposed by the trailer, act the same, except that the limit switch contact does not stop. Limit the maximum speed, acceleration and deceleration function. 1) moves the motor according to the speed FastHome, uFastHome and flag HOME\_DIR\_FAST until limit switch, if the flag is set HOME\_STOP\_ENDS, until the signal from the input synchronization if the flag HOME\_STOP\_SYNC (as accurately as possible is important to catch the moment of operation limit switch) or until the signal is received from the speed sensor, if the flag HOME\_STOP\_REV\_SN 2) then moves according to the speed SlowHome, uSlowHome and flag HOME\_DIR\_SLOW until signal from the clock input, if the flag HOME\_MV\_SEC. If the flag HOME\_MV\_SEC is reset skip this paragraph. 3) then move the motor according to the speed FastHome, uFastHome and flag HOME\_DIR\_SLOW a distance HomeDelta, uHomeDelta. description of flags and variable see in description for commands GHOM/SHOM

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

See Also

[home\\_settings.t](#)  
[get\\_home\\_settings](#)  
[set\\_home\\_settings](#)

#### 5.1.4.7 **result\_t XIMC\_API command\_homezero ( device\_t id )**

Make home command, wait until it is finished and make zero command.

This is a convenient way to calibrate zero position.

Parameters

	<i>id</i>	an identifier of device
out	<i>ret</i>	RESULT_OK if controller has finished home & zero correctly or result of first controller query that returned anything other than RESULT_OK.

#### 5.1.4.8 **result\_t XIMC\_API command\_left ( device\_t id )**

Start continuous moving to the left.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

#### 5.1.4.9 **result\_t XIMC\_API command\_loft ( device\_t id )**

Upon receiving the command "loft" the engine is shifted from the current point to a distance GENG :: Antiplay, then move to the same point.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

#### 5.1.4.10 **result\_t XIMC\_API command\_move ( device\_t id, int Position, int uPosition )**

Upon receiving the command "move" the engine starts to move with pre-set parameters (speed, acceleration, retention), to the point specified to the Position, uPosition.

For stepper motor uPosition sets the microstep for DC motor, this field is not used.

Parameters

<i>Position</i>	position to move.
<i>uPosition</i>	part of the position to move, microsteps. Range: -255..255.
<i>id</i>	an identifier of device

#### 5.1.4.11 **result\_t XIMC\_API command\_movr ( device\_t id, int DeltaPosition, int uDeltaPosition )**

Upon receiving the command "movr" engine starts to move with pre-set parameters (speed, acceleration, hold), left or right (depending on the sign of DeltaPosition) by the number of pulses specified in the fields DeltaPosition, uDeltaPosition.

For stepper motor uDeltaPosition sets the microstep for DC motor, this field is not used.

Parameters

<i>DeltaPosition</i>	shift from initial position.
<i>uDeltaPosition</i>	part of the offset shift, microsteps. Range: -255..255.
<i>id</i>	an identifier of device

#### 5.1.4.12 **result\_t XIMC\_API command\_power\_off ( device\_t id )**

Immediately power off motor regardless its state.

Shouldn't be used during motion as the motor could be power on again automatically to continue movement. The command is designed for manual motor power off. When automatic power off after stop is required, use power management system.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

See Also

[get\\_power\\_settings](#)  
[set\\_power\\_settings](#)

#### 5.1.4.13 **result\_t XIMC\_API command\_read\_settings ( device\_t id )**

Read all settings from controller's flash memory to controller's RAM, replacing previous data in controller's RAM.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

#### 5.1.4.14 **result\_t XIMC\_API command\_reset ( device\_t id )**

Reset controller.

Can be used by manufacturer only

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

#### 5.1.4.15 **result\_t XIMC\_API command\_right ( device\_t id )**

Start continous moving to the right.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

#### 5.1.4.16 **result\_t XIMC\_API command\_save\_settings ( device\_t id )**

Save all settings from controller's RAM to controller's flash memory, replacing previous data in controller's flash memory.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

#### 5.1.4.17 **result\_t XIMC\_API command\_sstp ( device\_t id )**

soft stop engine.

The motor stops with deceleration speed.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

#### 5.1.4.18 **result\_t XIMC\_API command\_stop ( device\_t id )**

Immediately stop the engine, the transition to the STOP, mode key BREAK (winding short-circuited), the regime "retention" is deactivated for DC motors, keeping current in the windings for stepper motors (with Power management settings).

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

#### 5.1.4.19 **result\_t XIMC\_API command\_update\_firmware ( const char \* name, const uint8\_t \* data, uint32\_t data\_size )**

Update firmware.

Service command

Parameters

<i>name</i>	a name of device
<i>data</i>	firmware byte stream
<i>data_size</i>	size of byte stream

#### 5.1.4.20 **result\_t XIMC\_API command\_wait\_for\_stop ( device\_t id, uint32\_t refresh\_interval\_ms )**

Wait for stop.

Parameters

	<i>id</i>	an identifier of device
	<i>refresh_interval_ms</i>	Status refresh interval. The function waits this number of milliseconds between get_status requests to the controller. Recommended value of this parameter is 10 ms. Use values of less than 3 ms only when necessary - small refresh interval values do not significantly increase response time of the function, but they create substantially more traffic in controller-computer data channel.
<i>out</i>	<i>ret</i>	RESULT_OK if controller has stopped and result of the first get_status command which returned anything other than RESULT_OK otherwise.

#### 5.1.4.21 **result\_t XIMC\_API command\_zero ( device\_t id )**

Sets the current position and the position in which the traffic moves by the move command and movr zero for all cases, except for movement to the target position.

In the latter case, set the zero current position and the target position counted so that the absolute position of the destination is the same. That is, if we were at 400 and moved to 500, then the command Zero makes the current position of 0, and the position of the destination - 100. Does not change the mode of movement that is if the motion is carried, it continues, and if the engine is in the "hold", the type of retention remains.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.22 **device\_enumeration\_t XIMC\_API enumerate\_devices ( int enumerate\_flags, const char \* hints )**

Enumerate all devices that looks like valid.

Parameters

in	<i>enumerate_flags</i>	enumerate devices flags
in	<i>hints</i>	extended information hints is a string of form "key=value\nkey2=value2". Unrecognized key-value pairs are ignored. Key list: addr - used together with ENUMERATE_NETWORK flag. Non-null value is a remote host name or a comma-separated list of host names which contain the devices to be found, absent value means broadcast discovery.

5.1.4.23 **result\_t XIMC\_API free\_enumerate\_devices ( device\_enumeration\_t device\_enumeration )**

Free memory returned by *enumerate\_devices*.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
----	---------------------------	--

5.1.4.24 **result\_t XIMC\_API get\_accessories\_settings ( device\_t id, accessories\_settings\_t \* accessories\_settings )**

Read additional accessories information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>accessories_settings</i>	structure contains information about additional accessories

5.1.4.25 **result\_t XIMC\_API get\_analog\_data ( device\_t id, analog\_data\_t \* analog\_data )**

Read analog data structure that contains raw analog data from ADC embedded on board.

This function used for device testing and deep recalibration by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
out	<i>analog_data</i>	analog data coefficients

5.1.4.26 **result\_t XIMC\_API get\_bootloader\_version ( device\_t id, unsigned int \* Major, unsigned int \* Minor, unsigned int \* Release )**

Read controller's firmware version.

Parameters

	<i>id</i>	an identifier of device
out	<i>Major</i>	major version
out	<i>Minor</i>	minor version
out	<i>Release</i>	release version

5.1.4.27 **result\_t XIMC\_API get\_brake\_settings ( device\_t id, brake\_settings\_t \* brake\_settings )**

Read settings of brake control.

Parameters

	<i>id</i>	an identifier of device
out	<i>brake_settings</i>	structure contains settings of brake control

5.1.4.28 **result\_t XIMC\_API get\_chart\_data ( device\_t id, chart\_data\_t \* chart\_data )**

Return device electrical parameters, useful for charts.

Useful function that fill structure with snapshot of controller voltages and currents.

See Also

[chart\\_data.t](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>chart_data</i>	structure with snapshot of controller parameters.

5.1.4.29 **result\_t XIMC\_API get\_control\_settings ( device\_t id, control\_settings\_t \* control\_settings )**

Read settings of motor control.

When choosing CTL\_MODE = 1 switches motor control with the joystick. In this mode, the joystick to the maximum engine tends Move at MaxSpeed [i], where i = 0 if the previous use This mode is not selected another i. Buttons switch the room rate i. When CTL\_MODE = 2 is switched on motor control using the Left / right. When you click on the button motor starts to move in the appropriate direction at a speed MaxSpeed [0], at the end of time Timeout [i] motor move at a speed MaxSpeed [i+1]. at Transition from MaxSpeed [i] on MaxSpeed [i + 1] to acceleration, as usual.

Parameters

	<i>id</i>	an identifier of device
out	<i>control_settings</i>	structure contains settings motor control by joystick or buttons left/right.

5.1.4.30 **result\_t XIMC\_API get\_controller\_name ( device\_t id, controller\_name\_t \* controller\_name )**

Read user controller name and flags of setting from FRAM.

Parameters

	<i>id</i>	an identifier of device
out	<i>controller_name</i>	structure contains previously set user controller name

5.1.4.31 **result\_t XIMC\_API get\_ctp\_settings ( device\_t id, ctp\_settings\_t \* ctp\_settings )**

Read settings of control position(is only used with stepper motor).

When controlling the step motor with encoder (CTP\_BASE 0) it is possible to detect the loss of steps. The controller knows the number of steps per revolution (GENG :: StepsPerRev) and the encoder resolution (GFBS :: IPT). When

the control (flag CTP\_ENABLED), the controller stores the current position in the footsteps of SM and the current position of the encoder. Further, at each step of the position encoder is converted into steps and if the difference is greater CTPMinError, a flag STATE\_CTP\_ERROR. When controlling the step motor with speed sensor (CTP\_BASE 1), the position is controlled by him. The active edge of input clock controller stores the current value of steps. Further, at each turn checks how many steps shifted. When a mismatch CTPMinError a flag STATE\_CTP\_ERROR.

Parameters

	<i>id</i>	an identifier of device
out	<i>ctp_settings</i>	structure contains settings of control position

#### 5.1.4.32 **result\_t XIMC\_API get\_debug\_read ( device\_t id, debug\_read\_t \* debug\_read )**

Read data from firmware for debug purpose.

Its use depends on context, firmware version and previous history.

Parameters

	<i>id</i>	an identifier of device
out	<i>debug_read</i>	Debug data.

#### 5.1.4.33 int XIMC\_API get\_device\_count ( device\_enumeration\_t device\_enumeration )

Get device count.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
----	---------------------------	--

#### 5.1.4.34 **result\_t XIMC\_API get\_device\_information ( device\_t id, device\_information\_t \* device\_information )**

Return device information.

All fields must point to allocated string buffers with at least 10 bytes. Works with both raw or initialized device.

Parameters

	<i>id</i>	an identifier of device
out	<i>device_information</i>	device information Device information.

See Also

[get\\_device\\_information](#)

#### 5.1.4.35 **pchar XIMC\_API get\_device\_name ( device\_enumeration\_t device\_enumeration, int device\_index )**

Get device name from the device enumeration.

Returns *device\_index* device name.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index

#### 5.1.4.36 **result\_t XIMC\_API get\_edges\_settings ( *device\_t id, edges\_settings\_t \* edges\_settings* )**

Read border and limit switches settings.

See Also

[set\\_edges\\_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>edges_settings</i>	edges settings, specify types of borders, motor behaviour and electrical behaviour of limit switches

#### 5.1.4.37 **result\_t XIMC\_API get\_encoder\_information ( *device\_t id, encoder\_information\_t \* encoder\_information* )**

Read encoder information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>encoder_information</i>	structure contains information about encoder

#### 5.1.4.38 **result\_t XIMC\_API get\_encoder\_settings ( *device\_t id, encoder\_settings\_t \* encoder\_settings* )**

Read encoder settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>encoder_settings</i>	structure contains encoder settings

#### 5.1.4.39 **result\_t XIMC\_API get\_engine\_settings ( *device\_t id, engine\_settings\_t \* engine\_settings* )**

Read engine settings.

This function fill structure with set of useful motor settings stored in controller's memory. These settings specify motor shaft movement algorithm, list of limitations and rated characteristics.

See Also

[set\\_engine\\_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>engine_settings</i>	engine settings

5.1.4.40 **result\_t XIMC\_API get\_enctype\_settings ( device\_t id, entype\_settings.t \* enctype\_settings )**

Return engine type and driver type.

Parameters

	<i>id</i>	an identifier of device
out	<i>EngineType</i>	engine type
out	<i>DriverType</i>	driver type

5.1.4.41 **result\_t XIMC\_API get\_enumerate\_device\_controller\_name ( device\_enumeration.t deviceEnumeration, int device\_index, controller\_name.t \* controller\_name )**

Get controller name from the device enumeration.

Returns *device\_index* device controller name.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index
out	<i>controller_name</i>	controller name

5.1.4.42 **result\_t XIMC\_API get\_enumerate\_device\_information ( device\_enumeration.t deviceEnumeration, int device\_index, device\_information.t \* deviceInformation )**

Get device information from the device enumeration.

Returns *device\_index* device information.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index
out	<i>device_information</i>	device information data

5.1.4.43 **result\_t XIMC\_API get\_enumerate\_device\_network\_information ( device\_enumeration.t deviceEnumeration, int device\_index, device\_network\_information.t \* deviceNetworkInformation )**

Get device network information from the device enumeration.

Returns *device\_index* device network information.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index
out	<i>device_network_information</i>	device network information data

5.1.4.44 **result\_t XIMC\_API** get\_enumerate\_device\_serial ( **device\_enumeration\_t** device\_enumeration, int device\_index, uint32\_t \* serial )

Get device serial number from the device enumeration.

Returns *device\_index* device serial number.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index
out	<i>serial</i>	device serial number

5.1.4.45 **result\_t XIMC\_API** get\_enumerate\_device\_stage\_name ( **device\_enumeration\_t** device\_enumeration, int device\_index, **stage\_name\_t** \* stage\_name )

Get stage name from the device enumeration.

Returns *device\_index* device stage name.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index
out	<i>stage_name</i>	stage name

5.1.4.46 **result\_t XIMC\_API** get\_extio\_settings ( **device\_t** id, **extio\_settings\_t** \* extio\_settings )

Read EXTIO settings.

This function reads a structure with a set of EXTIO settings from controller's memory.

See Also

[set\\_extio\\_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>extio_settings</i>	EXTIO settings

5.1.4.47 **result\_t XIMC\_API** get\_feedback\_settings ( **device\_t** id, **feedback\_settings\_t** \* feedback\_settings )

Read feedback settings.

Parameters

	<i>id</i>	an identifier of device
out	<i>IPS</i>	number of encoder pulses per shaft revolution. Range: 1..65535
out	<i>FeedbackType</i>	type of feedback
out	<i>FeedbackFlags</i>	flags of feedback

5.1.4.48 **result\_t XIMC\_API** get\_firmware\_version ( **device\_t id**, **unsigned int \* Major**, **unsigned int \* Minor**, **unsigned int \* Release** )

Read controller's firmware version.

Parameters

	<i>id</i>	an identifier of device
out	<i>Major</i>	major version
out	<i>Minor</i>	minor version
out	<i>Release</i>	release version

5.1.4.49 **result\_t XIMC\_API** get\_gear\_information ( **device\_t id**, **gear\_information\_t \* gear\_information** )

Read gear information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>gear_information</i>	structure contains information about step gearhead

5.1.4.50 **result\_t XIMC\_API** get\_gear\_settings ( **device\_t id**, **gear\_settings\_t \* gear\_settings** )

Read gear settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>gear_settings</i>	structure contains step gearhead settings

5.1.4.51 **result\_t XIMC\_API** get\_hallsensor\_information ( **device\_t id**, **hallsensor\_information\_t \* hallsensor\_information** )

Read hall sensor information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>hallsensor_information</i>	structure contains information about hall sensor

5.1.4.52 **result\_t XIMC\_API** get\_hallsensor\_settings ( **device\_t id**, **hallsensor\_settings\_t \* hallsensor\_settings** )

Read hall sensor settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>hallsensor_settings</i>	structure contains hall sensor settings

5.1.4.53 **result\_t XIMC\_API get\_home\_settings ( device\_t id, home\_settings\_t \* home\_settings )**

Read home settings.

This function fill structure with settings of calibrating position.

See Also

[home\\_settings.t](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>home_settings</i>	calibrating position settings

5.1.4.54 **result\_t XIMC\_API get\_init\_random ( device\_t id, init\_random\_t \* init\_random )**

Read random number from controller.

Parameters

	<i>id</i>	an identifier of device
out	<i>random</i>	sequence generated by the controller

5.1.4.55 **result\_t XIMC\_API get\_joystick\_settings ( device\_t id, joystick\_settings\_t \* joystick\_settings )**

Read settings of joystick.

If joystick position is outside DeadZone limits from the central position a movement with speed, defined by the joystick DeadZone edge to 100% deviation, begins. Joystick positions inside DeadZone limits correspond to zero speed (soft stop of motion) and positions beyond Low and High limits correspond MaxSpeed [i] or -MaxSpeed [i] (see command SCTL), where i = 0 by default and can be changed with left/right buttons (see command SCTL). If next speed in list is zero (both integer and microstep parts), the button press is ignored. First speed in list shouldn't be zero. The DeadZone ranges are illustrated on the following picture. !/attachments/download/5563/range25p.png! The relationship between the deviation and the rate is exponential, allowing no switching speed combine high mobility and accuracy. The following picture illustrates this: !/attachments/download/3092/ExpJoystick.png! The nonlinearity parameter is adjustable. Setting it to zero makes deviation/speed relation linear.

Parameters

	<i>id</i>	an identifier of device
out	<i>joystick_settings</i>	structure contains joystick settings

5.1.4.56 **result\_t XIMC\_API get\_motor\_information ( device\_t id, motor\_information\_t \* motor\_information )**

Read motor information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>motor-information</i>	structure contains motor information

5.1.4.57 **result\_t XIMC\_API get\_motor\_settings ( device\_t id, motor\_settings\_t \* motor\_settings )**

Read motor settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>motor_settings</i>	structure contains motor settings

5.1.4.58 **result\_t XIMC\_API get\_move\_settings ( device\_t id, move\_settings\_t \* move\_settings )**

Read command setup movement (speed, acceleration, threshold and etc).

Parameters

	<i>id</i>	an identifier of device
out	<i>move_settings</i>	structure contains move settings: speed, acceleration, deceleration etc.

5.1.4.59 **result\_t XIMC\_API get\_pid\_settings ( device\_t id, pid\_settings\_t \* pid\_settings )**

Read PID settings.

This function fill structure with set of motor PID settings stored in controller's memory. These settings specify behaviour of PID routine for voltage. These factors are slightly different for different positioners. All boards are supplied with standart set of PID setting on controller's flash memory.

See Also

[set\\_pid\\_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>pid_settings</i>	pid settings

5.1.4.60 **result\_t XIMC\_API get\_position ( device\_t id, get\_position\_t \* the\_get\_position )**

Reads the value position in steps and micro for stepper motor and encoder steps all engines.

Parameters

	<i>id</i>	an identifier of device
out	<i>position</i>	structure contains move settings: speed, acceleration, deceleration etc.

5.1.4.61 **result\_t XIMC\_API get\_power\_settings ( device\_t id, power\_settings\_t \* power\_settings )**

Read settings of step motor power control.

Used with stepper motor only.

Parameters

	<i>id</i>	an identifier of device
out	<i>power_settings</i>	structure contains settings of step motor power control

5.1.4.62 **result\_t XIMC\_API get\_secure\_settings ( device\_t id, secure\_settings\_t \* secure\_settings )**

Read protection settings.

Parameters

	<i>id</i>	an identifier of device
out	<i>secure_settings</i>	critical parameter settings to protect the hardware

See Also

`status_t::flags`

5.1.4.63 **result\_t XIMC\_API get\_serial\_number ( device\_t id, unsigned int \* SerialNumber )**

Read device serial number.

Parameters

	<i>id</i>	an identifier of device
out	<i>serial</i>	serial number

5.1.4.64 **result\_t XIMC\_API get\_stage\_information ( device\_t id, stage\_information\_t \* stage\_information )**

Read stage information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>stage-information</i>	structure contains stage information

5.1.4.65 **result\_t XIMC\_API get\_stage\_name ( device\_t id, stage\_name\_t \* stage\_name )**

Read user stage name from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>stage_name</i>	structure contains previously set user stage name

5.1.4.66 **result\_t XIMC\_API get\_stage\_settings ( device\_t id, stage\_settings\_t \* stage\_settings )**

Read stage settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>stage_settings</i>	structure contains stage settings

5.1.4.67 **result\_t XIMC\_API** get\_status ( **device\_t id**, **status.t \* status** )

Return device state.

Parameters

	<i>id</i>	an identifier of device
out	<i>status</i>	structure with snapshot of controller status Device state. Useful structure that contains current controller status, including speed, position and boolean flags.

See Also

[get\\_status](#)

5.1.4.68 **result\_t XIMC\_API** get\_status\_calb ( **device\_t id**, **status\_calb.t \* status**, **const calibration.t \* calibration** )

Calibrated device state.

Useful structure that contains current controller status, including speed, position and boolean flags.

See Also

[get\\_status](#)

5.1.4.69 **result\_t XIMC\_API** get\_sync\_in\_settings ( **device\_t id**, **sync\_in\_settings.t \* sync\_in\_settings** )

Read input synchronization settings.

This function fill structure with set of input synchronization settings, modes, periods and flags, that specify behaviour of input synchronization. All boards are supplied with standart set of these settings.

See Also

[set\\_sync\\_in\\_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>sync_in_settings</i>	synchronization settings

5.1.4.70 **result\_t XIMC\_API** get\_sync\_out\_settings ( **device\_t id**, **sync\_out\_settings.t \* sync\_out\_settings** )

Read output synchronization settings.

This function fill structure with set of output synchronization settings, modes, periods and flags, that specify behaviour of output synchronization. All boards are supplied with standart set of these settings.

See Also

[set\\_sync\\_out\\_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>sync_out_settings</i>	synchronization settings

5.1.4.71 **result\_t XIMC\_API** get\_uart\_settings ( **device\_t id**, **uart\_settings\_t \* uart\_settings** )

Read UART settings.

This function fill structure with UART settings.

See Also

[uart\\_settings\\_t](#)

Parameters

	<i>Speed</i>	UART speed
<i>out</i>	<i>uart_settings</i>	UART settings

5.1.4.72 **result\_t XIMC\_API** goto\_firmware ( **device\_t id**, **uint8\_t \* ret** )

Reboot to firmware.

Parameters

	<i>id</i>	an identifier of device
<i>out</i>	<i>ret</i>	RESULT_OK, if reboot to firmware is possible. Reboot is done after reply to this command. RESULT_NO_FIRMWARE, if firmware is not found. RESULT_ALREADY_IN_FIRMWARE, if this command was sent when controller is already in firmware.

5.1.4.73 **result\_t XIMC\_API** has\_firmware ( **const char \* name**, **uint8\_t \* ret** )

Check for firmware on device.

Parameters

	<i>name</i>	a name of device
<i>out</i>	<i>ret</i>	non-zero if firmware existed

5.1.4.74 **void XIMC\_API** logging\_callback\_stderr\_narrow ( **int loglevel**, **const wchar\_t \* message**, **void \* user\_data** )

Simple callback for logging to stderr in narrow (single byte) chars.

Parameters

<i>loglevel</i>	a loglevel
<i>message</i>	a message

5.1.4.75 **void XIMC\_API** logging\_callback\_stderr\_wide ( **int loglevel**, **const wchar\_t \* message**, **void \* user\_data** )

Simple callback for logging to stderr in wide chars.

Parameters

<i>loglevel</i>	a loglevel
<i>message</i>	a message

5.1.4.76 void **XIMC\_API** msec\_sleep ( unsigned int msec )

Sleeps for a specified amount of time.

Parameters

<i>msec</i>	time in milliseconds
-------------	----------------------

5.1.4.77 **device\_t XIMC\_API** open\_device ( const char \* name )

Open a device with OS name *name* and return identifier of the device which can be used in calls.

Parameters

in	<i>name</i>	a device name Device name has form "xi-com:port" or "xi-net://host/serial" or "xi-emu://file". In case of USB-COM port the "port" is the OS device name. For example "xi-com:\\.\COM3" in Windows or "xi-com:/dev/tty.s123" in Linux/Mac. In case of network device the "host" is an IPv4 address or fully qualified domain name (FQDN), "serial" is the device serial number in hexadecimal system. For example "xi-net://192.168.0.1/00001234" or "xi-net://hostname.com/89ABCDEF". In case of virtual device the "file" is the full filename with device memory state, if it doesn't exist then it is initialized with default values. For example "xi-emu://C:\\dir\\file.bin" in Windows or "xi-emu:///home/user/file-bin" in Linux/Mac.
----	-------------	---

5.1.4.78 **result\_t XIMC\_API** probe\_device ( const char \* name )

Check if a device with OS name *name* is XIMC device.

Be careful with this call because it sends some data to the device.

Parameters

in	<i>name</i>	- a device name
----	-------------	-----------------

5.1.4.79 **result\_t XIMC\_API** service\_command\_updf ( **device\_t id** )

Command puts the controller to update the firmware.

After receiving this command, the firmware board sets a flag (for loader), sends echo reply and restarts the controller.

5.1.4.80 **result\_t XIMC\_API** set\_accessories\_settings ( **device\_t id**, const **accessories\_settings\_t \*** accessories\_settings )

Set additional accessories information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>accessories_settings</i>	structure contains information about additional accessories

#### 5.1.4.81 **result\_t XIMC\_API set\_brake\_settings ( device\_t id, const brake\_settings\_t \* brake\_settings )**

Set settings of brake control.

Parameters

	<i>id</i>	an identifier of device
in	<i>brake_settings</i>	structure contains settings of brake control

#### 5.1.4.82 **result\_t XIMC\_API set\_control\_settings ( device\_t id, const control\_settings\_t \* control\_settings )**

Set settings of motor control.

When choosing CTL\_MODE = 1 switches motor control with the joystick. In this mode, the joystick to the maximum engine tends Move at MaxSpeed [i], where i = 0 if the previous use This mode is not selected another i. Buttons switch the room rate i. When CTL\_MODE = 2 is switched on motor control using the Left / right. When you click on the button motor starts to move in the appropriate direction at a speed MaxSpeed [0], at the end of time Timeout [i] motor move at a speed MaxSpeed [i+1]. at Transition from MaxSpeed [i] on MaxSpeed [i + 1] to acceleration, as usual.

Parameters

	<i>id</i>	an identifier of device
in	<i>control_settings</i>	structure contains settings motor control by joystick or buttons left/right.

#### 5.1.4.83 **result\_t XIMC\_API set\_controller\_name ( device\_t id, const controller\_name\_t \* controller\_name )**

Write user controller name and flags of setting from FRAM.

Parameters

	<i>id</i>	an identifier of device
in	<i>controller_name</i>	structure contains previously set user controller name

#### 5.1.4.84 **result\_t XIMC\_API set\_ctp\_settings ( device\_t id, const ctp\_settings\_t \* ctp\_settings )**

Set settings of control position(is only used with stepper motor).

When controlling the step motor with encoder (CTP\_BASE 0) it is possible to detect the loss of steps. The controller knows the number of steps per revolution (GENG :: StepsPerRev) and the encoder resolution (GFBS :: IPT). When the control (flag CTP\_ENABLED), the controller stores the current position in the footsteps of SM and the current position of the encoder. Further, at each step of the position encoder is converted into steps and if the difference is greater CTPMinError, a flag STATE\_CTP\_ERROR. When controlling the step motor with speed sensor (CTP\_BASE 1), the position is controlled by him. The active edge of input clock controller stores the current value of steps. Further, at each turn checks how many steps shifted. When a mismatch CTPMinError a flag STATE\_CTP\_ERROR.

Parameters

	<i>id</i>	an identifier of device
in	<i>ctp_settings</i>	structure contains settings of control position

5.1.4.85 **result\_t XIMC\_API** set\_debug\_write ( **device\_t** id, **const debug\_write\_t** \* debug\_write )

Write data to firmware for debug purpose.

Parameters

	<i>id</i>	an identifier of device
in	<i>debug_write</i>	Debug data.

5.1.4.86 **result\_t XIMC\_API** set\_edges\_settings ( **device\_t** id, **const edges\_settings\_t** \* edges\_settings )

Set border and limit switches settings.

See Also

[set\\_edges\\_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>edges_settings</i>	edges settings, specify types of borders, motor behaviour and electrical behaviour of limit switches

5.1.4.87 **result\_t XIMC\_API** set\_encoder\_information ( **device\_t** id, **const encoder\_information\_t** \* encoder\_information )

Set encoder information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>encoder-information</i>	structure contains information about encoder

5.1.4.88 **result\_t XIMC\_API** set\_encoder\_settings ( **device\_t** id, **const encoder\_settings\_t** \* encoder\_settings )

Set encoder settings to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>encoder_settings</i>	structure contains encoder settings

5.1.4.89 **result\_t XIMC\_API** set\_engine\_settings ( **device\_t** id, **const engine\_settings\_t** \* engine\_settings )

Set engine settings.

This function send structure with set of engine settings to controller's memory. These settings specify motor shaft movement algorithm, list of limitations and rated characteristics. Use it when you change motor, encoder, positioner etc. Please note that wrong engine settings lead to device malfunction, can lead to irreversible damage of board.

See Also

[get\\_engine\\_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>engine_settings</i>	engine settings

#### 5.1.4.90 **result\_t XIMC\_API set\_engtype\_settings ( device\_t id, const entype\_settings\_t \* entype\_settings )**

Set engine type and driver type.

Parameters

	<i>id</i>	an identifier of device
in	<i>EngineType</i>	engine type
in	<i>DriverType</i>	driver type

#### 5.1.4.91 **result\_t XIMC\_API set\_extio\_settings ( device\_t id, const extio\_settings\_t \* extio\_settings )**

Set EXTIO settings.

This function writes a structure with a set of EXTIO settings to controller's memory. By default input event are signalled through rising front and output states are signalled by high logic state.

See Also

[get\\_extio\\_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>extio_settings</i>	EXTIO settings

#### 5.1.4.92 **result\_t XIMC\_API set\_feedback\_settings ( device\_t id, const feedback\_settings\_t \* feedback\_settings )**

Set feedback settings.

Parameters

	<i>id</i>	an identifier of device
in	<i>IPS</i>	number of encoder pulses per shaft revolution. Range: 1..65535
in	<i>FeedbackType</i>	type of feedback
in	<i>FeedbackFlags</i>	flags of feedback

#### 5.1.4.93 **result\_t XIMC\_API set\_gear\_information ( device\_t id, const gear\_information\_t \* gear\_information )**

Set gear information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>gear_information</i>	structure contains information about step gearhead

#### 5.1.4.94 **result\_t XIMC\_API set\_gear\_settings ( *device\_t id*, *const gear\_settings\_t \* gear\_settings* )**

Set gear settings to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>gear_settings</i>	structure contains step gearhead settings

#### 5.1.4.95 **result\_t XIMC\_API set\_hallsensor\_information ( *device\_t id*, *const hallsensor\_information\_t \* hallsensor\_information* )**

Set hall sensor information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>hallsensor_information</i>	structure contains information about hall sensor

#### 5.1.4.96 **result\_t XIMC\_API set\_hallsensor\_settings ( *device\_t id*, *const hallsensor\_settings\_t \* hallsensor\_settings* )**

Set hall sensor settings to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>hallsensor_settings</i>	structure contains hall sensor settings

#### 5.1.4.97 **result\_t XIMC\_API set\_home\_settings ( *device\_t id*, *const home\_settings\_t \* home\_settings* )**

Set home settings.

This function send structure with calibrating position settings to controller's memory.

See Also

[home\\_settings.t](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>home_settings</i>	calibrating position settings

5.1.4.98 **result\_t XIMC\_API** set\_joystick\_settings ( **device\_t id**, **const joystick\_settings\_t \* joystick\_settings** )

Set settings of joystick.

If joystick position is outside DeadZone limits from the central position a movement with speed, defined by the joystick DeadZone edge to 100% deviation, begins. Joystick positions inside DeadZone limits correspond to zero speed (soft stop of motion) and positions beyond Low and High limits correspond MaxSpeed [i] or -MaxSpeed [i] (see command SCTL), where i = 0 by default and can be changed with left/right buttons (see command SCTL). If next speed in list is zero (both integer and microstep parts), the button press is ignored. First speed in list shouldn't be zero. The DeadZone ranges are illustrated on the following picture. !/attachments/download/5563/range25p.png! The relationship between the deviation and the rate is exponential, allowing no switching speed combine high mobility and accuracy. The following picture illustrates this: !/attachments/download/3092/ExpJoystick.png! The nonlinearity parameter is adjustable. Setting it to zero makes deviation/speed relation linear.

Parameters

	<i>id</i>	an identifier of device
in	<i>joystick_settings</i>	structure contains joystick settings

5.1.4.99 **void XIMC\_API** set\_logging\_callback ( **logging\_callback\_t logging\_callback**, **void \* user\_data** )

Sets a logging callback.

Call resets a callback to default (stderr, syslog) if NULL passed.

Parameters

<i>logging_callback</i>	a callback for log messages
-------------------------	-----------------------------

5.1.4.100 **result\_t XIMC\_API** set\_motor\_information ( **device\_t id**, **const motor\_information\_t \* motor\_information** )

Set motor information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>motor-information</i>	structure contains motor information

5.1.4.101 **result\_t XIMC\_API** set\_motor\_settings ( **device\_t id**, **const motor\_settings\_t \* motor\_settings** )

Set motor settings to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>motor_settings</i>	structure contains motor information

5.1.4.102 **result\_t XIMC\_API** set\_move\_settings ( **device\_t** id, **const move\_settings\_t** \* move\_settings )

Set command setup movement (speed, acceleration, threshold and etc).

Parameters

	<i>id</i>	an identifier of device
in	<i>move_settings</i>	structure contains move settings: speed, acceleration, deceleration etc.

5.1.4.103 **result\_t XIMC\_API** set\_pid\_settings ( **device\_t** id, **const pid\_settings\_t** \* pid\_settings )

Set PID settings.

This function send structure with set of PID factors to controller's memory. These settings specify behaviour of PID routine for voltage. These factors are slightly different for different positioners. All boards are supplied with standart set of PID setting on controller's flash memory. Please use it for loading new PID settings when you change positioner. Please note that wrong PID settings lead to device malfunction.

See Also

[get\\_pid\\_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>pid_settings</i>	pid settings

5.1.4.104 **result\_t XIMC\_API** set\_position ( **device\_t** id, **const set\_position\_t** \* the\_set\_position )

Sets any position value in steps and micro for stepper motor and encoder steps of all engines.

It means, that changing main indicator of position.

Parameters

	<i>id</i>	an identifier of device
out	<i>position</i>	structure contains move settings: speed, acceleration, deceleration etc.

5.1.4.105 **result\_t XIMC\_API** set\_power\_settings ( **device\_t** id, **const power\_settings\_t** \* power\_settings )

Set settings of step motor power control.

Used with stepper motor only.

Parameters

	<i>id</i>	an identifier of device
in	<i>power_settings</i>	structure contains settings of step motor power control

5.1.4.106 **result\_t XIMC\_API** set\_secure\_settings ( **device\_t** id, **const secure\_settings\_t** \* secure\_settings )

Set protection settings.

Parameters

<i>id</i>	an identifier of device
<i>secure_settings</i>	structure with secure data

See Also

`status_t::flags`

#### 5.1.4.107 **result\_t XIMC\_API set\_serial\_number ( `device_t id, const serial_number_t * serial_number` )**

Write device serial number and hardware version to controller's flash memory.

Along with the new serial number and hardware version a "Key" is transmitted. The SN and hardware version are changed and saved when keys match. Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>serial</i>	number structure contains new serial number and secret key.

#### 5.1.4.108 **result\_t XIMC\_API set\_stage\_information ( `device_t id, const stage_information_t * stage_information` )**

Set stage information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>stage_-information</i>	structure contains stage information

#### 5.1.4.109 **result\_t XIMC\_API set\_stage\_name ( `device_t id, const stage_name_t * stage_name` )**

Write user stage name from EEPROM.

Parameters

	<i>id</i>	an identifier of device
in	<i>stage_name</i>	structure contains previously set user stage name

#### 5.1.4.110 **result\_t XIMC\_API set\_stage\_settings ( `device_t id, const stage_settings_t * stage_settings` )**

Set stage settings to EEPROM.

Can be used by manufacturer only

Parameters

	<i>id</i>	an identifier of device
in	<i>stage_settings</i>	structure contains stage settings

5.1.4.111 **result\_t XIMC\_API** set\_sync\_in\_settings ( **device\_t** id, **const sync\_in\_settings\_t** \* sync\_in\_settings )

Set input synchronization settings.

This function send structure with set of input synchronization settings, that specify behaviour of input synchronization, to controller's memory. All boards are supplied with standart set of these settings.

See Also

[get\\_sync\\_in\\_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>sync_in_settings</i>	synchronization settings

5.1.4.112 **result\_t XIMC\_API** set\_sync\_out\_settings ( **device\_t** id, **const sync\_out\_settings\_t** \* sync\_out\_settings )

Set output synchronization settings.

This function send structure with set of output synchronization settings, that specify behaviour of output synchronization, to controller's memory. All boards are supplied with standart set of these settings.

See Also

[get\\_sync\\_out\\_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>sync_out_settings</i>	synchronization settings

5.1.4.113 **result\_t XIMC\_API** set\_uart\_settings ( **device\_t** id, **const uart\_settings\_t** \* uart\_settings )

Set UART settings.

This function send structure with UART settings to controller's memory.

See Also

[uart\\_settings\\_t](#)

Parameters

	<i>Speed</i>	UART speed
in	<i>uart_settings</i>	UART settings

5.1.4.114 **result\_t XIMC\_API** write\_key ( **const char** \* name, **uint8\_t** \* key )

Write controller key.

Can be used by manufacturer only

Parameters

	<i>name</i>	a name of device
in	<i>key</i>	protection key. Range: 0..4294967295

5.1.4.115 **result\_t XIMC\_API** ximc\_fix\_usbser\_sys ( const char \* device\_name )

Fix for errors in Windows USB driver stack.

USB subsystem on Windows does not always work correctly. The following bugs are possible: the device cannot be opened at all, or the device can be opened and written to, but it will not respond with data. These errors can be fixed by device reconnection or removal-rescan in device manager. [ximc\\_fix\\_usbser\\_sys\(\)](#) is a shortcut function to do the remove-rescan process. You should call this function if libximc library cannot open the device which was not physically removed from the system or if the device does not respond.

5.1.4.116 void **XIMC\_API** ximc\_version ( char \* version )

Returns a library version.

Parameters

<i>version</i>	a buffer to hold a version string, 32 bytes is enough
----------------	---

# Index

A1Voltage  
    analog\_data\_t, 12

A1Voltage\_ADC  
    analog\_data\_t, 12

A2Voltage  
    analog\_data\_t, 12

A2Voltage\_ADC  
    analog\_data\_t, 12

ACurrent  
    analog\_data\_t, 12

ACurrent\_ADC  
    analog\_data\_t, 12

Accel  
    move\_settings\_calb\_t, 46  
    move\_settings\_t, 47

accessories\_settings\_t, 9  
    LimitSwitchesSettings, 10  
    MBRatedCurrent, 10  
    MBRatedVoltage, 10  
    MBSettings, 10  
    MBTorque, 10  
    MagneticBrakeInfo, 10  
    TSGrad, 10  
    TSMax, 10  
    TSMIn, 10  
    TSSettings, 10  
    TemperatureSensorInfo, 10

Accuracy  
    sync\_out\_settings\_calb\_t, 63  
    sync\_out\_settings\_t, 64

analog\_data\_t, 11  
    A1Voltage, 12  
    A1Voltage\_ADC, 12  
    A2Voltage, 12  
    A2Voltage\_ADC, 12  
    ACurrent, 12  
    ACurrent\_ADC, 12  
    B1Voltage, 12  
    B1Voltage\_ADC, 13  
    B2Voltage, 13  
    B2Voltage\_ADC, 13  
    BCurrent, 13  
    BCurrent\_ADC, 13  
    FullCurrent, 13  
    FullCurrent\_ADC, 13  
    Joy, 13  
    Joy\_ADC, 13  
    L, 13  
    L5, 13

L5\_ADC, 13

Pot, 14

R, 14

SupVoltage, 14

SupVoltage\_ADC, 14

Temp, 14

Temp\_ADC, 14

Antiplay  
    engine\_settings\_calb\_t, 28  
    engine\_settings\_t, 30

AntiplaySpeed  
    move\_settings\_calb\_t, 46  
    move\_settings\_t, 47

B1Voltage  
    analog\_data\_t, 12

B1Voltage\_ADC  
    analog\_data\_t, 13

B2Voltage  
    analog\_data\_t, 13

B2Voltage\_ADC  
    analog\_data\_t, 13

BCurrent  
    analog\_data\_t, 13

BCurrent\_ADC  
    analog\_data\_t, 13

BORDER\_IS\_ENCODER  
    ximc.h, 87

BORDER\_STOP\_LEFT  
    ximc.h, 87

BORDER\_STOP\_RIGHT  
    ximc.h, 87

BRAKE\_ENABLED  
    ximc.h, 87

BRAKE\_ENG\_PWROFF  
    ximc.h, 87

BorderFlags  
    edges\_settings\_calb\_t, 24  
    edges\_settings\_t, 25

brake\_settings\_t, 14  
    BrakeFlags, 15  
    t1, 15  
    t2, 15  
    t3, 15  
    t4, 15

BrakeFlags  
    brake\_settings\_t, 15

CONTROL\_MODE\_BITS  
    ximc.h, 87

CONTROL\_MODE\_JOY  
    ximc.h, 87  
CONTROL\_MODE\_LR  
    ximc.h, 87  
CONTROL\_MODE\_OFF  
    ximc.h, 88  
CTP\_ALARM\_ON\_ERROR  
    ximc.h, 88  
CTP\_BASE  
    ximc.h, 88  
CTP\_ENABLED  
    ximc.h, 88  
CTP\_ERROR\_CORRECTION  
    ximc.h, 88  
CTPFlags  
    ctp\_settings\_t, 21  
CTPMInError  
    ctp\_settings\_t, 21  
calibration\_t, 15  
chart\_data\_t, 16  
    DutyCycle, 16  
    Joy, 16  
    Pot, 16  
    WindingCurrentA, 17  
    WindingCurrentB, 17  
    WindingCurrentC, 17  
    WindingVoltageA, 17  
    WindingVoltageB, 17  
    WindingVoltageC, 17  
close\_device  
    ximc.h, 101  
ClutterTime  
    sync\_in\_settings\_calb\_t, 61  
    sync\_in\_settings\_t, 62  
CmdBufFreeSpace  
    status\_calb\_t, 57  
    status\_t, 59  
command\_add\_sync\_in\_action  
    ximc.h, 101  
command\_add\_sync\_in\_action\_calb\_t, 17  
    Position, 17  
    Time, 17  
command\_add\_sync\_in\_action\_t, 18  
    Time, 18  
    uPosition, 18  
command\_clear\_fram  
    ximc.h, 101  
command\_eeread\_settings  
    ximc.h, 102  
command\_eesave\_settings  
    ximc.h, 102  
command\_home  
    ximc.h, 102  
command\_homezero  
    ximc.h, 102  
command\_left  
    ximc.h, 103  
command\_loft  
    ximc.h, 103  
command\_move  
    ximc.h, 103  
command\_movr  
    ximc.h, 103  
command\_power\_off  
    ximc.h, 103  
command\_read\_settings  
    ximc.h, 104  
command\_reset  
    ximc.h, 104  
command\_right  
    ximc.h, 104  
command\_save\_settings  
    ximc.h, 104  
command\_sstp  
    ximc.h, 104  
command\_stop  
    ximc.h, 105  
command\_update\_firmware  
    ximc.h, 105  
command\_wait\_for\_stop  
    ximc.h, 105  
command\_zero  
    ximc.h, 105  
control\_settings\_calb\_t, 18  
    Flags, 19  
    MaxClickTime, 19  
    MaxSpeed, 19  
    Timeout, 19  
control\_settings\_t, 19  
    Flags, 20  
    MaxClickTime, 20  
    MaxSpeed, 20  
    Timeout, 20  
    uDeltaPosition, 20  
    uMaxSpeed, 20  
controller\_name\_t, 20  
    ControllerName, 21  
    CtrlFlags, 21  
ControllerName  
    controller\_name\_t, 21  
Criticallpwr  
    secure\_settings\_t, 50  
Criticalllusb  
    secure\_settings\_t, 50  
CriticalT  
    secure\_settings\_t, 50  
CriticalUpwr  
    secure\_settings\_t, 50  
CriticalUusb  
    secure\_settings\_t, 50  
ctp\_settings\_t, 21  
    CTPFlags, 21  
    CTPMInError, 21  
CtrlFlags  
    controller\_name\_t, 21  
CurPosition

status.calb.t, 57  
status.t, 59  
CurSpeed  
status.calb.t, 57  
status.t, 59  
CurT  
status.calb.t, 57  
status.t, 59  
CurrReductDelay  
power.settings.t, 49  
CurrentSetTime  
power.settings.t, 49  
  
DRIVER\_TYPE\_EXTERNAL  
ximc.h, 88  
DeadZone  
joystick.settings.t, 41  
debug.read.t, 22  
DebugData, 22  
debug.write.t, 22  
DebugData, 23  
DebugData  
debug.read.t, 22  
debug.write.t, 23  
Decel  
move.settings.calb.t, 46  
move.settings.t, 47  
DetentTorque  
motor.settings.t, 43  
device.information.t, 23  
Major, 23  
Minor, 23  
Release, 23  
device.network.information.t, 24  
DriverType  
entype.settings.t, 31  
DutyCycle  
chart\_data.t, 16  
  
EEPROM\_PRECEDENCE  
ximc.h, 88  
ENC\_STATE\_ABSENT  
ximc.h, 88  
ENC\_STATE\_MALFUNC  
ximc.h, 88  
ENC\_STATE\_OK  
ximc.h, 88  
ENC\_STATE\_REVERS  
ximc.h, 89  
ENC\_STATE\_UNKNOWN  
ximc.h, 89  
ENDER\_SW1\_ACTIVE\_LOW  
ximc.h, 89  
ENDER\_SW2\_ACTIVE\_LOW  
ximc.h, 89  
ENDER\_SWAP  
ximc.h, 89  
ENGINE\_ACCEL\_ON  
ximc.h, 89  
ENGINE\_ANTIPLAY  
ximc.h, 89  
ENGINE\_LIMIT\_CURR  
ximc.h, 89  
ENGINE\_LIMIT\_RPM  
ximc.h, 89  
ENGINE\_LIMIT\_VOLT  
ximc.h, 89  
ENGINE\_MAX\_SPEED  
ximc.h, 89  
ENGINE\_REVERSE  
ximc.h, 90  
ENGINE\_TYPE\_2DC  
ximc.h, 90  
ENGINE\_TYPE\_DC  
ximc.h, 90  
ENGINE\_TYPE\_NONE  
ximc.h, 90  
ENGINE\_TYPE\_STEP  
ximc.h, 90  
ENGINE\_TYPE\_TEST  
ximc.h, 90  
ENUMERATE\_PROBE  
ximc.h, 90  
EXTIO\_SETUP\_INVERT  
ximc.h, 90  
EXTIO\_SETUP\_OUTPUT  
ximc.h, 92  
EXTIOModeFlags  
extio.settings.t, 32  
EXTIOSetupFlags  
extio.settings.t, 32  
edges.settings.calb.t, 24  
BorderFlags, 24  
EnderFlags, 24  
LeftBorder, 24  
RightBorder, 24  
edges.settings.t, 25  
BorderFlags, 25  
EnderFlags, 25  
LeftBorder, 25  
RightBorder, 25  
uLeftBorder, 26  
uRightBorder, 26  
Efficiency  
gear.settings.t, 34  
EncPosition  
get\_position.calb.t, 35  
get\_position.t, 36  
set\_position.calb.t, 52  
set\_position.t, 53  
status.calb.t, 57  
status.t, 59  
EncSts  
status.calb.t, 57  
status.t, 59  
encoder.information.t, 26  
Manufacturer, 26

PartNumber, 26  
encoder\_settings\_t, 27  
EncoderSettings, 27  
MaxCurrentConsumption, 27  
MaxOperatingFrequency, 27  
SupplyVoltageMax, 27  
SupplyVoltageMin, 27  
EncoderSettings  
  encoder\_settings\_t, 27  
EnderFlags  
  edges\_settings\_calb\_t, 24  
  edges\_settings\_t, 25  
engine\_settings\_calb\_t, 28  
  Antiplay, 28  
  EngineFlags, 28  
  MicrostepMode, 28  
  NomCurrent, 28  
  NomSpeed, 28  
  NomVoltage, 28  
  StepsPerRev, 29  
engine\_settings\_t, 29  
  Antiplay, 30  
  EngineFlags, 30  
  MicrostepMode, 30  
  NomCurrent, 30  
  NomSpeed, 30  
  NomVoltage, 30  
  StepsPerRev, 30  
  uNomSpeed, 30  
EngineFlags  
  engine\_settings\_calb\_t, 28  
  engine\_settings\_t, 30  
EngineType  
  entype\_settings\_t, 31  
entype\_settings\_t, 30  
  DriverType, 31  
  EngineType, 31  
enumerate\_devices  
  ximc.h, 105  
ExpFactor  
  joystick\_settings\_t, 41  
extio\_settings\_t, 31  
  EXTIOModeFlags, 32  
  EXTIOSetupFlags, 32  
FEEDBACK\_EMF  
  ximc.h, 92  
FEEDBACK\_ENC\_REVERSE  
  ximc.h, 92  
FEEDBACK\_ENCODER  
  ximc.h, 92  
FEEDBACK\_ENCODERHALL  
  ximc.h, 92  
FEEDBACK\_NONE  
  ximc.h, 92  
FastHome  
  home\_settings\_calb\_t, 38  
  home\_settings\_t, 39  
feedback\_settings\_t, 32  
  FeedbackFlags, 32  
  FeedbackType, 32  
  HallSPR, 33  
  HallShift, 33  
  FeedbackFlags  
    feedback\_settings\_t, 32  
  FeedbackType  
    feedback\_settings\_t, 32  
Flags  
  control\_settings\_calb\_t, 19  
  control\_settings\_t, 20  
  secure\_settings\_t, 50  
  status\_calb\_t, 57  
  status\_t, 59  
  free\_enumerate\_devices  
    ximc.h, 106  
FullCurrent  
  analog\_data\_t, 13  
FullCurrent\_ADC  
  analog\_data\_t, 13  
GPIOFlags  
  status\_calb\_t, 57  
  status\_t, 59  
gear\_information\_t, 33  
  Manufacturer, 33  
  PartNumber, 33  
gear\_settings\_t, 33  
  Efficiency, 34  
  InputInertia, 34  
  MaxOutputBacklash, 34  
  RatedInputSpeed, 34  
  RatedInputTorque, 34  
  ReductionIn, 35  
  ReductionOut, 35  
get\_accessories\_settings  
  ximc.h, 106  
get\_analog\_data  
  ximc.h, 106  
get\_bootloader\_version  
  ximc.h, 106  
get\_brake\_settings  
  ximc.h, 107  
get\_chart\_data  
  ximc.h, 107  
get\_control\_settings  
  ximc.h, 107  
get\_controller\_name  
  ximc.h, 107  
get\_ctp\_settings  
  ximc.h, 107  
get\_debug\_read  
  ximc.h, 108  
get\_device\_count  
  ximc.h, 108  
get\_device\_information  
  ximc.h, 108  
get\_device\_name  
  ximc.h, 108

get\_edges\_settings  
    ximc.h, 109  
get\_encoder\_information  
    ximc.h, 109  
get\_encoder\_settings  
    ximc.h, 109  
get\_engine\_settings  
    ximc.h, 109  
get\_entype\_settings  
    ximc.h, 110  
get\_enumerate\_device\_controller\_name  
    ximc.h, 110  
get\_enumerate\_device\_information  
    ximc.h, 110  
get\_enumerate\_device\_network\_information  
    ximc.h, 110  
get\_enumerate\_device\_serial  
    ximc.h, 110  
get\_enumerate\_device\_stage\_name  
    ximc.h, 111  
get\_extio\_settings  
    ximc.h, 111  
get\_feedback\_settings  
    ximc.h, 111  
get\_firmware\_version  
    ximc.h, 111  
get\_gear\_information  
    ximc.h, 112  
get\_gear\_settings  
    ximc.h, 112  
get\_hallsensor\_information  
    ximc.h, 112  
get\_hallsensor\_settings  
    ximc.h, 112  
get\_home\_settings  
    ximc.h, 112  
get\_init\_random  
    ximc.h, 113  
get\_joystick\_settings  
    ximc.h, 113  
get\_motor\_information  
    ximc.h, 113  
get\_motor\_settings  
    ximc.h, 113  
get\_move\_settings  
    ximc.h, 114  
get\_pid\_settings  
    ximc.h, 114  
get\_position  
    ximc.h, 114  
get\_position\_calb\_t, 35  
    EncPosition, 35  
    Position, 35  
get\_position\_t, 35  
    EncPosition, 36  
get\_power\_settings  
    ximc.h, 114  
get\_secure\_settings  
    ximc.h, 114  
get\_serial\_number  
    ximc.h, 115  
get\_stage\_information  
    ximc.h, 115  
get\_stage\_name  
    ximc.h, 115  
get\_stage\_settings  
    ximc.h, 115  
get\_status  
    ximc.h, 115  
get\_status\_calb  
    ximc.h, 116  
get\_sync\_in\_settings  
    ximc.h, 116  
get\_sync\_out\_settings  
    ximc.h, 116  
get\_uart\_settings  
    ximc.h, 117  
goto\_firmware  
    ximc.h, 117  
  
H\_BRIDGE\_ALERT  
    ximc.h, 92  
HOME\_DIR\_FIRST  
    ximc.h, 92  
HOME\_DIR\_SECOND  
    ximc.h, 92  
HOME\_HALF\_MV  
    ximc.h, 92  
HOME\_MV\_SEC\_EN  
    ximc.h, 93  
HOME\_STOP\_FIRST\_LIM  
    ximc.h, 93  
HOME\_STOP\_FIRST\_REV  
    ximc.h, 93  
HOME\_STOP\_FIRST\_SYN  
    ximc.h, 93  
HallSPR  
    feedback\_settings\_t, 33  
HallShift  
    feedback\_settings\_t, 33  
hallsensor\_information\_t, 36  
    Manufacturer, 36  
    PartNumber, 36  
hallsensor\_settings\_t, 36  
    MaxCurrentConsumption, 37  
    MaxOperatingFrequency, 37  
    SupplyVoltageMax, 37  
    SupplyVoltageMin, 37  
has\_firmware  
    ximc.h, 117  
HoldCurrent  
    power\_settings\_t, 49  
home\_settings\_calb\_t, 37  
    FastHome, 38  
    HomeDelta, 38  
    HomeFlags, 38  
    SlowHome, 38

home\_settings\_t, 38  
FastHome, 39  
HomeDelta, 39  
HomeFlags, 39  
SlowHome, 39  
uFastHome, 39  
uHomeDelta, 39  
uSlowHome, 39  
HomeDelta  
    home\_settings\_calb\_t, 38  
    home\_settings\_t, 39  
HomeFlags  
    home\_settings\_calb\_t, 38  
    home\_settings\_t, 39  
HorizontalLoadCapacity  
    stage\_settings\_t, 55  
  
init\_random\_t, 39  
    key, 40  
InputInertia  
    gear\_settings\_t, 34  
lpwr  
    status\_calb\_t, 57  
    status\_t, 60  
lusb  
    status\_calb\_t, 57  
    status\_t, 60  
  
JOY\_REVERSE  
    ximc.h, 93  
Joy  
    analog\_data\_t, 13  
    chart\_data\_t, 16  
Joy\_ADC  
    analog\_data\_t, 13  
JoyCenter  
    joystick\_settings\_t, 41  
JoyFlags  
    joystick\_settings\_t, 41  
JoyHighEnd  
    joystick\_settings\_t, 41  
JoyLowEnd  
    joystick\_settings\_t, 41  
joystick\_settings\_t, 40  
    DeadZone, 41  
    ExpFactor, 41  
    JoyCenter, 41  
    JoyFlags, 41  
    JoyHighEnd, 41  
    JoyLowEnd, 41  
  
Key  
    serial\_number\_t, 51  
key  
    init\_random\_t, 40  
  
L  
    analog\_data\_t, 13  
L5  
    analog\_data\_t, 13  
    analog\_data\_t, 13  
L5\_ADC  
    analog\_data\_t, 13  
LOW\_UPWR\_PROTECTION  
    ximc.h, 93  
LeadScrewPitch  
    stage\_settings\_t, 55  
LeftBorder  
    edges\_settings\_calb\_t, 24  
    edges\_settings\_t, 25  
LimitSwitchesSettings  
    accessories\_settings\_t, 10  
logging\_callback\_stderr\_narrow  
    ximc.h, 117  
logging\_callback\_stderr\_wide  
    ximc.h, 117  
logging\_callback\_t  
    ximc.h, 101  
LowUpwrOff  
    secure\_settings\_t, 50  
  
MBRatedCurrent  
    accessories\_settings\_t, 10  
MBRatedVoltage  
    accessories\_settings\_t, 10  
MBSettings  
    accessories\_settings\_t, 10  
MBTorque  
    accessories\_settings\_t, 10  
MICROSTEP\_MODE\_FULL  
    ximc.h, 94  
MOVE\_STATE\_ANTIPLAY  
    ximc.h, 94  
MOVE\_STATE\_MOVING  
    ximc.h, 94  
MVCMD\_ERROR  
    ximc.h, 94  
MVCMD\_HOME  
    ximc.h, 95  
MVCMD\_LEFT  
    ximc.h, 95  
MVCMD\_LOFT  
    ximc.h, 95  
MVCMD\_MOVE  
    ximc.h, 95  
MVCMD\_MOVR  
    ximc.h, 95  
MVCMD\_NAME\_BITS  
    ximc.h, 95  
MVCMD\_RIGHT  
    ximc.h, 95  
MVCMD\_RUNNING  
    ximc.h, 95  
MVCMD\_SSTP  
    ximc.h, 95  
MVCMD\_STOP  
    ximc.h, 95  
MVCMD\_UKNWN  
    ximc.h, 95

MagneticBrakeInfo  
  accessories\_settings\_t, 10

Major  
  device\_information\_t, 23  
  serial\_number\_t, 51

Manufacturer  
  encoder\_information\_t, 26  
  gear\_information\_t, 33  
  hallsensor\_information\_t, 36  
  motor\_information\_t, 42  
  stage\_information\_t, 53

MaxClickTime  
  control\_settings\_calb\_t, 19  
  control\_settings\_t, 20

MaxCurrent  
  motor\_settings\_t, 43

MaxCurrentConsumption  
  encoder\_settings\_t, 27  
  hallsensor\_settings\_t, 37  
  stage\_settings\_t, 55

MaxCurrentTime  
  motor\_settings\_t, 43

MaxOperatingFrequency  
  encoder\_settings\_t, 27  
  hallsensor\_settings\_t, 37

MaxOutputBacklash  
  gear\_settings\_t, 34

MaxSpeed  
  control\_settings\_calb\_t, 19  
  control\_settings\_t, 20  
  motor\_settings\_t, 44  
  stage\_settings\_t, 55

MechanicalTimeConstant  
  motor\_settings\_t, 44

MicrostepMode  
  engine\_settings\_calb\_t, 28  
  engine\_settings\_t, 30

MinimumUusb  
  secure\_settings\_t, 50

Minor  
  device\_information\_t, 23  
  serial\_number\_t, 51

motor\_information\_t, 41  
  Manufacturer, 42  
  PartNumber, 42

motor\_settings\_t, 42  
  DetentTorque, 43  
  MaxCurrent, 43  
  MaxCurrentTime, 43  
  MaxSpeed, 44  
  MechanicalTimeConstant, 44  
  MotorType, 44  
  NoLoadCurrent, 44  
  NoLoadSpeed, 44  
  NominalCurrent, 44  
  NominalPower, 44  
  NominalSpeed, 44  
  NominalTorque, 44

NominalVoltage, 45  
  Phases, 45  
  Poles, 45  
  RotorInertia, 45  
  SpeedConstant, 45  
  SpeedTorqueGradient, 45  
  StallTorque, 45  
  TorqueConstant, 45  
  WindingInductance, 45  
  WindingResistance, 46

MotorType  
  motor\_settings\_t, 44

move\_settings\_calb\_t, 46  
  Accel, 46  
  AntiplaySpeed, 46  
  Decel, 46  
  Speed, 46

move\_settings\_t, 46  
  Accel, 47  
  AntiplaySpeed, 47  
  Decel, 47  
  Speed, 47  
  uAntiplaySpeed, 47  
  uSpeed, 47

MoveSts  
  status\_calb\_t, 57  
  status\_t, 60

msec\_sleep  
  ximc.h, 118

MvCmdSts  
  status\_calb\_t, 57  
  status\_t, 60

NoLoadCurrent  
  motor\_settings\_t, 44

NoLoadSpeed  
  motor\_settings\_t, 44

NomCurrent  
  engine\_settings\_calb\_t, 28  
  engine\_settings\_t, 30

NomSpeed  
  engine\_settings\_calb\_t, 28  
  engine\_settings\_t, 30

NomVoltage  
  engine\_settings\_calb\_t, 28  
  engine\_settings\_t, 30

NominalCurrent  
  motor\_settings\_t, 44

NominalPower  
  motor\_settings\_t, 44

NominalSpeed  
  motor\_settings\_t, 44

NominalTorque  
  motor\_settings\_t, 44

NominalVoltage  
  motor\_settings\_t, 45

open\_device  
  ximc.h, 118

POWER\_OFF\_ENABLED  
  ximc.h, 95  
POWER\_REDUCED\_ENABLED  
  ximc.h, 96  
POWER\_SMOOTH\_CURRENT  
  ximc.h, 96  
PWR\_STATE\_MAX  
  ximc.h, 96  
PWR\_STATE\_NORM  
  ximc.h, 96  
PWR\_STATE\_OFF  
  ximc.h, 96  
PWR\_STATE\_REDUCED  
  ximc.h, 96  
PWR\_STATE\_UNKNOWN  
  ximc.h, 96  
PWRSts  
  status\_calb.t, 57  
  status.t, 60  
PartNumber  
  encoder.information.t, 26  
  gear.information.t, 33  
  hallsensor.information.t, 36  
  motor.information.t, 42  
  stage.information.t, 53  
Phases  
  motor.settings.t, 45  
pid\_settings.t, 48  
Poles  
  motor.settings.t, 45  
PosFlags  
  set\_position\_calb.t, 52  
  set\_position.t, 53  
Position  
  command\_add\_sync\_in\_action\_calb.t, 17  
  get\_position\_calb.t, 35  
  set\_position\_calb.t, 52  
  sync\_in\_settings\_calb.t, 61  
PositionerName  
  stage\_name.t, 54  
Pot  
  analog\_data.t, 14  
  chart\_data.t, 16  
power\_settings.t, 48  
  CurrReductDelay, 49  
  CurrentSetTime, 49  
  HoldCurrent, 49  
  PowerFlags, 49  
  PowerOffDelay, 49  
PowerFlags  
  power\_settings.t, 49  
PowerOffDelay  
  power\_settings.t, 49  
probe\_device  
  ximc.h, 118  
  
R  
  analog\_data.t, 14  
REV\_SENS\_INV

  ximc.h, 96  
RatedInputSpeed  
  gear\_settings.t, 34  
RatedInputTorque  
  gear\_settings.t, 34  
ReductionIn  
  gear\_settings.t, 35  
ReductionOut  
  gear\_settings.t, 35  
Release  
  device.information.t, 23  
  serial\_number.t, 51  
RightBorder  
  edges\_settings.calb.t, 24  
  edges\_settings.t, 25  
RotorInertia  
  motor\_settings.t, 45  
  
SN  
  serial\_number.t, 51  
STATE\_ALARM  
  ximc.h, 96  
STATE\_BRAKE  
  ximc.h, 97  
STATE\_BUTTON\_LEFT  
  ximc.h, 97  
STATE\_BUTTON\_RIGHT  
  ximc.h, 97  
STATE\_CONTR  
  ximc.h, 97  
STATE\_CTP\_ERROR  
  ximc.h, 97  
STATE\_DIG\_SIGNAL  
  ximc.h, 97  
STATE\_ENC\_A  
  ximc.h, 97  
STATE\_ENC\_B  
  ximc.h, 97  
STATE\_ERRC  
  ximc.h, 97  
STATE\_ERRD  
  ximc.h, 97  
STATE.ERRV  
  ximc.h, 98  
STATE\_GPIO\_LEVEL  
  ximc.h, 98  
STATE\_GPIO\_PINOUT  
  ximc.h, 98  
STATE\_HALL\_A  
  ximc.h, 98  
STATE\_HALL\_B  
  ximc.h, 98  
STATE\_HALL\_C  
  ximc.h, 98  
STATE\_LEFT\_EDGE  
  ximc.h, 98  
STATE\_POWER\_OVERHEAT  
  ximc.h, 99  
STATE\_REV\_SENSOR

ximc.h, 99  
STATE\_RIGHT\_EDGE  
    ximc.h, 99  
STATE\_SECUR  
    ximc.h, 99  
STATE\_SYNC\_INPUT  
    ximc.h, 99  
STATE\_SYNC\_OUTPUT  
    ximc.h, 99  
SYNCIN\_ENABLED  
    ximc.h, 99  
SYNCIN\_GOTOPOSITION  
    ximc.h, 99  
SYNCIN\_INVERT  
    ximc.h, 99  
SYNCOUP\_ENABLED  
    ximc.h, 99  
SYNCOUP\_IN\_STEPS  
    ximc.h, 99  
SYNCOUP\_INVERT  
    ximc.h, 99  
SYNCOUP\_ONPERIOD  
    ximc.h, 100  
SYNCOUP\_ONSTART  
    ximc.h, 100  
SYNCOUP\_ONSTOP  
    ximc.h, 100  
SYNCOUP\_STATE  
    ximc.h, 100  
secure\_settings\_t, 49  
    CriticallyPwr, 50  
    CriticallyUsb, 50  
    CriticalT, 50  
    CriticalUpwr, 50  
    CriticalUusb, 50  
    Flags, 50  
    LowUpwrOff, 50  
    MinimumUusb, 50  
serial\_number\_t, 51  
    Key, 51  
    Major, 51  
    Minor, 51  
    Release, 51  
    SN, 51  
service\_command\_updf  
    ximc.h, 118  
set\_accessories\_settings  
    ximc.h, 118  
set\_brake\_settings  
    ximc.h, 119  
set\_control\_settings  
    ximc.h, 119  
set\_controller\_name  
    ximc.h, 119  
set\_ctp\_settings  
    ximc.h, 119  
set\_debug\_write  
    ximc.h, 120  
set\_edges\_settings  
    ximc.h, 120  
set\_encoder\_information  
    ximc.h, 120  
set\_encoder\_settings  
    ximc.h, 120  
set\_engine\_settings  
    ximc.h, 120  
set\_entype\_settings  
    ximc.h, 121  
set\_extio\_settings  
    ximc.h, 121  
set\_feedback\_settings  
    ximc.h, 121  
set\_gear\_information  
    ximc.h, 121  
set\_gear\_settings  
    ximc.h, 122  
set\_hallsensor\_information  
    ximc.h, 122  
set\_hallsensor\_settings  
    ximc.h, 122  
set\_home\_settings  
    ximc.h, 122  
set\_joystick\_settings  
    ximc.h, 123  
set\_logging\_callback  
    ximc.h, 123  
set\_motor\_information  
    ximc.h, 123  
set\_motor\_settings  
    ximc.h, 123  
set\_move\_settings  
    ximc.h, 123  
set\_pid\_settings  
    ximc.h, 124  
set\_position  
    ximc.h, 124  
set\_position\_calb\_t, 52  
    EncPosition, 52  
    PosFlags, 52  
    Position, 52  
set\_position\_t, 52  
    EncPosition, 53  
    PosFlags, 53  
set\_power\_settings  
    ximc.h, 124  
set\_secure\_settings  
    ximc.h, 124  
set\_serial\_number  
    ximc.h, 125  
set\_stage\_information  
    ximc.h, 125  
set\_stage\_name  
    ximc.h, 125  
set\_stage\_settings  
    ximc.h, 125  
set\_sync\_in\_settings

ximc.h, 125  
set\_sync\_out.settings  
    ximc.h, 126  
set\_uart\_settings  
    ximc.h, 126  
SlowHome  
    home\_settings\_calb\_t, 38  
    home\_settings\_t, 39  
Speed  
    move\_settings\_calb\_t, 46  
    move\_settings\_t, 47  
    sync\_in\_settings\_calb\_t, 61  
    sync\_in\_settings\_t, 62  
SpeedConstant  
    motor\_settings\_t, 45  
SpeedTorqueGradient  
    motor\_settings\_t, 45  
stage.information.t, 53  
    Manufacturer, 53  
    PartNumber, 53  
stage.name.t, 53  
    PositionerName, 54  
stage.settings.t, 54  
    HorizontalLoadCapacity, 55  
    LeadScrewPitch, 55  
    MaxCurrentConsumption, 55  
    MaxSpeed, 55  
    SupplyVoltageMax, 55  
    SupplyVoltageMin, 55  
    TravelRange, 55  
    Units, 55  
    VerticalLoadCapacity, 56  
StallTorque  
    motor\_settings\_t, 45  
status.calb.t, 56  
    CmdBufFreeSpace, 57  
    CurPosition, 57  
    CurSpeed, 57  
    CurT, 57  
    EncPosition, 57  
    EncSts, 57  
    Flags, 57  
    GPIOFlags, 57  
    Ipwr, 57  
    Iusb, 57  
    MoveSts, 57  
    MvCmdsts, 57  
    PWRsts, 57  
    Upwr, 58  
    Uusb, 58  
    Windsts, 58  
status.t, 58  
    CmdBufFreeSpace, 59  
    CurPosition, 59  
    CurSpeed, 59  
    CurT, 59  
    EncPosition, 59  
    EncSts, 59  
Flags, 59  
GPIOFlags, 59  
Ipwr, 60  
Iusb, 60  
Movests, 60  
MvCmdsts, 60  
PWRsts, 60  
uCurPosition, 60  
uCurSpeed, 60  
Upwr, 60  
Uusb, 60  
Windsts, 60  
StepsPerRev  
    engine\_settings\_calb\_t, 29  
    engine\_settings\_t, 30  
SupVoltage  
    analog\_data.t, 14  
SupVoltage\_ADC  
    analog\_data.t, 14  
SupplyVoltageMax  
    encoder\_settings\_t, 27  
    hallsensor\_settings\_t, 37  
    stage\_settings\_t, 55  
SupplyVoltageMin  
    encoder\_settings\_t, 27  
    hallsensor\_settings\_t, 37  
    stage\_settings\_t, 55  
sync\_in\_settings\_calb.t, 61  
    ClutterTime, 61  
    Position, 61  
    Speed, 61  
    SyncInFlags, 61  
sync\_in\_settings.t, 61  
    ClutterTime, 62  
    Speed, 62  
    SyncInFlags, 62  
    uPosition, 62  
    uSpeed, 62  
sync\_out.settings.calb.t, 62  
    Accuracy, 63  
    SyncOutFlags, 63  
    SyncOutPeriod, 63  
    SyncOutPulseSteps, 63  
sync\_out.settings.t, 63  
    Accuracy, 64  
    SyncOutFlags, 64  
    SyncOutPeriod, 64  
    SyncOutPulseSteps, 64  
    uAccuracy, 64  
SyncInFlags  
    sync\_in\_settings\_calb\_t, 61  
    sync\_in\_settings\_t, 62  
SyncOutFlags  
    sync\_out\_settings\_calb\_t, 63  
    sync\_out\_settings\_t, 64  
SyncOutPeriod  
    sync\_out\_settings\_calb\_t, 63  
    sync\_out\_settings\_t, 64

SyncOutPulseSteps  
    sync\_out\_settings\_calb\_t, 63  
    sync\_out\_settings\_t, 64

t1  
    brake\_settings\_t, 15

t2  
    brake\_settings\_t, 15

t3  
    brake\_settings\_t, 15

t4  
    brake\_settings\_t, 15

TSGrad  
    accessories\_settings\_t, 10

TSMax  
    accessories\_settings\_t, 10

TSMin  
    accessories\_settings\_t, 10

TSSettings  
    accessories\_settings\_t, 10

Temp  
    analog\_data\_t, 14

Temp\_ADC  
    analog\_data\_t, 14

TemperatureSensorInfo  
    accessories\_settings\_t, 10

Time  
    command\_add\_sync\_in\_action\_calb\_t, 17  
    command\_add\_sync\_in\_action\_t, 18

Timeout  
    control\_settings\_calb\_t, 19  
    control\_settings\_t, 20

TorqueConstant  
    motor\_settings\_t, 45

TravelRange  
    stage\_settings\_t, 55

UART\_PARITY\_BITS  
    ximc.h, 100

UARTSetupFlags  
    uart\_settings\_t, 65

uAccuracy  
    sync\_out\_settings\_t, 64

uAntiplaySpeed  
    move\_settings\_t, 47

uCurPosition  
    status\_t, 60

uCurSpeed  
    status\_t, 60

uDeltaPosition  
    control\_settings\_t, 20

uFastHome  
    home\_settings\_t, 39

uHomeDelta  
    home\_settings\_t, 39

uLeftBorder  
    edges\_settings\_t, 26

uMaxSpeed  
    control\_settings\_t, 20

uNomSpeed  
    engine\_settings\_t, 30

uPosition  
    command\_add\_sync\_in\_action\_t, 18  
    sync\_in\_settings\_t, 62

uRightBorder  
    edges\_settings\_t, 26

uSlowHome  
    home\_settings\_t, 39

uSpeed  
    move\_settings\_t, 47  
    sync\_in\_settings\_t, 62

uart\_settings\_t, 64  
    UARTSetupFlags, 65

Units  
    stage\_settings\_t, 55

Upwr  
    status\_calb\_t, 58  
    status\_t, 60

Uusb  
    status\_calb\_t, 58  
    status\_t, 60

VerticalLoadCapacity  
    stage\_settings\_t, 56

WIND\_A\_STATE\_ABSENT  
    ximc.h, 100

WIND\_A\_STATE\_OK  
    ximc.h, 100

WIND\_B\_STATE\_ABSENT  
    ximc.h, 100

WIND\_B\_STATE\_OK  
    ximc.h, 100

WindSts  
    status\_calb\_t, 58  
    status\_t, 60

WindingCurrentA  
    chart\_data\_t, 17

WindingCurrentB  
    chart\_data\_t, 17

WindingCurrentC  
    chart\_data\_t, 17

WindingInductance  
    motor\_settings\_t, 45

WindingResistance  
    motor\_settings\_t, 46

WindingVoltageA  
    chart\_data\_t, 17

WindingVoltageB  
    chart\_data\_t, 17

WindingVoltageC  
    chart\_data\_t, 17

write\_key  
    ximc.h, 126

XIMC\_API  
    ximc.h, 101

ximc.h, 66

BORDER\_IS\_ENCODER, 87  
BORDER\_STOP\_LEFT, 87  
BORDER\_STOP\_RIGHT, 87  
BRAKE\_ENABLED, 87  
BRAKE\_ENG\_PWROFF, 87  
CONTROL\_MODE\_BITS, 87  
CONTROL\_MODE\_JOY, 87  
CONTROL\_MODE\_LR, 87  
CONTROL\_MODE\_OFF, 88  
CTP\_ALARM\_ON\_ERROR, 88  
CTP\_BASE, 88  
CTP\_ENABLED, 88  
close\_device, 101  
command\_add\_sync\_in\_action, 101  
command\_clear\_fram, 101  
command\_eeread\_settings, 102  
command\_eesave\_settings, 102  
command\_home, 102  
command\_homezero, 102  
command\_left, 103  
command\_loft, 103  
command\_move, 103  
command\_movr, 103  
command\_power\_off, 103  
command\_read\_settings, 104  
command\_reset, 104  
command\_right, 104  
command\_save\_settings, 104  
command\_sstp, 104  
command\_stop, 105  
command\_update\_firmware, 105  
command\_wait\_for\_stop, 105  
command\_zero, 105  
EEPROM\_PRECEDENCE, 88  
ENC\_STATE\_ABSENT, 88  
ENC\_STATE\_MALFUNC, 88  
ENC\_STATE\_OK, 88  
ENC\_STATE\_REVERS, 89  
ENC\_STATE\_UNKNOWN, 89  
ENDER\_SWAP, 89  
ENGINE\_ACCEL\_ON, 89  
ENGINE\_ANTIPLAY, 89  
ENGINE\_LIMIT\_CURR, 89  
ENGINE\_LIMIT\_RPM, 89  
ENGINE\_LIMIT\_VOLT, 89  
ENGINE\_MAX\_SPEED, 89  
ENGINE\_REVERSE, 90  
ENGINE\_TYPE\_2DC, 90  
ENGINE\_TYPE\_DC, 90  
ENGINE\_TYPE\_NONE, 90  
ENGINE\_TYPE\_STEP, 90  
ENGINE\_TYPE\_TEST, 90  
ENUMERATE\_PROBE, 90  
EXTIO\_SETUP\_INVERT, 90  
EXTIO\_SETUP\_OUTPUT, 92  
enumerate\_devices, 105  
FEEDBACK\_EMF, 92  
FEEDBACK\_ENCODER, 92  
FEEDBACK\_ENCODERHALL, 92  
FEEDBACK\_NONE, 92  
free\_enumerate\_devices, 106  
get\_accessories\_settings, 106  
get\_analog\_data, 106  
get\_bootloader\_version, 106  
get\_brake\_settings, 107  
get\_chart\_data, 107  
get\_control\_settings, 107  
get\_controller\_name, 107  
get\_ctp\_settings, 107  
get\_debug\_read, 108  
get\_device\_count, 108  
get\_device\_information, 108  
get\_device\_name, 108  
get\_edges\_settings, 109  
get\_encoder\_information, 109  
get\_encoder\_settings, 109  
get\_engine\_settings, 109  
get\_entype\_settings, 110  
get\_enumerate\_device\_controller\_name, 110  
get\_enumerate\_device\_information, 110  
get\_enumerate\_device\_network\_information, 110  
get\_enumerate\_device\_serial, 110  
get\_enumerate\_device\_stage\_name, 111  
get\_extio\_settings, 111  
get\_feedback\_settings, 111  
get\_firmware\_version, 111  
get\_gear\_information, 112  
get\_gear\_settings, 112  
get\_hallsensor\_information, 112  
get\_hallsensor\_settings, 112  
get\_home\_settings, 112  
get\_init\_random, 113  
get\_joystick\_settings, 113  
get\_motor\_information, 113  
get\_motor\_settings, 113  
get\_move\_settings, 114  
get\_pid\_settings, 114  
get\_position, 114  
get\_power\_settings, 114  
get\_secure\_settings, 114  
get\_serial\_number, 115  
get\_stage\_information, 115  
get\_stage\_name, 115  
get\_stage\_settings, 115  
get\_status, 115  
get\_status\_calb, 116  
get\_sync\_in\_settings, 116  
get\_sync\_out\_settings, 116  
get\_uart\_settings, 117  
goto\_firmware, 117  
H\_BRIDGE\_ALERT, 92  
HOME\_DIR\_FIRST, 92  
HOME\_DIR\_SECOND, 92  
HOME\_HALF\_MV, 92  
HOME\_MV\_SEC\_EN, 93  
has\_firmware, 117

JOY.REVERSE, 93  
LOW\_UPWR\_PROTECTION, 93  
logging\_callback\_stderr\_narrow, 117  
logging\_callback\_stderr\_wide, 117  
logging\_callback\_t, 101  
MICROSTEP\_MODE\_FULL, 94  
MOVE\_STATE\_ANTIPLAY, 94  
MOVE\_STATE\_MOVING, 94  
MVCMD\_ERROR, 94  
MVCMD\_HOME, 95  
MVCMD\_LEFT, 95  
MVCMD\_LOFT, 95  
MVCMD\_MOVE, 95  
MVCMD\_MOVR, 95  
MVCMD\_NAME\_BITS, 95  
MVCMD\_RIGHT, 95  
MVCMD\_RUNNING, 95  
MVCMD\_SSTP, 95  
MVCMD\_STOP, 95  
MVCMD\_UKNWN, 95  
msec\_sleep, 118  
open\_device, 118  
POWER\_OFF\_ENABLED, 95  
PWR\_STATE\_MAX, 96  
PWR\_STATE\_NORM, 96  
PWR\_STATE\_OFF, 96  
PWR\_STATE\_REDUCT, 96  
PWR\_STATE\_UNKNOWN, 96  
probe\_device, 118  
REV\_SENS\_INV, 96  
STATE\_ALARM, 96  
STATE\_BRAKE, 97  
STATE\_BUTTON\_LEFT, 97  
STATE\_BUTTON\_RIGHT, 97  
STATE CONTR, 97  
STATE\_CTP\_ERROR, 97  
STATE\_DIG\_SIGNAL, 97  
STATE\_ENC\_A, 97  
STATE\_ENC\_B, 97  
STATE\_ERRC, 97  
STATE\_ERRD, 97  
STATE\_ERRV, 98  
STATE\_GPIO\_LEVEL, 98  
STATE\_GPIO\_PINOUT, 98  
STATE\_HALL\_A, 98  
STATE\_HALL\_B, 98  
STATE\_HALL\_C, 98  
STATE\_LEFT\_EDGE, 98  
STATE\_REV\_SENSOR, 99  
STATE\_RIGHT\_EDGE, 99  
STATE\_SECUR, 99  
STATE\_SYNC\_INPUT, 99  
STATE\_SYNC\_OUTPUT, 99  
SYNCIN\_ENABLED, 99  
SYNCIN\_GOTOPOSITION, 99  
SYNCIN\_INVERT, 99  
SYNCOUT\_ENABLED, 99  
SYNCOUT\_IN\_STEPS, 99  
SYNCOUT\_INVERT, 99  
SYNCOUT\_ONPERIOD, 100  
SYNCOUT\_ONSTART, 100  
SYNCOUT\_ONSTOP, 100  
SYNCOUT\_STATE, 100  
service\_command\_updf, 118  
set\_accessories\_settings, 118  
set\_brake\_settings, 119  
set\_control\_settings, 119  
set\_controller\_name, 119  
set\_ctp\_settings, 119  
set\_debug\_write, 120  
set\_edges\_settings, 120  
set\_encoder\_information, 120  
set\_encoder\_settings, 120  
set\_engine\_settings, 120  
set\_entype\_settings, 121  
set\_extio\_settings, 121  
set\_feedback\_settings, 121  
set\_gear\_information, 121  
set\_gear\_settings, 122  
set\_hallsensor\_information, 122  
set\_hallsensor\_settings, 122  
set\_home\_settings, 122  
set\_joystick\_settings, 123  
set\_logging\_callback, 123  
set\_motor\_information, 123  
set\_motor\_settings, 123  
set\_move\_settings, 123  
set\_pid\_settings, 124  
set\_position, 124  
set\_power\_settings, 124  
set\_secure\_settings, 124  
set\_serial\_number, 125  
set\_stage\_information, 125  
set\_stage\_name, 125  
set\_stage\_settings, 125  
set\_sync\_in\_settings, 125  
set\_sync\_out\_settings, 126  
set\_uart\_settings, 126  
UART\_PARITY\_BITS, 100  
WIND\_A\_STATE\_OK, 100  
WIND\_B\_STATE\_OK, 100  
write\_key, 126  
XIMC\_API, 101  
ximc\_fix\_usbser\_sys, 127  
ximc\_version, 127  
ximc\_fix\_usbser\_sys  
    ximc.h, 127  
ximc\_version  
    ximc.h, 127