

libximc

2.2.1

Generated by Doxygen 1.8.1

Tue Nov 19 2013 18:04:30

Contents

1	Introduction	1
1.1	About	1
1.2	System requirements	1
1.2.1	For rebuilding library	1
1.2.2	For using library	2
2	How to rebuild library	3
2.1	Building on generic UNIX	3
2.2	Building on debian-based linux systems	3
2.3	Building on redhat-based linux systems	3
2.4	Building on FreeBSD	4
2.5	Buliding on Mac OS X	4
2.6	Buliding on Windows	4
2.7	Source code access	4
3	How to use with...	5
3.1	Usage with C	5
3.1.1	Visual C++	5
3.1.2	MinGW	5
3.1.3	C++ Builder	5
3.1.4	XCode	6
3.1.5	GCC	6
3.2	.NET	6
3.3	Delphi	6
3.4	MATLAB	6
4	Data Structure Documentation	7
4.1	accessories_settings_t Struct Reference	7
4.1.1	Detailed Description	7
4.1.2	Field Documentation	8
4.1.2.1	MBRatedCurrent	8
4.1.2.2	MBRatedVoltage	8

4.1.2.3	MBTorque	8
4.1.2.4	TSGrad	8
4.2	add_sync.in.action.calb.t Struct Reference	8
4.3	add_sync.in.action.t Struct Reference	8
4.3.1	Detailed Description	9
4.3.2	Field Documentation	9
4.3.2.1	Speed	9
4.3.2.2	uPosition	9
4.3.2.3	uSpeed	9
4.4	analog.data.t Struct Reference	9
4.4.1	Detailed Description	10
4.5	brake_settings.t Struct Reference	11
4.5.1	Detailed Description	11
4.5.2	Field Documentation	11
4.5.2.1	t1	11
4.5.2.2	t2	11
4.5.2.3	t3	11
4.5.2.4	t4	11
4.6	calibration.t Struct Reference	12
4.6.1	Detailed Description	12
4.7	chart.data.t Struct Reference	12
4.7.1	Detailed Description	12
4.8	control_settings.calb.t Struct Reference	13
4.8.1	Field Documentation	13
4.8.1.1	MaxClickTime	13
4.8.1.2	Timeout	13
4.9	control_settings.t Struct Reference	13
4.9.1	Detailed Description	14
4.9.2	Field Documentation	14
4.9.2.1	MaxClickTime	14
4.9.2.2	MaxSpeed	14
4.9.2.3	Timeout	14
4.9.2.4	uDeltaPosition	14
4.9.2.5	uMaxSpeed	14
4.10	controller_name.t Struct Reference	14
4.10.1	Detailed Description	15
4.10.2	Field Documentation	15
4.10.2.1	ControllerName	15
4.11	ctp_settings.t Struct Reference	15
4.11.1	Detailed Description	15

4.11.2 Field Documentation	16
4.11.2.1 CTPMinError	16
4.12 debug_read_t Struct Reference	16
4.12.1 Detailed Description	16
4.13 device_information_t Struct Reference	16
4.13.1 Detailed Description	16
4.14 edges_settings_calb_t Struct Reference	17
4.15 edges_settings_t Struct Reference	17
4.15.1 Detailed Description	17
4.15.2 Field Documentation	17
4.15.2.1 LeftBorder	17
4.15.2.2 RightBorder	18
4.15.2.3 uLeftBorder	18
4.15.2.4 uRightBorder	18
4.16 encoder_information_t Struct Reference	18
4.16.1 Detailed Description	18
4.16.2 Field Documentation	18
4.16.2.1 Manufacturer	18
4.16.2.2 PartNumber	18
4.17 encoder_settings_t Struct Reference	19
4.17.1 Detailed Description	19
4.17.2 Field Documentation	19
4.17.2.1 MaxCurrentConsumption	19
4.17.2.2 MaxOperatingFrequency	19
4.17.2.3 SupplyVoltageMax	19
4.17.2.4 SupplyVoltageMin	19
4.18 engine_settings_calb_t Struct Reference	20
4.18.1 Field Documentation	20
4.18.1.1 Antiplay	20
4.18.1.2 NomCurrent	20
4.18.1.3 NomSpeed	20
4.18.1.4 NomVoltage	20
4.18.1.5 StepsPerRev	20
4.19 engine_settings_t Struct Reference	21
4.19.1 Detailed Description	21
4.19.2 Field Documentation	21
4.19.2.1 Antiplay	21
4.19.2.2 NomCurrent	21
4.19.2.3 NomSpeed	22
4.19.2.4 NomVoltage	22

4.19.2.5	StepsPerRev	22
4.19.2.6	uNomSpeed	22
4.20	entype_settings_t Struct Reference	22
4.20.1	Detailed Description	22
4.21	extio_settings_t Struct Reference	22
4.21.1	Detailed Description	23
4.22	feedback_settings_t Struct Reference	23
4.22.1	Detailed Description	23
4.23	gear_information_t Struct Reference	23
4.23.1	Detailed Description	24
4.23.2	Field Documentation	24
4.23.2.1	Manufacturer	24
4.23.2.2	PartNumber	24
4.24	gear_settings_t Struct Reference	24
4.24.1	Detailed Description	25
4.24.2	Field Documentation	25
4.24.2.1	Efficiency	25
4.24.2.2	InputInertia	25
4.24.2.3	MaxOutputBacklash	25
4.24.2.4	RatedInputSpeed	25
4.24.2.5	RatedInputTorque	25
4.24.2.6	ReductionIn	25
4.24.2.7	ReductionOut	25
4.25	get_position_calb_t Struct Reference	26
4.26	get_position_t Struct Reference	26
4.26.1	Detailed Description	26
4.27	hallsensor_information_t Struct Reference	26
4.27.1	Detailed Description	26
4.27.2	Field Documentation	27
4.27.2.1	Manufacturer	27
4.27.2.2	PartNumber	27
4.28	hallsensor_settings_t Struct Reference	27
4.28.1	Detailed Description	27
4.28.2	Field Documentation	27
4.28.2.1	MaxCurrentConsumption	27
4.28.2.2	MaxOperatingFrequency	27
4.28.2.3	SupplyVoltageMax	28
4.28.2.4	SupplyVoltageMin	28
4.29	home_settings_calb_t Struct Reference	28
4.30	home_settings_t Struct Reference	28

4.30.1	Detailed Description	29
4.30.2	Field Documentation	29
4.30.2.1	FastHome	29
4.30.2.2	HomeDelta	29
4.30.2.3	SlowHome	29
4.30.2.4	uFastHome	29
4.30.2.5	uHomeDelta	29
4.30.2.6	uSlowHome	29
4.31	joystick_settings.t Struct Reference	29
4.31.1	Detailed Description	30
4.32	motor_information.t Struct Reference	30
4.32.1	Detailed Description	30
4.32.2	Field Documentation	31
4.32.2.1	Manufacturer	31
4.32.2.2	PartNumber	31
4.33	motor_settings.t Struct Reference	31
4.33.1	Detailed Description	32
4.33.2	Field Documentation	32
4.33.2.1	DetentTorque	32
4.33.2.2	MaxCurrent	32
4.33.2.3	MaxCurrentTime	32
4.33.2.4	MaxSpeed	32
4.33.2.5	MechanicalTimeConstant	33
4.33.2.6	NoLoadCurrent	33
4.33.2.7	NoLoadSpeed	33
4.33.2.8	NominalCurrent	33
4.33.2.9	NominalPower	33
4.33.2.10	NominalSpeed	33
4.33.2.11	NominalTorque	33
4.33.2.12	NominalVoltage	33
4.33.2.13	RotorInertia	33
4.33.2.14	SpeedConstant	34
4.33.2.15	SpeedTorqueGradient	34
4.33.2.16	StallTorque	34
4.33.2.17	TorqueConstant	34
4.33.2.18	WindingInductance	34
4.33.2.19	WindingResistance	34
4.34	move_settings_calb.t Struct Reference	34
4.35	move_settings.t Struct Reference	35
4.35.1	Detailed Description	35

4.35.2 Field Documentation	35
4.35.2.1 Accel	35
4.35.2.2 AntiplaySpeed	35
4.35.2.3 Decel	35
4.35.2.4 Speed	35
4.35.2.5 uAntiplaySpeed	36
4.35.2.6 uSpeed	36
4.36 pid_settings.t Struct Reference	36
4.36.1 Detailed Description	36
4.37 power_settings.t Struct Reference	36
4.37.1 Detailed Description	37
4.37.2 Field Documentation	37
4.37.2.1 CurrentSetTime	37
4.37.2.2 CurrReductDelay	37
4.37.2.3 HoldCurrent	37
4.37.2.4 PowerOffDelay	37
4.38 secure_settings.t Struct Reference	37
4.38.1 Detailed Description	38
4.38.2 Field Documentation	38
4.38.2.1 Criticallpwr	38
4.38.2.2 Criticallusb	38
4.38.2.3 CriticalT	38
4.38.2.4 CriticalUpwr	38
4.38.2.5 CriticalUusb	38
4.38.2.6 LowUpwrOff	39
4.38.2.7 MinimumUusb	39
4.39 serial_number.t Struct Reference	39
4.39.1 Detailed Description	39
4.40 set_position_calb.t Struct Reference	39
4.41 set_position.t Struct Reference	39
4.41.1 Detailed Description	40
4.42 stage_information.t Struct Reference	40
4.42.1 Detailed Description	40
4.42.2 Field Documentation	40
4.42.2.1 Manufacturer	40
4.42.2.2 PartNumber	41
4.43 stage_name.t Struct Reference	41
4.43.1 Detailed Description	41
4.43.2 Field Documentation	41
4.43.2.1 PositionerName	41

4.44 stage_settings_t Struct Reference	41
4.44.1 Detailed Description	42
4.44.2 Field Documentation	42
4.44.2.1 HorizontalLoadCapacity	42
4.44.2.2 LeadScrewPitch	42
4.44.2.3 MaxCurrentConsumption	42
4.44.2.4 MaxSpeed	42
4.44.2.5 SupplyVoltageMax	42
4.44.2.6 SupplyVoltageMin	42
4.44.2.7 TravelRange	43
4.44.2.8 Units	43
4.44.2.9 VerticalLoadCapacity	43
4.45 status_calb_t Struct Reference	43
4.46 status_t Struct Reference	44
4.46.1 Detailed Description	44
4.46.2 Field Documentation	45
4.46.2.1 uCurPosition	45
4.46.2.2 uCurSpeed	45
4.47 sync_in_settings_calb_t Struct Reference	45
4.47.1 Field Documentation	45
4.47.1.1 ClutterTime	45
4.48 sync_in_settings_t Struct Reference	45
4.48.1 Detailed Description	46
4.48.2 Field Documentation	46
4.48.2.1 ClutterTime	46
4.48.2.2 Speed	46
4.48.2.3 uPosition	46
4.48.2.4 uSpeed	46
4.49 sync_out_settings_calb_t Struct Reference	46
4.49.1 Field Documentation	47
4.49.1.1 SyncOutPeriod	47
4.49.1.2 SyncOutPulseSteps	47
4.50 sync_out_settings_t Struct Reference	47
4.50.1 Detailed Description	47
4.50.2 Field Documentation	48
4.50.2.1 Accuracy	48
4.50.2.2 SyncOutPeriod	48
4.50.2.3 SyncOutPulseSteps	48
4.50.2.4 uAccuracy	48
4.51 uart_settings_t Struct Reference	48

4.51.1	Detailed Description	48
5	File Documentation	49
5.1	ximc.h File Reference	49
5.1.1	Detailed Description	69
5.1.2	Macro Definition Documentation	69
5.1.2.1	BORDERS_SWAP_MISSET_DETECTION	69
5.1.2.2	DRIVER_TYPE_DISCRETE_FET	69
5.1.2.3	ENGINE_ACCEL_ON	69
5.1.2.4	ENGINE_ANTIPLAY	69
5.1.2.5	ENGINE_MAX_SPEED	69
5.1.2.6	ENGINE_REVERSE	70
5.1.2.7	ENGINE_TYPE_TEST	70
5.1.2.8	ENUMERATE_PROBE	70
5.1.2.9	EXTIO_SETUP_INVERT	70
5.1.2.10	HOME_DIR_FIRST	70
5.1.2.11	HOME_DIR_SECOND	70
5.1.2.12	JOY_REVERSE	70
5.1.2.13	MVCMD_ERROR	70
5.1.2.14	REV_SENS_INV	70
5.1.2.15	STATE_ALARM	71
5.1.2.16	SYNCIN_GOTOPOSITION	71
5.1.2.17	SYNCOOUT_ENABLED	71
5.1.2.18	XIMC_API	71
5.1.3	Typedef Documentation	71
5.1.3.1	logging_callback_t	71
5.1.4	Function Documentation	71
5.1.4.1	close_device	71
5.1.4.2	command_clear_fram	71
5.1.4.3	command_eeread_settings	72
5.1.4.4	command_eesave_settings	72
5.1.4.5	command_home	72
5.1.4.6	command_left	72
5.1.4.7	command_loft	73
5.1.4.8	command_move	73
5.1.4.9	command_movr	73
5.1.4.10	command_power_off	73
5.1.4.11	command_read_settings	73
5.1.4.12	command_reset	74
5.1.4.13	command_right	74

5.1.4.14	command_save_settings	74
5.1.4.15	command_sstp	74
5.1.4.16	command_stop	74
5.1.4.17	command_update_firmware	75
5.1.4.18	command_zero	75
5.1.4.19	enumerate_devices	75
5.1.4.20	free_enumerate_devices	75
5.1.4.21	get_accessories_settings	75
5.1.4.22	get_analog_data	76
5.1.4.23	get_bootloader_version	76
5.1.4.24	get_brake_settings	76
5.1.4.25	get_chart_data	76
5.1.4.26	get_control_settings	76
5.1.4.27	get_controller_name	77
5.1.4.28	get_ctp_settings	77
5.1.4.29	get_debug_read	77
5.1.4.30	get_device_count	77
5.1.4.31	get_device_information	78
5.1.4.32	get_device_name	78
5.1.4.33	get_edges_settings	78
5.1.4.34	get_encoder_information	78
5.1.4.35	get_encoder_settings	79
5.1.4.36	get_engine_settings	79
5.1.4.37	get_entype_settings	79
5.1.4.38	get_enumerate_device_information	79
5.1.4.39	get_enumerate_device_serial	79
5.1.4.40	get_extio_settings	80
5.1.4.41	get_feedback_settings	80
5.1.4.42	get_firmware_version	80
5.1.4.43	get_gear_information	80
5.1.4.44	get_gear_settings	81
5.1.4.45	get_hallsensor_information	81
5.1.4.46	get_hallsensor_settings	81
5.1.4.47	get_home_settings	81
5.1.4.48	get_joystick_settings	82
5.1.4.49	get_motor_information	82
5.1.4.50	get_motor_settings	82
5.1.4.51	get_move_settings	82
5.1.4.52	get_pid_settings	82
5.1.4.53	get_position	83

5.1.4.54	get_power_settings	83
5.1.4.55	get_secure_settings	83
5.1.4.56	get_serial_number	83
5.1.4.57	get_stage_information	84
5.1.4.58	get_stage_name	84
5.1.4.59	get_stage_settings	84
5.1.4.60	get_status	84
5.1.4.61	get_status_calb	84
5.1.4.62	get_sync_in_settings	85
5.1.4.63	get_sync_out_settings	85
5.1.4.64	get_uart_settings	85
5.1.4.65	goto_firmware	85
5.1.4.66	has_firmware	86
5.1.4.67	logging_callback_stderr_narrow	86
5.1.4.68	logging_callback_stderr_wide	86
5.1.4.69	msec_sleep	86
5.1.4.70	open_device	86
5.1.4.71	probe_device	86
5.1.4.72	service_command_updf	87
5.1.4.73	set_accessories_settings	87
5.1.4.74	set_add_sync_in_action	87
5.1.4.75	set_brake_settings	87
5.1.4.76	set_control_settings	87
5.1.4.77	set_controller_name	88
5.1.4.78	set_ctp_settings	88
5.1.4.79	set_edges_settings	88
5.1.4.80	set_encoder_information	88
5.1.4.81	set_encoder_settings	89
5.1.4.82	set_engine_settings	89
5.1.4.83	set_entype_settings	89
5.1.4.84	set_extio_settings	89
5.1.4.85	set_feedback_settings	90
5.1.4.86	set_gear_information	90
5.1.4.87	set_gear_settings	90
5.1.4.88	set_hallsensor_information	90
5.1.4.89	set_hallsensor_settings	90
5.1.4.90	set_home_settings	91
5.1.4.91	set_joystick_settings	91
5.1.4.92	set_logging_callback	91
5.1.4.93	set_motor_information	91

5.1.4.94 set_motor_settings	92
5.1.4.95 set_move_settings	92
5.1.4.96 set_pid_settings	92
5.1.4.97 set_position	92
5.1.4.98 set_power_settings	93
5.1.4.99 set_secure_settings	93
5.1.4.100 set_serial_number	93
5.1.4.101 set_stage_information	93
5.1.4.102 set_stage_name	94
5.1.4.103 set_stage_settings	94
5.1.4.104 set_sync_in_settings	94
5.1.4.105 set_sync_out_settings	94
5.1.4.106 set_uart_settings	95
5.1.4.107 write_key	95
5.1.4.108 ximc_fix_usbser_sys	95
5.1.4.109 ximc_version	95

Chapter 1

Introduction

1.1 About

Congratulations on choosing XIMC multi-platform programming library! This document contains all information about XIMC library. It utilizes well known virtual COM-port interface, so you can use it on Windows 7, Windows Vista, Windows XP, Windows Server 2003, Windows 2000, Linux, Mac OS X. XIMC multi-platform programing library supports plug/unplug on the fly. One program can control one device. Multiple processes (programs) that control one device simultaneously are not allowed.

1.2 System requirements

1.2.1 For rebuilding library

On Windows:

- Windows 2000 or later, 64-bit system (if compiling both architectures) or 32-bit system.
- Microsoft Visual C++ 2008 or later
- cygwin with tar, bison, flex installed

On Linux or FreeBSD:

- 64-bit or/and 32-bit system system
- gcc 4 or later
- common autotools: autoconf, autoheader, aclocal, automake, autoreconf, libtool
- gmake
- doxygen - for building docs
- LaTeX distribution (teTeX or texlive) - for building docs
- flex 2.5.30+
- bison
- mercurial (for building developer version from hg)

On Mac OS X:

- XCode 4

- doxygen
- mactex
- autotools
- mercurial (for building developer version from hg)

If mercurial is used, please enable 'purge' extension by adding to `~/.hgrc` following lines:

```
[extensions]
hgext.purge=
```

1.2.2 For using library

Supported operating systems (32 or 64 bit):

- Mac OS X 10.6
- Windows 2000 or later
- Autotools-compatible unix. Package is installed from sources.
- Linux debian-based. DEB package is built against Debian Squeeze 6
- Linux rpm-based. RPM is built against OpenSUSE 10
- FreeBSD 9. Package is provided.

Build requirements:

- Windows: Microsoft Visual C++ 2008 or mingw (currently not supported)
- UNIX: gcc 4, gmake
- Mac OS X: XCode 4

Chapter 2

How to rebuild library

2.1 Building on generic UNIX

Generic version could be built with standard autotools.

```
./build.sh lib
```

Built files (library, headers, documentation) are installed to ./dist/local directory. It is a generic developer build. Sometimes you need to specify additional parameters to command line for your machine. Please look to following OS sections.

2.2 Building on debian-based linux systems

Requirement: 64-bit and 32-bit debian system, ubuntu Typical set of packages: gcc, autotools, autoconf, libtool, dpkg-dev, flex, bison, doxygen, texlive, mercurial

It's required to match library and host architecture: 64-bit library can be built only at 64-bit host, 32-bit library - only at 32-bit host.

To build library and package invoke a script:

```
$ ./build.sh libdeb
```

Grab packages from ./dist/latest/deb and locally installed binaries from ./dist/local.

2.3 Building on redhat-based linux systems

Requirement: 64-bit redhat-based system (Fedora, Red Hat, SUSE) Typical set of packages: gcc, autotools, autoconf, libtool, flex, bison, doxygen, texlive, mercurial

It's possible to build both 32- and 64-bit libraries on 64-bit host system. 64-bit library can't be built on 32-bit system.

To build library and package invoke a script:

```
$ ./build.sh librpm
```

Grab packages from ./dist/latest/rpm and locally installed binaries from ./dist/local.

2.4 Building on FreeBSD

Requirement: 64-bit or 32-bit FreeBSD Typical set of packages: gcc, autotools, autoconf, libtool, flex, bison, doxygen, teTeX, mercurial

It's required to match library and host architecture. Also you need to fix a configure.ac to exclude SOVER from the package name (freebsd does not use linux conventions on library versioning).

Attention! It's needed to specify additional parameters for a simple build.

```
$ ./build.sh lib LEX=/usr/local/bin/flex CXXFLAGS=-I/usr/local/include/flex
```

To build a library and package invoke following command. It requires sudo privileges for port installing and specially crafted /usr/ports/local tree. Consult a script for details.

```
$ ./build.sh libfreebsd
```

Grab packages from ./dist/latest/freebsd.

2.5 Buliding on Mac OS X

To build and package a script invoke a script:

```
$ ./build.sh libosx
```

Built library (classical and framework), examples (classical and .app), documentation are located at ./dist/latest/macosx, locally installed binaries from ./dist/local.

2.6 Buliding on Windows

Requirements: 64-bit windows (build script builds both architectures), cygwin (must be installed to a default path), mercurial.

Invoke a script:

```
$ ./build.bat
```

Grab packages from ./dist/latest/win32 and ./dist/latest/win64

2.7 Source code access

XIMC source codes are given under special request.

Chapter 3

How to use with...

Library usage can be examined from test application testapp. Non-C languages are supported because library supports stdcall calling convention and so can be used with a variety of languages.

C test project is located at 'examples/testapp' directory, C# test project - at 'examples/testcs', VB.NET - 'examples/testvbn', Delphi 6 - 'examples/testdelphi', sample bindings for MATLAB - 'examples/testmatlab'

3.1 Usage with C

3.1.1 Visual C++

Testapp can be built using testapp.sln. Library must be compiled with MS Visual C++ too, mingw-library isn't supported. Make sure that Microsoft Visual C++ Redistributable Package is installed.

NOTE: Example compiled with(MS Visual C++ 2008 SP1 and needs package 9.0.307291 (provided with SDK - vcredist_x86 or vcredist_x64)

Open solution examples/testapp/testapp.sln, build and run from the IDE.

3.1.2 MinGW

MinGW is a port of GCC to win32 platform. It's required to install MinGW package. Currently not supported
MinGW-compiled testapp can be built with MS Visual C++ or mingw library.

```
$ mingw32-make -f Makefile.mingw all
```

Then copy library libximc.dll to current directory and launch testapp.exe.

3.1.3 C++ Builder

First of all you should create C++ Builder-style import library. Visual C++ library is not compatible with BCB. Invoke:

```
$ implib libximc.lib libximc.def
```

Then compile test application:

```
$ bcc32 -I..\..\ximc\win32 -L..\..\ximc\win32 -DWIN32 -DNDEBUG -D_WINDOWS  
testapp.c libximc.lib
```

3.1.4 XCode

Test app should be built with XCode project testapp.xcodeproj. Library is a Mac OS X framework, and at example application it's bundled inside testapp.app

Then launch application testapp.app and check activity output in Console.app.

3.1.5 GCC

Make sure that libximc (rpm, deb, freebsd package or tarball) is installed at your system. Installation of package should be performed with a package manager of operating system. On OS X plain dylib library and a framework is provided.

Note that user should belong to system group which allows access to a serial port (dip or serial, for example).

Test application can be built with the installed library with the following script:

```
$ make
```

In case of cross-compilation (target architecture differs from the current system architecture) feed -m64 or -m32 flag to compiler. On OS X it's needed to use -arch flag instead to build an universal binary. Please consult a compiler documentation.

Then launch the application as:

```
$ make run
```

Note: make run on OS X copies a library to the current directory. If you want to use library from the custom directory please be sure to specify LD_LIBRARY_PATH or DYLD_LIBRARY_PATH to the directory with the library.

3.2 .NET

Wrapper assembly for libximc.dll is wrappers/csharp/ximcnet.dll. It is provided with two different architectures and depends on .NET 2.0.

Test .NET applications for Visual Studio 2008 is located at testcs (for C#) and testvbnet (for VB.NET) respectively. Open solutions, build and run.

3.3 Delphi

Wrapper for libximc.dll is a unit wrappers/delphi/ximc.pas

Console test application for is located at testdelphi. Tested with Delphi 6 and only 32-bit version.

Just compile, place DLL near the executable and run program.

3.4 MATLAB

Sample MATLAB program testximc.m is provided at the directory examples/testmatlab. Fix first lines with the actual location of the XIMC library and launch M-file as:

```
$ testximc
```

Chapter 4

Data Structure Documentation

4.1 accessories_settings_t Struct Reference

Additional accessories information.

Data Fields

- char [MagneticBrakeInfo](#) [25]
The manufacturer and the part number of magnetic brake, the maximum string length is 24 characters.
- float [MBRatedVoltage](#)
Rated voltage for controlling the magnetic brake (B).
- float [MBRatedCurrent](#)
Rated current for controlling the magnetic brake (A).
- float [MBTorque](#)
Retention moment (mN m).
- unsigned int [MBSettings](#)
Magnetic brake settings flags.
- char [TemperatureSensorInfo](#) [25]
The manufacturer and the part number of the temperature sensor, the maximum string length: 24 characters.
- float [TMin](#)
The minimum measured temperature (degrees Celsius) Data type: float.
- float [TMax](#)
The maximum measured temperature (degrees Celsius) Data type: float.
- float [TGrad](#)
The temperature gradient (V/degrees Celsius).
- unsigned int [TSSettings](#)
Temperature sensor settings flags.
- unsigned int [LimitSwitchesSettings](#)
Temperature sensor settings flags.

4.1.1 Detailed Description

Additional accessories information.

See also

[set_accessories_settings](#)
[get_accessories_settings](#)
[get_accessories_settings, set.accessories.settings](#)

4.1.2 Field Documentation

4.1.2.1 float MBRatedCurrent

Rated current for controlling the magnetic brake (A).

Data type: float.

4.1.2.2 float MBRatedVoltage

Rated voltage for controlling the magnetic brake (B).

Data type: float.

4.1.2.3 float MBTorque

Retention moment (mN m).

Data type: float.

4.1.2.4 float TSGrad

The temperature gradient (V/degrees Celsius).

Data type: float.

4.2 add_sync_in_action_calb_t Struct Reference

Data Fields

- float **Position**
Desired position or shift.
- float **Speed**
Target speed.

4.3 add_sync_in_action_t Struct Reference

This command adds one element of the FIFO commands.

Data Fields

- int **Position**
Desired position or shift (whole steps)
- int **uPosition**
The fractional part of a position or shift in microsteps (-255 .. 255).
- unsigned int **Speed**
Target speed(for stepper motor: steps / c, for DC: rpm).
- unsigned int **uSpeed**
Target speed in microsteps/s.

4.3.1 Detailed Description

This command adds one element of the FIFO commands.

See also

[set_add_sync_in_action](#)

4.3.2 Field Documentation

4.3.2.1 unsigned int Speed

Target speed(for stepper motor: steps / c, for DC: rpm).

Range: 0..1000000.

4.3.2.2 int uPosition

The fractional part of a position or shift in microsteps (-255 .

. 255)(is only used with stepper motor)

4.3.2.3 unsigned int uSpeed

Target speed in microsteps/s.

Using with stepper motor only. Range: 0..255.

4.4 analog_data_t Struct Reference

Analog data.

Data Fields

- unsigned int [A1Voltage_ADC](#)
"Voltage on pin 1 winding A" raw data from ADC.
- unsigned int [A2Voltage_ADC](#)
"Voltage on pin 2 winding A" raw data from ADC.
- unsigned int [B1Voltage_ADC](#)
"Voltage on pin 1 winding B" raw data from ADC.
- unsigned int [B2Voltage_ADC](#)
"Voltage on pin 2 winding B" raw data from ADC.
- unsigned int [SupVoltage_ADC](#)
"Voltage on the top of MOSFET full bridge" raw data from ADC.
- unsigned int [ACurrent_ADC](#)
"Winding A current" raw data from ADC.
- unsigned int [BCurrent_ADC](#)
"Winding B current" raw data from ADC.
- unsigned int [FullCurrent_ADC](#)
"Full current" raw data from ADC.
- unsigned int [Temp_ADC](#)
Voltage from temperature sensor, raw data from ADC.

- unsigned int [Joy_ADC](#)
Joystick raw data from ADC.
- unsigned int [Pot_ADC](#)
Voltage on "Potentiometer", raw data from ADC.
- unsigned int [L5_ADC](#)
USB supply voltage after the current sense resistor, from ADC.
- unsigned int [H5_ADC](#)
Power supply USB from ADC.
- int [A1Voltage](#)
"Voltage on pin 1 winding A" calibrated data.
- int [A2Voltage](#)
"Voltage on pin 2 winding A" calibrated data.
- int [B1Voltage](#)
"Voltage on pin 1 winding B" calibrated data.
- int [B2Voltage](#)
"Voltage on pin 2 winding B" calibrated data.
- int [SupVoltage](#)
"Voltage on the top of MOSFET full bridge" calibrated data.
- int [ACurrent](#)
"Winding A current" calibrated data.
- int [BCurrent](#)
"Winding B current" calibrated data.
- int [FullCurrent](#)
"Full current" calibrated data.
- int [Temp](#)
Temperature, calibrated data.
- int [Joy](#)
Joystick, calibrated data.
- int [Pot](#)
Potentiometer, calibrated data.
- int [L5](#)
USB supply voltage after the current sense resistor.
- int [H5](#)
Power supply USB.
- unsigned int [deprecated](#)
- int [R](#)
Motor winding resistance in mOhms(is only used with stepper motor).
- int [L](#)
Motor winding pseudo inductance in uHn(is only used with stepper motor).

4.4.1 Detailed Description

Analog data.

This structure contains raw analog data from ADC embedded on board. These data used for device testing and deep recalibration by manufacturer only.

See also

[get_analog_data](#)
[get_analog_data](#)

4.5 brake_settings_t Struct Reference

Brake settings.

Data Fields

- unsigned int **t1**
Time in ms between turn on motor power and turn off brake.
- unsigned int **t2**
Time in ms between turn off brake and moving readiness.
- unsigned int **t3**
Time in ms between motor stop and turn on brake.
- unsigned int **t4**
Time in ms between turn on brake and turn off motor power.
- unsigned int **BrakeFlags**
Brake settings flags.

4.5.1 Detailed Description

Brake settings.

This structure contains parameters of brake control.

See also

[set_brake_settings](#)
[get_brake_settings](#)
[get_brake_settings, set_brake_settings](#)

4.5.2 Field Documentation

4.5.2.1 unsigned int t1

Time in ms between turn on motor power and turn off brake.

Range: 0..65535.

4.5.2.2 unsigned int t2

Time in ms between turn off brake and moving readiness.

All moving commands will execute after this interval. Range: 0..65535.

4.5.2.3 unsigned int t3

Time in ms between motor stop and turn on brake.

Range: 0..65535.

4.5.2.4 unsigned int t4

Time in ms between turn on brake and turn off motor power.

Range: 0..65535.

4.6 calibration_t Struct Reference

Calibration companion structure TODO docme.

Data Fields

- double [A](#)
Mulitiplier.
- unsigned int [MicrostepMode](#)
Microstep mode.

4.6.1 Detailed Description

Calibration companion structure TODO docme.

4.7 chart_data_t Struct Reference

Additional device state.

Data Fields

- int [WindingVoltageA](#)
In the case step motor, the voltage across the winding A; in the case of a brushless, the voltage on the first coil, in the case of the only DC.
- int [WindingVoltageB](#)
In the case step motor, the voltage across the winding B; in case of a brushless, the voltage on the second winding, and in the case of DC is not used.
- int [WindingVoltageC](#)
In the case of a brushless, the voltage on the third winding, in the case step motor and DC is not used.
- int [WindingCurrentA](#)
In the case step motor, the current in the coil A; brushless if the current in the first coil, and in the case of a single DC.
- int [WindingCurrentB](#)
In the case step motor, the current in the coil B; brushless if the current in the second coil, and in the case of DC is not used.
- int [WindingCurrentC](#)
In the case of a brushless, the current in the third winding, in the case step motor and DC is not used.
- unsigned int [Pot](#)
Potentiometer in ten-thousandths of [0, 10000].
- unsigned int [Joy](#)
The joystick to the ten-thousandths [0, 10000].
- int [DutyCycle](#)
Duty cycle of PWM.

4.7.1 Detailed Description

Additional device state.

This structure contains additional values such as winding's voltages, currents and temperature.

See also

- [get_chart_data](#)
- [get_chart_data](#)

4.8 control_settings_calb_t Struct Reference

Data Fields

- float **MaxSpeed** [10]
Array of speeds using with joystick and button control.
- unsigned int **Timeout** [9]
timeout[i] is time in ms, after that max_speed[i+1] is applying.
- unsigned int **MaxClickTime**
Maximum click time.
- unsigned int **Flags**
Control flags.
- float **DeltaPosition**
Shift (delta) of position.

4.8.1 Field Documentation

4.8.1.1 unsigned int MaxClickTime

Maximum click time.

Prior to the expiration of this time the first speed isn't enabled.

4.8.1.2 unsigned int Timeout[9]

timeout[i] is time in ms, after that max_speed[i+1] is applying.

It is using with buttons control only. Range: 0..65535.

4.9 control_settings_t Struct Reference

Control settings.

Data Fields

- unsigned int **MaxSpeed** [10]
Array of speeds (full step) using with joystick and button control.
- unsigned int **uMaxSpeed** [10]
Array of speeds (1/256 microstep) using with joystick and button control.
- unsigned int **Timeout** [9]
timeout[i] is time in ms, after that max_speed[i+1] is applying.
- unsigned int **MaxClickTime**
Maximum click time.
- unsigned int **Flags**
Control flags.
- int **DeltaPosition**
Shift (delta) of position.
- int **uDeltaPosition**
Fractional part of the shift in micro steps (-255 .. 255).

4.9.1 Detailed Description

Control settings.

This structure contains control parameters. When choosing CTL_MODE=1 switches motor control with the joystick. In this mode, the joystick to the maximum engine tends Move at MaxSpeed [i], where i=0 if the previous use This mode is not selected another i. Buttons switch the room rate i. When CTL_MODE=2 is switched on motor control using the Left / right. When you click on the button motor starts to move in the appropriate direction at a speed MaxSpeed [0], at the end of time Timeout[i] motor move at a speed MaxSpeed [i+1]. at Transition from MaxSpeed [i] on MaxSpeed [i+1] to acceleration, as usual. The figure above shows the sensitivity of the joystick feature on its position.

See also

[set_control_settings](#)
[get_control_settings](#)
[get_control_settings, set_control_settings](#)

4.9.2 Field Documentation

4.9.2.1 unsigned int MaxClickTime

Maximum click time.

Prior to the expiration of this time the first speed isn't enabled.

4.9.2.2 unsigned int MaxSpeed[10]

Array of speeds (full step) using with joystick and button control.

Range: 0..1000000.

4.9.2.3 unsigned int Timeout[9]

timeout[i] is time in ms, after that max_speed[i+1] is applying.

It is using with buttons control only. Range: 0..65535.

4.9.2.4 int uDeltaPosition

Fractional part of the shift in micro steps (-255 .

. 255) is only used with stepper motor

4.9.2.5 unsigned int uMaxSpeed[10]

Array of speeds (1/256 microstep) using with joystick and button control.

Range: 0..255.

4.10 controller_name_t Struct Reference

Controller user name and flags of setting.

Data Fields

- char [ControllerName](#) [17]
User controller name.
- unsigned int [CtrlFlags](#)
Flags of internal controller settings.

4.10.1 Detailed Description

Controller user name and flags of setting.

See also

[get_controller_name](#), [set_controller_name](#)

4.10.2 Field Documentation

4.10.2.1 char ControllerName[17]

User controller name.

Can be set by user for his/her convinience. Max string length: 16 chars.

4.11 ctp_settings_t Struct Reference

Control position settings(is only used with stepper motor).

Data Fields

- unsigned int [CTPMinError](#)
Minimum contrast steps from step motor encoder position, which set STATE_CTP_ERROR flag.
- unsigned int [CTPFlags](#)
Position control flags.

4.11.1 Detailed Description

Control position settings(is only used with stepper motor).

When controlling the step motor with encoder (CTP_BASE 0) it is possible to detect the loss of steps. The controller knows the number of steps per revolution (GENG :: StepsPerRev) and the encoder resolution (GFBs :: IPT). When the control (flag CTP_ENABLED), the controller stores the current position in the footsteps of SM and the current position of the encoder. Further, at each step of the position encoder is converted into steps and if the difference is greater CTPMinError, a flag STATE_CTP_ERROR and set ALARM state. When controlling the step motor with speed sensor (CTP_BASE 1), the position is controlled by him. The active edge of input clock controller stores the current value of steps. Further, at each turn checks how many steps shifted. When a mismatch CTPMinError a flag STATE_CTP_ERROR and set ALARM state.

See also

[set_ctp_settings](#)
[get_ctp_settings](#)
[get_ctp_settings](#), [set_ctp_settings](#)

4.11.2 Field Documentation

4.11.2.1 unsigned int CTPMinError

Minimum contrast steps from step motor encoder position, which set STATE_CTP_ERROR flag.

Measured in steps step motor. Range: 0..255.

4.12 debug_read_t Struct Reference

Debug data.

Data Fields

- unsigned int [DebugData](#) [128]
Arbitrary debug data.

4.12.1 Detailed Description

Debug data.

These data are used for device debugging by manufacturer only.

See also

[get_debug_read](#)

4.13 device_information_t Struct Reference

Read command controller information.

Data Fields

- char [Manufacturer](#) [5]
Manufacturer.
- char [ManufacturerId](#) [3]
Manufacturer id.
- char [ProductDescription](#) [9]
Product description.

4.13.1 Detailed Description

Read command controller information.

The controller responds to this command in any state. Manufacturer field for all XI ** devices should contain the string "XIMC" (validation is performed on it) The remaining fields contain information about the device.

See also

[get_device_information](#)
[get_device_information_impl](#)

4.14 edges_settings_calb_t Struct Reference

Data Fields

- unsigned int [BorderFlags](#)
Border flags.
- unsigned int [EnderFlags](#)
Limit switches flags.
- float [LeftBorder](#)
Left border position, used if BORDER_IS_ENCODER flag is set.
- float [RightBorder](#)
Right border position, used if BORDER_IS_ENCODER flag is set.

4.15 edges_settings_t Struct Reference

Edges settings.

Data Fields

- unsigned int [BorderFlags](#)
Border flags.
- unsigned int [EnderFlags](#)
Limit switches flags.
- int [LeftBorder](#)
Left border position, used if BORDER_IS_ENCODER flag is set.
- int [uLeftBorder](#)
Left border position in 1/256 microsteps(used with stepper motor only).
- int [RightBorder](#)
Right border position, used if BORDER_IS_ENCODER flag is set.
- int [uRightBorder](#)
Right border position in 1/256 microsteps.

4.15.1 Detailed Description

Edges settings.

This structure contains border and limit switches settings. Please load new engine settings when you change positioner etc. Please note that wrong engine settings lead to device malfunction, can lead to irreversible damage of board.

See also

[set_edges_settings](#)
[get_edges_settings](#)
[get_edges_settings, set_edges_settings](#)

4.15.2 Field Documentation

4.15.2.1 int LeftBorder

Left border position, used if BORDER_IS_ENCODER flag is set.

Range: -2147483647..2147483647.

4.15.2.2 int RightBorder

Right border position, used if BORDER_IS_ENCODER flag is set.

Range: -2147483647..2147483647.

4.15.2.3 int uLeftBorder

Left border position in 1/256 microsteps(used with stepper motor only).

Range: -255..255.

4.15.2.4 int uRightBorder

Right border position in 1/256 microsteps.

Range: -255..255(used with stepper motor only).

4.16 encoder_information_t Struct Reference

Encoder information.

Data Fields

- char [Manufacturer](#) [17]
Manufacturer.
- char [PartNumber](#) [25]
Series and PartNumber.

4.16.1 Detailed Description

Encoder information.

See also

[set_encoder_information](#)
[get_encoder_information](#)
[get_encoder_information](#), [set_encoder_information](#)

4.16.2 Field Documentation

4.16.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

4.16.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

4.17 encoder_settings_t Struct Reference

Encoder settings.

Data Fields

- float [MaxOperatingFrequency](#)
Max operation frequency (kHz).
- float [SupplyVoltageMin](#)
Minimum supply voltage (V).
- float [SupplyVoltageMax](#)
Maximum supply voltage (V).
- float [MaxCurrentConsumption](#)
Max current consumption (mA).
- unsigned int [PPR](#)
The number of counts per revolution.
- unsigned int [EncoderSettings](#)
Encoder settings flags.

4.17.1 Detailed Description

Encoder settings.

See also

[set_encoder_settings](#)
[get_encoder_settings](#)
[get_encoder_settings, set_encoder_settings](#)

4.17.2 Field Documentation

4.17.2.1 float MaxCurrentConsumption

Max current consumption (mA).

Data type: float.

4.17.2.2 float MaxOperatingFrequency

Max operation frequency (kHz).

Data type: float.

4.17.2.3 float SupplyVoltageMax

Maximum supply voltage (V).

Data type: float.

4.17.2.4 float SupplyVoltageMin

Minimum supply voltage (V).

Data type: float.

4.18 engine_settings_calb_t Struct Reference

Data Fields

- unsigned int [NomVoltage](#)
Rated voltage.
- unsigned int [NomCurrent](#)
Rated current.
- float [NomSpeed](#)
Nominal speed.
- unsigned int [EngineFlags](#)
Flags of engine settings.
- float [Antiplay](#)
Number of pulses or steps for backlash (play) compensation procedure.
- unsigned int [MicrostepMode](#)
Flags of microstep mode.
- unsigned int [StepsPerRev](#)
Number of full steps per revolution(Used with steper motor only).

4.18.1 Field Documentation

4.18.1.1 float Antiplay

Number of pulses or steps for backlash (play) compensation procedure.

Used if ENGINE_ANTIPLAY flag is set.

4.18.1.2 unsigned int NomCurrent

Rated current.

Controller will keep current consumed by motor below this value if ENGINE_LIMIT_CURR flag is set. Range: 1..65535

4.18.1.3 float NomSpeed

Nominal speed.

Controller will keep motor speed below this value if ENGINE_LIMIT_RPM flag is set.

4.18.1.4 unsigned int NomVoltage

Rated voltage.

Controller will keep the voltage drop on motor below this value if ENGINE_LIMIT_VOLT flag is set(Used with DC only). Range: 1..65535

4.18.1.5 unsigned int StepsPerRev

Number of full steps per revolution(Used with steper motor only).

Range: 1..65535.

4.19 engine_settings_t Struct Reference

Engine settings.

Data Fields

- unsigned int [NomVoltage](#)
Rated voltage.
- unsigned int [NomCurrent](#)
Rated current.
- unsigned int [NomSpeed](#)
Nominal speed (in whole steps / s or rpm for DC and stepper motor as a master encoder).
- unsigned int [uNomSpeed](#)
The fractional part of a nominal speed in microsteps (is only used with stepper motor).
- unsigned int [EngineFlags](#)
Flags of engine settings.
- int [Antiplay](#)
Number of pulses or steps for backlash (play) compensation procedure.
- unsigned int [MicrostepMode](#)
Flags of microstep mode.
- unsigned int [StepsPerRev](#)
Number of full steps per revolution(Used with steper motor only).

4.19.1 Detailed Description

Engine settings.

This structure contains useful motor settings. These settings specify motor shaft movement algorithm, list of limitations and rated characteristics. All boards are supplied with standart set of engine setting on controller's flash memory. Please load new engine settings when you change motor, encoder, positioner etc. Please note that wrong engine settings lead to device malfunction, can lead to irreversible damage of board.

See also

[set_engine_settings](#)
[get_engine_settings](#)
[get_engine_settings, set_engine_settings](#)

4.19.2 Field Documentation

4.19.2.1 int Antiplay

Number of pulses or steps for backlash (play) compensation procedure.

Used if ENGINE_ANTIPLAY flag is set. Range: -32768..32767

4.19.2.2 unsigned int NomCurrent

Rated current.

Controller will keep current consumed by motor below this value if ENGINE_LIMIT_CURR flag is set. Range: 1..65535

4.19.2.3 unsigned int NomSpeed

Nominal speed (in whole steps / s or rpm for DC and stepper motor as a master encoder).

Controller will keep motor shaft RPM below this value if ENGINE_LIMIT_RPM flag is set. Range: 1..1000000.

4.19.2.4 unsigned int NomVoltage

Rated voltage.

Controller will keep the voltage drop on motor below this value if ENGINE_LIMIT_VOLT flag is set(Used with DC only). Range: 1..65535

4.19.2.5 unsigned int StepsPerRev

Number of full steps per revolution(Used with steper motor only).

Range: 1..65535.

4.19.2.6 unsigned int uNomSpeed

The fractional part of a nominal speed in microsteps (is only used with stepper motor).

Range: 0..255

4.20 entype_settings_t Struct Reference

Engine type and driver type settings.

Data Fields

- unsigned int [EngineType](#)
Flags of engine type.
- unsigned int [DriverType](#)
Flags of driver type.

4.20.1 Detailed Description

Engine type and driver type settings.

Parameters

<i>id</i>	an identifier of device
<i>EngineType</i>	engine type
<i>DriverType</i>	driver type

See also

[get_entype_settings](#), [set_entype_settings](#)

4.21 extio_settings_t Struct Reference

EXTIO settings.

Data Fields

- unsigned int [EXTIOSetupFlags](#)
External IO setup flags.
- unsigned int [EXTIOModeFlags](#)
External IO mode flags.

4.21.1 Detailed Description

EXTIO settings.

This structure contains all EXTIO settings. By default input event are signalled through rising front and output states are signalled by high logic state.

See also

[get_extio_settings](#)
[set_extio_settings](#)
[get_extio_settings](#), [set_extio_settings](#)

4.22 feedback_settings_t Struct Reference

Feedback settings.

Data Fields

- unsigned int [IPS](#)
The number of measured counts per revolution encoder.
- unsigned int [FeedbackType](#)
Feedback type.
- unsigned int [FeedbackFlags](#)
Describes feedback flags.
- unsigned int [HallSPR](#)
The number of hall steps per revolution.
- int [HallShift](#)
Phase shift between output signal on BLDC engine and hall sensor input(0 - when only active the Hall sensor, the output state is a positive voltage on the winding A and a negative voltage on the winding B).

4.22.1 Detailed Description

Feedback settings.

This structure contains feedback settings.

See also

[get_feedback_settings](#), [set_feedback_settings](#)

4.23 gear_information_t Struct Reference

Gear information.

Data Fields

- char [Manufacturer](#) [17]
Manufacturer.
- char [PartNumber](#) [25]
Series and PartNumber.

4.23.1 Detailed Description

Gear information.

See also

[set_gear_information](#)
[get_gear_information](#)
[get_gear_information](#), [set_gear_information](#)

4.23.2 Field Documentation

4.23.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

4.23.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

4.24 gear_settings_t Struct Reference

Gear settings.

Data Fields

- float [ReductionIn](#)
Input reduction coefficient.
- float [ReductionOut](#)
Output reduction coefficient.
- float [RatedInputTorque](#)
Max continuous torque (N m).
- float [RatedInputSpeed](#)
Max speed on the input shaft (rpm).
- float [MaxOutputBacklash](#)
Output backlash of the reduction gear(degree).
- float [InputInertia](#)
Equivalent input gear inertia (g cm²).
- float [Efficiency](#)
Reduction gear efficiency (%).

4.24.1 Detailed Description

Gear settings.

See also

[set_gear_settings](#)
[get_gear_settings](#)
[get_gear_settings, set_gear_settings](#)

4.24.2 Field Documentation

4.24.2.1 float Efficiency

Reduction gear efficiency (%).

Data type: float.

4.24.2.2 float InputInertia

Equivalent input gear inertia (g cm²).

Data type: float.

4.24.2.3 float MaxOutputBacklash

Output backlash of the reduction gear(degree).

Data type: float.

4.24.2.4 float RatedInputSpeed

Max speed on the input shaft (rpm).

Data type: float.

4.24.2.5 float RatedInputTorque

Max continuous torque (N m).

Data type: float.

4.24.2.6 float ReductionIn

Input reduction coefficient.

(Output = (ReductionOut / ReductionIn) * Input) Data type: float.

4.24.2.7 float ReductionOut

Output reduction coefficient.

(Output = (ReductionOut / ReductionIn) * Input) Data type: float.

4.25 get_position_calb_t Struct Reference

Data Fields

- float [Position](#)
The position in the engine.
- long long [EncPosition](#)
Encoder position.

4.26 get_position_t Struct Reference

Position information.

Data Fields

- int [Position](#)
The position of the whole steps in the engine.
- int [uPosition](#)
Microstep position is only used with stepper motors.
- long long [EncPosition](#)
Encoder position.

4.26.1 Detailed Description

Position information.

Useful structure that contains position value in steps and micro for stepper motor and encoder steps of all engines.

See also

[get_position](#)

4.27 hallsensor_information_t Struct Reference

Hall sensor information.

Data Fields

- char [Manufacturer](#) [17]
Manufacturer.
- char [PartNumber](#) [25]
Series and PartNumber.

4.27.1 Detailed Description

Hall sensor information.

See also

[set_hallsensor_information](#)
[get_hallsensor_information](#)
[get_hallsensor_information, set_hallsensor_information](#)

4.27.2 Field Documentation

4.27.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

4.27.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

4.28 hallsensor_settings_t Struct Reference

Hall sensor settings.

Data Fields

- float [MaxOperatingFrequency](#)
Max operation frequency (kHz).
- float [SupplyVoltageMin](#)
Minimum supply voltage (V).
- float [SupplyVoltageMax](#)
Maximum supply voltage (V).
- float [MaxCurrentConsumption](#)
Max current consumption (mA).
- unsigned int [PPR](#)
The number of counts per revolution.

4.28.1 Detailed Description

Hall sensor settings.

See also

[set_hallsensor_settings](#)
[get_hallsensor_settings](#)
[get_hallsensor_settings](#), [set_hallsensor_settings](#)

4.28.2 Field Documentation

4.28.2.1 float MaxCurrentConsumption

Max current consumption (mA).

Data type: float.

4.28.2.2 float MaxOperatingFrequency

Max operation frequency (kHz).

Data type: float.

4.28.2.3 float SupplyVoltageMax

Maximum supply voltage (V).

Data type: float.

4.28.2.4 float SupplyVoltageMin

Minimum supply voltage (V).

Data type: float.

4.29 home_settings_calb_t Struct Reference

Data Fields

- float [FastHome](#)
Speed used for first motion.
- float [SlowHome](#)
Speed used for second motion.
- float [HomeDelta](#)
Distance from break point.
- unsigned int [HomeFlags](#)
Home settings flags.

4.30 home_settings_t Struct Reference

Position calibration settings.

Data Fields

- unsigned int [FastHome](#)
Speed used for first motion.
- unsigned int [uFastHome](#)
Part of the speed for first motion, microsteps.
- unsigned int [SlowHome](#)
Speed used for second motion.
- unsigned int [uSlowHome](#)
Part of the speed for second motion, microsteps.
- int [HomeDelta](#)
Distance from break point.
- int [uHomeDelta](#)
Part of the delta distance, microsteps.
- unsigned int [HomeFlags](#)
Home settings flags.

4.30.1 Detailed Description

Position calibration settings.

This structure contains settings used in position calibrating. It specify behaviour of calibrating position.

See also

[get_home_settings](#)
[set_home_settings](#)
[command_home](#)
[get_home_settings, set_home_settings](#)

4.30.2 Field Documentation

4.30.2.1 unsigned int FastHome

Speed used for first motion.

Range: 0..1000000.

4.30.2.2 int HomeDelta

Distance from break point.

Range: -2147483647..2147483647.

4.30.2.3 unsigned int SlowHome

Speed used for second motion.

Range: 0..1000000.

4.30.2.4 unsigned int uFastHome

Part of the speed for first motion, microsteps.

Range: 0..255.

4.30.2.5 int uHomeDelta

Part of the delta distance, microsteps.

Range: -255..255.

4.30.2.6 unsigned int uSlowHome

Part of the speed for second motion, microsteps.

Range: 0..255.

4.31 joystick_settings_t Struct Reference

Joystick settings.

Data Fields

- unsigned int [JoyLowEnd](#)
Joystick lower end position.
- unsigned int [JoyCenter](#)
Joystick center position.
- unsigned int [JoyHighEnd](#)
Joystick higher end position.
- unsigned int [ExpFactor](#)
Exponential nonlinearity factor.
- unsigned int [DeadZone](#)
Joystick dead zone.
- unsigned int [JoyFlags](#)
Joystick flags.

4.31.1 Detailed Description

Joystick settings.

This structure contains joystick parameters. If joystick position is outside DeadZone limits from the central position a movement with speed, defined by the joystick DeadZone edge to 100% deviation, begins. Joystick positions inside DeadZone limits correspond to zero speed (soft stop of motion) and positions beyond Low and High limits correspond MaxSpeed [i] or -MaxSpeed [i] (see command SCTL), where i = 0 by default and can be changed with left/right buttons (see command SCTL). If next speed in list is zero (both integer and microstep parts), the button press is ignored. First speed in list shouldn't be zero. The relationship between the deviation and the rate is exponential, allowing no switching speed combine high mobility and accuracy.

See also

[set_joystick_settings](#)
[get_joystick_settings](#)
[get_joystick_settings](#), [set_joystick_settings](#)

4.32 motor_information_t Struct Reference

motor information.

Data Fields

- char [Manufacturer](#) [17]
Manufacturer.
- char [PartNumber](#) [25]
Series and PartNumber.

4.32.1 Detailed Description

motor information.

See also

[set_motor_information](#)
[get_motor_information](#)
[get_motor_information](#), [set_motor_information](#)

4.32.2 Field Documentation

4.32.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

4.32.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

4.33 motor_settings_t Struct Reference

motor settings.

Data Fields

- unsigned int **MotorType**
Motor Type flags.
- unsigned int **ReservedField**
Reserved.
- unsigned int **Poles**
Number of pole pairs for DC or BLDC motors or number of steps per rotation for stepper motor.
- unsigned int **Phases**
Number of phases for BLDC motors.
- float **NominalVoltage**
Nominal voltage on winding (B).
- float **NominalCurrent**
Maximum direct current in winding for DC and BLDC engines, nominal current in windings for stepper motor (A).
- float **NominalSpeed**
Nominal speed(rpm).
- float **NominalTorque**
Nominal torque(mN m).
- float **NominalPower**
Nominal power(W).
- float **WindingResistance**
Resistance of windings for DC engine, each of two windings for stepper motor or each of three windings for BLDC engine(Ohm).
- float **WindingInductance**
Inductance of windings for DC engine, each of two windings for stepper motor or each of three windings for BLDC engine(mH).
- float **RotorInertia**
Rotor inertia(g cm²).
- float **StallTorque**
Torque hold position for a stepper motor or torque at a motionless rotor for other types of engines (mN m).
- float **DetentTorque**
Holding torque position with un-powered coils (mN m).
- float **TorqueConstant**

Torque constant, which determines the aspect ratio of maximum moment of force from the rotor current flowing in the coil (mN m / A).

- float [SpeedConstant](#)

Velocity constant, which determines the value or amplitude of the induced voltage on the motion of DC or BLDC motor (rpm / V) or stepper motor (steps/s / V).

- float [SpeedTorqueGradient](#)

Speed torque gradient (rpm / mN m).

- float [MechanicalTimeConstant](#)

Mechanical time constant (ms).

- float [MaxSpeed](#)

The maximum speed for stepper motors (steps/s) or DC and BLDC motors (rmp).

- float [MaxCurrent](#)

The maximum current in the winding (A).

- float [MaxCurrentTime](#)

Safe duration of overcurrent in the winding (ms).

- float [NoLoadCurrent](#)

The current consumption in idle mode (A).

- float [NoLoadSpeed](#)

Idle speed (rpm).

4.33.1 Detailed Description

motor settings.

See also

[set_motor_settings](#)

[get_motor_settings](#)

[get_motor_settings, set_motor_settings](#)

4.33.2 Field Documentation

4.33.2.1 float DetentTorque

Holding torque position with un-powered coils (mN m).

Data type: float.

4.33.2.2 float MaxCurrent

The maximum current in the winding (A).

Data type: float.

4.33.2.3 float MaxCurrentTime

Safe duration of overcurrent in the winding (ms).

Data type: float.

4.33.2.4 float MaxSpeed

The maximum speed for stepper motors (steps/s) or DC and BLDC motors (rmp).

Data type: float.

4.33.2.5 float MechanicalTimeConstant

Mechanical time constant (ms).

Data type: float.

4.33.2.6 float NoLoadCurrent

The current consumption in idle mode (A).

Used for DC and BLDC motors. Data type: float.

4.33.2.7 float NoLoadSpeed

Idle speed (rpm).

Used for DC and BLDC motors. Data type: float.

4.33.2.8 float NominalCurrent

Maximum direct current in winding for DC and BLDC engines, nominal current in windings for stepper motor (A).

Data type: float.

4.33.2.9 float NominalPower

Nominal power(W).

Used for DC and BLDC engine. Data type: float.

4.33.2.10 float NominalSpeed

Nominal speed(rpm).

Used for DC and BLDC engine. Data type: float.

4.33.2.11 float NominalTorque

Nominal torque(mN m).

Used for DC and BLDC engine. Data type: float.

4.33.2.12 float NominalVoltage

Nominal voltage on winding (B).

Data type: float

4.33.2.13 float RotorInertia

Rotor inertia(g cm²).

Data type: float.

4.33.2.14 float SpeedConstant

Velocity constant, which determines the value or amplitude of the induced voltage on the motion of DC or BLDC motor (rpm / V) or stepper motor (steps/s / V).

Data type: float.

4.33.2.15 float SpeedTorqueGradient

Speed torque gradient (rpm / mN m).

Data type: float.

4.33.2.16 float StallTorque

Torque hold position for a stepper motor or torque at a motionless rotor for other types of engines (mN m).

Data type: float.

4.33.2.17 float TorqueConstant

Torque constant, which determines the aspect ratio of maximum moment of force from the rotor current flowing in the coil (mN m / A).

Used mainly for DC motors. Data type: float.

4.33.2.18 float WindingInductance

Inductance of windings for DC engine, each of two windings for stepper motor or each of there windings for BLDC engine(mH).

Data type: float.

4.33.2.19 float WindingResistance

Resistance of windings for DC engine, each of two windings for stepper motor or each of there windings for BLDC engine(Ohm).

Data type: float.

4.34 move_settings_calb_t Struct Reference

Data Fields

- float [Speed](#)
Target speed.
- float [Accel](#)
Motor shaft acceleration, steps/s^2 (stepper motor) or RPM/s (DC).
- float [Decel](#)
Motor shaft deceleration, steps/s^2 (stepper motor) or RPM/s (DC).
- float [AntiplaySpeed](#)
Speed in antiplay mode.

4.35 move_settings_t Struct Reference

Move settings.

Data Fields

- `unsigned int Speed`
Target speed(for stepper motor: steps / c, for DC: rpm).
- `unsigned int uSpeed`
Target speed in 1/256 microsteps/s.
- `unsigned int Accel`
Motor shaft acceleration, steps/s²(stepper motor) or RPM/s(DC).
- `unsigned int Decel`
Motor shaft deceleration, steps/s²(stepper motor) or RPM/s(DC).
- `unsigned int AntiplaySpeed`
Speed in antiplay mode, full steps/s(stepper motor) or RPM(DC).
- `unsigned int uAntiplaySpeed`
Speed in antiplay mode, 1/256 microsteps/s.

4.35.1 Detailed Description

Move settings.

See also

[set_move_settings](#)
[get_move_settings](#)
[get_move_settings, set_move_settings](#)

4.35.2 Field Documentation

4.35.2.1 `unsigned int Accel`

Motor shaft acceleration, steps/s²(stepper motor) or RPM/s(DC).

Range: 0..65535.

4.35.2.2 `unsigned int AntiplaySpeed`

Speed in antiplay mode, full steps/s(stepper motor) or RPM(DC).

Range: 0..1000000.

4.35.2.3 `unsigned int Decel`

Motor shaft deceleration, steps/s²(stepper motor) or RPM/s(DC).

Range: 0..65535.

4.35.2.4 `unsigned int Speed`

Target speed(for stepper motor: steps / c, for DC: rpm).

Range: 0..1000000.

4.35.2.5 unsigned int uAntiplaySpeed

Speed in antiplay mode, 1/256 microsteps/s.

Used with stepper motor only. Range: 0..255.

4.35.2.6 unsigned int uSpeed

Target speed in 1/256 microsteps/s.

Using with stepper motor only. Range: 0..255.

4.36 pid_settings_t Struct Reference

PID settings.

Data Fields

- unsigned int [KpU](#)
Proportional gain for voltage PID routine.
- unsigned int [KiU](#)
Integral gain for voltage PID routine.
- unsigned int [KdU](#)
Differential gain for voltage PID routine.

4.36.1 Detailed Description

PID settings.

This structure contains factors for PID routine. Range: 0..65535. It specify behaviour of PID routine for voltage. These factors are slightly different for different positioners. All boards are supplied with standart set of PID setting on controller's flash memory. Please load new PID settings when you change positioner. Please note that wrong PID settings lead to device malfunction.

See also

[set_pid_settings](#)
[get_pid_settings](#)
[get_pid_settings, set_pid_settings](#)

4.37 power_settings_t Struct Reference

Step motor power settings.

Data Fields

- unsigned int [HoldCurrent](#)
Current in holding regime, percent of nominal.
- unsigned int [CurrReductDelay](#)
Time in ms from going to STOP state to reducing current.
- unsigned int [PowerOffDelay](#)
Time in s from going to STOP state to turning power off.

- unsigned int [CurrentSetTime](#)
Time in ms to reach nominal current.
- unsigned int [PowerFlags](#)
Flags of power settings of stepper motor.

4.37.1 Detailed Description

Step motor power settings.

See also

[set_move_settings](#)
[get_move_settings](#)
[get_power_settings](#), [set_power_settings](#)

4.37.2 Field Documentation

4.37.2.1 unsigned int CurrentSetTime

Time in ms to reach nominal current.

Range: 0..65535.

4.37.2.2 unsigned int CurrReductDelay

Time in ms from going to STOP state to reducing current.

Range: 0..65535.

4.37.2.3 unsigned int HoldCurrent

Current in holding regime, percent of nominal.

Range: 0..100.

4.37.2.4 unsigned int PowerOffDelay

Time in s from going to STOP state to turning power off.

Range: 0..65535.

4.38 secure_settings_t Struct Reference

This structure contains raw analog data from ADC embedded on board.

Data Fields

- unsigned int [LowUpwrOff](#)
Lower voltage limit to turn off the motor, in mV.
- unsigned int [Criticallpwr](#)
Maximum motor current which triggers ALARM state, in mA.
- unsigned int [CriticalUpwr](#)
Maximum motor voltage which triggers ALARM state, in mV.

- `unsigned int CriticalT`
Maximum temperature, which triggers ALARM state, in tenths of degrees Celcius.
- `unsigned int Criticallusb`
Maximum USB current which triggers ALARM state, in mA.
- `unsigned int CriticalUusb`
Maximum USB voltage which triggers ALARM state, in mV.
- `unsigned int MinimumUusb`
Minimum USB voltage which triggers ALARM state, in mV.
- `unsigned int Flags`
Flags of secure settings.

4.38.1 Detailed Description

This structure contains raw analog data from ADC embedded on board.

These data used for device testing and deep recalibraton by manufacturer only.

See also

[get_secure_settings](#)
[set_secure_settings](#)
[get_secure_settings, set_secure_settings](#)

4.38.2 Field Documentation

4.38.2.1 `unsigned int Criticallpwr`

Maximum motor current which triggers ALARM state, in mA.

Range: 0..65535.

4.38.2.2 `unsigned int Criticallusb`

Maximum USB current which triggers ALARM state, in mA.

Range: 0..65535.

4.38.2.3 `unsigned int CriticalT`

Maximum temperature, which triggers ALARM state, in tenths of degrees Celcius.

Range: 0..65535.

4.38.2.4 `unsigned int CriticalUpwr`

Maximum motor voltage which triggers ALARM state, in mV.

Range: 0..65535.

4.38.2.5 `unsigned int CriticalUusb`

Maximum USB voltage which triggers ALARM state, in mV.

Range: 0..65535.

4.38.2.6 unsigned int LowUpwrOff

Lower voltage limit to turn off the motor, in mV.

Range: 0..65535.

4.38.2.7 unsigned int MinimumUusb

Minimum USB voltage which triggers ALARM state, in mV.

Range: 0..65535.

4.39 serial_number_t Struct Reference

Serial number structure.

Data Fields

- unsigned int **SN**
New board serial number.
- unsigned int **Key** [32]
Protection key (256 bit).

4.39.1 Detailed Description

Serial number structure.

The structure keep new serial number and valid key. The SN is changed and saved when transmitted key matches stored key. Can be used by manufacturer only.

See also

[set_serial_number](#)

4.40 set_position_calb_t Struct Reference

Data Fields

- float **Position**
The position in the engine.
- long long **EncPosition**
Encoder position.
- unsigned int **PosFlags**
Position setting flags.

4.41 set_position_t Struct Reference

Position information.

Data Fields

- int [Position](#)
The position of the whole steps in the engine.
- int [uPosition](#)
Microstep position is only used with stepper motors.
- long long [EncPosition](#)
Encoder position.
- unsigned int [PosFlags](#)
Position setting flags.

4.41.1 Detailed Description

Position information.

Useful structure that contains position value in steps and micro for stepper motor and encoder steps of all engines.

See also

[set_position](#)

4.42 stage_information_t Struct Reference

Stage information.

Data Fields

- char [Manufacturer](#) [17]
Manufacturer.
- char [PartNumber](#) [25]
Series and PartNumber.

4.42.1 Detailed Description

Stage information.

See also

[set_stage_information](#)
[get_stage_information](#)
[get_stage_information](#), [set_stage_information](#)

4.42.2 Field Documentation

4.42.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

4.42.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

4.43 stage_name_t Struct Reference

Stage user name.

Data Fields

- char [PositionerName](#) [17]
User positioner name.

4.43.1 Detailed Description

Stage user name.

See also

[get_stage_name](#), [set_stage_name](#)

4.43.2 Field Documentation

4.43.2.1 char PositionerName[17]

User positioner name.

Can be set by user for his/her convinience. Max string length: 16 chars.

4.44 stage_settings_t Struct Reference

Stage settings.

Data Fields

- float [LeadScrewPitch](#)
Lead screw pitch (mm).
- char [Units](#) [9]
Units for MaxSpeed and TravelRange fields of the structure (steps, degrees, mm, ...).
- float [MaxSpeed](#)
Max speed (Units/c).
- float [TravelRange](#)
Travel range (Units).
- float [SupplyVoltageMin](#)
Supply voltage minimum (V).
- float [SupplyVoltageMax](#)
Supply voltage maximum (V).
- float [MaxCurrentConsumption](#)

- Max current consumption (A).
- float [HorizontalLoadCapacity](#)
Horizontal load capacity (kg).
- float [VerticalLoadCapacity](#)
Vertical load capacity (kg).

4.44.1 Detailed Description

Stage settings.

See also

- [set_stage_settings](#)
- [get_stage_settings](#)
- [get_stage_settings, set_stage_settings](#)

4.44.2 Field Documentation

4.44.2.1 float HorizontalLoadCapacity

Horizontal load capacity (kg).

Data type: float.

4.44.2.2 float LeadScrewPitch

Lead screw pitch (mm).

Data type: float.

4.44.2.3 float MaxCurrentConsumption

Max current consumption (A).

Data type: float.

4.44.2.4 float MaxSpeed

Max speed (Units/c).

Data type: float.

4.44.2.5 float SupplyVoltageMax

Supply voltage maximum (V).

Data type: float.

4.44.2.6 float SupplyVoltageMin

Supply voltage minimum (V).

Data type: float.

4.44.2.7 float TravelRange

Travel range (Units).

Data type: float.

4.44.2.8 char Units[9]

Units for MaxSpeed and TravelRange fields of the structure (steps, degrees, mm, ...).

Max string length: 8 chars.

4.44.2.9 float VerticalLoadCapacity

Vertical load capacity (kg).

Data type: float.

4.45 status_calb_t Struct Reference

Data Fields

- unsigned int **MoveSts**
Flags of move state.
- unsigned int **MvCmdSts**
Move command state.
- unsigned int **PWRSts**
Flags of power state of stepper motor.
- unsigned int **EncSts**
Encoder state.
- unsigned int **WindSts**
Winding state.
- float **CurPosition**
Current position.
- long long **EncPosition**
Current encoder position.
- float **CurSpeed**
Motor shaft speed.
- int **Ipwr**
Engine current.
- int **Upwr**
Power supply voltage.
- int **Iusb**
USB current consumption.
- int **Uusb**
USB voltage.
- int **CurT**
Temperature in tenths of degrees C.
- unsigned int **Flags**
Status flags.
- unsigned int **GPIOFlags**
Status flags.
- unsigned int **CmdBufFreeSpace**
This field shows the amount of free cells buffer synchronization chain.

4.46 status_t Struct Reference

Device state.

Data Fields

- unsigned int **MoveSts**
Flags of move state.
- unsigned int **MvCmdSts**
Move command state.
- unsigned int **PWRSts**
Flags of power state of stepper motor.
- unsigned int **EncSts**
Encoder state.
- unsigned int **WindSts**
Winding state.
- int **CurPosition**
Current position.
- int **uCurPosition**
Step motor shaft position in 1/256 microsteps.
- long long **EncPosition**
Current encoder position.
- int **CurSpeed**
Motor shaft speed.
- int **uCurSpeed**
Part of motor shaft speed in 1/256 microsteps.
- int **Ipwr**
Engine current.
- int **Upwr**
Power supply voltage.
- int **Iusb**
USB current consumption.
- int **Uusb**
USB voltage.
- int **CurT**
Temperature in tenths of degrees C.
- unsigned int **Flags**
Status flags.
- unsigned int **GPIOFlags**
Status flags.
- unsigned int **CmdBufFreeSpace**
This field shows the amount of free cells buffer synchronization chain.

4.46.1 Detailed Description

Device state.

Useful structure that contains current controller state, including speed, position and boolean flags.

See also

[get_status_impl](#)

4.46.2 Field Documentation

4.46.2.1 int uCurPosition

Step motor shaft position in 1/256 microsteps.

Used only with stepper motor.

4.46.2.2 int uCurSpeed

Part of motor shaft speed in 1/256 microsteps.

Used only with stepper motor.

4.47 sync_in_settings_calb_t Struct Reference

Data Fields

- unsigned int [SyncInFlags](#)
Flags for synchronization input setup.
- unsigned int [ClutterTime](#)
Input synchronization pulse dead time (mks).
- float [Position](#)
Desired position or shift.
- float [Speed](#)
Target speed.

4.47.1 Field Documentation

4.47.1.1 unsigned int ClutterTime

Input synchronization pulse dead time (mks).

Range: 0..65535

4.48 sync_in_settings_t Struct Reference

Synchronization settings.

Data Fields

- unsigned int [SyncInFlags](#)
Flags for synchronization input setup.
- unsigned int [ClutterTime](#)
Input synchronization pulse dead time (mks).
- int [Position](#)
Desired position or shift (whole steps)
- int [uPosition](#)
The fractional part of a position or shift in microsteps (-255 .. 255).
- unsigned int [Speed](#)
Target speed(for stepper motor: steps / c, for DC: rpm).

- unsigned int [uSpeed](#)
Target speed in microsteps/s.

4.48.1 Detailed Description

Synchronization settings.

This structure contains all synchronization settings, modes, periods and flags. It specifies behaviour of input synchronization. All boards are supplied with standard set of these settings.

See also

- [get_sync_in_settings](#)
- [set_sync_in_settings](#)
- [get_sync_in_settings](#), [set_sync_in_settings](#)

4.48.2 Field Documentation

4.48.2.1 unsigned int ClutterTime

Input synchronization pulse dead time (mks).

Range: 0..65535

4.48.2.2 unsigned int Speed

Target speed(for stepper motor: steps / c, for DC: rpm).

Range: 0..1000000.

4.48.2.3 int uPosition

The fractional part of a position or shift in microsteps (-255 ..

. 255)(is only used with stepper motor)

4.48.2.4 unsigned int uSpeed

Target speed in microsteps/s.

Using with stepper motor only. Range: 0..255.

4.49 sync_out_settings_calb_t Struct Reference

Data Fields

- unsigned int [SyncOutFlags](#)
Flags of synchronization output.
- unsigned int [SyncOutPulseSteps](#)
This value specifies duration of output pulse.
- unsigned int [SyncOutPeriod](#)
This value specifies number of encoder pulses or steps between two output synchronization pulses when SYNCOUT_ONPERIOD is set.
- float [Accuracy](#)

This is the neighborhood around the target coordinates, which is getting hit in the target position and the momentum generated by the stop.

4.49.1 Field Documentation

4.49.1.1 unsigned int SyncOutPeriod

This value specifies number of encoder pulses or steps between two output synchronization pulses when SYNCOUT_ONPERIOD is set.

Range: 0..65535

4.49.1.2 unsigned int SyncOutPulseSteps

This value specifies duration of output pulse.

It is measured microseconds when SYNCOUT_IN_STEPS flag is cleared or in encoder pulses or motor steps when SYNCOUT_IN_STEPS is set. Range: 0..65535

4.50 sync_out_settings_t Struct Reference

Synchronization settings.

Data Fields

- unsigned int [SyncOutFlags](#)

Flags of synchronization output.
- unsigned int [SyncOutPulseSteps](#)

This value specifies duration of output pulse.
- unsigned int [SyncOutPeriod](#)

This value specifies number of encoder pulses or steps between two output synchronization pulses when SYNCOUT_ONPERIOD is set.
- unsigned int [Accuracy](#)

This is the neighborhood around the target coordinates, which is getting hit in the target position and the momentum generated by the stop.
- unsigned int [uAccuracy](#)

This is the neighborhood around the target coordinates in micro steps (only used with stepper motor).

4.50.1 Detailed Description

Synchronization settings.

This structure contains all synchronization settings, modes, periods and flags. It specifies behaviour of output synchronization. All boards are supplied with standard set of these settings.

See also

[get_sync_out_settings](#)
[set_sync_out_settings](#)
[get_sync_out_settings](#), [set_sync_out_settings](#)

4.50.2 Field Documentation

4.50.2.1 unsigned int Accuracy

This is the neighborhood around the target coordinates, which is getting hit in the target position and the momentum generated by the stop.

Range: 0..4294967295.

4.50.2.2 unsigned int SyncOutPeriod

This value specifies number of encoder pulses or steps between two output synchronization pulses when SYNCOUT_ONPERIOD is set.

Range: 0..65535

4.50.2.3 unsigned int SyncOutPulseSteps

This value specifies duration of output pulse.

It is measured microseconds when SYNCOUT_IN_STEPS flag is cleared or in encoder pulses or motor steps when SYNCOUT_IN_STEPS is set. Range: 0..65535

4.50.2.4 unsigned int uAccuracy

This is the neighborhood around the target coordinates in micro steps (only used with stepper motor).

Range: 0 .. 255.

4.51 uart_settings_t Struct Reference

UART settings.

Data Fields

- unsigned int [Speed](#)
UART speed.
- unsigned int [UARTSetupFlags](#)
UART parity flags.

4.51.1 Detailed Description

UART settings.

This structure contains UART settings.

See also

[get_uart_settings](#)
[set_uart_settings](#)
[get_uart_settings](#), [set_uart_settings](#)

Chapter 5

File Documentation

5.1 ximc.h File Reference

Header file for libximc library.

Data Structures

- struct `calibration.t`
Calibration companion structure TODO docme.
- struct `feedback_settings.t`
Feedback settings.
- struct `home_settings.t`
Position calibration settings.
- struct `home_settings.calb.t`
- struct `move_settings.t`
Move settings.
- struct `move_settings.calb.t`
- struct `engine_settings.t`
Engine settings.
- struct `engine_settings.calb.t`
- struct `entype_settings.t`
Engine type and driver type settings.
- struct `power_settings.t`
Step motor power settings.
- struct `secure_settings.t`
This structure contains raw analog data from ADC embedded on board.
- struct `edges_settings.t`
Edges settings.
- struct `edges_settings.calb.t`
- struct `pid_settings.t`
PID settings.
- struct `sync_in_settings.t`
Synchronization settings.
- struct `sync_in_settings.calb.t`
- struct `sync_out_settings.t`
Synchronization settings.
- struct `sync_out_settings.calb.t`

- struct `extio_settings_t`
EXTIO settings.
- struct `brake_settings_t`
Brake settings.
- struct `control_settings_t`
Control settings.
- struct `control_settings_calb_t`
- struct `joystick_settings_t`
Joystick settings.
- struct `ctp_settings_t`
Control position settings(is only used with stepper motor).
- struct `uart_settings_t`
UART settings.
- struct `controller_name_t`
Controller user name and flags of setting.
- struct `add_sync_in_action_t`
This command adds one element of the FIFO commands.
- struct `add_sync_in_action_calb_t`
- struct `get_position_t`
Position information.
- struct `get_position_calb_t`
- struct `set_position_t`
Position information.
- struct `set_position_calb_t`
- struct `status_t`
Device state.
- struct `status_calb_t`
- struct `chart_data_t`
Additional device state.
- struct `device_information_t`
Read command controller information.
- struct `serial_number_t`
Serial number structure.
- struct `analog_data_t`
Analog data.
- struct `debug_read_t`
Debug data.
- struct `stage_name_t`
Stage user name.
- struct `stage_information_t`
Stage information.
- struct `stage_settings_t`
Stage settings.
- struct `motor_information_t`
motor information.
- struct `motor_settings_t`
motor settings.
- struct `encoder_information_t`
Encoder information.
- struct `encoder_settings_t`
Encoder settings.

- struct `hallsensor.information.t`
Hall sensor information.
- struct `hallsensor.settings.t`
Hall sensor settings.
- struct `gear.information.t`
Gear information.
- struct `gear.settings.t`
Gear settings.
- struct `accessories.settings.t`
Additional accessories information.

Macros

- `#define XIMC_API`
Library import macro Macros allows to automatically import function from shared library.
- `#define XIMC_CALLCONV`
Library calling convention macros.
- `#define device_undefined -1`
Handle specified undefined device.

Result statuses

- `#define result_ok 0`
success
- `#define result_error -1`
generic error
- `#define result_not_implemented -2`
function is not implemented
- `#define result_value_error -3`
value error
- `#define result_nodevice -4`
device is lost

Logging level

- `#define LOGLEVEL_ERROR 0x01`
Logging level - error.
- `#define LOGLEVEL_WARNING 0x02`
Logging level - warning.
- `#define LOGLEVEL_INFO 0x03`
Logging level - info.
- `#define LOGLEVEL_DEBUG 0x04`
Logging level - debug.

Enumerate devices flags

- `#define ENUMERATE_PROBE 0x01`
Check if a device with OS name name is XIMC device.
- `#define ENUMERATE_ALL_COM 0x02`
Check all COM devices.

Flags of move state

Specify move states.

See also

- get_status*
- status_t::move_state*
- status_t::MoveSts, get_status_impl*
- #define **MOVE_STATE_MOVING** 0x01
This flag indicates that controller is trying to move the motor.
- #define **MOVE_STATE_TARGET_SPEED** 0x02
Target speed is reached, if flag set.
- #define **MOVE_STATE_ANTIPLAY** 0x04
Motor is playing compensation, if flag set.

Flags of internal controller settings

See also

- set_controller_name*
- get_controller_name*
- controller_name_t::CtrlFlags, get_controller_name, set_controller_name*
- #define **EEPROM_PRECEDENCE** 0x01
If the flag is set settings from external EEPROM override controller settings.

Flags of power state of stepper motor

Specify power states.

See also

- status_t::power_state*
- get_status*
- status_t::PWRSts, get_status_impl*
- #define **PWR_STATE_UNKNOWN** 0x00
Unknown state, should never happen.
- #define **PWR_STATE_OFF** 0x01
Motor windings are disconnected from the driver.
- #define **PWR_STATE_NORM** 0x03
Motor windings are powered by nominal current.
- #define **PWR_STATE_REDUC** 0x04
Motor windings are powered by reduced current to lower power consumption.
- #define **PWR_STATE_MAX** 0x05
Motor windings are powered by maximum current driver can provide at this voltage.

Status flags

GPIO state flags returned by device query. Contains boolean part of controller state. May be combined with bitwise OR.

See also

- status_t::flags*
- get_status*
- status_t::GPIOFlags, get_status_impl*
- #define **STATE_CONTR** 0x0003F
Flags of controller states.
- #define **STATE_ERRC** 0x000001
Command error encountered.
- #define **STATE_ERRD** 0x000002
Data integrity error encountered.

- #define STATE_ERRV 0x00004
Value error encountered.
- #define STATE_EEPROM_CONNECTED 0x00010
EEPROM with settings is connected.
- #define STATE_SECUR 0x3FFC0
Flags of security.
- #define STATE_ALARM 0x00040
Controller is in alarm state indicating that something dangerous had happened.
- #define STATE_CTP_ERROR 0x00080
Control position error(is only used with stepper motor).
- #define STATE_POWER_OVERHEAT 0x00100
Power driver overheat.
- #define STATE_CONTROLLER_OVERHEAT 0x00200
Controller overheat.
- #define STATE_OVERLOAD_POWER_VOLTAGE 0x00400
Power voltage exceeds safe limit.
- #define STATE_OVERLOAD_POWER_CURRENT 0x00800
Power current exceeds safe limit.
- #define STATE_OVERLOAD_USB_VOLTAGE 0x01000
USB voltage exceeds safe limit.
- #define STATE_LOW_USB_VOLTAGE 0x02000
USB voltage is insufficient for normal operation.
- #define STATE_OVERLOAD_USB_CURRENT 0x04000
USB current exceeds safe limit.
- #define STATE_BORDERS_SWAP_MISSET 0x08000
Engine stuck at the wrong edge.
- #define STATE_LOW_POWER_VOLTAGE 0x10000
Power voltage is lower than Low Voltage Protection limit.
- #define STATE_H_BRIDGEFAULT 0x20000
Signal from the driver that fault happened.
- #define STATE_DIG_SIGNAL 0xFFFF
Flags of digital signals.
- #define STATE_RIGHT_EDGE 0x0001
Engine stuck at the right edge.
- #define STATE_LEFT_EDGE 0x0002
Engine stuck at the left edge.
- #define STATE_BUTTON_RIGHT 0x0004
Button "right" state (1 if pressed).
- #define STATE_BUTTON_LEFT 0x0008
Button "left" state (1 if pressed).
- #define STATE_GPIO_PINOUT 0x0010
External GPIO works as Out, if flag set; otherwise works as In.
- #define STATE_GPIO_LEVEL 0x0020
State of external GPIO pin.
- #define STATE_HALL_A 0x0040
State of Hall.a pin.
- #define STATE_HALL_B 0x0080
State of Hall.b pin.
- #define STATE_HALL_C 0x0100
State of Hall.c pin.
- #define STATE_BRAKE 0x0200
State of Brake pin.
- #define STATE_REV_SENSOR 0x0400
State of Revolution sensor pin.
- #define STATE_SYNC_INPUT 0x0800

- #define STATE_SYNC_OUTPUT 0x1000
State of Sync input pin.
- #define STATE_ENC_A 0x2000
State of Sync output pin.
- #define STATE_ENC_B 0x4000
State of encoder A pin.
- #define STATE_ENC_B 0x4000
State of encoder B pin.

Encoder state

Encoder state returned by device query.

See also

`status_t::encsts`
`get_status`
`status_t::EncSts, get_status_impl`

- #define ENC_STATE_ABSENT 0x00
Encoder is absent.
- #define ENC_STATE_UNKNOWN 0x01
Encoder state is unknown.
- #define ENC_STATE_MALFUNC 0x02
Encoder is connected and malfunctioning.
- #define ENC_STATE_REVERS 0x03
Encoder is connected and operational but counts in otyher direction.
- #define ENC_STATE_OK 0x04
Encoder is connected and working properly.

Winding state

Motor winding state returned by device query.

See also

`status_t::windsts`
`get_status`
`status_t::WindSts, get_status_impl`

- #define WIND_A_STATE_ABSENT 0x00
Winding A is disconnected.
- #define WIND_A_STATE_UNKNOWN 0x01
Winding A state is unknown.
- #define WIND_A_STATE_MALFUNC 0x02
Winding A is short-circuited.
- #define WIND_A_STATE_OK 0x03
Winding A is connected and working properly.
- #define WIND_B_STATE_ABSENT 0x00
Winding B is disconnected.
- #define WIND_B_STATE_UNKNOWN 0x10
Winding B state is unknown.
- #define WIND_B_STATE_MALFUNC 0x20
Winding B is short-circuited.
- #define WIND_B_STATE_OK 0x30
Winding B is connected and working properly.

Move command state

Move command (`command_move`, `command_movr`, `command_left`, `command_right`, `command_stop`, `command_home`, `command_loft`, `command_sstp`) and its state (`run`, `finished`, `error`).

See also

- `status_t::mvcmdsts`
- `get_status`
- `status_t::MvCmdSts, get_status_impl`
- `#define MVCMD_NAME_BITS 0x3F`
Move command bit mask.
- `#define MVCMD_UKNWN 0x00`
Unknown command.
- `#define MVCMD_MOVE 0x01`
Command move.
- `#define MVCMD_MOVR 0x02`
Command movr.
- `#define MVCMD_LEFT 0x03`
Command left.
- `#define MVCMD_RIGHT 0x04`
Command right.
- `#define MVCMD_STOP 0x05`
Command stop.
- `#define MVCMD_HOME 0x06`
Command home.
- `#define MVCMD_LOFT 0x07`
Command loft.
- `#define MVCMD_SSTP 0x08`
Command soft stop.
- `#define MVCMD_ERROR 0x40`
Finish state (1 - move command have finished with an error, 0 - move command have finished correctly).
- `#define MVCMD_RUNNING 0x80`
Move command state (0 - move command have finished, 1 - move command is being executed).

Flags of engine settings

Specify motor shaft movement algorithm and list of limitations. Flags returned by query of engine settings. May be combined with bitwise OR.

See also

- `engine_settings_t::flags`
- `set_engine_settings`
- `get_engine_settings`
- `engine_settings_t::EngineFlags, get_engine_settings, set_engine_settings`

- `#define ENGINE_REVERSE 0x01`
Reverse flag.
- `#define ENGINE_MAX_SPEED 0x04`
Max speed flag.
- `#define ENGINE_ANTIPLAY 0x08`
Play compensation flag.
- `#define ENGINE_ACCEL_ON 0x10`
Acceleration enable flag.
- `#define ENGINE_LIMIT_VOLT 0x20`
Maximum motor voltage limit enable flag(is only used with DC motor).
- `#define ENGINE_LIMIT_CURR 0x40`
Maximum motor current limit enable flag(is only used with DC motor).
- `#define ENGINE_LIMIT_RPM 0x80`
Maximum motor speed limit enable flag.

Flags of microstep mode

Specify settings of microstep mode. Using with step motors. Flags returned by query of engine settings. May be combined with bitwise OR

See also

`engine_settings_t::flags`
`set_engine_settings`
`get_engine_settings`
`engine_settings_t::MicrostepMode, get_engine_settings, set_engine_settings`

- `#define MICROSTEP_MODE_FULL 0x01`
Full step mode.
- `#define MICROSTEP_MODE_FRAC_2 0x02`
1/2 step mode.
- `#define MICROSTEP_MODE_FRAC_4 0x03`
1/4 step mode.
- `#define MICROSTEP_MODE_FRAC_8 0x04`
1/8 step mode.
- `#define MICROSTEP_MODE_FRAC_16 0x05`
1/16 step mode.
- `#define MICROSTEP_MODE_FRAC_32 0x06`
1/32 step mode.
- `#define MICROSTEP_MODE_FRAC_64 0x07`
1/64 step mode.
- `#define MICROSTEP_MODE_FRAC_128 0x08`
1/128 step mode.
- `#define MICROSTEP_MODE_FRAC_256 0x09`
1/256 step mode.

Flags of engine type

Specify motor type. Flags returned by query of engine settings.

See also

`engine_settings_t::flags`
`set_entype_settings`
`get_entype_settings`
`entype_settings_t::EngineType, get_entype_settings, set_entype_settings`

- `#define ENGINE_TYPE_NONE 0x00`
A value that shouldn't be used.
- `#define ENGINE_TYPE_DC 0x01`
DC motor.
- `#define ENGINE_TYPE_2DC 0x02`
2 DC motors.
- `#define ENGINE_TYPE_STEP 0x03`
Step motor.
- `#define ENGINE_TYPE_TEST 0x04`
Duty cycle are fixed.
- `#define ENGINE_TYPE_BRUSHLESS 0x05`
Brushless motor.

Flags of driver type

Specify driver type. Flags returned by query of engine settings.

See also

`engine_settings_t::flags`
`set_entype_settings`
`get_entype_settings`
`entype_settings_t::DriverType, get_entype_settings, set_entype_settings`

- `#define DRIVER_TYPE_DISCRETE_FET 0x01`
Driver with discrete FET keys.
- `#define DRIVER_TYPE_INTEGRATE 0x02`
Driver with integrated IC.
- `#define DRIVER_TYPE_EXTERNAL 0x03`
External driver.

Flags of power settings of stepper motor

Specify power settings. Flags returned by query of power settings.

See also

`power_settings_t::flags`
`get_power_settings`
`set_power_settings`
`power_settings_t::PowerFlags, get_power_settings, set_power_settings`

- `#define POWER_REDUCT_ENABLED 0x01`
Current reduction enabled after CurrReductDelay, if this flag is set.
- `#define POWER_OFF_ENABLED 0x02`
Power off enabled after PowerOffDelay, if this flag is set.
- `#define POWER_SMOOTH_CURRENT 0x04`
Current ramp-up/down is performed smoothly during current.set_time, if this flag is set.

Flags of secure settings

Specify secure settings. Flags returned by query of secure settings.

See also

`secure_settings_t::flags`
`get_secure_settings`
`set_secure_settings`
`secure_settings_t::Flags, get_secure_settings, set_secure_settings`

- `#define ALARM_ON_DRIVER_OVERHEATING 0x01`
If this flag is set enter Alarm state on driver overheat signal.
- `#define LOW_UPWR_PROTECTION 0x02`
If this flag is set turn off motor when voltage is lower than LowUpwrOff.
- `#define H_BRIDGE_ALERT 0x04`
If this flag is set then turn off the power unit with a signal problem in one of the transistor bridge.
- `#define ALARM_ON_BORDERS_SWAP_MISSET 0x08`
If this flag is set enter Alarm state on borders swap misset.
- `#define ALARM_FLAGS_STICKING 0x10`
If this flag is set only a STOP command can turn all alarms to 0.
- `#define USB_BREAK_RECONNECT 0x20`
If this flag is set USB brake reconnect module will be enable.

Position setting flags

Flags used in setting of position.

See also

`get_position`
`set_position`
`set_position_t::PosFlags, set_position`

- `#define SETPOS_IGNORE_POSITION 0x01`
Will not reload position in steps/microsteps if this flag is set.
- `#define SETPOS_IGNORE_ENCODER 0x02`
Will not reload encoder state if this flag is set.

Feedback type.

See also

`set_feedback_settings`
`get_feedback_settings`
`feedback_settings_t::FeedbackType, get_feedback_settings, set_feedback_settings`

- `#define FEEDBACK_ENCODER 0x01`
Feedback by encoder.
- `#define FEEDBACK_ENCODERHALL 0x03`
Feedback by Hall detector.
- `#define FEEDBACK_EMF 0x04`
Feedback by EMF.
- `#define FEEDBACK_NONE 0x05`
Feedback is absent.

Describes feedback flags.

See also

`set_feedback_settings`
`get_feedback_settings`
`feedback_settings_t::FeedbackFlags, get_feedback_settings, set_feedback_settings`

- `#define FEEDBACK_ENC_REVERSE 0x01`
Reverse count of encoder.
- `#define FEEDBACK_HALL_REVERSE 0x02`
Reverce count position on the Hall sensor.

Flags for synchronization input setup

See also

`sync_settings.t::syncin_flags`
`get_sync_settings`
`set_sync_settings`
`sync_in_settings.t::SyncInFlags, get_sync_in_settings, set_sync_in_settings`

- `#define SYNCIN_ENABLED 0x01`
Synchronization in mode is enabled, if this flag is set.
- `#define SYNCIN_INVERT 0x02`
Trigger on falling edge if flag is set, on rising edge otherwise.
- `#define SYNCIN_GOTOPOSITION 0x04`
The engine is go to position specified in Position and uPosition, if this flag is set.

Flags of synchronization output

See also

- `sync_settings.t::syncout_flags`
- `get_sync_settings`
- `set_sync_settings`
- `sync_out_settings.t::SyncOutFlags, get_sync_out_settings, set_sync_out_settings`
- `#define SYNCOUT_ENABLED 0x01`
Synchronization out pin follows the synchronization logic, if set.
- `#define SYNCOUT_STATE 0x02`
When output state is fixed by negative SYNCOUT_ENABLED flag, the pin state is in accordance with this flag state.
- `#define SYNCOUT_INVERT 0x04`
Low level is active, if set, and high level is active otherwise.
- `#define SYNCOUT_IN_STEPS 0x08`
Use motor steps/encoder pulses instead of milliseconds for output pulse generation if the flag is set.
- `#define SYNCOUT_ONSTART 0x10`
Generate synchronization pulse when movement starts.
- `#define SYNCOUT_ONSTOP 0x20`
Generate synchronization pulse when movement stops.
- `#define SYNCOUT_ONPERIOD 0x40`
Generate synchronization pulse every SyncOutPeriod encoder pulses.

External IO setup flags

See also

- `extio_settings.t::setup_flags`
- `get_extio_settings`
- `set_extio_settings`
- `extio_settings.t::EXTIOSetupFlags, get_extio_settings, set_extio_settings`
- `#define EXTIO_SETUP_OUTPUT 0x01`
EXTIO works as output if flag is set, works as input otherwise.
- `#define EXTIO_SETUP_INVERT 0x02`
Interpret EXTIO states and fronts inverted if flag is set.

External IO mode flags

See also

- `extio_settings.t::extio_mode_flags`
- `get_extio_settings`
- `set_extio_settings`
- `extio_settings.t::EXTIOModeFlags, get_extio_settings, set_extio_settings`
- `#define EXTIO_SETUP_MODE_IN_NOP 0x00`
Do nothing.
- `#define EXTIO_SETUP_MODE_IN_STOP 0x01`
Issue STOP command, ceasing the engine movement.
- `#define EXTIO_SETUP_MODE_IN_PWOF 0x02`
Issue PWOF command, powering off all engine windings.
- `#define EXTIO_SETUP_MODE_IN_MOVR 0x03`
Issue MOVR command with last used settings.
- `#define EXTIO_SETUP_MODE_IN_HOME 0x04`
Issue HOME command.
- `#define EXTIO_SETUP_MODE_OUT_OFF 0x00`
EXTIO pin always set in inactive state.
- `#define EXTIO_SETUP_MODE_OUT_ON 0x10`

- #define EXTIO_SETUP_MODE_OUT_MOVING 0x20
EXTIO pin always set in active state.
- #define EXTIO_SETUP_MODE_OUT_ALARM 0x30
EXTIO pin stays active during moving state.
- #define EXTIO_SETUP_MODE_OUT_MOTOR_ON 0x40
EXTIO pin stays active during Alarm state.
- #define EXTIO_SETUP_MODE_OUT_MOTOR_FOUND 0x50
EXTIO pin stays active when windings are powered.
- #define EXTIO_SETUP_MODE_OUT_MOTOR_CONNECTED 0x60
EXTIO pin stays active when motor is connected (first winding).

Border flags

Specify types of borders and motor behaviour on borders. May be combined with bitwise OR.

See also

`get_edges_settings`
`set_edges_settings`
`edges_settings.t::BorderFlags, get_edges_settings, set_edges_settings`

- #define BORDER_IS_ENCODER 0x01
Borders are fixed by predetermined encoder values, if set; borders position on limit switches, if not set.
- #define BORDER_STOP_LEFT 0x02
Motor should stop on left border.
- #define BORDER_STOP_RIGHT 0x04
Motor should stop on right border.
- #define BORDERS_SWAP_MISSET_DETECTION 0x08
Motor should stop on both borders.

Limit switches flags

Specify electrical behaviour of limit switches like order and pulled positions. May be combined with bitwise OR.

See also

`get_edges_settings`
`set_edges_settings`
`edges_settings.t::EnderFlags, get_edges_settings, set_edges_settings`

- #define ENDER_SWAP 0x01
First limit switch on the right side, if set; otherwise on the left side.
- #define ENDER_SW1_ACTIVE_LOW 0x02
1 - Limit switch connected to pin SW1 is triggered by a low level on pin.
- #define ENDER_SW2_ACTIVE_LOW 0x04
1 - Limit switch connected to pin SW2 is triggered by a low level on pin.

Brake settings flags

Specify behaviour of brake. May be combined with bitwise OR.

See also

`get_brake_settings`
`set_brake_settings`
`brake_settings.t::BrakeFlags, get_brake_settings, set_brake_settings`

- #define BRAKE_ENABLED 0x01
Brake control is enabled, if this flag is set.
- #define BRAKE_ENG_PWROFF 0x02
Brake turns off power of step motor, if this flag is set.

Control flags

Specify motor control settings by joystick or buttons. May be combined with bitwise OR.

See also

get_control_settings
set_control_settings
control_settings_t::Flags, *get_control_settings*, *set_control_settings*

- #define **CONTROL_MODE_BITS** 0x03
Bits to control engine by joystick or buttons.
- #define **CONTROL_MODE_OFF** 0x00
Control is disabled.
- #define **CONTROL_MODE_JOY** 0x01
Control by joystick.
- #define **CONTROL_MODE_LR** 0x02
Control by left/right buttons.
- #define **CONTROL_BTN_LEFT_PUSHED_OPEN** 0x04
Pushed left button corresponds to open contact, if this flag is set.
- #define **CONTROL_BTN_RIGHT_PUSHED_OPEN** 0x08
Pushed right button corresponds to open contact, if this flag is set.

Joystick flags

Control joystick states.

See also

set_joystick_settings
get_joystick_settings
joystick_settings_t::JoyFlags, *get_joystick_settings*, *set_joystick_settings*

- #define **JOY_REVERSE** 0x01
Joystick action is reversed.

Position control flags

Specify settings of position control. May be combined with bitwise OR.

See also

get_ctp_settings
set_ctp_settings
ctp_settings_t::CTPFlags, *get_ctp_settings*, *set_ctp_settings*

- #define **CTP_ENABLED** 0x01
Position control is enabled, if flag set.
- #define **CTP_BASE** 0x02
Position control is based on revolution sensor, if this flag is set; otherwise it is based on encoder.
- #define **CTP_ALARM_ON_ERROR** 0x04
Set ALARM on mismatch, if flag set.
- #define **REV_SENS_INV** 0x08
Sensor is active when it 0 and invert makes active level 1.

Home settings flags

Specify behaviour for home command. May be combined with bitwise OR.

See also

get_home_settings
set_home_settings
command_home
home_settings_t::HomeFlags, *get_home_settings*, *set_home_settings*

- #define **HOME_DIR_FIRST** 0x01

- `#define HOME_DIR_SECOND 0x02`
Flag defines direction of 1st motion after execution of home command.
- `#define HOME_MV_SEC_EN 0x04`
Flag defines direction of 2nd motion.
- `#define HOME_HALF_MV 0x08`
Use the second phase of calibration to the home position, if set; otherwise the second phase is skipped.
- `#define HOME_STOP_FIRST_BITS 0x30`
Bits of the first stop selector.
- `#define HOME_STOP_FIRST_REV 0x10`
First motion stops by revolution sensor.
- `#define HOME_STOP_FIRST_SYN 0x20`
First motion stops by synchronization input.
- `#define HOME_STOP_FIRST_LIM 0x30`
First motion stops by limit switch.
- `#define HOME_STOP_SECOND_BITS 0xC0`
Bits of the second stop selector.
- `#define HOME_STOP_SECOND_REV 0x40`
Second motion stops by revolution sensor.
- `#define HOME_STOP_SECOND_SYN 0x80`
Second motion stops by synchronization input.
- `#define HOME_STOP_SECOND_LIM 0xC0`
Second motion stops by limit switch.

UART parity flags

See also

- uart_settings_t::UARTSetupFlags, get_uart_settings, set_uart_settings*
- `#define UART_PARITY_BITS 0x03`
Bits of the parity.
 - `#define UART_PARITY_BIT_EVEN 0x00`
Parity bit 1, if even.
 - `#define UART_PARITY_BIT_ODD 0x01`
Parity bit 1, if odd.
 - `#define UART_PARITY_BIT_SPACE 0x02`
Parity bit always 0.
 - `#define UART_PARITY_BIT_MARK 0x03`
Parity bit always 1.
 - `#define UART_PARITY_BIT_USE 0x04`
None parity.
 - `#define UART_STOP_BIT 0x08`
If set - one stop bit, else two stop bit.

Motor Type flags

See also

- motor_settings_t::MotorType, get_motor_settings, set_motor_settings*
- `#define MOTOR_TYPE_STEP 0x01`
Step engine.
 - `#define MOTOR_TYPE_DC 0x02`
DC engine.
 - `#define MOTOR_TYPE_BLDC 0x03`
BLDC engine.

Encoder settings flags

See also

- `encoder.settings_t::EncoderSettings`, `get_encoder_settings`, `set_encoder_settings`
- `#define ENCSET_DIFFERENTIAL_OUTPUT 0x001`
If flag is set the encoder has differential output, else single ended output.
- `#define ENCSET_PUSHPULL_OUTPUT 0x004`
If flag is set the encoder has push-pull output, else open drain output.
- `#define ENCSET_INDEXCHANNEL_PRESENT 0x010`
If flag is set the encoder has index channel, else encoder hasn't it.
- `#define ENCSET_REVOLUTIONSENSOR_PRESENT 0x040`
If flag is set the encoder has revolution sensor, else encoder hasn't it.
- `#define ENCSET_REVOLUTIONSENSOR_ACTIVE_HIGH 0x100`
If flag is set the revolution sensor active state is high logic state, else active state is low logic state.

Magnetic brake settings flags

See also

- `accessories.settings_t::MBSettings`, `get_accessories_settings`, `set_accessories_settings`

- `#define MB_AVAILABLE 0x01`
If flag is set the magnetic brake is available.
- `#define MB_POWERED_HOLD 0x02`
If this flag is set the magnetic brake is on when powered.

Temperature sensor settings flags

See also

- `accessories.settings_t::LimitSwitchesSettings`, `get_accessories_settings`, `set_accessories_settings`

- `#define TS_TYPE_BITS 0x07`
Bits of the temperature sensor type.
- `#define TS_TYPE_THERMOCOUPLE 0x01`
Thermocouple.
- `#define TS_TYPE_SEMICONDUCTOR 0x02`
The semiconductor temperature sensor.
- `#define TS_AVAILABLE 0x08`
If flag is set the temperature sensor is available.
- `#define LS_ON_SW1_AVAILABLE 0x01`
If flag is set the limit switch connected to pin SW1 is available.
- `#define LS_ON_SW2_AVAILABLE 0x02`
If flag is set the limit switch connected to pin SW2 is available.
- `#define LS_SW1_ACTIVE_LOW 0x04`
If flag is set the limit switch connected to pin SW1 is triggered by a low level on pin.
- `#define LS_SW2_ACTIVE_LOW 0x08`
If flag is set the limit switch connected to pin SW2 is triggered by a low level on pin.
- `#define LS_SHORTED 0x10`
If flag is set the Limit switches is shorted.

Typedefs

- `typedef int device_t`
Type describes device identifier.
- `typedef int result_t`
Type specifies result of any operation.
- `typedef uint32_t device_enumeration_t`
TODO.
- `typedef struct calibration_t calibration_t`
Calibration companion structure TODO docme.

Functions

Controller settings setup

Functions for adjusting engine read/write almost all controller settings.

- `result_t XIMC_API set_feedback_settings (device_t id, const feedback_settings_t *feedback_settings)`
Set feedback settings.
- `result_t XIMC_API get_feedback_settings (device_t id, feedback_settings_t *feedback_settings)`
Read feedback settings.
- `result_t XIMC_API set_home_settings (device_t id, const home_settings_t *home_settings)`
Set home settings.
- `result_t XIMC_API set_home_settings_calb (device_t id, const home_settings_calb_t *home_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API get_home_settings (device_t id, home_settings_t *home_settings)`
Read home settings.
- `result_t XIMC_API get_home_settings_calb (device_t id, home_settings_calb_t *home_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API set_move_settings (device_t id, const move_settings_t *move_settings)`
Set command setup movement (speed, acceleration, threshold and etc).
- `result_t XIMC_API set_move_settings_calb (device_t id, const move_settings_calb_t *move_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API get_move_settings (device_t id, move_settings_t *move_settings)`
Read command setup movement (speed, acceleration, threshold and etc).
- `result_t XIMC_API get_move_settings_calb (device_t id, move_settings_calb_t *move_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API set_engine_settings (device_t id, const engine_settings_t *engine_settings)`
Set engine settings.
- `result_t XIMC_API set_engine_settings_calb (device_t id, const engine_settings_calb_t *engine_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API get_engine_settings (device_t id, engine_settings_t *engine_settings)`
Read engine settings.
- `result_t XIMC_API get_engine_settings_calb (device_t id, engine_settings_calb_t *engine_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API set_entype_settings (device_t id, const entype_settings_t *entype_settings)`
Set engine type and driver type.
- `result_t XIMC_API get_entype_settings (device_t id, entype_settings_t *entype_settings)`
Return engine type and driver type.
- `result_t XIMC_API set_power_settings (device_t id, const power_settings_t *power_settings)`
Set settings of step motor power control.
- `result_t XIMC_API get_power_settings (device_t id, power_settings_t *power_settings)`
Read settings of step motor power control.
- `result_t XIMC_API set_secure_settings (device_t id, const secure_settings_t *secure_settings)`
Set protection settings.
- `result_t XIMC_API get_secure_settings (device_t id, secure_settings_t *secure_settings)`
Read protection settings.
- `result_t XIMC_API set_edges_settings (device_t id, const edges_settings_t *edges_settings)`
Set border and limit switches settings.
- `result_t XIMC_API set_edges_settings_calb (device_t id, const edges_settings_calb_t *edges_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API get_edges_settings (device_t id, edges_settings_t *edges_settings)`
Read border and limit switches settings.
- `result_t XIMC_API get_edges_settings_calb (device_t id, edges_settings_calb_t *edges_settings_calb, const calibration_t *calibration)`
- `result_t XIMC_API set_pid_settings (device_t id, const pid_settings_t *pid_settings)`
Set PID settings.
- `result_t XIMC_API get_pid_settings (device_t id, pid_settings_t *pid_settings)`
Read PID settings.
- `result_t XIMC_API set_sync_in_settings (device_t id, const sync_in_settings_t *sync_in_settings)`
Set input synchronization settings.

- `result_t XIMC_API set_sync_in_settings_calb (device_t id, const sync_in_settings_calb_t *sync_in_settings_calb, const calibration_t *calibration)`
`Read input synchronization settings.`
- `result_t XIMC_API get_sync_in_settings (device_t id, sync_in_settings_t *sync_in_settings)`
`Read input synchronization settings.`
- `result_t XIMC_API set_sync_out_settings_calb (device_t id, sync_out_settings_calb_t *sync_out_settings_calb, const calibration_t *calibration)`
`Set output synchronization settings.`
- `result_t XIMC_API get_sync_out_settings_calb (device_t id, sync_out_settings_calb_t *sync_out_settings_calb, const calibration_t *calibration)`
`Read output synchronization settings.`
- `result_t XIMC_API get_sync_out_settings (device_t id, sync_out_settings_t *sync_out_settings)`
`Read output synchronization settings.`
- `result_t XIMC_API set_extio_settings (device_t id, const extio_settings_t *extio_settings)`
`Set EXTIO settings.`
- `result_t XIMC_API get_extio_settings (device_t id, extio_settings_t *extio_settings)`
`Read EXTIO settings.`
- `result_t XIMC_API set_brake_settings (device_t id, const brake_settings_t *brake_settings)`
`Set settings of brake control.`
- `result_t XIMC_API get_brake_settings (device_t id, brake_settings_t *brake_settings)`
`Read settings of brake control.`
- `result_t XIMC_API set_control_settings (device_t id, const control_settings_t *control_settings)`
`Set settings of motor control.`
- `result_t XIMC_API set_control_settings_calb (device_t id, const control_settings_calb_t *control_settings_calb, const calibration_t *calibration)`
`Set control settings calibration.`
- `result_t XIMC_API get_control_settings (device_t id, control_settings_t *control_settings)`
`Read settings of motor control.`
- `result_t XIMC_API get_control_settings_calb (device_t id, control_settings_calb_t *control_settings_calb, const calibration_t *calibration)`
`Read control settings calibration.`
- `result_t XIMC_API set_joystick_settings (device_t id, const joystick_settings_t *joystick_settings)`
`Set settings of joystick.`
- `result_t XIMC_API get_joystick_settings (device_t id, joystick_settings_t *joystick_settings)`
`Read settings of joystick.`
- `result_t XIMC_API set_ctp_settings (device_t id, const ctp_settings_t *ctp_settings)`
`Set settings of control position(is only used with stepper motor).`
- `result_t XIMC_API get_ctp_settings (device_t id, ctp_settings_t *ctp_settings)`
`Read settings of control position(is only used with stepper motor).`
- `result_t XIMC_API set_uart_settings (device_t id, const uart_settings_t *uart_settings)`
`Set UART settings.`
- `result_t XIMC_API get_uart_settings (device_t id, uart_settings_t *uart_settings)`
`Read UART settings.`
- `result_t XIMC_API set_controller_name (device_t id, const controller_name_t *controller_name)`
`Write user controller name and flags of setting from FRAM.`
- `result_t XIMC_API get_controller_name (device_t id, controller_name_t *controller_name)`
`Read user controller name and flags of setting from FRAM.`

Group of commands movement control

- `result_t XIMC_API command_stop (device_t id)`
`Immediately stop the engine, the transition to the STOP mode key BREAK (winding short-circuited), the regime "retention" is deactivated for DC motors, keeping current in the windings for stepper motors (with Power management settings).`
- `result_t XIMC_API set_add_sync_in_action (device_t id, const add_sync_in_action_t *add_sync_in_action)`
`This command adds one element of the FIFO commands that are executed when input clock pulse.`
- `result_t XIMC_API set_add_sync_in_action_calb (device_t id, const add_sync_in_action_calb_t *add_sync_in_action_calb, const calibration_t *calibration)`
`Set add sync in action calibration.`
- `result_t XIMC_API command_power_off (device_t id)`
`Power off device.`

- **result_t XIMC_API command_move (device_t id, int Position, int uPosition)**

Immediately power off motor regardless its state.
- **result_t XIMC_API command_move_calb (device_t id, float Position, const calibration_t *calibration)**

Upon receiving the command "move" the engine starts to move with pre-set parameters (speed, acceleration, retention), to the point specified to the Position, uPosition.
- **result_t XIMC_API command_movr (device_t id, int DeltaPosition, int uDeltaPosition)**

Upon receiving the command "movr" engine starts to move with pre-set parameters (speed, acceleration, hold), left or right (depending on the sign of DeltaPosition) by the number of pulses specified in the fields DeltaPosition, uDeltaPosition.
- **result_t XIMC_API command_movr_calb (device_t id, float DeltaPosition, const calibration_t *calibration)**
- **result_t XIMC_API command_home (device_t id)**

The positive direction is to the right.
- **result_t XIMC_API command_left (device_t id)**

Start continuous moving to the left.
- **result_t XIMC_API command_right (device_t id)**

Start continuous moving to the right.
- **result_t XIMC_API command_loft (device_t id)**

Upon receiving the command "loft" the engine is shifted from the current point to a distance GENG :: Antiplay, then move to the same point.
- **result_t XIMC_API command_sstp (device_t id)**

soft stop engine.
- **result_t XIMC_API get_position (device_t id, get_position_t *the_get_position)**

Reads the value position in steps and micro for stepper motor and encoder steps all engines.
- **result_t XIMC_API get_position_calb (device_t id, get_position_calb_t *the_get_position_calb, const calibration_t *calibration)**
- **result_t XIMC_API set_position (device_t id, const set_position_t *the_set_position)**

Sets any position value in steps and micro for stepper motor and encoder steps of all engines.
- **result_t XIMC_API set_position_calb (device_t id, const set_position_calb_t *the_set_position_calb, const calibration_t *calibration)**
- **result_t XIMC_API command_zero (device_t id)**

Sets the current position and the position in which the traffic moves by the move command and movr zero for all cases, except for movement to the target position.

Group of commands to save and load settings

- **result_t XIMC_API command_save_settings (device_t id)**

Save all settings from controller's RAM to controller's flash memory, replacing previous data in controller's flash memory.
- **result_t XIMC_API command_read_settings (device_t id)**

Read all settings from controller's flash memory to controller's RAM, replacing previous data in controller's RAM.
- **result_t XIMC_API command_eesave_settings (device_t id)**

Save settings from controller's RAM to stage's EEPROM memory, whitch spontaneity connected to stage and it isn't change without it mechanical reconstruction.
- **result_t XIMC_API command_eeread_settings (device_t id)**

Read settings from controller's RAM to stage's EEPROM memory, whitch spontaneity connected to stage and it isn't change without it mechanical reconstruction.
- **result_t XIMC_API get_chart_data (device_t id, chart_data_t *chart_data)**

Return device electrical parameters, useful for charts.
- **result_t XIMC_API get_serial_number (device_t id, unsigned int *SerialNumber)**

Read device serial number.
- **result_t XIMC_API get_firmware_version (device_t id, unsigned int *Major, unsigned int *Minor, unsigned int *Release)**

Read controller's firmware version.
- **result_t XIMC_API service_command_updf (device_t id)**

Command puts the controller to update the firmware.

Service commands

- `result_t XIMC_API set_serial_number (device_t id, const serial_number_t *serial_number)`
Write device serial number to controller's flash memory.
- `result_t XIMC_API get_analog_data (device_t id, analog_data_t *analog_data)`
Read analog data structure that contains raw analog data from ADC embedded on board.
- `result_t XIMC_API get_debug_read (device_t id, debug_read_t *debug_read)`
Read data from firmware for debug purpose.

Group of commands to work with EEPROM

- `result_t XIMC_API set_stage_name (device_t id, const stage_name_t *stage_name)`
Write user stage name from EEPROM.
- `result_t XIMC_API get_stage_name (device_t id, stage_name_t *stage_name)`
Read user stage name from EEPROM.
- `result_t XIMC_API set_stage_information (device_t id, const stage_information_t *stage_information)`
Set stage information to EEPROM.
- `result_t XIMC_API get_stage_information (device_t id, stage_information_t *stage_information)`
Read stage information from EEPROM.
- `result_t XIMC_API set_stage_settings (device_t id, const stage_settings_t *stage_settings)`
Set stage settings to EEPROM.
- `result_t XIMC_API get_stage_settings (device_t id, stage_settings_t *stage_settings)`
Read stage settings from EEPROM.
- `result_t XIMC_API set_motor_information (device_t id, const motor_information_t *motor_information)`
Set motor information to EEPROM.
- `result_t XIMC_API get_motor_information (device_t id, motor_information_t *motor_information)`
Read motor information from EEPROM.
- `result_t XIMC_API set_motor_settings (device_t id, const motor_settings_t *motor_settings)`
Set motor settings to EEPROM.
- `result_t XIMC_API get_motor_settings (device_t id, motor_settings_t *motor_settings)`
Read motor settings from EEPROM.
- `result_t XIMC_API set_encoder_information (device_t id, const encoder_information_t *encoder_information)`
Set encoder information to EEPROM.
- `result_t XIMC_API get_encoder_information (device_t id, encoder_information_t *encoder_information)`
Read encoder information from EEPROM.
- `result_t XIMC_API set_encoder_settings (device_t id, const encoder_settings_t *encoder_settings)`
Set encoder settings to EEPROM.
- `result_t XIMC_API get_encoder_settings (device_t id, encoder_settings_t *encoder_settings)`
Read encoder settings from EEPROM.
- `result_t XIMC_API set_hallsensor_information (device_t id, const hallsensor_information_t *hallsensor_information)`
Set hall sensor information to EEPROM.
- `result_t XIMC_API get_hallsensor_information (device_t id, hallsensor_information_t *hallsensor_information)`
Read hall sensor information from EEPROM.
- `result_t XIMC_API set_hallsensor_settings (device_t id, const hallsensor_settings_t *hallsensor_settings)`
Set hall sensor settings to EEPROM.
- `result_t XIMC_API get_hallsensor_settings (device_t id, hallsensor_settings_t *hallsensor_settings)`
Read hall sensor settings from EEPROM.
- `result_t XIMC_API set_gear_information (device_t id, const gear_information_t *gear_information)`
Set gear information to EEPROM.
- `result_t XIMC_API get_gear_information (device_t id, gear_information_t *gear_information)`
Read gear information from EEPROM.
- `result_t XIMC_API set_gear_settings (device_t id, const gear_settings_t *gear_settings)`
Set gear settings to EEPROM.
- `result_t XIMC_API get_gear_settings (device_t id, gear_settings_t *gear_settings)`

- `result_t XIMC_API set_accessories_settings (device_t id, const accessories_settings_t *accessories_settings)`

Read gear settings from EEPROM.
- `result_t XIMC_API get_accessories_settings (device_t id, accessories_settings_t *accessories_settings)`

Set additional accessories information to EEPROM.
- `result_t XIMC_API get_bootloader_version (device_t id, unsigned int *Major, unsigned int *Minor, unsigned int *Release)`

Read additional accessories information from EEPROM.
- `result_t XIMC_API goto_firmware (device_t id, uint8_t *ret)`

Read controller's firmware version.
- `result_t XIMC_API has_firmware (const char *name, uint8_t *ret)`

TODO Check for firmware on device.
- `result_t XIMC_API command_update_firmware (const char *name, const uint8_t *data, uint32_t data_size)`

Check for firmware on device.
- `result_t XIMC_API write_key (const char *name, uint8_t *key)`

Update firmware.
- `result_t XIMC_API command_reset (device_t id)`

Write controller key.
- `result_t XIMC_API command_clear_fram (device_t id)`

Reset controller.
- `result_t XIMC_API command_clear_fram (device_t id)`

Clear controller FRAM.

Boards and drivers control

Functions for searching and opening/closing devices

- `typedef char * pchar`

Nevermind.
- `typedef void(XIMC_CALLCONV * logging_callback_t)(int loglevel, const wchar_t *message)`

Logging callback prototype.
- `device_t XIMC_API open_device (const char *name)`

Open a device with OS name name and return identifier of the device which can be used in calls.
- `result_t XIMC_API close_device (device_t *id)`

Close specified device.
- `result_t XIMC_API probe_device (const char *name)`

Check if a device with OS name name is XIMC device.
- `device_enumeration_t XIMC_API enumerate_devices (int probe_flags)`

Enumerate all devices that looks like valid.
- `result_t XIMC_API free_enumerate_devices (device_enumeration_t device_enumeration)`

Free memory returned by enumerate_devices.
- `int XIMC_API get_device_count (device_enumeration_t device_enumeration)`

Get device count.
- `pchar XIMC_API get_device_name (device_enumeration_t device_enumeration, int device_index)`

Get device name from the device enumeration.
- `result_t XIMC_API get_enumerate_device_serial (device_enumeration_t device_enumeration, int device_index, uint32_t *serial)`

Get device serial number from the device enumeration.
- `result_t XIMC_API get_enumerate_device_information (device_enumeration_t device_enumeration, int device_index, device_information_t *device_information)`

Get device information from the device enumeration.
- `result_t XIMC_API reset_locks ()`

Reset library locks in a case of deadlock.
- `result_t XIMC_API ximc_fix_usbser_sys (const char *device_name)`

Fix for errors in Windows USB driver stack.

- void **XIMC_API msec_sleep** (unsigned int msec)
Sleeps for a specified amount of time.
- void **XIMC_API ximc_version** (char *version)
Returns a library version.
- void **XIMC_API logging_callback_stderr_wide** (int loglevel, const wchar_t *message)
Simple callback for logging to stderr in wide chars.
- void **XIMC_API logging_callback_stderr_narrow** (int loglevel, const wchar_t *message)
Simple callback for logging to stderr in narrow (single byte) chars.
- void **XIMC_API set_logging_callback** (logging_callback_t logging_callback)
Sets a logging callback.
- result_t **XIMC_API get_status** (device_t id, status_t *status)
Return device state.
- result_t **XIMC_API get_status_calb** (device_t id, status_calb_t *status, const calibration_t *calibration)
TODO document me Useful structure that contains current controller status, including speed, position and boolean flags.
- result_t **XIMC_API get_device_information** (device_t id, device_information_t *device_information)
Return device information.

5.1.1 Detailed Description

Header file for libximc library.

5.1.2 Macro Definition Documentation

5.1.2.1 #define BORDERS_SWAP_MISSET_DETECTION 0x08

Motor should stop on both borders.

Need to save motor then wrong border settings is set

5.1.2.2 #define DRIVER_TYPE_DISCRETE_FET 0x01

Driver with discrete FET keys.

Default option.

5.1.2.3 #define ENGINE_ACCEL_ON 0x10

Acceleration enable flag.

If it set, motion begins with acceleration and ends with deceleration.

5.1.2.4 #define ENGINE_ANTIPLAY 0x08

Play compensation flag.

If it set, engine makes backlash (play) compensation procedure and reach the predetermined position accurately on low speed.

5.1.2.5 #define ENGINE_MAX_SPEED 0x04

Max speed flag.

If it is set, engine uses maximum speed achievable with the present engine settings as nominal speed.

5.1.2.6 #define ENGINE_REVERSE 0x01

Reverse flag.

It determines motor shaft rotation direction that corresponds to feedback counts increasing. If not set (default), motor shaft rotation direction under positive voltage corresponds to feedback counts increasing and vice versa. Change it if you see that positive directions on motor and feedback are opposite.

5.1.2.7 #define ENGINE_TYPE_TEST 0x04

Duty cycle are fixed.

Used only manufacturer.

5.1.2.8 #define ENUMERATE_PROBE 0x01

Check if a device with OS name name is XIMC device.

Be carefuyl with this flag because it sends some data to the device.

5.1.2.9 #define EXTIO_SETUP_INVERT 0x02

Interpret EXTIO states and fronts inverted if flag is set.

Falling front as input event and low logic level as active state.

5.1.2.10 #define HOME_DIR_FIRST 0x01

Flag defines direction of 1st motion after execution of home command.

Direction is right, if set; otherwise left.

5.1.2.11 #define HOME_DIR_SECOND 0x02

Flag defines direction of 2nd motion.

Direction is right, if set; otherwise left.

5.1.2.12 #define JOY_REVERSE 0x01

Joystick action is reversed.

Joystick deviation to the upper values correspond to negative speeds and vice versa.

5.1.2.13 #define MVCMD_ERROR 0x40

Finish state (1 - move command have finished with an error, 0 - move command have finished correctly).

This flags is actual when MVCMD_RUNNING signals movement finish.

5.1.2.14 #define REV_SENS_INV 0x08

Sensor is active when it 0 and invert makes active level 1.

That is, if you do not invert, it is normal logic - 0 is the activation.

5.1.2.15 #define STATE_ALARM 0x00040

Controller is in alarm state indicating that something dangerous had happened.

Most commands are ignored in this state. To reset the flag a STOP command must be issued.

5.1.2.16 #define SYNCIN_GOTOPOSITION 0x04

The engine is go to position specified in Position and uPosition, if this flag is set.

And it is shift on the Position and uPosition, if this flag is unset

5.1.2.17 #define SYNCOUT_ENABLED 0x01

Synchronization out pin follows the synchronization logic, if set.

It governed by SYNCOUT_STATE flag otherwise.

5.1.2.18 #define XIMC_API

Library import macro Macros allows to automatically import function from shared library.

It automatically expands to `dllimport` on msvc when including header file

5.1.3 Typedef Documentation

5.1.3.1 `typedef void(XIMC_CALLCONV * logging_callback_t)(int loglevel, const wchar_t *message)`

Logging callback prototype.

Parameters

<i>loglevel</i>	a loglevel
<i>message</i>	a message

5.1.4 Function Documentation

5.1.4.1 `result_t XIMC_API close_device (device_t * id)`

Close specified device.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.2 `result_t XIMC_API command_clear_fram (device_t id)`

Clear controller FRAM.

Can be used by manufacturer only

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.3 **result_t XIMC_API command_eeread_settings (device_t id)**

Read settings from controller's RAM to stage's EEPROM memory, whitch spontaneity connected to stage and it isn't change without it mechanical reconstruction.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.4 **result_t XIMC_API command_eesave_settings (device_t id)**

Save settings from controller's RAM to stage's EEPROM memory, whitch spontaneity connected to stage and it isn't change without it mechanical reconstruction.

Can be used by manufacturer only.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.5 **result_t XIMC_API command_home (device_t id)**

The positive direction is to the right.

A value of zero reverses the direction of the direction of the flag, the set speed. Restriction imposed by the trailer, act the same, except that the limit switch contact does not stop. Limit the maximum speed, acceleration and deceleration function. 1) moves the motor according to the speed FastHome, uFastHome and flag HOME_DIR_FAST until limit switch, if the flag is set HOME_STOP_ENDS, until the signal from the input synchronization if the flag HOME_STOP_SYNC (as accurately as possible is important to catch the moment of operation limit switch) or until the signal is received from the speed sensor, if the flag HOME_STOP_REV_SN 2) then moves according to the speed SlowHome, uSlowHome and flag HOME_DIR_SLOW until signal from the clock input, if the flag HOME_MV_SEC. If the flag HOME_MV_SEC reset skip this paragraph. 3) then move the motor according to the speed FastHome, uFastHome and flag HOME_DIR_SLOW a distance HomeDelta, uHomeDelta. description of flags and variable see in description for commands GHOM/SHOM

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

See also

[home_settings.t](#)
[get_home_settings](#)
[set_home_settings](#)

5.1.4.6 **result_t XIMC_API command_left (device_t id)**

Start continous moving to the left.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.7 **result_t XIMC_API command_loft (device_t id)**

Upon receiving the command "loft" the engine is shifted from the current point to a distance GENG :: Antiplay, then move to the same point.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.8 **result_t XIMC_API command_move (device_t id, int Position, int uPosition)**

Upon receiving the command "move" the engine starts to move with pre-set parameters (speed, acceleration, re-tention), to the point specified to the Position, uPosition.

For stepper motor uPosition sets the microstep for DC motor, this field is not used.

Parameters

<i>Position</i>	position to move. Range: -2147483647..2147483647.
<i>uPosition</i>	part of the position to move, microsteps. Range: -255..255.
<i>id</i>	an identifier of device

5.1.4.9 **result_t XIMC_API command_movr (device_t id, int DeltaPosition, int uDeltaPosition)**

Upon receiving the command "movr" engine starts to move with pre-set parameters (speed, acceleration, hold), left or right (depending on the sign of DeltaPosition) by the number of pulses specified in the fields DeltaPosition, uDeltaPosition.

For stepper motor uDeltaPosition sets the microstep for DC motor, this field is not used.

Parameters

<i>DeltaPosition</i>	shift from initial position. Range: -2147483647..2147483647.
<i>uDeltaPosition</i>	part of the offset shift, microsteps. Range: -255..255.
<i>id</i>	an identifier of device

5.1.4.10 **result_t XIMC_API command_power_off (device_t id)**

Immediately power off motor regardless its state.

Shouldn't be used during motion as the motor could be power on again automatically to continue movement. The command is designed for manual motor power off. When automatic power off after stop is required, use power management system.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

See also

[get_power_settings](#)
[set_power_settings](#)

5.1.4.11 **result_t XIMC_API command_read_settings (device_t id)**

Read all settings from controller's flash memory to controller's RAM, replacing previous data in controller's RAM.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.12 **result_t XIMC_API command_reset (device_t id)**

Reset controller.

Can be used by manufacturer only

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.13 **result_t XIMC_API command_right (device_t id)**

Start continuous moving to the right.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.14 **result_t XIMC_API command_save_settings (device_t id)**

Save all settings from controller's RAM to controller's flash memory, replacing previous data in controller's flash memory.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.15 **result_t XIMC_API command_sstp (device_t id)**

soft stop engine.

The motor stops with deceleration speed.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.16 **result_t XIMC_API command_stop (device_t id)**

Immediately stop the engine, the transition to the STOP, mode key BREAK (winding short-circuited), the regime "retention" is deactivated for DC motors, keeping current in the windings for stepper motors (with Power management settings).

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.17 **result_t XIMC_API command_update_firmware (const char * name, const uint8_t * data, uint32_t data_size)**

Update firmware.

Service command

Parameters

<i>name</i>	a name of device
<i>data</i>	firmware byte stream
<i>data_size</i>	size of byte stream

5.1.4.18 **result_t XIMC_API command_zero (device_t id)**

Sets the current position and the position in which the traffic moves by the move command and movr zero for all cases, except for movement to the target position.

In the latter case, set the zero current position and the target position counted so that the absolute position of the destination is the same. That is, if we were at 400 and moved to 500, then the command Zero makes the current position of 0, and the position of the destination - 100. Does not change the mode of movement that is if the motion is carried, it continues, and if the engine is in the "hold", the type of retention remains.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.19 **device_enumeration_t XIMC_API enumerate_devices (int probe_flags)**

Enumerate all devices that looks like valid.

Parameters

<i>in</i>	<i>probe_flags</i>	enumerate devices flags
-----------	--------------------	-------------------------

5.1.4.20 **result_t XIMC_API free_enumerate_devices (device_enumeration_t device_enumeration)**

Free memory returned by *enumerate_devices*.

Parameters

<i>in</i>	<i>device_enumeration</i>	opaque pointer to an enumeration device data
-----------	---------------------------	--

5.1.4.21 **result_t XIMC_API get_accessories_settings (device_t id, accessories_settings_t * accessories_settings)**

Read additional accessories information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
<i>out</i>	<i>accessories_settings</i>	structure contains information about additional accessories

5.1.4.22 **result_t XIMC_API** get_analog_data (**device_t id**, **analog_data_t * analog_data**)

Read analog data structure that contains raw analog data from ADC embedded on board.

This function used for device testing and deep recalibratlon by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
out	<i>analog_data</i>	analog data coefficients

5.1.4.23 **result_t XIMC_API** get_bootloader_version (**device_t id**, **unsigned int * Major**, **unsigned int * Minor**, **unsigned int * Release**)

Read controller's firmware version.

Parameters

	<i>id</i>	an identifier of device
out	<i>Major</i>	major version
out	<i>Minor</i>	minor version
out	<i>Release</i>	release version

5.1.4.24 **result_t XIMC_API** get_brake_settings (**device_t id**, **brake_settings_t * brake_settings**)

Read settings of brake control.

Parameters

	<i>id</i>	an identifier of device
out	<i>brake_settings</i>	structure contains settings of brake control

5.1.4.25 **result_t XIMC_API** get_chart_data (**device_t id**, **chart_data_t * chart_data**)

Return device electrical parameters, useful for charts.

Useful function that fill structure with snapshot of controller voltages and currents.

See also

[chart_data.t](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>chart_data</i>	structure with snapshot of controller parameters.

5.1.4.26 **result_t XIMC_API** get_control_settings (**device_t id**, **control_settings_t * control_settings**)

Read settings of motor control.

When choosing CTL_MODE = 1 switches motor control with the joystick. In this mode, the joystick to the maximum engine tends Move at MaxSpeed [i], where i = 0 if the previous use This mode is not selected another i. Buttons switch the room rate i. When CTL_MODE = 2 is switched on motor control using the Left / right. When you click on the button motor starts to move in the appropriate direction at a speed MaxSpeed [0], at the end of time Timeout

[i] motor move at a speed MaxSpeed [i+1]. at Transition from MaxSpeed [i] on MaxSpeed [i + 1] to acceleration, as usual.

Parameters

	<i>id</i>	an identifier of device
out	<i>control_settings</i>	structure contains settings motor control by joystick or buttons left/right.

5.1.4.27 **result_t XIMC_API get_controller_name (device_t id, controller_name_t * controller_name)**

Read user controller name and flags of setting from FRAM.

Parameters

	<i>id</i>	an identifier of device
out	<i>controller_name</i>	structure contains previously set user controller name

5.1.4.28 **result_t XIMC_API get_ctp_settings (device_t id, ctp_settings_t * ctp_settings)**

Read settings of control position(is only used with stepper motor).

When controlling the step motor with encoder (CTP_BASE 0) it is possible to detect the loss of steps. The controller knows the number of steps per revolution (GENG :: StepsPerRev) and the encoder resolution (GFBS :: IPT). When the control (flag CTP_ENABLED), the controller stores the current position in the footsteps of SM and the current position of the encoder. Further, at each step of the position encoder is converted into steps and if the difference is greater CTPMinError, a flag STATE_CTP_ERROR. When controlling the step motor with speed sensor (CTP_BASE 1), the position is controlled by him. The active edge of input clock controller stores the current value of steps. Further, at each turn checks how many steps shifted. When a mismatch CTPMinError a flag STATE_CTP_ERROR.

Parameters

	<i>id</i>	an identifier of device
out	<i>ctp_settings</i>	structure contains settings of control position

5.1.4.29 **result_t XIMC_API get_debug_read (device_t id, debug_read_t * debug_read)**

Read data from firmware for debug purpose.

Its use depends on context, firmware version and previous history.

Parameters

	<i>id</i>	an identifier of device
out	<i>DebugData[128]</i>	Debug data.

5.1.4.30 **int XIMC_API get_device_count (device_enumeration_t device_enumeration)**

Get device count.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
----	---------------------------	--

5.1.4.31 **result_t XIMC_API** get_device_information (**device_t id**, **device_information_t * device_information**)

Return device information.

All fields must point to allocated string buffers with at least 10 bytes. Works with both raw or initialized device.

Parameters

	<i>id</i>	an identifier of device
out	<i>device_information</i>	device information Device information.

See also

[get_device_information](#)

5.1.4.32 **pchar XIMC_API** get_device_name (**device_enumeration_t deviceEnumeration**, **int device_index**)

Get device name from the device enumeration.

Returns *device_index* device name.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index

5.1.4.33 **result_t XIMC_API** get_edges_settings (**device_t id**, **edges_settings_t * edges_settings**)

Read border and limit switches settings.

See also

[set_edges_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>edges_settings</i>	edges settings, specify types of borders, motor behaviour and electrical behaviour of limit switches

5.1.4.34 **result_t XIMC_API** get_encoder_information (**device_t id**, **encoder_information_t * encoder_information**)

Read encoder information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>encoder_information</i>	structure contains information about encoder

5.1.4.35 **result_t XIMC_API** get_encoder_settings (**device_t id**, **encoder_settings_t * encoder_settings**)

Read encoder settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>encoder_settings</i>	structure contains encoder settings

5.1.4.36 **result_t XIMC_API** get_engine_settings (**device_t id**, **engine_settings_t * engine_settings**)

Read engine settings.

This function fill structure with set of useful motor settings stored in controller's memory. These settings specify motor shaft movement algorithm, list of limitations and rated characteristics.

See also

[set_engine_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>engine_settings</i>	engine settings

5.1.4.37 **result_t XIMC_API** get_entype_settings (**device_t id**, **entype_settings_t * entype_settings**)

Return engine type and driver type.

Parameters

	<i>id</i>	an identifier of device
out	<i>EngineType</i>	engine type
out	<i>DriverType</i>	driver type

5.1.4.38 **result_t XIMC_API** get_enumerate_device_information (**device_enumeration_t device_enumeration**, **int device_index**, **device_information_t * device_information**)

Get device information from the device enumeration.

Returns *device_index* device serial number.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index
out	<i>device_information</i>	device information data

5.1.4.39 **result_t XIMC_API** get_enumerate_device_serial (**device_enumeration_t device_enumeration**, **int device_index**, **uint32_t * serial**)

Get device serial number from the device enumeration.

Returns *device_index* device serial number.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index
out	<i>serial</i>	device serial number

5.1.4.40 **result_t XIMC_API get_extio_settings (*device_t id*, *extio_settings_t * extio_settings*)**

Read EXTIO settings.

This function reads a structure with a set of EXTIO settings from controller's memory.

See also

[set_extio_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>extio_settings</i>	EXTIO settings

5.1.4.41 **result_t XIMC_API get_feedback_settings (*device_t id*, *feedback_settings_t * feedback_settings*)**

Read feedback settings.

Parameters

	<i>id</i>	an identifier of device
out	<i>IPS</i>	number of encoder pulses per shaft revolution. Range: 1..65535
out	<i>FeedbackType</i>	type of feedback
out	<i>FeedbackFlags</i>	flags of feedback

5.1.4.42 **result_t XIMC_API get_firmware_version (*device_t id*, *unsigned int * Major*, *unsigned int * Minor*, *unsigned int * Release*)**

Read controller's firmware version.

Parameters

	<i>id</i>	an identifier of device
out	<i>Major</i>	major version
out	<i>Minor</i>	minor version
out	<i>Release</i>	release version

5.1.4.43 **result_t XIMC_API get_gear_information (*device_t id*, *gear_information_t * gear_information*)**

Read gear information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>gear_information</i>	structure contains information about step gearhead

5.1.4.44 **result_t XIMC_API get_gear_settings (**device_t id, gear_settings_t * gear_settings**)**

Read gear settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>gear_settings</i>	structure contains step gearhead settings

5.1.4.45 **result_t XIMC_API get_hallsensor_information (**device_t id, hallsensor_information_t * hallsensor_information**)**

Read hall sensor information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>hallsensor_information</i>	structure contains information about hall sensor

5.1.4.46 **result_t XIMC_API get_hallsensor_settings (**device_t id, hallsensor_settings_t * hallsensor_settings**)**

Read hall sensor settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>hallsensor_settings</i>	structure contains hall sensor settings

5.1.4.47 **result_t XIMC_API get_home_settings (**device_t id, home_settings_t * home_settings**)**

Read home settings.

This function fill structure with settings of calibrating position.

See also

[home_settings.t](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>home_settings</i>	calibrating position settings

5.1.4.48 **result_t XIMC_API get_joystick_settings (device_t id, joystick_settings_t * joystick_settings)**

Read settings of joystick.

If joystick position is outside DeadZone limits from the central position a movement with speed, defined by the joystick DeadZone edge to 100% deviation, begins. Joystick positions inside DeadZone limits correspond to zero speed (soft stop of motion) and positions beyond Low and High limits correspond MaxSpeed [i] or -MaxSpeed [i] (see command SCTL), where i = 0 by default and can be changed with left/right buttons (see command SCTL). If next speed in list is zero (both integer and microstep parts), the button press is ignored. First speed in list shouldn't be zero. The DeadZone ranges are illustrated on the following picture. !/attachments/download/5563/range25p.png! The relationship between the deviation and the rate is exponential, allowing no switching speed combine high mobility and accuracy. The following picture illustrates this: !/attachments/download/3092/ExpJoystick.png! The nonlinearity parameter is adjustable. Setting it to zero makes deviation/speed relation linear.

Parameters

	<i>id</i>	an identifier of device
out	<i>joystick_settings</i>	structure contains joystick settings

5.1.4.49 **result_t XIMC_API get_motor_information (device_t id, motor_information_t * motor_information)**

Read motor information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>motor-information</i>	structure contains motor information

5.1.4.50 **result_t XIMC_API get_motor_settings (device_t id, motor_settings_t * motor_settings)**

Read motor settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>motor_settings</i>	structure contains motor settings

5.1.4.51 **result_t XIMC_API get_move_settings (device_t id, move_settings_t * move_settings)**

Read command setup movement (speed, acceleration, threshold and etc).

Parameters

	<i>id</i>	an identifier of device
out	<i>move_settings</i>	structure contains move settings: speed, acceleration, deceleration etc.

5.1.4.52 **result_t XIMC_API get_pid_settings (device_t id, pid_settings_t * pid_settings)**

Read PID settings.

This function fill structure with set of motor PID settings stored in controller's memory. These settings specify behaviour of PID routine for voltage. These factors are slightly different for different positioners. All boards are supplied with standart set of PID setting on controller's flash memory.

See also

[set_pid_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>pid_settings</i>	pid settings

5.1.4.53 **result_t XIMC_API get_position (device_t id, get_position_t * the_get_position)**

Reads the value position in steps and micro for stepper motor and encoder steps all engines.

Parameters

	<i>id</i>	an identifier of device
out	<i>position</i>	structure contains move settings: speed, acceleration, deceleration etc.

5.1.4.54 **result_t XIMC_API get_power_settings (device_t id, power_settings_t * power_settings)**

Read settings of step motor power control.

Used with stepper motor only.

Parameters

	<i>id</i>	an identifier of device
out	<i>power_settings</i>	structure contains settings of step motor power control

5.1.4.55 **result_t XIMC_API get_secure_settings (device_t id, secure_settings_t * secure_settings)**

Read protection settings.

Parameters

	<i>id</i>	an identifier of device
out	<i>secure_settings</i>	critical parameter settings to protect the hardware

See also

[status_t::flags](#)

5.1.4.56 **result_t XIMC_API get_serial_number (device_t id, unsigned int * SerialNumber)**

Read device serial number.

Parameters

	<i>id</i>	an identifier of device
out	<i>serial</i>	serial number

5.1.4.57 **result_t XIMC_API** get_stage_information (**device_t id**, **stage_information_t * stage_information**)

Read stage information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>stage_information</i>	structure contains stage information

5.1.4.58 **result_t XIMC_API** get_stage_name (**device_t id**, **stage_name_t * stage_name**)

Read user stage name from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>stage_name</i>	structure contains previously set user stage name

5.1.4.59 **result_t XIMC_API** get_stage_settings (**device_t id**, **stage_settings_t * stage_settings**)

Read stage settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>stage_settings</i>	structure contains stage settings

5.1.4.60 **result_t XIMC_API** get_status (**device_t id**, **status_t * status**)

Return device state.

Parameters

	<i>id</i>	an identifier of device
out	<i>status</i>	structure with snapshot of controller status Device state. Useful structure that contains current controller status, including speed, position and boolean flags.

See also

[get_status](#)

5.1.4.61 **result_t XIMC_API** get_status_calb (**device_t id**, **status_calb_t * status**, **const calibration_t * calibration**)

TODO document me Useful structure that contains current controller status, including speed, position and boolean flags.

See also

[get_status](#)

5.1.4.62 **result_t XIMC_API** get_sync_in_settings (**device_t id**, **sync_in_settings_t * sync_in_settings**)

Read input synchronization settings.

This function fill structure with set of input synchronization settings, modes, periods and flags, that specify behaviour of input synchronization. All boards are supplied with standart set of these settings.

See also

[set_sync_in_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>sync_in_settings</i>	synchronization settings

5.1.4.63 **result_t XIMC_API** get_sync_out_settings (**device_t id**, **sync_out_settings_t * sync_out_settings**)

Read output synchronization settings.

This function fill structure with set of output synchronization settings, modes, periods and flags, that specify behaviour of output synchronization. All boards are supplied with standart set of these settings.

See also

[set_sync_out_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>sync_out_settings</i>	synchronization settings

5.1.4.64 **result_t XIMC_API** get_uart_settings (**device_t id**, **uart_settings_t * uart_settings**)

Read UART settings.

This function fill structure with UART settings.

See also

[uart_settings_t](#)

Parameters

	<i>Speed</i>	UART speed
out	<i>uart.settings</i>	UART settings

5.1.4.65 **result_t XIMC_API** goto_firmware (**device_t id**, **uint8_t * ret**)

TODO Check for firmware on device.

Parameters

	<i>id</i>	an identifier of device
out	<i>ret</i>	non-zero if firmware existed

5.1.4.66 **result_t XIMC_API** has_firmware (const char * name, uint8_t * ret)

Check for firmware on device.

Parameters

	<i>name</i>	a name of device
out	<i>ret</i>	non-zero if firmware existed

5.1.4.67 void **XIMC_API** logging_callback_stderr_narrow (int loglevel, const wchar_t * message)

Simple callback for logging to stderr in narrow (single byte) chars.

Parameters

<i>loglevel</i>	a loglevel
<i>message</i>	a message

5.1.4.68 void **XIMC_API** logging_callback_stderr_wide (int loglevel, const wchar_t * message)

Simple callback for logging to stderr in wide chars.

Parameters

<i>loglevel</i>	a loglevel
<i>message</i>	a message

5.1.4.69 void **XIMC_API** msec_sleep (unsigned int msec)

Sleeps for a specified amount of time.

Parameters

<i>msec</i>	time in milliseconds
-------------	----------------------

5.1.4.70 **device_t XIMC_API** open_device (const char * name)

Open a device with OS name *name* and return identifier of the device which can be used in calls.

Parameters

in	<i>name</i>	- a device name - e.g. COM3 or /dev/tty.s123
----	-------------	--

5.1.4.71 **result_t XIMC_API** probe_device (const char * name)

Check if a device with OS name *name* is XIMC device.

Be carefuyl with this call because it sends some data to the device.

Parameters

in	<i>name</i>	- a device name
----	-------------	-----------------

5.1.4.72 **result_t XIMC_API service_command_updf (device_t id)**

Command puts the controller to update the firmware.

After receiving this command, the firmware board sets a flag (for loader), sends echo reply and restarts the controller.

5.1.4.73 **result_t XIMC_API set_accessories_settings (device_t id, const accessories_settings_t * accessories_settings)**

Set additional accessories information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>accessories_settings</i>	structure contains information about additional accessories

5.1.4.74 **result_t XIMC_API set_add_sync_in_action (device_t id, const add_sync_in_action_t * add_sync_in_action)**

This command adds one element of the FIFO commands that are executed when input clock pulse.

Each pulse synchronization or perform that action, which is described in SSNI, if the buffer is empty, or the oldest loaded into the buffer action to temporarily replace the speed and coordinate in SSNI. In the latter case this action is erased from the buffer. The number of remaining empty buffer elements can be found in the structure of GETS.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

5.1.4.75 **result_t XIMC_API set_brake_settings (device_t id, const brake_settings_t * brake_settings)**

Set settings of brake control.

Parameters

	<i>id</i>	an identifier of device
in	<i>brake_settings</i>	structure contains settings of brake control

5.1.4.76 **result_t XIMC_API set_control_settings (device_t id, const control_settings_t * control_settings)**

Set settings of motor control.

When choosing CTL_MODE = 1 switches motor control with the joystick. In this mode, the joystick to the maximum engine tends Move at MaxSpeed [i], where i = 0 if the previous use This mode is not selected another i. Buttons switch the room rate i. When CTL_MODE = 2 is switched on motor control using the Left / right. When you click on the button motor starts to move in the appropriate direction at a speed MaxSpeed [0], at the end of time Timeout [i] motor move at a speed MaxSpeed [i+1]. at Transition from MaxSpeed [i] on MaxSpeed [i +1] to acceleration, as usual.

Parameters

	<i>id</i>	an identifier of device
in	<i>control_settings</i>	structure contains settings motor control by joystick or buttons left/right.

5.1.4.77 **result_t XIMC_API** set_controller_name (**device_t id**, **const controller_name_t * controller_name**)

Write user controller name and flags of setting from FRAM.

Parameters

	<i>id</i>	an identifier of device
in	<i>controller_name</i>	structure contains previously set user controller name

5.1.4.78 **result_t XIMC_API** set_ctp_settings (**device_t id**, **const ctp_settings_t * ctp_settings**)

Set settings of control position(is only used with stepper motor).

When controlling the step motor with encoder (CTP_BASE 0) it is possible to detect the loss of steps. The controller knows the number of steps per revolution (GENG :: StepsPerRev) and the encoder resolution (GFBS :: IPT). When the control (flag CTP_ENABLED), the controller stores the current position in the footsteps of SM and the current position of the encoder. Further, at each step of the position encoder is converted into steps and if the difference is greater CTPMinError, a flag STATE_CTP_ERROR. When controlling the step motor with speed sensor (CTP_BASE 1), the position is controlled by him. The active edge of input clock controller stores the current value of steps. Further, at each turn checks how many steps shifted. When a mismatch CTPMinError a flag STATE_CTP_ERROR.

Parameters

	<i>id</i>	an identifier of device
in	<i>ctp_settings</i>	structure contains settings of control position

5.1.4.79 **result_t XIMC_API** set_edges_settings (**device_t id**, **const edges_settings_t * edges_settings**)

Set border and limit switches settings.

See also

[set_edges_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>edges_settings</i>	edges settings, specify types of borders, motor behaviour and electrical behaviour of limit switches

5.1.4.80 **result_t XIMC_API** set_encoder_information (**device_t id**, **const encoder_information_t * encoder_information**)

Set encoder information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>encoder_information</i>	structure contains information about encoder

5.1.4.81 **result_t XIMC_API** set_encoder_settings (**device_t id**, **const encoder_settings_t * encoder_settings**)

Set encoder settings to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>encoder_settings</i>	structure contains encoder settings

5.1.4.82 **result_t XIMC_API** set_engine_settings (**device_t id**, **const engine_settings_t * engine_settings**)

Set engine settings.

This function send structure with set of engine settings to controller's memory. These settings specify motor shaft movement algorithm, list of limitations and rated characteristics. Use it when you change motor, encoder, positioner etc. Please note that wrong engine settings lead to device malfunction, can lead to irreversible damage of board.

See also

[get_engine_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>engine_settings</i>	engine settings

5.1.4.83 **result_t XIMC_API** set_entype_settings (**device_t id**, **const entype_settings_t * entype_settings**)

Set engine type and driver type.

Parameters

	<i>id</i>	an identifier of device
in	<i>EngineType</i>	engine type
in	<i>DriverType</i>	driver type

5.1.4.84 **result_t XIMC_API** set_extio_settings (**device_t id**, **const extio_settings_t * extio_settings**)

Set EXTIO settings.

This function writes a structure with a set of EXTIO settings to controller's memory. By default input event are signalled through rising front and output states are signalled by high logic state.

See also

[get_extio_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>extio_settings</i>	EXTIO settings

5.1.4.85 **result_t XIMC_API** set_feedback_settings (**device_t** id, **const feedback_settings_t *** feedback_settings)

Set feedback settings.

Parameters

	<i>id</i>	an identifier of device
in	<i>IPS</i>	number of encoder pulses per shaft revolution. Range: 1..65535
in	<i>FeedbackType</i>	type of feedback
in	<i>FeedbackFlags</i>	flags of feedback

5.1.4.86 **result_t XIMC_API** set_gear_information (**device_t** id, **const gear_information_t *** gear_information)

Set gear information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>gear_information</i>	structure contains information about step gearhead

5.1.4.87 **result_t XIMC_API** set_gear_settings (**device_t** id, **const gear_settings_t *** gear_settings)

Set gear settings to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>gear_settings</i>	structure contains step gearhead settings

5.1.4.88 **result_t XIMC_API** set_hallsensor_information (**device_t** id, **const hallsensor_information_t *** hallsensor_information)

Set hall sensor information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>hallsensor_information</i>	structure contains information about hall sensor

5.1.4.89 **result_t XIMC_API** set_hallsensor_settings (**device_t** id, **const hallsensor_settings_t *** hallsensor_settings)

Set hall sensor settings to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>hallsensor_settings</i>	structure contains hall sensor settings

5.1.4.90 **result_t XIMC_API set_home_settings (device_t id, const home_settings_t * home_settings)**

Set home settings.

This function send structure with calibrating position settings to controller's memory.

See also

[home_settings.t](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>home_settings</i>	calibrating position settings

5.1.4.91 **result_t XIMC_API set_joystick_settings (device_t id, const joystick_settings_t * joystick_settings)**

Set settings of joystick.

If joystick position is outside DeadZone limits from the central position a movement with speed, defined by the joystick DeadZone edge to 100% deviation, begins. Joystick positions inside DeadZone limits correspond to zero speed (soft stop of motion) and positions beyond Low and High limits correspond MaxSpeed [i] or -MaxSpeed [i] (see command SCTL), where i = 0 by default and can be changed with left/right buttons (see command SCTL). If next speed in list is zero (both integer and microstep parts), the button press is ignored. First speed in list shouldn't be zero. The DeadZone ranges are illustrated on the following picture. !/attachments/download/5563/range25p.png! The relationship between the deviation and the rate is exponential, allowing no switching speed combine high mobility and accuracy. The following picture illustrates this: !/attachments/download/3092/ExpJoystick.png! The nonlinearity parameter is adjustable. Setting it to zero makes deviation/speed relation linear.

Parameters

	<i>id</i>	an identifier of device
in	<i>joystick_settings</i>	structure contains joystick settings

5.1.4.92 **void XIMC_API set_logging_callback (logging_callback_t logging_callback)**

Sets a logging callback.

Call resets a callback to default (stderr, syslog) if NULL passed.

Parameters

<i>logging_callback</i>	a callback for log messages
-------------------------	-----------------------------

5.1.4.93 **result_t XIMC_API set_motor_information (device_t id, const motor_information_t * motor_information)**

Set motor information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>motor-information</i>	structure contains motor information

5.1.4.94 **result_t XIMC_API set_motor_settings (device_t id, const motor_settings_t * motor_settings)**

Set motor settings to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>motor_settings</i>	structure contains motor information

5.1.4.95 **result_t XIMC_API set_move_settings (device_t id, const move_settings_t * move_settings)**

Set command setup movement (speed, acceleration, threshold and etc).

Parameters

	<i>id</i>	an identifier of device
in	<i>move_settings</i>	structure contains move settings: speed, acceleration, deceleration etc.

5.1.4.96 **result_t XIMC_API set_pid_settings (device_t id, const pid_settings_t * pid_settings)**

Set PID settings.

This function send structure with set of PID factors to controller's memory. These settings specify behaviour of PID routine for voltage. These factors are slightly different for different positioners. All boards are supplied with standart set of PID setting on controller's flash memory. Please use it for loading new PID settings when you change positioner. Please note that wrong PID settings lead to device malfunction.

See also

[get_pid_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>pid_settings</i>	pid settings

5.1.4.97 **result_t XIMC_API set_position (device_t id, const set_position_t * the_set_position)**

Sets any position value in steps and micro for stepper motor and encoder steps of all engines.

It means, that changing main indicator of position.

Parameters

	<i>id</i>	an identifier of device
out	<i>position</i>	structure contains move settings: speed, acceleration, deceleration etc.

5.1.4.98 **result_t XIMC_API set_power_settings (device_t id, const power_settings_t * power_settings)**

Set settings of step motor power control.

Used with stepper motor only.

Parameters

	<i>id</i>	an identifier of device
in	<i>power_settings</i>	structure contains settings of step motor power control

5.1.4.99 **result_t XIMC_API set_secure_settings (device_t id, const secure_settings_t * secure_settings)**

Set protection settings.

Parameters

	<i>id</i>	an identifier of device
	<i>secure_settings</i>	structure with secure data

See also

[status_t::flags](#)

5.1.4.100 **result_t XIMC_API set_serial_number (device_t id, const serial_number_t * serial_number)**

Write device serial number to controller's flash memory.

Along with the new serial number a "Key" is transmitted. The SN is changed and saved when keys match. Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>serial</i>	number structure contains new serial number and secret key.

5.1.4.101 **result_t XIMC_API set_stage_information (device_t id, const stage_information_t * stage_information)**

Set stage information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>stage-information</i>	structure contains stage information

5.1.4.102 **result_t XIMC_API** set_stage_name (**device_t** id, **const stage_name_t * stage_name**)

Write user stage name from EEPROM.

Parameters

	<i>id</i>	an identifier of device
in	<i>stage_name</i>	structure contains previously set user stage name

5.1.4.103 **result_t XIMC_API** set_stage_settings (**device_t** id, **const stage_settings_t * stage_settings**)

Set stage settings to EEPROM.

Can be used by manufacturer only

Parameters

	<i>id</i>	an identifier of device
in	<i>stage_settings</i>	structure contains stage settings

5.1.4.104 **result_t XIMC_API** set_sync_in_settings (**device_t** id, **const sync_in_settings_t * sync_in_settings**)

Set input synchronization settings.

This function send structure with set of input synchronization settings, that specify behaviour of input synchronization, to controller's memory. All boards are supplied with standart set of these settings.

See also

[get_sync_in_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>sync_in_settings</i>	synchronization settings

5.1.4.105 **result_t XIMC_API** set_sync_out_settings (**device_t** id, **const sync_out_settings_t * sync_out_settings**)

Set output synchronization settings.

This function send structure with set of output synchronization settings, that specify behaviour of output synchronization, to controller's memory. All boards are supplied with standart set of these settings.

See also

[get_sync_out_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>sync_out_settings</i>	synchronization settings

5.1.4.106 **result_t XIMC_API** set_uart_settings (**device_t** id, **const uart_settings_t *** uart_settings)

Set UART settings.

This function send structure with UART settings to controller's memory.

See also

[uart_settings_t](#)

Parameters

	<i>Speed</i>	UART speed
in	<i>uart_settings</i>	UART settings

5.1.4.107 **result_t XIMC_API** write_key (**const char * name**, **uint8_t * key**)

Write controller key.

TODO fix docs Can be used by manufacturer only

Parameters

	<i>name</i>	a name of device
in	<i>key</i>	protection key. Range: 0..4294967295

5.1.4.108 **result_t XIMC_API** ximc_fix_usbser_sys (**const char * device_name**)

Fix for errors in Windows USB driver stack.

Resets a driver if a device exists and in a hanged state.

5.1.4.109 **void XIMC_API** ximc_version (**char * version**)

Returns a library version.

Parameters

<i>version</i>	a buffer to hold a version string, 32 bytes is enough
----------------	---

Index

Accel
 move_settings_t, 35
accessories_settings_t, 7
 MBRatedCurrent, 8
 MBRatedVoltage, 8
 MBTorque, 8
 TSGrad, 8
Accuracy
 sync_out_settings_t, 48
add_sync_in_action.calb_t, 8
add_sync_in_action_t, 8
 Speed, 9
 uPosition, 9
 uSpeed, 9
analog_data_t, 9
Antiplay
 engine_settings.calb_t, 20
 engine_settings_t, 21
AntiplaySpeed
 move_settings_t, 35
brake_settings_t, 11
 t1, 11
 t2, 11
 t3, 11
 t4, 11
CTPMInError
 ctp_settings_t, 16
calibration_t, 12
chart_data_t, 12
close_device
 ximc.h, 71
ClutterTime
 sync_in_settings.calb_t, 45
 sync_in_settings_t, 46
command_clear_fram
 ximc.h, 71
command_eeread_settings
 ximc.h, 71
command_eesave_settings
 ximc.h, 72
command_home
 ximc.h, 72
command_left
 ximc.h, 72
command_loft
 ximc.h, 72
command_move
 ximc.h, 73
command_movr
 ximc.h, 73
command_power_off
 ximc.h, 73
command_read_settings
 ximc.h, 73
command_reset
 ximc.h, 74
command_right
 ximc.h, 74
command_save_settings
 ximc.h, 74
command_sstp
 ximc.h, 74
command_stop
 ximc.h, 74
command_update_firmware
 ximc.h, 74
command_zero
 ximc.h, 75
control_settings.calb_t, 13
 MaxClickTime, 13
 Timeout, 13
control_settings_t, 13
 MaxClickTime, 14
 MaxSpeed, 14
 Timeout, 14
 uDeltaPosition, 14
 uMaxSpeed, 14
controller_name_t, 14
 ControllerName, 15
ControllerName
 controller_name_t, 15
CriticalPwr
 secure_settings_t, 38
CriticalUsb
 secure_settings_t, 38
CriticalT
 secure_settings_t, 38
CriticalUpwr
 secure_settings_t, 38
CriticalUusb
 secure_settings_t, 38
ctp_settings_t, 15
 CTPMInError, 16
CurrReductDelay
 power_settings_t, 37
CurrentSetTime
 power_settings_t, 37

debug_read_t, 16
Decel
 move_settings_t, 35
DetentTorque
 motor_settings_t, 32
device_information_t, 16

ENGINE_ACCEL_ON
 ximc.h, 69
ENGINE_ANTIPLAY
 ximc.h, 69
ENGINE_MAX_SPEED
 ximc.h, 69
ENGINE_REVERSE
 ximc.h, 69
ENGINE_TYPE_TEST
 ximc.h, 70
ENUMERATE_PROBE
 ximc.h, 70
EXTIO_SETUP_INVERT
 ximc.h, 70
edges_settings_calb_t, 17
edges_settings_t, 17
 LeftBorder, 17
 RightBorder, 17
 uLeftBorder, 18
 uRightBorder, 18
Efficiency
 gear_settings_t, 25
encoder_information_t, 18
 Manufacturer, 18
 PartNumber, 18
encoder_settings_t, 19
 MaxCurrentConsumption, 19
 MaxOperatingFrequency, 19
 SupplyVoltageMax, 19
 SupplyVoltageMin, 19
engine_settings_calb_t, 20
 Antiplay, 20
 NomCurrent, 20
 NomSpeed, 20
 NomVoltage, 20
 StepsPerRev, 20
engine_settings_t, 21
 Antiplay, 21
 NomCurrent, 21
 NomSpeed, 21
 NomVoltage, 22
 StepsPerRev, 22
 uNomSpeed, 22
entype_settings_t, 22
enumerate_devices
 ximc.h, 75
extio_settings_t, 22

FastHome
 home_settings_t, 29
feedback_settings_t, 23
free_enumerate_devices
 ximc.h, 80
 ximc.h, 75
 gear_information_t, 23
 Manufacturer, 24
 PartNumber, 24
 gear_settings_t, 24
 Efficiency, 25
 InputInertia, 25
 MaxOutputBacklash, 25
 RatedInputSpeed, 25
 RatedInputTorque, 25
 ReductionIn, 25
 ReductionOut, 25
 get_accessories_settings
 ximc.h, 75
 get_analog_data
 ximc.h, 75
 get_bootloader_version
 ximc.h, 76
 get_brake_settings
 ximc.h, 76
 get_chart_data
 ximc.h, 76
 get_control_settings
 ximc.h, 76
 get_controller_name
 ximc.h, 77
 get_ctp_settings
 ximc.h, 77
 get_debug_read
 ximc.h, 77
 get_device_count
 ximc.h, 77
 get_device_information
 ximc.h, 77
 get_device_name
 ximc.h, 78
 get_edges_settings
 ximc.h, 78
 get_encoder_information
 ximc.h, 78
 get_encoder_settings
 ximc.h, 78
 get_engine_settings
 ximc.h, 79
 get_entype_settings
 ximc.h, 79
 get_enumerate_device_information
 ximc.h, 79
 get_enumerate_device_serial
 ximc.h, 79
 get_extio_settings
 ximc.h, 80
 get_feedback_settings
 ximc.h, 80
 get_firmware_version
 ximc.h, 80
 get_gear_information
 ximc.h, 80

get_gear_settings
 ximc.h, 81
get_hallsensor_information
 ximc.h, 81
get_hallsensor_settings
 ximc.h, 81
get_home_settings
 ximc.h, 81
get_joystick_settings
 ximc.h, 81
get_motor_information
 ximc.h, 82
get_motor_settings
 ximc.h, 82
get_move_settings
 ximc.h, 82
get_pid_settings
 ximc.h, 82
get_position
 ximc.h, 83
get_position_calb_t, 26
get_position_t, 26
get_power_settings
 ximc.h, 83
get_secure_settings
 ximc.h, 83
get_serial_number
 ximc.h, 83
get_stage_information
 ximc.h, 83
get_stage_name
 ximc.h, 84
get_stage_settings
 ximc.h, 84
get_status
 ximc.h, 84
get_status_calb
 ximc.h, 84
get_sync_in_settings
 ximc.h, 84
get_sync_out_settings
 ximc.h, 85
get_uart_settings
 ximc.h, 85
goto_firmware
 ximc.h, 85

HOME_DIR_FIRST
 ximc.h, 70
HOME_DIR_SECOND
 ximc.h, 70

hallsensor_information_t, 26
 Manufacturer, 27
 PartNumber, 27

hallsensor_settings_t, 27
 MaxCurrentConsumption, 27
 MaxOperatingFrequency, 27
 SupplyVoltageMax, 27
 SupplyVoltageMin, 28

has_firmware
 ximc.h, 86

HoldCurrent
 power_settings_t, 37

home_settings_calb_t, 28

home_settings_t, 28
 FastHome, 29
 HomeDelta, 29
 SlowHome, 29
 uFastHome, 29
 uHomeDelta, 29
 uSlowHome, 29

HomeDelta
 home_settings_t, 29

HorizontalLoadCapacity
 stage_settings_t, 42

InputInertia
 gear_settings_t, 25

JOY_REVERSE
 ximc.h, 70

joystick_settings_t, 29

LeadScrewPitch
 stage_settings_t, 42

LeftBorder
 edges_settings_t, 17

logging_callback_stderr_narrow
 ximc.h, 86

logging_callback_stderr_wide
 ximc.h, 86

logging_callback_t
 ximc.h, 71

LowUpwrOff
 secure_settings_t, 38

MBRatedCurrent
 accessories_settings_t, 8

MBRatedVoltage
 accessories_settings_t, 8

MBTorque
 accessories_settings_t, 8

MVCMD_ERROR
 ximc.h, 70

Manufacturer
 encoder_information_t, 18
 gear_information_t, 24
 hallsensor_information_t, 27
 motor_information_t, 31
 stage_information_t, 40

MaxClickTime
 control_settings_calb_t, 13
 control_settings_t, 14

MaxCurrent
 motor_settings_t, 32

MaxCurrentConsumption
 encoder_settings_t, 19

hallsensor_settings_t, 27

stage_settings_t, 42
MaxCurrentTime
 motor_settings_t, 32
MaxOperatingFrequency
 encoder_settings_t, 19
 hallsensor_settings_t, 27
MaxOutputBacklash
 gear_settings_t, 25
MaxSpeed
 control_settings_t, 14
 motor_settings_t, 32
 stage_settings_t, 42
MechanicalTimeConstant
 motor_settings_t, 32
MinimumUusb
 secure_settings_t, 39
motor_information.t, 30
 Manufacturer, 31
 PartNumber, 31
motor_settings.t, 31
 DetentTorque, 32
 MaxCurrent, 32
 MaxCurrentTime, 32
 MaxSpeed, 32
 MechanicalTimeConstant, 32
 NoLoadCurrent, 33
 NoLoadSpeed, 33
 NominalCurrent, 33
 NominalPower, 33
 NominalSpeed, 33
 NominalTorque, 33
 NominalVoltage, 33
 RotorInertia, 33
 SpeedConstant, 33
 SpeedTorqueGradient, 34
 StallTorque, 34
 TorqueConstant, 34
 WindingInductance, 34
 WindingResistance, 34
move_settings_calb.t, 34
move_settings.t, 35
 Accel, 35
 AntiplaySpeed, 35
 Decel, 35
 Speed, 35
 uAntiplaySpeed, 35
 uSpeed, 36
msec_sleep
 ximc.h, 86

NoLoadCurrent
 motor_settings_t, 33
NoLoadSpeed
 motor_settings_t, 33
NomCurrent
 engine_settings_calb_t, 20
 engine_settings_t, 21
NomSpeed
 engine_settings_calb_t, 20
 engine_settings_t, 21
NomVoltage
 engine_settings_calb_t, 20
 engine_settings_t, 22
NominalCurrent
 motor_settings_t, 33
NominalPower
 motor_settings_t, 33
NominalSpeed
 motor_settings_t, 33
NominalTorque
 motor_settings_t, 33
NominalVoltage
 motor_settings_t, 33

open_device
 ximc.h, 86

PartNumber
 encoder_information.t, 18
 gear_information_t, 24
 hallsensor_information_t, 27
 motor_information_t, 31
 stage_information_t, 40
pid_settings.t, 36
PositionerName
 stage_name.t, 41
power_settings.t, 36
 CurrReductDelay, 37
 CurrentSetTime, 37
 HoldCurrent, 37
 PowerOffDelay, 37
PowerOffDelay
 power_settings_t, 37
probe_device
 ximc.h, 86

REV_SENS_INV
 ximc.h, 70
RatedInputSpeed
 gear_settings_t, 25
RatedInputTorque
 gear_settings_t, 25
ReductionIn
 gear_settings_t, 25
ReductionOut
 gear_settings_t, 25
RightBorder
 edges_settings_t, 17
RotorInertia
 motor_settings_t, 33

STATE_ALARM
 ximc.h, 70
SYNCIN_GOTOPOSITION
 ximc.h, 71
SYNCOUT_ENABLED
 ximc.h, 71
secure_settings.t, 37

CriticalIppwr, 38
CriticalIusb, 38
CriticalT, 38
CriticalUpwr, 38
CriticalUusb, 38
LowUpwrOff, 38
MinimumUusb, 39
serial_number_t, 39
service_command_updf
 ximc.h, 86
set_accessories_settings
 ximc.h, 87
set_add_sync_in_action
 ximc.h, 87
set_brake_settings
 ximc.h, 87
set_control_settings
 ximc.h, 87
set_controller_name
 ximc.h, 88
set_ctp_settings
 ximc.h, 88
set_edges_settings
 ximc.h, 88
set_encoder_information
 ximc.h, 88
set_encoder_settings
 ximc.h, 88
set_engine_settings
 ximc.h, 89
set_entype_settings
 ximc.h, 89
set_extio_settings
 ximc.h, 89
set_feedback_settings
 ximc.h, 89
set_gear_information
 ximc.h, 90
set_gear_settings
 ximc.h, 90
set_hallsensor_information
 ximc.h, 90
set_hallsensor_settings
 ximc.h, 90
set_home_settings
 ximc.h, 91
set_joystick_settings
 ximc.h, 91
set_logging_callback
 ximc.h, 91
set_motor_information
 ximc.h, 91
set_motor_settings
 ximc.h, 92
set_move_settings
 ximc.h, 92
set_pid_settings
 ximc.h, 92
set_position
 ximc.h, 92
set_position_calb_t, 39
set_position_t, 39
set_power_settings
 ximc.h, 93
set_secure_settings
 ximc.h, 93
set_serial_number
 ximc.h, 93
set_stage_information
 ximc.h, 93
set_stage_name
 ximc.h, 93
set_stage_settings
 ximc.h, 94
set_sync_in_settings
 ximc.h, 94
set_sync_out_settings
 ximc.h, 94
set_uart_settings
 ximc.h, 94
SlowHome
 home_settings_t, 29
Speed
 add_sync.in.action_t, 9
 move_settings_t, 35
 sync_in_settings_t, 46
SpeedConstant
 motor_settings_t, 33
SpeedTorqueGradient
 motor_settings_t, 34
stage_information_t, 40
 Manufacturer, 40
 PartNumber, 40
stage_name_t, 41
 PositionerName, 41
stage_settings_t, 41
 HorizontalLoadCapacity, 42
 LeadScrewPitch, 42
 MaxCurrentConsumption, 42
 MaxSpeed, 42
 SupplyVoltageMax, 42
 SupplyVoltageMin, 42
 TravelRange, 42
 Units, 43
 VerticalLoadCapacity, 43
StallTorque
 motor_settings_t, 34
status_calb_t, 43
status_t, 44
 uCurPosition, 45
 uCurSpeed, 45
StepsPerRev
 engine_settings_calb_t, 20
 engine_settings_t, 22
SupplyVoltageMax
 encoder_settings_t, 19

hallsensor_settings.t, 27
 stage_settings.t, 42
SupplyVoltageMin
 encoder_settings.t, 19
 hallsensor_settings.t, 28
 stage_settings.t, 42
sync_in_settings.calb.t, 45
 ClutterTime, 45
sync_in_settings.t, 45
 ClutterTime, 46
 Speed, 46
 uPosition, 46
 uSpeed, 46
sync_out_settings.calb.t, 46
 SyncOutPeriod, 47
 SyncOutPulseSteps, 47
sync_out_settings.t, 47
 Accuracy, 48
 SyncOutPeriod, 48
 SyncOutPulseSteps, 48
 uAccuracy, 48
SyncOutPeriod
 sync_out_settings.calb.t, 47
 sync_out_settings.t, 48
SyncOutPulseSteps
 sync_out_settings.calb.t, 47
 sync_out_settings.t, 48

t1
 brake_settings.t, 11
t2
 brake_settings.t, 11
t3
 brake_settings.t, 11
t4
 brake_settings.t, 11
TSGrad
 accessories_settings.t, 8
Timeout
 control_settings.calb.t, 13
 control_settings.t, 14
TorqueConstant
 motor_settings.t, 34
TravelRange
 stage_settings.t, 42

uAccuracy
 sync_out_settings.t, 48
uAntiplaySpeed
 move_settings.t, 35
uCurPosition
 status.t, 45
uCurSpeed
 status.t, 45
uDeltaPosition
 control_settings.t, 14
uFastHome
 home_settings.t, 29
uHomeDelta
 home_settings.t, 29
uLeftBorder
 edges_settings.t, 18
uMaxSpeed
 control_settings.t, 14
uNomSpeed
 engine_settings.t, 22
uPosition
 add_sync_in_action.t, 9
 sync_in_settings.t, 46
uRightBorder
 edges_settings.t, 18
uSlowHome
 home_settings.t, 29
uSpeed
 add_sync_in_action.t, 9
 move_settings.t, 36
 sync_in_settings.t, 46
uart_settings.t, 48
Units
 stage_settings.t, 43

VerticalLoadCapacity
 stage_settings.t, 43

WindingInductance
 motor_settings.t, 34
WindingResistance
 motor_settings.t, 34
write_key
 ximc.h, 95

XIMC_API
 ximc.h, 71
ximc.h, 49
 close_device, 71
 command_clear_fram, 71
 command_eeread_settings, 71
 command_eesave_settings, 72
 command_home, 72
 command_left, 72
 command_loft, 72
 command_move, 73
 command_movr, 73
 command_power_off, 73
 command_read_settings, 73
 command_reset, 74
 command_right, 74
 command_save_settings, 74
 command_ssfp, 74
 command_stop, 74
 command_update_firmware, 74
 command_zero, 75
 ENGINE_ACCEL_ON, 69
 ENGINE_ANTIPLAY, 69
 ENGINE_MAX_SPEED, 69
 ENGINE_REVERSE, 69
 ENGINE_TYPE_TEST, 70
 ENUMERATE_PROBE, 70

EXTIO_SETUP_INVERT, 70
enumerate_devices, 75
free_enumerate_devices, 75
get_accessories_settings, 75
get_analog_data, 75
get_bootloader_version, 76
get_brake_settings, 76
get_chart_data, 76
get_control_settings, 76
get_controller_name, 77
get_ctp_settings, 77
get_debug_read, 77
get_device_count, 77
get_device_information, 77
get_device_name, 78
get_edges_settings, 78
get_encoder_information, 78
get_encoder_settings, 78
get_engine_settings, 79
get_entype_settings, 79
get_enumerate_device_information, 79
get_enumerate_device_serial, 79
get_extio_settings, 80
get_feedback_settings, 80
get_firmware_version, 80
get_gear_information, 80
get_gear_settings, 81
get_hallsensor_information, 81
get_hallsensor_settings, 81
get_home_settings, 81
get_joystick_settings, 81
get_motor_information, 82
get_motor_settings, 82
get_move_settings, 82
get_pid_settings, 82
get_position, 83
get_power_settings, 83
get_secure_settings, 83
get_serial_number, 83
get_stage_information, 83
get_stage_name, 84
get_stage_settings, 84
get_status, 84
get_status_calb, 84
get_sync_in_settings, 84
get_sync_out_settings, 85
get_uart_settings, 85
goto_firmware, 85
HOME_DIR_FIRST, 70
HOME_DIR_SECOND, 70
has_firmware, 86
JOY_REVERSE, 70
logging_callback_stderr_narrow, 86
logging_callback_stderr_wide, 86
logging_callback_t, 71
MVCMD_ERROR, 70
msec_sleep, 86
open_device, 86
probe_device, 86
REV_SENS_INV, 70
STATE_ALARM, 70
SYNCIN_GOTOPOSITION, 71
SYNCOUT_ENABLED, 71
service_command_updf, 86
set_accessories_settings, 87
set_add_sync_in_action, 87
set_brake_settings, 87
set_control_settings, 87
set_controller_name, 88
set_ctp_settings, 88
set_edges_settings, 88
set_encoder_information, 88
set_encoder_settings, 88
set_engine_settings, 89
set_entype_settings, 89
set_extio_settings, 89
set_feedback_settings, 89
set_gear_information, 90
set_gear_settings, 90
set_hallsensor_information, 90
set_hallsensor_settings, 90
set_home_settings, 91
set_joystick_settings, 91
set_logging_callback, 91
set_motor_information, 91
set_motor_settings, 92
set_move_settings, 92
set_pid_settings, 92
set_position, 92
set_power_settings, 93
set_secure_settings, 93
set_serial_number, 93
set_stage_information, 93
set_stage_name, 93
set_stage_settings, 94
set_sync_in_settings, 94
set_sync_out_settings, 94
set_uart_settings, 94
write_key, 95
XIMC_API, 71
ximc_fix_usbser_sys, 95
ximc_version, 95
ximc_fix_usbser_sys
 ximc.h, 95
ximc_version
 ximc.h, 95