

libximc

2.14.14

Generated by Doxygen 1.8.2

Thu Jun 22 2023 14:59:43

Contents

1	libximc library	1
1.1	What the controller does	1
1.2	What can do libximc library	1
1.3	Assistance	2
2	Introduction	3
2.1	About library	3
2.1.1	Supported OS and environment requirements:	3
3	How to rebuild library	4
3.1	Buliding on Windows	4
3.2	Building on debian-based linux systems	4
3.3	Buliding on MacOS X	4
3.4	Building on generic UNIX	5
3.5	Building on redhat-based linux systems	5
3.6	Source code access	5
4	How to use with...	6
4.1	Generic logging facility	9
4.2	Required permissions	9
4.3	C-profiles	9
4.4	Python-profiles	9
5	Working with user units	10
5.1	The structure of the conversion units calibration_t	10
5.2	Alternative functions for working with user units and data structures for them	10
5.3	Coordinate correction table for more accurate positioning	11
6	Data Structure Documentation	12
6.1	accessories.settings_t Struct Reference	12
6.1.1	Detailed Description	12
6.1.2	Field Documentation	13

6.1.2.1	LimitSwitchesSettings	13
6.1.2.2	MagneticBrakeInfo	13
6.1.2.3	MBRatedCurrent	13
6.1.2.4	MBRatedVoltage	13
6.1.2.5	MBSettings	13
6.1.2.6	MBTorque	13
6.1.2.7	TemperatureSensorInfo	13
6.1.2.8	TSGrad	13
6.1.2.9	TSMax	13
6.1.2.10	TSMin	14
6.1.2.11	TSSettings	14
6.2	analog_data_t Struct Reference	14
6.2.1	Detailed Description	15
6.2.2	Field Documentation	15
6.2.2.1	A1Voltage	15
6.2.2.2	A1Voltage_ADC	15
6.2.2.3	A2Voltage	15
6.2.2.4	A2Voltage_ADC	16
6.2.2.5	ACurrent	16
6.2.2.6	ACurrent_ADC	16
6.2.2.7	B1Voltage	16
6.2.2.8	B1Voltage_ADC	16
6.2.2.9	B2Voltage	16
6.2.2.10	B2Voltage_ADC	16
6.2.2.11	BCurrent	16
6.2.2.12	BCurrent_ADC	16
6.2.2.13	FullCurrent	16
6.2.2.14	FullCurrent_ADC	16
6.2.2.15	H5	16
6.2.2.16	Joy	17
6.2.2.17	Joy_ADC	17
6.2.2.18	L	17
6.2.2.19	L5	17
6.2.2.20	L5_ADC	17
6.2.2.21	Pot	17
6.2.2.22	R	17
6.2.2.23	SupVoltage	17
6.2.2.24	SupVoltage_ADC	17
6.2.2.25	Temp	17

6.2.2.26	Temp_ADC	17
6.3	brake_settings_t Struct Reference	18
6.3.1	Detailed Description	18
6.3.2	Field Documentation	18
6.3.2.1	BrakeFlags	18
6.3.2.2	t1	18
6.3.2.3	t2	18
6.3.2.4	t3	18
6.3.2.5	t4	18
6.4	calibration_settings_t Struct Reference	19
6.4.1	Detailed Description	19
6.4.2	Field Documentation	19
6.4.2.1	CSS1_A	19
6.4.2.2	CSS1_B	19
6.4.2.3	CSS2_A	19
6.4.2.4	CSS2_B	19
6.4.2.5	FullCurrent_A	20
6.4.2.6	FullCurrent_B	20
6.5	calibration_t Struct Reference	20
6.5.1	Detailed Description	20
6.6	chart_data_t Struct Reference	20
6.6.1	Detailed Description	21
6.6.2	Field Documentation	21
6.6.2.1	DutyCycle	21
6.6.2.2	Joy	21
6.6.2.3	Pot	21
6.6.2.4	WindingCurrentA	21
6.6.2.5	WindingCurrentB	21
6.6.2.6	WindingCurrentC	21
6.6.2.7	WindingVoltageA	22
6.6.2.8	WindingVoltageB	22
6.6.2.9	WindingVoltageC	22
6.7	control_settings_calb_t Struct Reference	22
6.7.1	Detailed Description	22
6.7.2	Field Documentation	23
6.7.2.1	Flags	23
6.7.2.2	MaxClickTime	23
6.7.2.3	MaxSpeed	23
6.7.2.4	Timeout	23

6.8 control_settings_t Struct Reference	23
6.8.1 Detailed Description	23
6.8.2 Field Documentation	24
6.8.2.1 Flags	24
6.8.2.2 MaxClickTime	24
6.8.2.3 MaxSpeed	24
6.8.2.4 Timeout	24
6.8.2.5 uDeltaPosition	24
6.8.2.6 uMaxSpeed	24
6.9 controller_name_t Struct Reference	24
6.9.1 Detailed Description	25
6.9.2 Field Documentation	25
6.9.2.1 ControllerName	25
6.9.2.2 CtrlFlags	25
6.10 ctp_settings_t Struct Reference	25
6.10.1 Detailed Description	25
6.10.2 Field Documentation	26
6.10.2.1 CTPFlags	26
6.10.2.2 CTPMinError	26
6.11 debug_read_t Struct Reference	26
6.11.1 Detailed Description	26
6.11.2 Field Documentation	26
6.11.2.1 DebugData	26
6.12 debug_write_t Struct Reference	26
6.12.1 Detailed Description	27
6.12.2 Field Documentation	27
6.12.2.1 DebugData	27
6.13 device_information_t Struct Reference	27
6.13.1 Detailed Description	27
6.13.2 Field Documentation	27
6.13.2.1 Major	27
6.13.2.2 Minor	28
6.13.2.3 Release	28
6.14 device_network_information_t Struct Reference	28
6.14.1 Detailed Description	28
6.15 edges_settings_calb_t Struct Reference	28
6.15.1 Detailed Description	29
6.15.2 Field Documentation	29
6.15.2.1 BorderFlags	29

6.15.2.2 EnderFlags	29
6.15.2.3 LeftBorder	29
6.15.2.4 RightBorder	29
6.16 edges_settings_t Struct Reference	29
6.16.1 Detailed Description	30
6.16.2 Field Documentation	30
6.16.2.1 BorderFlags	30
6.16.2.2 EnderFlags	30
6.16.2.3 LeftBorder	30
6.16.2.4 RightBorder	30
6.16.2.5 uLeftBorder	30
6.16.2.6 uRightBorder	30
6.17 emf_settings_t Struct Reference	30
6.17.1 Detailed Description	31
6.17.2 Field Documentation	31
6.17.2.1 BackEMFFlags	31
6.17.2.2 Km	31
6.17.2.3 L	31
6.17.2.4 R	31
6.18 encoder_information_t Struct Reference	31
6.18.1 Detailed Description	32
6.18.2 Field Documentation	32
6.18.2.1 Manufacturer	32
6.18.2.2 PartNumber	32
6.19 encoder_settings_t Struct Reference	32
6.19.1 Detailed Description	33
6.19.2 Field Documentation	33
6.19.2.1 EncoderSettings	33
6.19.2.2 MaxCurrentConsumption	33
6.19.2.3 MaxOperatingFrequency	33
6.19.2.4 SupplyVoltageMax	33
6.19.2.5 SupplyVoltageMin	33
6.20 engine_advanced_setup_t Struct Reference	33
6.20.1 Detailed Description	34
6.20.2 Field Documentation	34
6.20.2.1 stepcloseloop_Kp_high	34
6.20.2.2 stepcloseloop_Kp_low	34
6.20.2.3 stepcloseloop_Kw	34
6.21 engine_settings_calb_t Struct Reference	34

6.21.1 Detailed Description	35
6.21.2 Field Documentation	35
6.21.2.1 Antiplay	35
6.21.2.2 EngineFlags	35
6.21.2.3 MicrostepMode	35
6.21.2.4 NomCurrent	35
6.21.2.5 NomSpeed	35
6.21.2.6 NomVoltage	35
6.21.2.7 StepsPerRev	35
6.22 engine_settings_t Struct Reference	36
6.22.1 Detailed Description	36
6.22.2 Field Documentation	36
6.22.2.1 Antiplay	36
6.22.2.2 EngineFlags	36
6.22.2.3 MicrostepMode	37
6.22.2.4 NomCurrent	37
6.22.2.5 NomSpeed	37
6.22.2.6 NomVoltage	37
6.22.2.7 StepsPerRev	37
6.22.2.8 uNomSpeed	37
6.23 entype_settings_t Struct Reference	37
6.23.1 Detailed Description	38
6.23.2 Field Documentation	38
6.23.2.1 DriverType	38
6.23.2.2 EngineType	38
6.24 extended_settings_t Struct Reference	38
6.24.1 Detailed Description	38
6.25 extio_settings_t Struct Reference	38
6.25.1 Detailed Description	39
6.25.2 Field Documentation	39
6.25.2.1 EXTIOModeFlags	39
6.25.2.2 EXTIOSetupFlags	39
6.26 feedback_settings_t Struct Reference	39
6.26.1 Detailed Description	39
6.26.2 Field Documentation	40
6.26.2.1 CountsPerTurn	40
6.26.2.2 FeedbackFlags	40
6.26.2.3 FeedbackType	40
6.26.2.4 IPS	40

6.27 gear_information_t Struct Reference	40
6.27.1 Detailed Description	40
6.27.2 Field Documentation	41
6.27.2.1 Manufacturer	41
6.27.2.2 PartNumber	41
6.28 gear_settings_t Struct Reference	41
6.28.1 Detailed Description	41
6.28.2 Field Documentation	41
6.28.2.1 Efficiency	41
6.28.2.2 InputInertia	42
6.28.2.3 MaxOutputBacklash	42
6.28.2.4 RatedInputSpeed	42
6.28.2.5 RatedInputTorque	42
6.28.2.6 ReductionIn	42
6.28.2.7 ReductionOut	42
6.29 get_position_calb_t Struct Reference	42
6.29.1 Detailed Description	42
6.29.2 Field Documentation	43
6.29.2.1 EncPosition	43
6.29.2.2 Position	43
6.30 get_position_t Struct Reference	43
6.30.1 Detailed Description	43
6.30.2 Field Documentation	43
6.30.2.1 EncPosition	43
6.30.2.2 uPosition	43
6.31 globally_unique_identifier_t Struct Reference	44
6.31.1 Detailed Description	44
6.31.2 Field Documentation	44
6.31.2.1 UniqueID0	44
6.31.2.2 UniqueID1	44
6.31.2.3 UniqueID2	44
6.31.2.4 UniqueID3	44
6.32 hallsensor_information_t Struct Reference	44
6.32.1 Detailed Description	45
6.32.2 Field Documentation	45
6.32.2.1 Manufacturer	45
6.32.2.2 PartNumber	45
6.33 hallsensor_settings_t Struct Reference	45
6.33.1 Detailed Description	46

6.33.2 Field Documentation	46
6.33.2.1 MaxCurrentConsumption	46
6.33.2.2 MaxOperatingFrequency	46
6.33.2.3 SupplyVoltageMax	46
6.33.2.4 SupplyVoltageMin	46
6.34 home_settings_calb_t Struct Reference	46
6.34.1 Detailed Description	47
6.34.2 Field Documentation	47
6.34.2.1 FastHome	47
6.34.2.2 HomeDelta	47
6.34.2.3 HomeFlags	47
6.34.2.4 SlowHome	47
6.35 home_settings_t Struct Reference	47
6.35.1 Detailed Description	48
6.35.2 Field Documentation	48
6.35.2.1 FastHome	48
6.35.2.2 HomeDelta	48
6.35.2.3 HomeFlags	48
6.35.2.4 SlowHome	48
6.35.2.5 uFastHome	48
6.35.2.6 uHomeDelta	48
6.35.2.7 uSlowHome	48
6.36 init_random_t Struct Reference	49
6.36.1 Detailed Description	49
6.36.2 Field Documentation	49
6.36.2.1 key	49
6.37 joystick_settings_t Struct Reference	49
6.37.1 Detailed Description	49
6.37.2 Field Documentation	50
6.37.2.1 DeadZone	50
6.37.2.2 ExpFactor	50
6.37.2.3 JoyCenter	50
6.37.2.4 JoyFlags	50
6.37.2.5 JoyHighEnd	50
6.37.2.6 JoyLowEnd	50
6.38 measurements_t Struct Reference	50
6.38.1 Detailed Description	51
6.38.2 Field Documentation	51
6.38.2.1 Error	51

6.38.2.2 Length	51
6.38.2.3 Speed	51
6.39 motor_information_t Struct Reference	51
6.39.1 Detailed Description	51
6.39.2 Field Documentation	52
6.39.2.1 Manufacturer	52
6.39.2.2 PartNumber	52
6.40 motor_settings_t Struct Reference	52
6.40.1 Detailed Description	53
6.40.2 Field Documentation	53
6.40.2.1 DetentTorque	53
6.40.2.2 MaxCurrent	53
6.40.2.3 MaxCurrentTime	54
6.40.2.4 MaxSpeed	54
6.40.2.5 MechanicalTimeConstant	54
6.40.2.6 MotorType	54
6.40.2.7 NoLoadCurrent	54
6.40.2.8 NoLoadSpeed	54
6.40.2.9 NominalCurrent	54
6.40.2.10 NominalPower	54
6.40.2.11 NominalSpeed	54
6.40.2.12 NominalTorque	55
6.40.2.13 NominalVoltage	55
6.40.2.14 Phases	55
6.40.2.15 Poles	55
6.40.2.16 RotorInertia	55
6.40.2.17 SpeedConstant	55
6.40.2.18 SpeedTorqueGradient	55
6.40.2.19 StallTorque	55
6.40.2.20 TorqueConstant	55
6.40.2.21 WindingInductance	56
6.40.2.22 WindingResistance	56
6.41 move_settings_calb_t Struct Reference	56
6.41.1 Detailed Description	56
6.41.2 Field Documentation	56
6.41.2.1 Accel	56
6.41.2.2 AntiplaySpeed	56
6.41.2.3 Decel	57
6.41.2.4 MoveFlags	57

6.41.2.5 Speed	57
6.42 move_settings_t Struct Reference	57
6.42.1 Detailed Description	57
6.42.2 Field Documentation	57
6.42.2.1 Accel	57
6.42.2.2 AntiplaySpeed	58
6.42.2.3 Decel	58
6.42.2.4 MoveFlags	58
6.42.2.5 Speed	58
6.42.2.6 uAntiplaySpeed	58
6.42.2.7 uSpeed	58
6.43 network_settings_t Struct Reference	58
6.43.1 Detailed Description	59
6.43.2 Field Documentation	59
6.43.2.1 DefaultGateway	59
6.43.2.2 DHCPEnabled	59
6.43.2.3 IPv4Address	59
6.43.2.4 SubnetMask	59
6.44 nonvolatile_memory_t Struct Reference	59
6.44.1 Detailed Description	59
6.44.2 Field Documentation	60
6.44.2.1 UserData	60
6.45 password_settings_t Struct Reference	60
6.45.1 Detailed Description	60
6.45.2 Field Documentation	60
6.45.2.1 UserPassword	60
6.46 pid_settings_t Struct Reference	60
6.46.1 Detailed Description	61
6.47 power_settings_t Struct Reference	61
6.47.1 Detailed Description	61
6.47.2 Field Documentation	61
6.47.2.1 CurrentSetTime	61
6.47.2.2 CurrReductDelay	62
6.47.2.3 HoldCurrent	62
6.47.2.4 PowerFlags	62
6.47.2.5 PowerOffDelay	62
6.48 secure_settings_t Struct Reference	62
6.48.1 Detailed Description	62
6.48.2 Field Documentation	63

6.48.2.1 CriticalIppwr	63
6.48.2.2 CriticalIusb	63
6.48.2.3 CriticalIT	63
6.48.2.4 CriticalUpwr	63
6.48.2.5 CriticalUusb	63
6.48.2.6 Flags	63
6.48.2.7 LowUpwrOff	63
6.48.2.8 MinimumUusb	63
6.49 serial_number_t Struct Reference	63
6.49.1 Detailed Description	64
6.49.2 Field Documentation	64
6.49.2.1 Key	64
6.49.2.2 Major	64
6.49.2.3 Minor	64
6.49.2.4 Release	64
6.49.2.5 SN	64
6.50 set_position_calb_t Struct Reference	64
6.50.1 Detailed Description	65
6.50.2 Field Documentation	65
6.50.2.1 EncPosition	65
6.50.2.2 PosFlags	65
6.50.2.3 Position	65
6.51 set_position_t Struct Reference	65
6.51.1 Detailed Description	65
6.51.2 Field Documentation	66
6.51.2.1 EncPosition	66
6.51.2.2 PosFlags	66
6.51.2.3 uPosition	66
6.52 stage_information_t Struct Reference	66
6.52.1 Detailed Description	66
6.52.2 Field Documentation	66
6.52.2.1 Manufacturer	66
6.52.2.2 PartNumber	66
6.53 stage_name_t Struct Reference	67
6.53.1 Detailed Description	67
6.53.2 Field Documentation	67
6.53.2.1 PositionerName	67
6.54 stage_settings_t Struct Reference	67
6.54.1 Detailed Description	68

6.54.2 Field Documentation	68
6.54.2.1 HorizontalLoadCapacity	68
6.54.2.2 LeadScrewPitch	68
6.54.2.3 MaxCurrentConsumption	68
6.54.2.4 MaxSpeed	68
6.54.2.5 SupplyVoltageMax	68
6.54.2.6 SupplyVoltageMin	68
6.54.2.7 TravelRange	68
6.54.2.8 Units	69
6.54.2.9 VerticalLoadCapacity	69
6.55 status_calb_t Struct Reference	69
6.55.1 Detailed Description	70
6.55.2 Field Documentation	70
6.55.2.1 CmdBufFreeSpace	70
6.55.2.2 CurPosition	70
6.55.2.3 CurSpeed	70
6.55.2.4 CurT	70
6.55.2.5 EncPosition	70
6.55.2.6 EncSts	70
6.55.2.7 Flags	70
6.55.2.8 GPIOFlags	70
6.55.2.9 Ipwr	70
6.55.2.10 Iusb	71
6.55.2.11 MoveSts	71
6.55.2.12 MvCmdSts	71
6.55.2.13 PWRSts	71
6.55.2.14 Upwr	71
6.55.2.15 Uusb	71
6.55.2.16 WindSts	71
6.56 status_t Struct Reference	71
6.56.1 Detailed Description	72
6.56.2 Field Documentation	72
6.56.2.1 CmdBufFreeSpace	72
6.56.2.2 CurPosition	72
6.56.2.3 CurSpeed	72
6.56.2.4 CurT	72
6.56.2.5 EncPosition	73
6.56.2.6 EncSts	73
6.56.2.7 Flags	73

6.56.2.8 GPIOFlags	73
6.56.2.9 Ipwr	73
6.56.2.10Iusb	73
6.56.2.11MoveSts	73
6.56.2.12MvCmdSts	73
6.56.2.13PWRSts	73
6.56.2.14uCurPosition	73
6.56.2.15uCurSpeed	73
6.56.2.16Upwr	74
6.56.2.17Uusb	74
6.56.2.18WindSts	74
6.57 sync_in_settings_calb_t Struct Reference	74
6.57.1 Detailed Description	74
6.57.2 Field Documentation	74
6.57.2.1 ClutterTime	74
6.57.2.2 Position	74
6.57.2.3 Speed	75
6.57.2.4 SyncInFlags	75
6.58 sync_in_settings_t Struct Reference	75
6.58.1 Detailed Description	75
6.58.2 Field Documentation	75
6.58.2.1 ClutterTime	75
6.58.2.2 Speed	75
6.58.2.3 SyncInFlags	76
6.58.2.4 uPosition	76
6.58.2.5 uSpeed	76
6.59 sync_out_settings_calb_t Struct Reference	76
6.59.1 Detailed Description	76
6.59.2 Field Documentation	76
6.59.2.1 Accuracy	77
6.59.2.2 SyncOutFlags	77
6.59.2.3 SyncOutPeriod	77
6.59.2.4 SyncOutPulseSteps	77
6.60 sync_out_settings_t Struct Reference	77
6.60.1 Detailed Description	77
6.60.2 Field Documentation	78
6.60.2.1 Accuracy	78
6.60.2.2 SyncOutFlags	78
6.60.2.3 SyncOutPeriod	78

6.60.2.4 SyncOutPulseSteps	78
6.60.2.5 uAccuracy	78
6.61 uart_settings_t Struct Reference	78
6.61.1 Detailed Description	78
6.61.2 Field Documentation	79
6.61.2.1 UARTSetupFlags	79
7 File Documentation	80
7.1 ximc.h File Reference	80
7.1.1 Detailed Description	104
7.1.2 Macro Definition Documentation	105
7.1.2.1 ALARM_ON_DRIVER_OVERHEATING	105
7.1.2.2 BACK_EMF_INDUCTANCE_AUTO	105
7.1.2.3 BACK_EMF_KM_AUTO	105
7.1.2.4 BACK_EMF_RESISTANCE_AUTO	105
7.1.2.5 BORDER_IS_ENCODER	105
7.1.2.6 BORDER_STOP_LEFT	105
7.1.2.7 BORDER_STOP_RIGHT	105
7.1.2.8 BORDERS_SWAP_MISSET_DETECTION	105
7.1.2.9 BRAKE_ENABLED	105
7.1.2.10 BRAKE_ENG_PWROFF	105
7.1.2.11 CONTROL_BTN_LEFT_PUSHED_OPEN	105
7.1.2.12 CONTROL_BTN_RIGHT_PUSHED_OPEN	106
7.1.2.13 CONTROL_MODE_BITS	106
7.1.2.14 CONTROL_MODE_JOY	106
7.1.2.15 CONTROL_MODE_LR	106
7.1.2.16 CONTROL_MODE_OFF	106
7.1.2.17 CTP_ALARM_ON_ERROR	106
7.1.2.18 CTP_BASE	106
7.1.2.19 CTP_ENABLED	106
7.1.2.20 CTP_ERROR_CORRECTION	106
7.1.2.21 DRIVER_TYPE_DISCRETE_FET	106
7.1.2.22 DRIVER_TYPE_EXTERNAL	106
7.1.2.23 DRIVER_TYPE_INTEGRATE	107
7.1.2.24 EEPROM_PRECEDENCE	107
7.1.2.25 ENC_STATE_ABSENT	107
7.1.2.26 ENC_STATE_MALFUNC	107
7.1.2.27 ENC_STATE_OK	107
7.1.2.28 ENC_STATE_REVERS	107

7.1.2.29 ENC_STATE_UNKNOWN	107
7.1.2.30 ENDER_SW1_ACTIVE_LOW	107
7.1.2.31 ENDER_SW2_ACTIVE_LOW	107
7.1.2.32 ENDER_SWAP	107
7.1.2.33 ENGINE_ACCEL_ON	107
7.1.2.34 ENGINE_ANTIPLAY	108
7.1.2.35 ENGINE_CURRENT_AS_RMS	108
7.1.2.36 ENGINE_LIMIT_CURR	108
7.1.2.37 ENGINE_LIMIT_RPM	108
7.1.2.38 ENGINE_LIMIT_VOLT	108
7.1.2.39 ENGINE_MAX_SPEED	108
7.1.2.40 ENGINE_REVERSE	108
7.1.2.41 ENGINE_TYPE_2DC	108
7.1.2.42 ENGINE_TYPE_BRUSHLESS	108
7.1.2.43 ENGINE_TYPE_DC	108
7.1.2.44 ENGINE_TYPE_NONE	109
7.1.2.45 ENGINE_TYPE_STEP	109
7.1.2.46 ENGINE_TYPE_TEST	109
7.1.2.47 ENUMERATE_PROBE	109
7.1.2.48 EXTIO_SETUP_INVERT	109
7.1.2.49 EXTIO_SETUP_MODE_IN_ALARM	109
7.1.2.50 EXTIO_SETUP_MODE_IN_BITS	109
7.1.2.51 EXTIO_SETUP_MODE_IN_HOME	109
7.1.2.52 EXTIO_SETUP_MODE_IN_MOVR	109
7.1.2.53 EXTIO_SETUP_MODE_IN_NOP	109
7.1.2.54 EXTIO_SETUP_MODE_IN_PWOF	109
7.1.2.55 EXTIO_SETUP_MODE_IN_STOP	110
7.1.2.56 EXTIO_SETUP_MODE_OUT_ALARM	110
7.1.2.57 EXTIO_SETUP_MODE_OUT_BITS	110
7.1.2.58 EXTIO_SETUP_MODE_OUT_MOTOR_ON	110
7.1.2.59 EXTIO_SETUP_MODE_OUT_MOVING	110
7.1.2.60 EXTIO_SETUP_MODE_OUT_OFF	110
7.1.2.61 EXTIO_SETUP_MODE_OUT_ON	110
7.1.2.62 EXTIO_SETUP_OUTPUT	110
7.1.2.63 FEEDBACK_EMF	110
7.1.2.64 FEEDBACK_ENC_REVERSE	110
7.1.2.65 FEEDBACK_ENC_TYPE_AUTO	110
7.1.2.66 FEEDBACK_ENC_TYPE_BITS	110
7.1.2.67 FEEDBACK_ENC_TYPE_DIFFERENTIAL	111

7.1.2.68 FEEDBACK_ENC_TYPE_SINGLE_ENDED	111
7.1.2.69 FEEDBACK_ENCODER	111
7.1.2.70 FEEDBACK_ENCODER_MEDIED	111
7.1.2.71 FEEDBACK_NONE	111
7.1.2.72 H_BRIDGE_ALERT	111
7.1.2.73 HOME_DIR_FIRST	111
7.1.2.74 HOME_DIR_SECOND	111
7.1.2.75 HOME_HALF_MV	111
7.1.2.76 HOME_MV_SEC_EN	111
7.1.2.77 HOME_STOP_FIRST_BITS	111
7.1.2.78 HOME_STOP_FIRST_LIM	112
7.1.2.79 HOME_STOP_FIRST_REV	112
7.1.2.80 HOME_STOP_FIRST_SYN	112
7.1.2.81 HOME_STOP_SECOND_BITS	112
7.1.2.82 HOME_STOP_SECOND_LIM	112
7.1.2.83 HOME_STOP_SECOND_REV	112
7.1.2.84 HOME_STOP_SECOND_SYN	112
7.1.2.85 HOME_USE_FAST	112
7.1.2.86 JOY_REVERSE	112
7.1.2.87 LOW_UPWR_PROTECTION	112
7.1.2.88 MICROSTEP_MODE_FRAC_128	112
7.1.2.89 MICROSTEP_MODE_FRAC_16	112
7.1.2.90 MICROSTEP_MODE_FRAC_2	113
7.1.2.91 MICROSTEP_MODE_FRAC_256	113
7.1.2.92 MICROSTEP_MODE_FRAC_32	113
7.1.2.93 MICROSTEP_MODE_FRAC_4	113
7.1.2.94 MICROSTEP_MODE_FRAC_64	113
7.1.2.95 MICROSTEP_MODE_FRAC_8	113
7.1.2.96 MICROSTEP_MODE_FULL	113
7.1.2.97 MOVE_STATE_ANTIPLAY	113
7.1.2.98 MOVE_STATE_MOVING	113
7.1.2.99 MOVE_STATE_TARGET_SPEED	113
7.1.2.100MVCMD_ERROR	113
7.1.2.101MVCMD_HOME	114
7.1.2.102MVCMD_LEFT	114
7.1.2.103MVCMD_LOFT	114
7.1.2.104MVCMD_MOVE	114
7.1.2.105MVCMD_MOVR	114
7.1.2.106MVCMD_NAME_BITS	114

7.1.2.107MVCMD_RIGHT	114
7.1.2.108MVCMD_RUNNING	114
7.1.2.109MVCMD_SSTP	114
7.1.2.110MVCMD_STOP	114
7.1.2.111MVCMD_UKNWN	114
7.1.2.112POWER_OFF_ENABLED	114
7.1.2.113POWER_REDUCED_ENABLED	115
7.1.2.114POWER_SMOOTH_CURRENT	115
7.1.2.115PWR_STATE_MAX	115
7.1.2.116PWR_STATE_NORM	115
7.1.2.117PWR_STATE_OFF	115
7.1.2.118PWR_STATE_REDUCED	115
7.1.2.119PWR_STATE_UNKNOWN	115
7.1.2.120REV_SENS_INV	115
7.1.2.121RPM_DIV_1000	115
7.1.2.122SETPOS_IGNORE_ENCODER	115
7.1.2.123SETPOS_IGNORE_POSITION	115
7.1.2.124STATE_ALARM	116
7.1.2.125STATE_BORDERS_SWAP_MISSET	116
7.1.2.126STATE_BRAKE	116
7.1.2.127STATE_BUTTON_LEFT	116
7.1.2.128STATE_BUTTON_RIGHT	116
7.1.2.129STATE_CONTR	116
7.1.2.130STATE_CONTROLLER_OVERHEAT	116
7.1.2.131STATE_CTP_ERROR	116
7.1.2.132STATE_DIG_SIGNAL	116
7.1.2.133STATE_EEPROM_CONNECTED	116
7.1.2.134STATE_ENC_A	117
7.1.2.135STATE_ENC_B	117
7.1.2.136STATE_ENGINE_RESPONSE_ERROR	117
7.1.2.137STATE_ERRC	117
7.1.2.138STATE_ERRD	117
7.1.2.139STATE_ERRV	117
7.1.2.140STATE_EXTIO_ALARM	117
7.1.2.141STATE_GPIO_LEVEL	117
7.1.2.142STATE_GPIO_PINOUT	117
7.1.2.143STATE_IS_HOMED	118
7.1.2.144STATE_LEFT_EDGE	118
7.1.2.145STATE_LOW_USB_VOLTAGE	118

7.1.2.146STATE_OVERLOAD_POWER_CURRENT	118
7.1.2.147STATE_OVERLOAD_POWER_VOLTAGE	118
7.1.2.148STATE_OVERLOAD_USB_CURRENT	118
7.1.2.149STATE_OVERLOAD_USB_VOLTAGE	118
7.1.2.150STATE_POWER_OVERHEAT	118
7.1.2.151STATE_REV_SENSOR	118
7.1.2.152STATE_RIGHT_EDGE	118
7.1.2.153STATE_SECUR	118
7.1.2.154STATE_SYNC_INPUT	119
7.1.2.155STATE_SYNC_OUTPUT	119
7.1.2.156STATE_WINDING_RES_MISMATCH	119
7.1.2.157SYNCIN_ENABLED	119
7.1.2.158SYNCIN_GOTOPOSITION	119
7.1.2.159SYNCIN_INVERT	119
7.1.2.160SYNCOUT_ENABLED	119
7.1.2.161SYNCOUT_IN_STEPS	119
7.1.2.162SYNCOUT_INVERT	119
7.1.2.163SYNCOUT_ONPERIOD	119
7.1.2.164SYNCOUT_ONSTART	119
7.1.2.165SYNCOUT_ONSTOP	120
7.1.2.166SYNCOUT_STATE	120
7.1.2.167UART_PARITY_BITS	120
7.1.2.168WIND_A_STATE_ABSENT	120
7.1.2.169WIND_A_STATE_MALFUNC	120
7.1.2.170WIND_A_STATE_OK	120
7.1.2.171WIND_A_STATE_UNKNOWN	120
7.1.2.172WIND_B_STATE_ABSENT	120
7.1.2.173WIND_B_STATE_MALFUNC	120
7.1.2.174WIND_B_STATE_OK	120
7.1.2.175WIND_B_STATE_UNKNOWN	120
7.1.2.176XIMC_API	121
7.1.3 Typedef Documentation	121
7.1.3.1 logging_callback_t	121
7.1.4 Function Documentation	121
7.1.4.1 close_device	121
7.1.4.2 command_clear_fram	121
7.1.4.3 command_eeread_settings	121
7.1.4.4 command_eesave_settings	122
7.1.4.5 command_home	122

7.1.4.6	command_homezero	122
7.1.4.7	command_left	122
7.1.4.8	command_loft	123
7.1.4.9	command_move	123
7.1.4.10	command_move_calb	123
7.1.4.11	command_movr	123
7.1.4.12	command_movr_calb	124
7.1.4.13	command_power_off	124
7.1.4.14	command_read_robust_settings	124
7.1.4.15	command_read_settings	125
7.1.4.16	command_reset	125
7.1.4.17	command_right	125
7.1.4.18	command_save_robust_settings	125
7.1.4.19	command_save_settings	125
7.1.4.20	command_sstp	125
7.1.4.21	command_start_measurements	126
7.1.4.22	command_stop	126
7.1.4.23	command_update_firmware	126
7.1.4.24	command_wait_for_stop	126
7.1.4.25	command_zero	127
7.1.4.26	enumerate_devices	127
7.1.4.27	free_enumerate_devices	127
7.1.4.28	get_accessories_settings	127
7.1.4.29	get_analog_data	128
7.1.4.30	get_bootloader_version	128
7.1.4.31	get_brake_settings	128
7.1.4.32	get_calibration_settings	128
7.1.4.33	get_chart_data	128
7.1.4.34	get_control_settings	129
7.1.4.35	get_control_settings_calb	129
7.1.4.36	get_controller_name	129
7.1.4.37	get_ctp_settings	130
7.1.4.38	get_debug_read	130
7.1.4.39	get_device_count	130
7.1.4.40	get_device_information	130
7.1.4.41	get_device_name	131
7.1.4.42	get_edges_settings	131
7.1.4.43	get_edges_settings_calb	131
7.1.4.44	get_emf_settings	132

7.1.4.45 get_encoder_information	132
7.1.4.46 get_encoder_settings	132
7.1.4.47 get_engine_advansed_setup	132
7.1.4.48 get_engine_settings	133
7.1.4.49 get_engine_settings_calb	133
7.1.4.50 get_entype_settings	133
7.1.4.51 get_enumerate_device_controller_name	133
7.1.4.52 get_enumerate_device_information	134
7.1.4.53 get_enumerate_device_network_information	134
7.1.4.54 get_enumerate_device_serial	134
7.1.4.55 get_enumerate_device_stage_name	135
7.1.4.56 get_extended_settings	135
7.1.4.57 get_extio_settings	135
7.1.4.58 get_feedback_settings	135
7.1.4.59 get_firmware_version	136
7.1.4.60 get_gear_information	136
7.1.4.61 get_gear_settings	136
7.1.4.62 get_globally_unique_identifier	136
7.1.4.63 get_hallsensor_information	137
7.1.4.64 get_hallsensor_settings	137
7.1.4.65 get_home_settings	137
7.1.4.66 get_home_settings_calb	137
7.1.4.67 get_init_random	138
7.1.4.68 get_joystick_settings	138
7.1.4.69 get_measurements	138
7.1.4.70 get_motor_information	139
7.1.4.71 get_motor_settings	139
7.1.4.72 get_move_settings	139
7.1.4.73 get_move_settings_calb	139
7.1.4.74 get_network_settings	139
7.1.4.75 get_nonvolatile_memory	140
7.1.4.76 get_password_settings	140
7.1.4.77 get_pid_settings	140
7.1.4.78 get_position	141
7.1.4.79 get_position_calb	141
7.1.4.80 get_power_settings	141
7.1.4.81 get_secure_settings	141
7.1.4.82 get_serial_number	141
7.1.4.83 get_stage_information	142

7.1.4.84 get_stage_name	142
7.1.4.85 get_stage_settings	142
7.1.4.86 get_status	142
7.1.4.87 get_status_calb	143
7.1.4.88 get_sync_in_settings	143
7.1.4.89 get_sync_in_settings_calb	143
7.1.4.90 get_sync_out_settings	144
7.1.4.91 get_sync_out_settings_calb	144
7.1.4.92 get_uart_settings	144
7.1.4.93 goto_firmware	145
7.1.4.94 has_firmware	145
7.1.4.95 load_correction_table	145
7.1.4.96 logging_callback_stderr_narrow	146
7.1.4.97 logging_callback_stderr_wide	146
7.1.4.98 msec_sleep	146
7.1.4.99 open_device	146
7.1.4.100probe_device	146
7.1.4.101reset_locks	147
7.1.4.102service_command_updf	147
7.1.4.103set_accessories_settings	147
7.1.4.104set_bindy_key	147
7.1.4.105set_brake_settings	147
7.1.4.106set_calibration_settings	148
7.1.4.107set_control_settings	148
7.1.4.108set_control_settings_calb	148
7.1.4.109set_controller_name	149
7.1.4.110set_correction_table	149
7.1.4.111set_ctp_settings	149
7.1.4.112set_debug_write	150
7.1.4.113set_edges_settings	150
7.1.4.114set_edges_settings_calb	150
7.1.4.115set_emf_settings	150
7.1.4.116set_encoder_information	151
7.1.4.117set_encoder_settings	151
7.1.4.118set_engine_advansed_setup	151
7.1.4.119set_engine_settings	152
7.1.4.120set_engine_settings_calb	152
7.1.4.121set_entype_settings	152
7.1.4.122set_extended_settings	153

7.1.4.123set_extio_settings	153
7.1.4.124set_feedback_settings	153
7.1.4.125set_gear_information	154
7.1.4.126set_gear_settings	154
7.1.4.127set_hallsensor_information	154
7.1.4.128set_hallsensor_settings	154
7.1.4.129set_home_settings	154
7.1.4.130set_home_settings_calb	155
7.1.4.131set_joystick_settings	155
7.1.4.132set_logging_callback	155
7.1.4.133set_motor_information	156
7.1.4.134set_motor_settings	156
7.1.4.135set_move_settings	156
7.1.4.136set_move_settings_calb	156
7.1.4.137set_network_settings	157
7.1.4.138set_nonvolatile_memory	157
7.1.4.139set_password_settings	157
7.1.4.140set_pid_settings	157
7.1.4.141set_position	158
7.1.4.142set_position_calb	158
7.1.4.143set_power_settings	158
7.1.4.144set_secure_settings	158
7.1.4.145set_serial_number	159
7.1.4.146set_stage_information	159
7.1.4.147set_stage_name	159
7.1.4.148set_stage_settings	159
7.1.4.149set_sync_in_settings	160
7.1.4.150set_sync_in_settings_calb	160
7.1.4.151set_sync_out_settings	160
7.1.4.152set_sync_out_settings_calb	161
7.1.4.153set_uart_settings	161
7.1.4.154write_key	161
7.1.4.155ximc_fix_usbser_sys	161
7.1.4.156ximc_version	162

Chapter 1

libximc library

Documentation for libximc library.

Libximc is **thread safe**, cross-platform library for working with 8SMC4-USB and 8SMC5-USB controllers.

Full documentation about controllers is [there](#)

Full documentation about libximc API is available on the page [ximc.h](#).

1.1 What the controller does

- Supports input and output synchronization signals to ensure the joint operation of multiple devices within a complex system ;.
- Works with all compact stepper motors with a winding current of up to 3 A, without feedback, as well as with stepper motors equipped with an encoder in the feedback circuit, including a linear encoder on the positioner.
- Manages controller using ready-made [xiLab software](#) or using examples which allow rapid development using C++, C#, .NET, Delphi, Visual Basic, Xcode, Python, Matlab, Java, LabWindows and LabVIEW.

1.2 What can do libximc library

- Libximc manages controller using interfaces: USB 2.0, RS232 and Ethernet, also uses a common and proven virtual serial port interface, so you can work with motor control modules through this library under almost all operating systems, including Windows, Linux and MacOS X
- Libximc library supports plug/unplug on the fly. Each device can be controlled only by one program at once. **Multiple processes (programs) that control one device simultaneously are not allowed!**

Warning

Libximc library opens the controller in exclusive access mode. Any controller opened with libximc (XiLab also uses this library) needs to be closed before it may be used by another process. So at first check that you have closed XiLab or other software dealing with the controller before trying to reopen the controller.

Please read the [Introduction](#) to start work with library.

To use libximc in your project please consult with [How to use with...](#)

1.3 Assistance

Many thanks to everyone who sends us **errors** and **suggestions**. We appreciate your suggestions and try to make our product better!

Chapter 2

Introduction

2.1 About library

This document contains all information about libximc library. It utilizes well known virtual COM-port interface, so you can use it on Windows, Linux, MacOS X for intel and Apple Silicone (via Rosetta 2) including 64-bit versions. Multi-platform programing library supports plug/unplug on the fly.

Each device can be controlled only by one program at once. Multiple processes (programs) that control one device simultaneously are not allowed.

2.1.1 Supported OS and environment requirements:

- MacOS X 10.6 or newer
- Windows 2000 or newer
- Linux debian-based. DEB package is built against Debian Squeeze 7
- Linux debian-based ARM. DEB package is built on Ubuntu 14.04
- Linux rpm-based. RPM is built against OpenSUSE 12

Build requirements:

- Windows: Microsoft Visual C++ 2013 or newer, MATLAB, Code::Blocks, Delphi, Java, Python, cygwin with tar, bison, flex, curl, 7z mingw
- UNIX: gcc 4 or newer, gmake, doxygen, LaTeX, flex 2.5.30+, bison 2.3+, autotools (autoconf, auto-header, aclocal, automake, autoreconf, libtool)
- MacOS X: XCode 4 or newer, doxygen, mactex, autotools (autoconf, autoheader, aclocal, automake, autoreconf, libtool)

Chapter 3

How to rebuild library

3.1 Buliding on Windows

Requirements: 64-bit windows (build script builds both architectures), cygwin (must be installed to a default path).

Invoke a script:

```
./build.bat
```

Grab packages from ./deb/win32 and ./deb/win64

To build debug version of the library set environment variable "DEBUG" to "true" before running the build script.

3.2 Building on debian-based linux systems

Requirement: 64-bit and 32-bit debian system, ubuntu Typical set of packages:

```
sudo apt-get install build-essential make cmake curl git ruby1.9.1 autotools-
dev automake autoconf libtool doxygen bison flex debhelper lintian texlive texlive-
-latex-extra texlive-latex texlive-fonts-extra texlive-lang-cyrillic java-1.7.0-
openjdk java-1.7.0-openjdk-devel default-jre-headless default-jdk openjdk-6-jdk
rpm-build rpm-devel rpmlint pkg-config check dh-autoreconf hardening-wrapper
libfl-dev lsb-release
```

For ARM cross-compiling install gcc-arm-linux-gnueabihf from your ARM toolchain.

It's required to match library and host architecture: 32-bit library can be built only at 32-bit host, 64-bit library - only at 64-bit host. ARM library is built with armhf cross-compiler gcc-arm-linux-gnueabihf.

To build library and package invoke a script:

```
./build.sh libdeb
```

For ARM library replace 'libdeb' with 'libdebarm'.

Grab packages from ./ximc/deb and locally installed binaries from ./dist/local.

3.3 Buliding on MacOS X

To build and package a script invoke a script:

```
./build.sh libosx
```

Built library (classical and framework), examples (classical and .app), documentation are located at ./ximc/macosx, locally installed binaries from ./dist/local.

3.4 Building on generic UNIX

Generic version could be built with standard autotools.

```
./build.sh lib
```

Built files (library, headers, documentation) are installed to ./dist/local directory. It is a generic developer build. Sometimes you need to specify additional parameters to command line for your machine. Please look to following OS sections.

3.5 Building on redhat-based linux systems

Requirement: 64-bit redhat-based system (Fedora, Red Hat, SUSE) Typical set of packages:

```
sudo apt-get install build-essential make cmake curl git ruby1.9.1 autotools-dev automake autoconf libtool doxygen bison flex debhelper lintian texlive texlive-latex-extra texlive-latex texlive-fonts-extra texlive-lang-cyrillic java-1.7.0-openjdk java-1.7.0-openjdk-devel default-jre-headless default-jdk openjdk-6-jdk rpm-build rpm-devel rpmlint pkg-config check dh-autoreconf hardening-wrapper libfl-dev lsb-release
```

It's possible to build both 32- and 64-bit libraries on 64-bit host system. 64-bit library can't be built on 32-bit system.

To build library and package invoke a script:

```
./build.sh librpm
```

Grab packages from ./ximc/rpm and locally installed binaries from ./dist/local.

3.6 Source code access

The source codes of the libximc library can be found on [github](#).

Chapter 4

How to use with...

To acquire the first skills of using the library, a simple testappeasy_C test application has been created. Languages other than C are supported using calls with conversion of arguments of the stdcall type. A simple C test application is located in the 'examples/test_C' directory, a C# project is located in 'examples/test_CSharp', on VB.NET - in 'examples/test_VBNET', for delphi 6 - in 'example/test_Delphi', for matlab - 'examples/test_MATLAB', for Java - 'examples/test_Java', for Python - 'examples/test_Python', for Lab-Windows - 'examples/test_LabWindows'. Libraries, header files and other necessary files are located in the directories 'ximc/win32', 'ximc/win64', 'ximc/macosx' and the like. The developer kit also includes already compiled examples: testapp and testappeasy x32 and x64 bits for windows and only x64 bits for macOS X, test_CSharp, test_VBNET, test_Delphi - only x32 bits, test_Java - cross-platform, test_MATLAB and test_Python do not require compilation, test_LabWindows - 64-bit build is installed by default.

Note

SDK requires Microsoft Visual C++ Redistributable Package (provided with SDK - vcredist_x86 or vcredist_x64)

On Linux both the libximc7_x.x.x and libximc7-dev_x.x.x target architecture in the specified order. For install packages, you can use the .deb command: dpkg -i filename.deb, where filename.deb is the name of the package (packages in Debian have the extension .deb). You must run dpkg with superuser privileges (root).

Testapp can be built using testapp.sln. Library must be compiled with MS Visual C++ too, mingw-library. Make sure that Microsoft Visual C++ Redistributable Package is installed.

Open solution examples/testapp/testapp.sln, build and run from the IDE.

In case of the 8SMC4-USB-Eth1 Ethernet adapter usage it is necessary to set correct IP address of the Ethernet adapter in testapp.c file before build (see enumerate_hints variable).

Testappeasy_C and testapp_C can be built using testappeasy_C.cbp and testapp_C.cbp respectively. Library must be compiled with MS Visual C++ too, mingw-library. Make sure that Microsoft Visual C++ Redistributable Package is installed. *

Open solution examples/test_C/testappeasy_C/testappeasy_C/testappeasy_C.cbp or examples/test_C/testapp_C/testapp_C.cbp, build and run from the IDE.

MinGW is a port of GCC to win32 platform. It's required to install MinGW package.

MinGW-compiled testapp can be built with MS Visual C++ or mingw library.

```
mingw32-make -f Makefile.mingw all
```

Then copy library libximc.dll to current directory and launch testapp.exe.

In case of the 8Eth1 Ethernet adapter usage it is necessary to set correct IP address of the Ethernet adapter in testapp.c file before build (see enumerate_hints variable).

First of all, you should create a library suitable for C++ Builder. **Visual C++ and Builder libraries are not compatible** Invoke:

```
imprib libximc.lib libximc.def
```

Then compile test application:

```
bcc32 -I..\\ximc\\win32 -L..\\ximc\\win32 -DWIN32 -DNDEBUG -DWINDOWS testapp.c libximc.lib
```

In case of the 8Eth1 Ethernet adapter usage it is necessary to set correct IP address of the Ethernet adapter in testapp.c file before build (see enumerate_hints variable).

There is also an [unsupported example](#) of using libximc in a C++ Builder project

testapp should be built with XCode project testapp.xcodeproj. Library is a MacOS X framework, and at example application it's bundled inside testapp.app

Then launch application testapp.app and check activity output in Console.app.

In case of the 8Eth1 Ethernet adapter usage it is necessary to set correct IP address of the Ethernet adapter in testapp.c file before build (see enumerate_hints variable). There is also [an example of using the libximc library](#) in a C++ Builder project, **but it is not supported**.

Make sure that libximc (rpm or deb) is installed at your system. Installation of package should be performed with a package manager of operating system. On MacOS X a framework is provided.

Note that user should belong to system group which allows access to a serial port (dip or serial, for example).

Test application can be built with the installed library with the following script:

```
make
```

In case of cross-compilation (target architecture differs from the current system architecture) feed -m64 or -m32 flag to compiler. On MacOS X it's needed to use -arch flag instead to build an universal binary. Please consult a compiler documentation.

Then launch the application as:

```
make run
```

Note: make run on MacOS X copies a library to the current directory. If you want to use library from the custom directory please be sure to specify LD_LIBRARY_PATH or DYLD_LIBRARY_PATH to the directory with the library.

In case of the 8SMC4-USB-Eth1 Ethernet adapter usage it is necessary to set correct IP address of the Ethernet adapter in testapp.c file before build (see enumerate_hints variable).

Wrapper assembly for libximc.dll is ximc/winX/wrappers/csharp/ximcnet.dll. It is provided with two different architectures. Tested on platforms .NET from 2.0 to 4.5.1

Test .NET applications for Visual Studio 2013 is located at test_CSharp (for C#) and test_VBNET (for VB.NET) respectively. Open solutions and build it.

In case of the 8SMC4-USB-Eth1 Ethernet adapter usage it is necessary to set correct IP address of the Ethernet adapter in testapp.cs or testapp.vb file (depending on programming language) before build (see enumerate_hints variable for C# or enum_hints variable for VB).

Wrapper for libximc.dll is a unit ximc/winX/wrappers/delphi/ximc.pas

Console test application for is located at test_Delphi. Tested on Delphi 6 and only 32-bit version.

Just compile, place .dll near the executable and run program.

In case of the 8Eth1 Ethernet adapter usage it is necessary to set correct IP address of the Ethernet adapter in test_Delphi.dpr file before build (see enum_hints variable).

How to run example on Linux. Go to to examples/test_Java/compiled-winX/ and run:

```
java -cp /usr/share/java/libjximc.jar:test_Java.jar ru.ximc.TestJava
```

How to run example on Windows. Go to to examples/test_Java/compiled-winX/. Then run:

```
java -classpath libjximc.jar -classpath test_Java.jar ru.ximc.TestJava
```

How to modify and recompile an example. Go to to examples/test_Java/compiled. Sources are embedded in a test_Java.jar. Extract them:

```
jar xvf test_Java.jar ru META-INF
```

Then rebuild sources:

```
javac -classpath /usr/share/java/libjximc.jar -Xlint ru/ximc/TestJava.java
```

or for Windows or MacOS X

```
javac -classpath libjximc.jar -Xlint ru/ximc/TestJava.java
```

Then build a jar:

```
jar cmf META-INF/MANIFEST.MF test_Java.jar ru
```

In case of the 8Eth1 Ethernet adapter usage it is necessary to set correct IP address of the Ethernet adapter in TestJava.java file before build (see ENUM_HINTS variable).

Change current directory to the examples/test_Python. For correct usage of the library libximc, the example uses the file wrapper, ximc/crossplatform/wrappers/python/pyximc.py with a description of the structures of the library.

Before launch:

On MacOS X: copy library ximc/macosx/libximc.framework to the current directory.

On Linux: you may need to set LD_LIBRARY_PATH so Python can locate libraries with RPATH. For example, you may need:

```
export LD_LIBRARY_PATH=$LD_LIBRARY_PATH:'pwd'
```

On Windows before the start nothing needs to be done. All necessary communication and dependencies are registered in the example code. Libraries used: bindy.dll libximc.dll xiwrapper.dll. Located in the folder for the respective versions of Windows.

Then run:

```
python test_Python.py
```

In case of the 8Eth1 Ethernet adapter usage it is necessary to set correct IP address of the Ethernet adapter in test_Python.py file before launch (see enum_hints variable).

Sample MATLAB program testximc.m is provided at the directory examples/test_MATLAB. On windows copy [ximc.h](#), libximc.dll, bindy.dll, xiwrapper.dll and contents of ximc/(win32,win64)/wrappers/matlab/ directory to the current directory.

Before launch:

On MacOS X: copy ximc/macosx/libximc.framework, ximc/macosx/wrappers/ximcm.h, ximc/ximc.h to the directory examples/test_MATLAB. Install XCode compatible with Matlab.

On Linux: install libximc*deb and libximc-dev*dev of target architecture. Then copy ximc/macosx/wrappers/ximcm.h to the directory examples/matlab. Install gcc compatible with Matlab.

For XCode and gcc version compatibility check document https://www.mathworks.com/content/dam/mathworks/mathworkSystemRequirements-Release2014a_SupportedCompilers.pdf or similar.

On Windows before the start nothing needs to be done

Change current directory in the MATLAB to the examples/test_MATLAB. Then launch in MATLAB prompt:

```
testximc
```

In case of the 8Eth1 Ethernet adapter usage it is necessary to set correct IP address of the Ethernet adapter in testximc.m file before launch (see enum_hints variable).

4.1 Generic logging facility

If you want to turn on file logging, you should run the program that uses libximc library with the "XILOG" environment variable set to desired file name. This file will be opened for writing on the first log event and will be closed when the program which uses libximc terminates. Data which is sent to/received from the controller is logged along with port open and close events.

4.2 Required permissions

libximc generally does not require special permissions to work, it only needs read/write access to USB-serial ports on the system. An exception to this rule is a Windows-only "fix_usbser.sys()" function - it needs elevation and will produce null result if run as a regular user.

4.3 C-profiles

C-profiles are header files distributed with the libximc library. They enable one to set all controller settings for any of the supported stages with a single function call in a C/C++ program.

You may see how to use C-profiles in the example directory "examples/test_C/testprofile_C".

4.4 Python-profiles

Python-profiles this is a set of configuration functions distributed with the libximc library. They enable one to set all controller settings for any of the supported stages with a single function call in a Python program.

You may see how to use Python-profiles in the example directory "examples/test_Python/profletest/testpythonprofile.py".

Chapter 5

Working with user units

In addition to working in basic units(steps, encoder value), the library allows you to work with user units. For this purpose are used:

- The structure of the conversion units [calibration_t](#)
- The functions of which have doubles for working with user units, data structures for these functions
- Coordinate correction table for more accurate positioning

5.1 The structure of the conversion units calibration_t

To specify conversion of the basic units in the user and back, [calibration_t](#) structure is used. With the help of coefficients A and MicrostepMode, specified in this structure, steps and microsteps which are integers are converted into the user value of the real type and back.

Conversion formulas:

- The conversion to user units.

```
user_value = A*(step + mstep/pow(2, MicrostepMode-1))
```

- Conversion from user units.

```
step = (int)(user_value/A)
mstep = (user_value/A - step)*pow(2, MicrostepMode-1)
```

5.2 Alternative functions for working with user units and data structures for them

Structures and functions for working with user units have the _calb postfix. The user using these functions can perform all actions in their own units without worrying about the computations of the controller. The data format of _calb structures is described in detail. For _calb functions particular descriptions are not used. They perform the same actions as the basic functions do. The difference between them and the basic functions is in the position, velocity, and acceleration of the data types defined as user-defined. If clarification for _calb functions is necessary, they are provided as notes in the description of the basic functions.

5.3 Coordinate correction table for more accurate positioning

Some functions for working with user units support coordinate transformation using a correction table. To load a table from a file, the [load_correction_table\(\)](#) function is used. Its description contains the functions and their data supporting correction.

Note

For data fields which are corrected in case of loading of the table in the description of the field is written
- corrected by the table.

File format:

- two columns separated by tabs;
- column headers are string;
- real type data, point is a separator;
- the first column is the coordinate, the second is the deviation caused by a mechanical error;
- the deviation between coordinates is calculated linearly;
- constant is equal to the deviation at the boundary beyond the range;
- maximum length of the table is 100 lines.

Sample file:

X	dX
0	0
5.0	0.005
10.0	-0.01

Chapter 6

Data Structure Documentation

6.1 accessories_settings_t Struct Reference

Additional accessories information.

Data Fields

- char [MagneticBrakeInfo](#) [25]
The manufacturer and the part number of magnetic brake, the maximum string length is 24 characters.
- float [MBRatedVoltage](#)
Rated voltage for controlling the magnetic brake (B).
- float [MBRatedCurrent](#)
Rated current for controlling the magnetic brake (A).
- float [MBTorque](#)
Retention moment (mN m).
- unsigned int [MBSettings](#)
Magnetic brake settings flags.
- char [TemperatureSensorInfo](#) [25]
The manufacturer and the part number of the temperature sensor, the maximum string length: 24 characters.
- float [TSMin](#)
The minimum measured temperature (degrees Celsius) Data type: float.
- float [TSMax](#)
The maximum measured temperature (degrees Celsius) Data type: float.
- float [TSGrad](#)
The temperature gradient (V/degrees Celsius).
- unsigned int [TSSettings](#)
Temperature sensor settings flags.
- unsigned int [LimitSwitchesSettings](#)
Temperature sensor settings flags.

6.1.1 Detailed Description

Additional accessories information.

See Also

[set_accessories_settings](#)
[get_accessories_settings](#)
[get_accessories_settings](#), [set_accessories_settings](#)

6.1.2 Field Documentation

6.1.2.1 unsigned int LimitSwitchesSettings

[Temperature sensor settings flags.](#)

6.1.2.2 char MagneticBrakeInfo[25]

The manufacturer and the part number of magnetic brake, the maximum string length is 24 characters.

6.1.2.3 float MBRatedCurrent

Rated current for controlling the magnetic brake (A).

Data type: float.

6.1.2.4 float MBRatedVoltage

Rated voltage for controlling the magnetic brake (B).

Data type: float.

6.1.2.5 unsigned int MBSettings

[Magnetic brake settings flags.](#)

6.1.2.6 float MBTorque

Retention moment (mN m).

Data type: float.

6.1.2.7 char TemperatureSensorInfo[25]

The manufacturer and the part number of the temperature sensor, the maximum string length: 24 characters.

6.1.2.8 float TSGrad

The temperature gradient (V/degrees Celsius).

Data type: float.

6.1.2.9 float TSMax

The maximum measured temperature (degrees Celsius) Data type: float.

6.1.2.10 float TSMin

The minimum measured temperature (degrees Celsius) Data type: float.

6.1.2.11 unsigned int TSSettings

Temperature sensor settings flags.

6.2 analog_data_t Struct Reference

Analog data.

Data Fields

- unsigned int [A1Voltage_ADC](#)
"Voltage on pin 1 winding A" raw data from ADC.
- unsigned int [A2Voltage_ADC](#)
"Voltage on pin 2 winding A" raw data from ADC.
- unsigned int [B1Voltage_ADC](#)
"Voltage on pin 1 winding B" raw data from ADC.
- unsigned int [B2Voltage_ADC](#)
"Voltage on pin 2 winding B" raw data from ADC.
- unsigned int [SupVoltage_ADC](#)
"Voltage on the top of MOSFET full bridge" raw data from ADC.
- unsigned int [ACurrent_ADC](#)
"Winding A current" raw data from ADC.
- unsigned int [BCurrent_ADC](#)
"Winding B current" raw data from ADC.
- unsigned int [FullCurrent_ADC](#)
"Full current" raw data from ADC.
- unsigned int [Temp_ADC](#)
Voltage from temperature sensor, raw data from ADC.
- unsigned int [Joy_ADC](#)
Joystick raw data from ADC.
- unsigned int [Pot_ADC](#)
Voltage on analog input, raw data from ADC.
- unsigned int [L5_ADC](#)
USB supply voltage after the current sense resistor, from ADC.
- unsigned int [H5_ADC](#)
Power supply USB from ADC.
- int [A1Voltage](#)
"Voltage on pin 1 winding A" calibrated data (in tens of mV).
- int [A2Voltage](#)
"Voltage on pin 2 winding A" calibrated data (in tens of mV).
- int [B1Voltage](#)
"Voltage on pin 1 winding B" calibrated data (in tens of mV).
- int [B2Voltage](#)
"Voltage on pin 2 winding B" calibrated data (in tens of mV).

- int [SupVoltage](#)
"Voltage on the top of MOSFET full bridge" calibrated data (in tens of mV).
- int [ACurrent](#)
"Winding A current" calibrated data (in mA).
- int [BCurrent](#)
"Winding B current" calibrated data (in mA).
- int [FullCurrent](#)
"Full current" calibrated data (in mA).
- int [Temp](#)
Temperature, calibrated data (in tenths of degrees Celcius).
- int [Joy](#)
Joystick, calibrated data.
- int [Pot](#)
Analog input, calibrated data.
- int [L5](#)
USB supply voltage after the current sense resistor (in tens of mV).
- int [H5](#)
Power supply USB (in tens of mV).
- unsigned int **deprecated**
- int [R](#)
Motor winding resistance in mOhms(is only used with stepper motor).
- int [L](#)
Motor winding pseudo inductance in uHn(is only used with stepper motor).

6.2.1 Detailed Description

Analog data.

This structure contains raw analog data from ADC embedded on board. These data used for device testing and deep recalibration by manufacturer only.

See Also

[get_analog_data](#)
[get_analog_data](#)

6.2.2 Field Documentation

6.2.2.1 int A1Voltage

"Voltage on pin 1 winding A" calibrated data (in tens of mV).

6.2.2.2 unsigned int A1Voltage_ADC

"Voltage on pin 1 winding A" raw data from ADC.

6.2.2.3 int A2Voltage

"Voltage on pin 2 winding A" calibrated data (in tens of mV).

6.2.2.4 unsigned int A2Voltage_ADC

"Voltage on pin 2 winding A" raw data from ADC.

6.2.2.5 int ACURRENT

"Winding A current" calibrated data (in mA).

6.2.2.6 unsigned int ACURRENT_ADC

"Winding A current" raw data from ADC.

6.2.2.7 int B1Voltage

"Voltage on pin 1 winding B" calibrated data (in tens of mV).

6.2.2.8 unsigned int B1Voltage_ADC

"Voltage on pin 1 winding B" raw data from ADC.

6.2.2.9 int B2Voltage

"Voltage on pin 2 winding B" calibrated data (in tens of mV).

6.2.2.10 unsigned int B2Voltage_ADC

"Voltage on pin 2 winding B" raw data from ADC.

6.2.2.11 int BCURRENT

"Winding B current" calibrated data (in mA).

6.2.2.12 unsigned int BCURRENT_ADC

"Winding B current" raw data from ADC.

6.2.2.13 int FullCurrent

"Full current" calibrated data (in mA).

6.2.2.14 unsigned int FullCurrent_ADC

"Full current" raw data from ADC.

6.2.2.15 int H5

Power supply USB (in tens of mV).

6.2.2.16 int Joy

Joystick, calibrated data.

Range: 0..10000

6.2.2.17 unsigned int Joy_ADC

Joystick raw data from ADC.

6.2.2.18 int L

Motor winding pseudo inductance in uHn(is only used with stepper motor).

6.2.2.19 int L5

USB supply voltage after the current sense resistor (in tens of mV).

6.2.2.20 unsigned int L5_ADC

USB supply voltage after the current sense resistor, from ADC.

6.2.2.21 int Pot

Analog input, calibrated data.

Range: 0..10000

6.2.2.22 int R

Motor winding resistance in mOhms(is only used with stepper motor).

6.2.2.23 int SupVoltage

"Voltage on the top of MOSFET full bridge" calibrated data (in tens of mV).

6.2.2.24 unsigned int SupVoltage_ADC

"Voltage on the top of MOSFET full bridge" raw data from ADC.

6.2.2.25 int Temp

Temperature, calibrated data (in tenths of degrees Celcius).

6.2.2.26 unsigned int Temp_ADC

Voltage from temperature sensor, raw data from ADC.

6.3 brake_settings_t Struct Reference

Brake settings.

Data Fields

- unsigned int [t1](#)
Time in ms between turn on motor power and turn off brake.
- unsigned int [t2](#)
Time in ms between turn off brake and moving readiness.
- unsigned int [t3](#)
Time in ms between motor stop and turn on brake.
- unsigned int [t4](#)
Time in ms between turn on brake and turn off motor power.
- unsigned int [BrakeFlags](#)
Brake settings flags.

6.3.1 Detailed Description

Brake settings.

This structure contains parameters of brake control.

See Also

[set_brake_settings](#)
[get_brake_settings](#)
[get_brake_settings](#), [set_brake_settings](#)

6.3.2 Field Documentation

6.3.2.1 unsigned int BrakeFlags

Brake settings flags.

6.3.2.2 unsigned int t1

Time in ms between turn on motor power and turn off brake.

6.3.2.3 unsigned int t2

Time in ms between turn off brake and moving readiness.

All moving commands will execute after this interval.

6.3.2.4 unsigned int t3

Time in ms between motor stop and turn on brake.

6.3.2.5 unsigned int t4

Time in ms between turn on brake and turn off motor power.

6.4 calibration_settings_t Struct Reference

Calibration settings.

Data Fields

- float [CSS1_A](#)
Scaling factor for the analogue measurements of the winding A current.
- float [CSS1_B](#)
Shift factor for the analogue measurements of the winding A current.
- float [CSS2_A](#)
Scaling factor for the analogue measurements of the winding B current.
- float [CSS2_B](#)
Shift factor for the analogue measurements of the winding B current.
- float [FullCurrent_A](#)
Scaling factor for the analogue measurements of the full current.
- float [FullCurrent_B](#)
Shift factor for the analogue measurements of the full current.

6.4.1 Detailed Description

Calibration settings.

This structure contains calibration settings.

See Also

[get_calibration_settings](#)
[set_calibration_settings](#)
[get_calibration_settings](#), [set_calibration_settings](#)

6.4.2 Field Documentation

6.4.2.1 float CSS1_A

Scaling factor for the analogue measurements of the winding A current.

6.4.2.2 float CSS1_B

Shift factor for the analogue measurements of the winding A current.

6.4.2.3 float CSS2_A

Scaling factor for the analogue measurements of the winding B current.

6.4.2.4 float CSS2_B

Shift factor for the analogue measurements of the winding B current.

6.4.2.5 float FullCurrent_A

Scaling factor for the analogue measurements of the full current.

6.4.2.6 float FullCurrent_B

Shift factor for the analogue measurements of the full current.

6.5 calibration_t Struct Reference

Calibration structure.

Data Fields

- double A
is a conversion factor which is equal number of millimeters (or other units) per one step
- unsigned int MicrostepMode
is a controller setting which is determine a step division mode

6.5.1 Detailed Description

Calibration structure.

6.6 chart_data_t Struct Reference

Additional device state.

Data Fields

- int WindingVoltageA
In the case step motor, the voltage across the winding A (in tens of mV); in the case of a brushless, the voltage on the first coil, in the case of the only DC.
- int WindingVoltageB
In the case step motor, the voltage across the winding B (in tens of mV); in case of a brushless, the voltage on the second winding, and in the case of DC is not used.
- int WindingVoltageC
In the case of a brushless, the voltage on the third winding (in tens of mV), in the case step motor and DC is not used.
- int WindingCurrentA
In the case step motor, the current in the coil A (in mA); brushless if the current in the first coil, and in the case of a single DC.
- int WindingCurrentB
In the case step motor, the current in the coil B (in mA); brushless if the current in the second coil, and in the case of DC is not used.
- int WindingCurrentC
In the case of a brushless, the current in the third winding (in mA), in the case step motor and DC is not used.
- unsigned int Pot

Analog input value in ten-thousandths.

- unsigned int `Joy`

The joystick position in the ten-thousandths.

- int `DutyCycle`

Duty cycle of PWM.

6.6.1 Detailed Description

Additional device state.

This structure contains additional values such as winding's voltages, currents and temperature.

See Also

[get_chart_data](#)
[get_chart_data](#)

6.6.2 Field Documentation

6.6.2.1 int DutyCycle

Duty cycle of PWM.

6.6.2.2 unsigned int Joy

The joystick position in the ten-thousandths.

Range: 0..10000

6.6.2.3 unsigned int Pot

Analog input value in ten-thousandths.

Range: 0..10000

6.6.2.4 int WindingCurrentA

In the case step motor, the current in the coil A (in mA); brushless if the current in the first coil, and in the case of a single DC.

6.6.2.5 int WindingCurrentB

In the case step motor, the current in the coil B (in mA); brushless if the current in the second coil, and in the case of DC is not used.

6.6.2.6 int WindingCurrentC

In the case of a brushless, the current in the third winding (in mA), in the case step motor and DC is not used.

6.6.2.7 int WindingVoltageA

In the case step motor, the voltage across the winding A (in tens of mV); in the case of a brushless, the voltage on the first coil, in the case of the only DC.

6.6.2.8 int WindingVoltageB

In the case step motor, the voltage across the winding B (in tens of mV); in case of a brushless, the voltage on the second winding, and in the case of DC is not used.

6.6.2.9 int WindingVoltageC

In the case of a brushless, the voltage on the third winding (in tens of mV), in the case step motor and DC is not used.

6.7 control_settings_calb_t Struct Reference

Control settings which use user units.

Data Fields

- float [MaxSpeed](#) [10]
Array of speeds using with joystick and button control.
- unsigned int [Timeout](#) [9]
timeout[i] is time in ms, after that max_speed[i+1] is applying.
- unsigned int [MaxClickTime](#)
Maximum click time (in ms).
- unsigned int [Flags](#)
Control flags.
- float [DeltaPosition](#)
Shift (delta) of position.

6.7.1 Detailed Description

Control settings which use user units.

This structure contains control parameters. When choosing CTL_MODE=1 switches motor control with the joystick. In this mode, the joystick to the maximum engine tends Move at MaxSpeed [i], where i=0 if the previous use This mode is not selected another i. Buttons switch the room rate i. When CTL_MODE=2 is switched on motor control using the Left / right. When you click on the button motor starts to move in the appropriate direction at a speed MaxSpeed [0], at the end of time Timeout[i] motor move at a speed MaxSpeed [i+1]. at Transition from MaxSpeed [i] on MaxSpeed [i+1] to acceleration, as usual. The figure above shows the sensitivity of the joystick feature on its position.

See Also

[set_control_settings_calb](#)
[get_control_settings_calb](#)
[get_control_settings](#), [set_control_settings](#)

6.7.2 Field Documentation

6.7.2.1 unsigned int Flags

Control flags.

6.7.2.2 unsigned int MaxClickTime

Maximum click time (in ms).

Prior to the expiration of this time the first speed isn't enabled.

6.7.2.3 float MaxSpeed[10]

Array of speeds using with joystick and button control.

6.7.2.4 unsigned int Timeout[9]

timeout[i] is time in ms, after that max_speed[i+1] is applying.

It is using with buttons control only.

6.8 control_settings_t Struct Reference

Control settings.

Data Fields

- **unsigned int MaxSpeed [10]**
Array of speeds (full step) using with joystick and button control.
- **unsigned int uMaxSpeed [10]**
Array of speeds (in microsteps) using with joystick and button control.
- **unsigned int Timeout [9]**
timeout[i] is time in ms, after that max_speed[i+1] is applying.
- **unsigned int MaxClickTime**
Maximum click time (in ms).
- **unsigned int Flags**
Control flags.
- **int DeltaPosition**
Shift (delta) of position (full step)
- **int uDeltaPosition**
Fractional part of the shift in micro steps.

6.8.1 Detailed Description

Control settings.

This structure contains control parameters. When choosing CTL_MODE=1 switches motor control with the joystick. In this mode, the joystick to the maximum engine tends Move at MaxSpeed [i], where i=0 if the previous use This mode is not selected another i. Buttons switch the room rate i. When CTL_MODE=2

is switched on motor control using the Left / right. When you click on the button motor starts to move in the appropriate direction at a speed MaxSpeed [0], at the end of time Timeout[i] motor move at a speed MaxSpeed [i+1]. at Transition from MaxSpeed [i] on MaxSpeed [i+1] to acceleration, as usual. The figure above shows the sensitivity of the joystick feature on its position.

See Also

[set_control_settings](#)
[get_control_settings](#)
[get_control_settings](#), [set_control_settings](#)

6.8.2 Field Documentation

6.8.2.1 unsigned int Flags

Control flags.

6.8.2.2 unsigned int MaxClickTime

Maximum click time (in ms).

Prior to the expiration of this time the first speed isn't enabled.

6.8.2.3 unsigned int MaxSpeed[10]

Array of speeds (full step) using with joystick and button control.

Range: 0..100000.

6.8.2.4 unsigned int Timeout[9]

timeout[i] is time in ms, after that max_speed[i+1] is applying.

It is using with buttons control only.

6.8.2.5 int uDeltaPosition

Fractional part of the shift in micro steps.

Is only used with stepper motor. Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings).

6.8.2.6 unsigned int uMaxSpeed[10]

Array of speeds (in microsteps) using with joystick and button control.

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings).

6.9 controller_name_t Struct Reference

Controller user name and flags of setting.

Data Fields

- char ControllerName [17]
User controller name.
- unsigned int CtrlFlags
Flags of internal controller settings.

6.9.1 Detailed Description

Controller user name and flags of setting.

See Also

[get_controller_name](#), [set_controller_name](#)

6.9.2 Field Documentation

6.9.2.1 char ControllerName[17]

User controller name.

Can be set by user for his/her convinience. Max string length: 16 chars.

6.9.2.2 unsigned int CtrlFlags

Flags of internal controller settings.

6.10 ctp_settings_t Struct Reference

Control position settings(is only used with stepper motor).

Data Fields

- unsigned int CTPMinError
Minimum contrast steps from step motor encoder position, which set STATE_CTP_ERROR flag.
- unsigned int CTPFlags
Position control flags.

6.10.1 Detailed Description

Control position settings(is only used with stepper motor).

When controlling the step motor with encoder (CTP_BASE 0) it is possible to detect the loss of steps. The controller knows the number of steps per revolution (GENG :: StepsPerRev) and the encoder resolution (GFBS :: IPT). When the control (flag CTP_ENABLED), the controller stores the current position in the footsteps of SM and the current position of the encoder. Further, at each step of the position encoder is converted into steps and if the difference is greater CTPMinError, a flag STATE_CTP_ERROR and set ALARM state. When controlling the step motor with speed sensor (CTP_BASE 1), the position is controlled by him. The active edge of input clock controller stores the current value of steps. Further, at each turn checks how many steps shifted. When a mismatch CTPMinError a flag STATE_CTP_ERROR and set ALARM state.

See Also

[set_ctp_settings](#)
[get_ctp_settings](#)
[get_ctp_settings](#), [set_ctp_settings](#)

6.10.2 Field Documentation

6.10.2.1 unsigned int CTPFlags

[Position control flags.](#)

6.10.2.2 unsigned int CTMinError

Minimum contrast steps from step motor encoder position, which set STATE_CTP_ERROR flag.

Measured in steps step motor.

6.11 debug_read_t Struct Reference

Debug data.

Data Fields

- `uint8_t DebugData [128]`

Arbitrary debug data.

6.11.1 Detailed Description

Debug data.

These data are used for device debugging by manufacturer only.

See Also

[get_debug_read](#)

6.11.2 Field Documentation

6.11.2.1 uint8_t DebugData[128]

Arbitrary debug data.

6.12 debug_write_t Struct Reference

Debug data.

Data Fields

- `uint8_t DebugData [128]`

Arbitrary debug data.

6.12.1 Detailed Description

Debug data.

These data are used for device debugging by manufacturer only.

See Also

[set_debug_write](#)

6.12.2 Field Documentation

6.12.2.1 uint8_t DebugData[128]

Arbitrary debug data.

6.13 device_information_t Struct Reference

Read command controller information.

Data Fields

- char [Manufacturer](#) [5]
Manufacturer.
- char [ManufacturerId](#) [3]
Manufacturer id.
- char [ProductDescription](#) [9]
Product description.
- unsigned int [Major](#)
The major number of the hardware version.
- unsigned int [Minor](#)
Minor number of the hardware version.
- unsigned int [Release](#)
Number of edits this release of hardware.

6.13.1 Detailed Description

Read command controller information.

The controller responds to this command in any state. Manufacturer field for all XI** devices should contain the string "XIMC" (validation is performed on it) The remaining fields contain information about the device.

See Also

[get_device_information](#)
[get_device_information_impl](#)

6.13.2 Field Documentation

6.13.2.1 unsigned int Major

The major number of the hardware version.

6.13.2.2 unsigned int Minor

Minor number of the hardware version.

6.13.2.3 unsigned int Release

Number of edits this release of hardware.

6.14 device_network_information_t Struct Reference

Device network information structure.

Data Fields

- `uint32_t ipv4`
IPv4 address, passed in network byte order (big-endian byte order)
- `char nodename [16]`
name of the Bindy node which hosts the device
- `uint32_t axis_state`
flags representing device state
- `char locker_username [16]`
name of the user who locked the device (if any)
- `char locker_nodename [16]`
Bindy node name, which was used to lock the device (if any)
- `time_t locked_time`
time the lock was acquired at (UTC, microseconds since the epoch)

6.14.1 Detailed Description

Device network information structure.

6.15 edges_settings_calb_t Struct Reference

Edges settings which use user units.

Data Fields

- `unsigned int BorderFlags`
Border flags.
- `unsigned int EnderFlags`
Limit switches flags.
- `float LeftBorder`
Left border position, used if BORDER_IS_ENCODER flag is set.
- `float RightBorder`
Right border position, used if BORDER_IS_ENCODER flag is set.

6.15.1 Detailed Description

Edges settings which use user units.

This structure contains border and limit switches settings. Please load new engine settings when you change positioner etc. Please note that wrong engine settings lead to device malfunction, can lead to irreversible damage of board.

See Also

[set_edges_settings_calb](#)
[get_edges_settings_calb](#)
[get_edges_settings](#), [set_edges_settings](#)

6.15.2 Field Documentation

6.15.2.1 unsigned int BorderFlags

[Border flags.](#)

6.15.2.2 unsigned int EnderFlags

[Limit switches flags.](#)

6.15.2.3 float LeftBorder

Left border position, used if BORDER_IS_ENCODER flag is set.

Corrected by the table.

6.15.2.4 float RightBorder

Right border position, used if BORDER_IS_ENCODER flag is set.

Corrected by the table.

6.16 edges_settings_t Struct Reference

Edges settings.

Data Fields

- [unsigned int BorderFlags](#)
Border flags.
- [unsigned int EnderFlags](#)
Limit switches flags.
- [int LeftBorder](#)
Left border position, used if BORDER_IS_ENCODER flag is set.
- [int uLeftBorder](#)
Left border position in microsteps(used with stepper motor only).
- [int RightBorder](#)
Right border position, used if BORDER_IS_ENCODER flag is set.

- int [uRightBorder](#)
Right border position in microsteps.

6.16.1 Detailed Description

Edges settings.

This structure contains border and limit switches settings. Please load new engine settings when you change positioner etc. Please note that wrong engine settings lead to device malfunction, can lead to irreversible damage of board.

See Also

[set_edges_settings](#)
[get_edges_settings](#)
[get_edges_settings](#), [set_edges_settings](#)

6.16.2 Field Documentation

6.16.2.1 unsigned int BorderFlags

[Border flags.](#)

6.16.2.2 unsigned int EnderFlags

[Limit switches flags.](#)

6.16.2.3 int LeftBorder

Left border position, used if BORDER_IS_ENCODER flag is set.

6.16.2.4 int RightBorder

Right border position, used if BORDER_IS_ENCODER flag is set.

6.16.2.5 int uLeftBorder

Left border position in microsteps(used with stepper motor only).

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings).

6.16.2.6 int uRightBorder

Right border position in microsteps.

Used with stepper motor only. Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings).

6.17 emf_settings_t Struct Reference

EMF settings.

Data Fields

- float [L](#)
The inductance of the windings of the motor.
- float [R](#)
The resistance of the windings of the motor.
- float [Km](#)
Electromechanical ratio of the motor.
- unsigned int [BackEMFFlags](#)
Flags of auto-detection of characteristics of windings of the engine.

6.17.1 Detailed Description

EMF settings.

This structure contains the data for Electromechanical characteristics(EMF) of the motor. They determine the inductance, resistance and Electromechanical coefficient of the motor. This data is stored in the flash memory of the controller. Please download the new settings when you change the motor. Remember that improper settings of the EMF may damage the equipment.

See Also

[set_emf_settings](#)
[get_emf_settings](#)
[get_emf_settings, set_emf_settings](#)

6.17.2 Field Documentation

6.17.2.1 unsigned int BackEMFFlags

Flags of auto-detection of characteristics of windings of the engine.

6.17.2.2 float Km

Electromechanical ratio of the motor.

6.17.2.3 float L

The inductance of the windings of the motor.

6.17.2.4 float R

The resistance of the windings of the motor.

6.18 encoder_information_t Struct Reference

Encoder information.

Data Fields

- char [Manufacturer](#) [17]
Manufacturer.
- char [PartNumber](#) [25]
Series and PartNumber.

6.18.1 Detailed Description

Encoder information.

See Also

[set_encoder_information](#)
[get_encoder_information](#)
[get_encoder_information](#), [set_encoder_information](#)

6.18.2 Field Documentation

6.18.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

6.18.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

6.19 encoder_settings_t Struct Reference

Encoder settings.

Data Fields

- float [MaxOperatingFrequency](#)
Max operation frequency (kHz).
- float [SupplyVoltageMin](#)
Minimum supply voltage (V).
- float [SupplyVoltageMax](#)
Maximum supply voltage (V).
- float [MaxCurrentConsumption](#)
Max current consumption (mA).
- unsigned int [PPR](#)
The number of counts per revolution.
- unsigned int [EncoderSettings](#)
Encoder settings flags.

6.19.1 Detailed Description

Encoder settings.

See Also

[set_encoder_settings](#)
[get_encoder_settings](#)
[get_encoder_settings, set_encoder_settings](#)

6.19.2 Field Documentation

6.19.2.1 unsigned int EncoderSettings

Encoder settings flags.

6.19.2.2 float MaxCurrentConsumption

Max current consumption (mA).

Data type: float.

6.19.2.3 float MaxOperatingFrequency

Max operation frequency (kHz).

Data type: float.

6.19.2.4 float SupplyVoltageMax

Maximum supply voltage (V).

Data type: float.

6.19.2.5 float SupplyVoltageMin

Minimum supply voltage (V).

Data type: float.

6.20 engine_advansed_setup_t Struct Reference

EAS settings.

Data Fields

- `unsigned int stepcloseloop_Kw`
Mixing ratio of the actual and set speed, range [0, 100], default value 50.
- `unsigned int stepcloseloop_Kp_low`
Position feedback in the low-speed zone, range [0, 65535], default value 1000.
- `unsigned int stepcloseloop_Kp_high`
Position feedback in the high-speed zone, range [0, 65535], default value 33.

6.20.1 Detailed Description

EAS settings.

This structure is intended for setting parameters of algorithms that cannot be attributed to standard Kp, Ki, Kd, and L, R, Km.

See Also

[set_engine_advansed_setup](#)
[get_engine_advansed_setup](#)
[get_engine_advansed_setup](#), [set_engine_advansed_setup](#)

6.20.2 Field Documentation

6.20.2.1 unsigned int stepcloseloop_Kp_high

Position feedback in the high-speed zone, range [0, 65535], default value 33.

6.20.2.2 unsigned int stepcloseloop_Kp_low

Position feedback in the low-speed zone, range [0, 65535], default value 1000.

6.20.2.3 unsigned int stepcloseloop_Kw

Mixing ratio of the actual and set speed, range [0, 100], default value 50.

6.21 engine_settings_calb_t Struct Reference

Movement limitations and settings, related to the motor, which use user units.

Data Fields

- **unsigned int NomVoltage**
Rated voltage in tens of mV.
- **unsigned int NomCurrent**
Rated current (in mA).
- **float NomSpeed**
Nominal speed.
- **unsigned int EngineFlags**
Flags of engine settings.
- **float Antiplay**
Number of pulses or steps for backlash (play) compensation procedure.
- **unsigned int MicrostepMode**
Flags of microstep mode.
- **unsigned int StepsPerRev**
Number of full steps per revolution(Used with stepper motor only).

6.21.1 Detailed Description

Movement limitations and settings, related to the motor, which use user units.

This structure contains useful motor settings. These settings specify motor shaft movement algorithm, list of limitations and rated characteristics. All boards are supplied with standard set of engine setting on controller's flash memory. Please load new engine settings when you change motor, encoder, positioner etc. Please note that wrong engine settings lead to device malfunction, can lead to irreversible damage of board.

See Also

[set_engine_settings_calb](#)
[get_engine_settings_calb](#)
[get_engine_settings, set_engine_settings](#)

6.21.2 Field Documentation

6.21.2.1 float Antiplay

Number of pulses or steps for backlash (play) compensation procedure.

Used if ENGINE_ANTIPLAY flag is set.

6.21.2.2 unsigned int EngineFlags

[Flags of engine settings.](#)

6.21.2.3 unsigned int MicrostepMode

[Flags of microstep mode.](#)

6.21.2.4 unsigned int NomCurrent

Rated current (in mA).

Controller will keep current consumed by motor below this value if ENGINE_LIMIT_CURR flag is set. Range: 15..8000

6.21.2.5 float NomSpeed

Nominal speed.

Controller will keep motor speed below this value if ENGINE_LIMIT_RPM flag is set.

6.21.2.6 unsigned int NomVoltage

Rated voltage in tens of mV.

Controller will keep the voltage drop on motor below this value if ENGINE_LIMIT_VOLT flag is set (used with DC only).

6.21.2.7 unsigned int StepsPerRev

Number of full steps per revolution(Used with stepper motor only).

Range: 1..65535.

6.22 engine_settings_t Struct Reference

Movement limitations and settings, related to the motor.

Data Fields

- `unsigned int NomVoltage`
Rated voltage in tens of mV.
- `unsigned int NomCurrent`
Rated current (in mA).
- `unsigned int NomSpeed`
Nominal (maximum) speed (in whole steps/s or rpm for DC and stepper motor as a master encoder).
- `unsigned int uNomSpeed`
The fractional part of a nominal speed in microsteps (is only used with stepper motor).
- `unsigned int EngineFlags`
Flags of engine settings.
- `int Antiplay`
Number of pulses or steps for backlash (play) compensation procedure.
- `unsigned int MicrostepMode`
Flags of microstep mode.
- `unsigned int StepsPerRev`
Number of full steps per revolution(Used with stepper motor only).

6.22.1 Detailed Description

Movement limitations and settings, related to the motor.

This structure contains useful motor settings. These settings specify motor shaft movement algorithm, list of limitations and rated characteristics. All boards are supplied with standard set of engine setting on controller's flash memory. Please load new engine settings when you change motor, encoder, positioner etc. Please note that wrong engine settings lead to device malfunction, can lead to irreversible damage of board.

See Also

[set_engine_settings](#)
[get_engine_settings](#)
[get_engine_settings, set_engine_settings](#)

6.22.2 Field Documentation

6.22.2.1 int Antiplay

Number of pulses or steps for backlash (play) compensation procedure.

Used if ENGINE_ANTIPLAY flag is set.

6.22.2.2 unsigned int EngineFlags

[Flags of engine settings.](#)

6.22.2.3 `unsigned int MicrostepMode`

Flags of microstep mode.

6.22.2.4 `unsigned int NomCurrent`

Rated current (in mA).

Controller will keep current consumed by motor below this value if ENGINE_LIMIT_CURR flag is set. Range: 15..8000

6.22.2.5 `unsigned int NomSpeed`

Nominal (maximum) speed (in whole steps/s or rpm for DC and stepper motor as a master encoder).

Controller will keep motor shaft RPM below this value if ENGINE_LIMIT_RPM flag is set. Range: 1..100000.

6.22.2.6 `unsigned int NomVoltage`

Rated voltage in tens of mV.

Controller will keep the voltage drop on motor below this value if ENGINE_LIMIT_VOLT flag is set (used with DC only).

6.22.2.7 `unsigned int StepsPerRev`

Number of full steps per revolution(Used with stepper motor only).

Range: 1..65535.

6.22.2.8 `unsigned int uNomSpeed`

The fractional part of a nominal speed in microsteps (is only used with stepper motor).

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings).

6.23 `entytype_settings_t` Struct Reference

Engine type and driver type settings.

Data Fields

- `unsigned int EngineType`
Flags of engine type.
- `unsigned int DriverType`
Flags of driver type.

6.23.1 Detailed Description

Engine type and driver type settings.

Parameters

<i>id</i>	an identifier of device
<i>EngineType</i>	engine type
<i>DriverType</i>	driver type

See Also

[get_entype_settings](#), [set_entype_settings](#)

6.23.2 Field Documentation

6.23.2.1 unsigned int DriverType

Flags of driver type.

6.23.2.2 unsigned int EngineType

Flags of engine type.

6.24 extended_settings_t Struct Reference

EST settings.

Data Fields

- unsigned int **Param1**

6.24.1 Detailed Description

EST settings.

This structure EST. This data is stored in the controller's flash memory. This structure is designed for the future. Currently not in use.

See Also

[set_extended_settings](#)
[get_extended_settings](#)
[get_extended_settings](#), [set_extended_settings](#)

6.25 extio_settings_t Struct Reference

EXTIO settings.

Data Fields

- unsigned int [EXTIOSetupFlags](#)
External IO setup flags.
- unsigned int [EXTIOModeFlags](#)
External IO mode flags.

6.25.1 Detailed Description

EXTIO settings.

This structure contains all EXTIO settings. By default input event are signalled through rising front and output states are signalled by high logic state.

See Also

[get_extio_settings](#)
[set_extio_settings](#)
[get_extio_settings, set_extio_settings](#)

6.25.2 Field Documentation

6.25.2.1 unsigned int EXTIOModeFlags

External IO mode flags.

6.25.2.2 unsigned int EXTIOSetupFlags

External IO setup flags.

6.26 feedback_settings_t Struct Reference

Feedback settings.

Data Fields

- unsigned int [IPS](#)
The number of encoder counts per shaft revolution.
- unsigned int [FeedbackType](#)
Feedback type.
- unsigned int [FeedbackFlags](#)
Describes feedback flags.
- unsigned int [CountsPerTurn](#)
The number of encoder counts per shaft revolution.

6.26.1 Detailed Description

Feedback settings.

This structure contains feedback settings.

See Also

[get_feedback_settings](#), [set_feedback_settings](#)

6.26.2 Field Documentation

6.26.2.1 unsigned int CountsPerTurn

The number of encoder counts per shaft revolution.

Range: 1..4294967295. To use the CountsPerTurn field, write 0 in the IPS field, otherwise the value from the IPS field will be used.

6.26.2.2 unsigned int FeedbackFlags

[Describes feedback flags.](#)

6.26.2.3 unsigned int FeedbackType

[Feedback type.](#)

6.26.2.4 unsigned int IPS

The number of encoder counts per shaft revolution.

Range: 1..655535. The field is obsolete, it is recommended to write 0 to IPS and use the extended CountsPerTurn field. You may need to update the controller firmware to the latest version.

6.27 gear_information_t Struct Reference

Gear information.

Data Fields

- char [Manufacturer](#) [17]
Manufacturer.
- char [PartNumber](#) [25]
Series and PartNumber.

6.27.1 Detailed Description

Gear information.

See Also

[set_gear_information](#)
[get_gear_information](#)
[get_gear_information](#), [set_gear_information](#)

6.27.2 Field Documentation

6.27.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

6.27.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

6.28 gear_settings_t Struct Reference

Gear settings.

Data Fields

- float [ReductionIn](#)
Input reduction coefficient.
- float [ReductionOut](#)
Output reduction coefficient.
- float [RatedInputTorque](#)
Max continuous torque (N m).
- float [RatedInputSpeed](#)
Max speed on the input shaft (rpm).
- float [MaxOutputBacklash](#)
Output backlash of the reduction gear(degree).
- float [InputInertia](#)
Equivalent input gear inertia (g cm²).
- float [Efficiency](#)
Reduction gear efficiency (%).

6.28.1 Detailed Description

Gear settings.

See Also

[set_gear_settings](#)
[get_gear_settings](#)
[get_gear_settings](#), [set_gear_settings](#)

6.28.2 Field Documentation

6.28.2.1 float Efficiency

Reduction gear efficiency (%).

Data type: float.

6.28.2.2 float InputInertia

Equivalent input gear inertia (g cm²).

Data type: float.

6.28.2.3 float MaxOutputBacklash

Output backlash of the reduction gear(degree).

Data type: float.

6.28.2.4 float RatedInputSpeed

Max speed on the input shaft (rpm).

Data type: float.

6.28.2.5 float RatedInputTorque

Max continuous torque (N m).

Data type: float.

6.28.2.6 float ReductionIn

Input reduction coefficient.

(Output = (ReductionOut / ReductionIn) * Input) Data type: float.

6.28.2.7 float ReductionOut

Output reduction coefficient.

(Output = (ReductionOut / ReductionIn) * Input) Data type: float.

6.29 get_position_calb_t Struct Reference

Position information.

Data Fields

- float [Position](#)
The position in the engine.
- long_t [EncPosition](#)
Encoder position.

6.29.1 Detailed Description

Position information.

Useful structure that contains position value in user units for stepper motor and encoder steps of all engines.

See Also

[get_position](#)

6.29.2 Field Documentation

6.29.2.1 long_t EncPosition

Encoder position.

6.29.2.2 float Position

The position in the engine.

Corrected by the table.

6.30 get_position_t Struct Reference

Position information.

Data Fields

- int **Position**
The position of the whole steps in the engine.
- int **uPosition**
Microstep position is only used with stepper motors.
- long_t **EncPosition**
Encoder position.

6.30.1 Detailed Description

Position information.

Useful structure that contains position value in steps and micro for stepper motor and encoder steps of all engines.

See Also

[get_position](#)

6.30.2 Field Documentation

6.30.2.1 long_t EncPosition

Encoder position.

6.30.2.2 int uPosition

Microstep position is only used with stepper motors.

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings).

6.31 `globally_unique_identifier_t` Struct Reference

Globally unique identifier.

Data Fields

- `unsigned int UniqueID0`
Unique ID 0.
- `unsigned int UniqueID1`
Unique ID 1.
- `unsigned int UniqueID2`
Unique ID 2.
- `unsigned int UniqueID3`
Unique ID 3.

6.31.1 Detailed Description

Globally unique identifier.

See Also

[get_globally_unique_identifier](#)

6.31.2 Field Documentation

6.31.2.1 `unsigned int UniqueID0`

Unique ID 0.

6.31.2.2 `unsigned int UniqueID1`

Unique ID 1.

6.31.2.3 `unsigned int UniqueID2`

Unique ID 2.

6.31.2.4 `unsigned int UniqueID3`

Unique ID 3.

6.32 `hallsensor_information_t` Struct Reference

Hall sensor information.

Data Fields

- char [Manufacturer](#) [17]
Manufacturer.
- char [PartNumber](#) [25]
Series and PartNumber.

6.32.1 Detailed Description

Hall sensor information.

See Also

[set_hallsensor_information](#)
[get_hallsensor_information](#)
[get_hallsensor_information](#), [set_hallsensor_information](#)

6.32.2 Field Documentation

6.32.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

6.32.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

6.33 hallsensor_settings_t Struct Reference

Hall sensor settings.

Data Fields

- float [MaxOperatingFrequency](#)
Max operation frequency (kHz).
- float [SupplyVoltageMin](#)
Minimum supply voltage (V).
- float [SupplyVoltageMax](#)
Maximum supply voltage (V).
- float [MaxCurrentConsumption](#)
Max current consumption (mA).
- unsigned int [PPR](#)
The number of counts per revolution.

6.33.1 Detailed Description

Hall sensor settings.

See Also

[set_hallsensor_settings](#)
[get_hallsensor_settings](#)
[get_hallsensor_settings](#), [set_hallsensor_settings](#)

6.33.2 Field Documentation

6.33.2.1 float MaxCurrentConsumption

Max current consumption (mA).

Data type: float.

6.33.2.2 float MaxOperatingFrequency

Max operation frequency (kHz).

Data type: float.

6.33.2.3 float SupplyVoltageMax

Maximum supply voltage (V).

Data type: float.

6.33.2.4 float SupplyVoltageMin

Minimum supply voltage (V).

Data type: float.

6.34 home_settings_calb_t Struct Reference

Position calibration settings which use user units.

Data Fields

- float [FastHome](#)
Speed used for first motion.
- float [SlowHome](#)
Speed used for second motion.
- float [HomeDelta](#)
Distance from break point.
- unsigned int [HomeFlags](#)
Home settings flags.

6.34.1 Detailed Description

Position calibration settings which use user units.

This structure contains settings used in position calibrating. It specify behaviour of calibrating position.

See Also

[get_home_settings_calb](#)
[set_home_settings_calb](#)
[command_home](#)
[get_home_settings](#), [set_home_settings](#)

6.34.2 Field Documentation

6.34.2.1 float FastHome

Speed used for first motion.

6.34.2.2 float HomeDelta

Distance from break point.

6.34.2.3 unsigned int HomeFlags

Home settings flags.

6.34.2.4 float SlowHome

Speed used for second motion.

6.35 home_settings_t Struct Reference

Position calibration settings.

Data Fields

- **unsigned int FastHome**
Speed used for first motion (full steps).
- **unsigned int uFastHome**
Part of the speed for first motion, microsteps.
- **unsigned int SlowHome**
Speed used for second motion (full steps).
- **unsigned int uSlowHome**
Part of the speed for second motion, microsteps.
- **int HomeDelta**
Distance from break point (full steps).
- **int uHomeDelta**
Part of the delta distance, microsteps.
- **unsigned int HomeFlags**
Home settings flags.

6.35.1 Detailed Description

Position calibration settings.

This structure contains settings used in position calibrating. It specify behaviour of calibrating position.

See Also

[get_home_settings](#)
[set_home_settings](#)
[command_home](#)
[get_home_settings, set_home_settings](#)

6.35.2 Field Documentation

6.35.2.1 unsigned int FastHome

Speed used for first motion (full steps).

Range: 0..100000.

6.35.2.2 int HomeDelta

Distance from break point (full steps).

6.35.2.3 unsigned int HomeFlags

[Home settings flags.](#)

6.35.2.4 unsigned int SlowHome

Speed used for second motion (full steps).

Range: 0..100000.

6.35.2.5 unsigned int uFastHome

Part of the speed for first motion, microsteps.

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings).

6.35.2.6 int uHomeDelta

Part of the delta distance, microsteps.

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings).

6.35.2.7 unsigned int uSlowHome

Part of the speed for second motion, microsteps.

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings).

6.36 init_random_t Struct Reference

Random key.

Data Fields

- `uint8_t key [16]`

Random key.

6.36.1 Detailed Description

Random key.

Structure that contains random key used in encryption of WKEY and SSER command contents.

See Also

[get_init_random](#)

6.36.2 Field Documentation

6.36.2.1 `uint8_t key[16]`

Random key.

6.37 joystick_settings_t Struct Reference

Joystick settings.

Data Fields

- `unsigned int JoyLowEnd`
Joystick lower end position.
- `unsigned int JoyCenter`
Joystick center position.
- `unsigned int JoyHighEnd`
Joystick higher end position.
- `unsigned int ExpFactor`
Exponential nonlinearity factor.
- `unsigned int DeadZone`
Joystick dead zone.
- `unsigned int JoyFlags`
Joystick flags.

6.37.1 Detailed Description

Joystick settings.

This structure contains joystick parameters. If joystick position is outside DeadZone limits from the central position a movement with speed, defined by the joystick DeadZone edge to 100% deviation, begins. Joystick

positions inside DeadZone limits correspond to zero speed (soft stop of motion) and positions beyond Low and High limits correspond MaxSpeed [i] or -MaxSpeed [i] (see command SCTL), where i = 0 by default and can be changed with left/right buttons (see command SCTL). If next speed in list is zero (both integer and microstep parts), the button press is ignored. First speed in list shouldn't be zero. The relationship between the deviation and the rate is exponential, allowing no switching speed combine high mobility and accuracy.

See Also

[set_joystick_settings](#)
[get_joystick_settings](#)
[get_joystick_settings, set_joystick_settings](#)

6.37.2 Field Documentation

6.37.2.1 unsigned int DeadZone

Joystick dead zone.

6.37.2.2 unsigned int ExpFactor

Exponential nonlinearity factor.

6.37.2.3 unsigned int JoyCenter

Joystick center position.

Range: 0..10000.

6.37.2.4 unsigned int JoyFlags

Joystick flags.

6.37.2.5 unsigned int JoyHighEnd

Joystick higher end position.

Range: 0..10000.

6.37.2.6 unsigned int JoyLowEnd

Joystick lower end position.

Range: 0..10000.

6.38 measurements_t Struct Reference

The buffer holds no more than 25 points.

Data Fields

- int [Speed](#) [25]

Current speed in microsteps per second (whole steps are recalculated taking into account the current step division mode) or encoder counts per second.

- int [Error](#) [25]

Current error in microsteps per second (whole steps are recalculated taking into account the current step division mode) or encoder counts per second.

- unsigned int [Length](#)

Length of actual data in buffer.

6.38.1 Detailed Description

The buffer holds no more than 25 points.

The exact length of the received buffer is reflected in the Length field.

See Also

[measurements](#)

[get_measurements](#)

6.38.2 Field Documentation

6.38.2.1 int Error[25]

Current error in microsteps per second (whole steps are recalculated taking into account the current step division mode) or encoder counts per second.

6.38.2.2 unsigned int Length

Length of actual data in buffer.

6.38.2.3 int Speed[25]

Current speed in microsteps per second (whole steps are recalculated taking into account the current step division mode) or encoder counts per second.

6.39 motor_information_t Struct Reference

motor information.

Data Fields

- char [Manufacturer](#) [17]

Manufacturer.

- char [PartNumber](#) [25]

Series and PartNumber.

6.39.1 Detailed Description

motor information.

See Also

[set_motor_information](#)
[get_motor_information](#)
[get_motor_information](#), [set_motor_information](#)

6.39.2 Field Documentation

6.39.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

6.39.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

6.40 motor_settings_t Struct Reference

Physical characteristics and limitations of the motor.

Data Fields

- `unsigned int MotorType`
Motor Type flags.
- `unsigned int ReservedField`
Reserved.
- `unsigned int Poles`
Number of pole pairs for DC or BLDC motors or number of steps per rotation for stepper motor.
- `unsigned int Phases`
Number of phases for BLDC motors.
- `float NominalVoltage`
Nominal voltage on winding (B).
- `float NominalCurrent`
Maximum direct current in winding for DC and BLDC engines, nominal current in windings for stepper motor (A).
- `float NominalSpeed`
Not used.
- `float NominalTorque`
Nominal torque(mN m).
- `float NominalPower`
Nominal power(W).
- `float WindingResistance`
Resistance of windings for DC engine, each of two windings for stepper motor or each of three windings for BLDC engine(Ohm).
- `float WindingInductance`
Inductance of windings for DC engine, each of two windings for stepper motor or each of three windings for BLDC engine(mH).

- float [RotorInertia](#)
Rotor inertia(g cm²).
- float [StallTorque](#)
Torque hold position for a stepper motor or torque at a motionless rotor for other types of engines (mN m).
- float [DetentTorque](#)
Holding torque position with un-powered coils (mN m).
- float [TorqueConstant](#)
Torque constant, which determines the aspect ratio of maximum moment of force from the rotor current flowing in the coil (mN m / A).
- float [SpeedConstant](#)
Velocity constant, which determines the value or amplitude of the induced voltage on the motion of DC or BLDC motor (rpm / V) or stepper motor (steps/s / V).
- float [SpeedTorqueGradient](#)
Speed torque gradient (rpm / mN m).
- float [MechanicalTimeConstant](#)
Mechanical time constant (ms).
- float [MaxSpeed](#)
The maximum speed for stepper motors (steps/s) or DC and BLDC motors (rmp).
- float [MaxCurrent](#)
The maximum current in the winding (A).
- float [MaxCurrentTime](#)
Safe duration of overcurrent in the winding (ms).
- float [NoLoadCurrent](#)
The current consumption in idle mode (A).
- float [NoLoadSpeed](#)
Idle speed (rpm).

6.40.1 Detailed Description

Physical characteristics and limitations of the motor.

See Also

[set_motor_settings](#)
[get_motor_settings](#)
[get_motor_settings](#), [set_motor_settings](#)

6.40.2 Field Documentation

6.40.2.1 float DetentTorque

Holding torque position with un-powered coils (mN m).

Data type: float.

6.40.2.2 float MaxCurrent

The maximum current in the winding (A).

Data type: float.

6.40.2.3 float MaxCurrentTime

Safe duration of overcurrent in the winding (ms).

Data type: float.

6.40.2.4 float MaxSpeed

The maximum speed for stepper motors (steps/s) or DC and BLDC motors (rmp).

Data type: float.

6.40.2.5 float MechanicalTimeConstant

Mechanical time constant (ms).

Data type: float.

6.40.2.6 unsigned int MotorType

[Motor Type flags.](#)

6.40.2.7 float NoLoadCurrent

The current consumption in idle mode (A).

Used for DC and BLDC motors. Data type: float.

6.40.2.8 float NoLoadSpeed

Idle speed (rpm).

Used for DC and BLDC motors. Data type: float.

6.40.2.9 float NominalCurrent

Maximum direct current in winding for DC and BLDC engines, nominal current in windings for stepper motor (A).

Data type: float.

6.40.2.10 float NominalPower

Nominal power(W).

Used for DC and BLDC engine. Data type: float.

6.40.2.11 float NominalSpeed

Not used.

Nominal speed(rpm). Used for DC and BLDC engine. Data type: float.

6.40.2.12 float NominalTorque

Nominal torque(mN m).

Used for DC and BLDC engine. Data type: float.

6.40.2.13 float NominalVoltage

Nominal voltage on winding (B).

Data type: float

6.40.2.14 unsigned int Phases

Number of phases for BLDC motors.

6.40.2.15 unsigned int Poles

Number of pole pairs for DC or BLDC motors or number of steps per rotation for stepper motor.

6.40.2.16 float RotorInertia

Rotor inertia(g cm²).

Data type: float.

6.40.2.17 float SpeedConstant

Velocity constant, which determines the value or amplitude of the induced voltage on the motion of DC or BLDC motor (rpm / V) or stepper motor (steps/s / V).

Data type: float.

6.40.2.18 float SpeedTorqueGradient

Speed torque gradient (rpm / mN m).

Data type: float.

6.40.2.19 float StallTorque

Torque hold position for a stepper motor or torque at a motionless rotor for other types of engines (mN m).

Data type: float.

6.40.2.20 float TorqueConstant

Torque constant, which determines the aspect ratio of maximum moment of force from the rotor current flowing in the coil (mN m / A).

Used mainly for DC motors. Data type: float.

6.40.2.21 float WindingInductance

Inductance of windings for DC engine, each of two windings for stepper motor or each of three windings for BLDC engine(mH).

Data type: float.

6.40.2.22 float WindingResistance

Resistance of windings for DC engine, each of two windings for stepper motor or each of three windings for BLDC engine(Ohm).

Data type: float.

6.41 move_settings_calb_t Struct Reference

Move settings which use user units.

Data Fields

- float [Speed](#)
Target speed.
- float [Accel](#)
Motor shaft acceleration, steps/s²(stepper motor) or RPM/s(DC).
- float [Decel](#)
Motor shaft deceleration, steps/s²(stepper motor) or RPM/s(DC).
- float [AntiplaySpeed](#)
Speed in antiplay mode.
- unsigned int [MoveFlags](#)
Flags of the motion parameters.

6.41.1 Detailed Description

Move settings which use user units.

See Also

[set_move_settings_calb](#)
[get_move_settings_calb](#)
[get_move_settings](#), [set_move_settings](#)

6.41.2 Field Documentation

6.41.2.1 float Accel

Motor shaft acceleration, steps/s²(stepper motor) or RPM/s(DC).

6.41.2.2 float AntiplaySpeed

Speed in antiplay mode.

6.41.2.3 float Decel

Motor shaft deceleration, steps/s²(stepper motor) or RPM/s(DC).

6.41.2.4 unsigned int MoveFlags

[Flags of the motion parameters.](#)

6.41.2.5 float Speed

Target speed.

6.42 move_settings_t Struct Reference

Move settings.

Data Fields

- [unsigned int Speed](#)
Target speed (for stepper motor: steps/s, for DC: rpm).
- [unsigned int uSpeed](#)
Target speed in microstep fractions/s.
- [unsigned int Accel](#)
Motor shaft acceleration, steps/s²(stepper motor) or RPM/s(DC).
- [unsigned int Decel](#)
Motor shaft deceleration, steps/s²(stepper motor) or RPM/s(DC).
- [unsigned int AntiplaySpeed](#)
Speed in antiplay mode, full steps/s(stepper motor) or RPM(DC).
- [unsigned int uAntiplaySpeed](#)
Speed in antiplay mode, microsteps/s.
- [unsigned int MoveFlags](#)
Flags of the motion parameters.

6.42.1 Detailed Description

Move settings.

See Also

[set_move_settings](#)
[get_move_settings](#)
[get_move_settings, set_move_settings](#)

6.42.2 Field Documentation

6.42.2.1 unsigned int Accel

Motor shaft acceleration, steps/s²(stepper motor) or RPM/s(DC).

Range: 1..65535.

6.42.2.2 unsigned int AntiplaySpeed

Speed in antiplay mode, full steps/s(stepper motor) or RPM(DC).

Range: 0..100000.

6.42.2.3 unsigned int Decel

Motor shaft deceleration, steps/s²(stepper motor) or RPM/s(DC).

Range: 1..65535.

6.42.2.4 unsigned int MoveFlags

[Flags of the motion parameters.](#)

6.42.2.5 unsigned int Speed

Target speed (for stepper motor: steps/s, for DC: rpm).

Range: 0..100000.

6.42.2.6 unsigned int uAntiplaySpeed

Speed in antiplay mode, microsteps/s.

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings). Used with stepper motor only.

6.42.2.7 unsigned int uSpeed

Target speed in microstep fractions/s.

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings). Using with stepper motor only.

6.43 network_settings_t Struct Reference

Network settings.

Data Fields

- unsigned int [DHCPEnabled](#)

Indicates method to get the IP-address.

- unsigned int [IPv4Address](#) [4]

IP-address of the device in format x.x.x.x.

- unsigned int [SubnetMask](#) [4]

Mask of the subnet in format x.x.x.x.

- unsigned int [DefaultGateway](#) [4]

Default value of the gateway in format x.x.x.x.

6.43.1 Detailed Description

Network settings.

This structure contains network settings.

See Also

[get_network_settings](#)
[set_network_settings](#)
[get_network_settings](#), [set_network_settings](#)

6.43.2 Field Documentation

6.43.2.1 unsigned int DefaultGateway[4]

Default value of the gateway in format x.x.x.x.

The value must be specified as four numbers separated by spaces, not dots

6.43.2.2 unsigned int DHCPEnabled

Indicates method to get the IP-address.

It can be: 0 — static, 1 — DHCP

6.43.2.3 unsigned int IPv4Address[4]

IP-address of the device in format x.x.x.x.

It must be specified as four numbers separated by spaces, not dots

6.43.2.4 unsigned int SubnetMask[4]

Mask of the subnet in format x.x.x.x.

The value must be specified as four numbers separated by spaces, not dots

6.44 nonvolatile_memory_t Struct Reference

Userdata for save into FRAM.

Data Fields

- unsigned int [UserData](#) [7]

User data.

6.44.1 Detailed Description

Userdata for save into FRAM.

See Also

[get_nonvolatile_memory](#), [set_nonvolatile_memory](#)

6.44.2 Field Documentation

6.44.2.1 unsigned int UserData[7]

User data.

Can be set by user for his/her convinience. Each element of the array stores only 32 bits of user data. This is important on systems where an int type contains more than 4 bytes. For example that all amd64 systems.

6.45 password_settings_t Struct Reference

Network settings.

Data Fields

- unsigned int [UserPassword](#) [20]

Password-string to web-page that user can change with usb command or via web-page.

6.45.1 Detailed Description

Network settings.

This structure contains network settings.

See Also

[get_password_settings](#)
[set_password_settings](#)
[get_password_settings](#), [set_password_settings](#)

6.45.2 Field Documentation

6.45.2.1 unsigned int UserPassword[20]

Password-string to web-page that user can change with usb command or via web-page.

6.46 pid_settings_t Struct Reference

PID settings.

Data Fields

- unsigned int [KpU](#)

Proportional gain for voltage PID routine.

- unsigned int [KiU](#)

Integral gain for voltage PID routine.

- unsigned int [KdU](#)

Differential gain for voltage PID routine.

- float [Kpf](#)

Proportional gain for BLDC position PID routine.

- float [Kif](#)

Integral gain for BLDC position PID routine.

- float [Kdf](#)

Differential gain for BLDC position PID routine.

6.46.1 Detailed Description

PID settings.

This structure contains factors for PID routine. It specify behaviour of PID routine for voltage. These factors are slightly different for different positioners. All boards are supplied with standard set of PID setting on controller's flash memory. Please load new PID settings when you change positioner. Please note that wrong PID settings lead to device malfunction.

See Also

[set_pid_settings](#)

[get_pid_settings](#)

[get_pid_settings, set_pid_settings](#)

6.47 power_settings_t Struct Reference

Step motor power settings.

Data Fields

- unsigned int [HoldCurrent](#)

Current in holding regime, percent of nominal.

- unsigned int [CurrReductDelay](#)

Time in ms from going to STOP state to reducing current.

- unsigned int [PowerOffDelay](#)

Time in s from going to STOP state to turning power off.

- unsigned int [CurrentSetTime](#)

Time in ms to reach nominal current.

- unsigned int [PowerFlags](#)

Flags of power settings of stepper motor.

6.47.1 Detailed Description

Step motor power settings.

See Also

[set_move_settings](#)

[get_move_settings](#)

[get_power_settings, set_power_settings](#)

6.47.2 Field Documentation

6.47.2.1 unsigned int CurrentSetTime

Time in ms to reach nominal current.

6.47.2.2 unsigned int CurrReductDelay

Time in ms from going to STOP state to reducing current.

6.47.2.3 unsigned int HoldCurrent

Current in holding regime, percent of nominal.

Range: 0..100.

6.47.2.4 unsigned int PowerFlags

Flags of power settings of stepper motor.

6.47.2.5 unsigned int PowerOffDelay

Time in s from going to STOP state to turning power off.

6.48 secure_settings_t Struct Reference

This structure contains raw analog data from ADC embedded on board.

Data Fields

- **unsigned int LowUpwrOff**
Lower voltage limit to turn off the motor, tens of mV.
- **unsigned int Criticallpwr**
Maximum motor current which triggers ALARM state, in mA.
- **unsigned int CriticalUpwr**
Maximum motor voltage which triggers ALARM state, tens of mV.
- **unsigned int CriticalT**
Maximum temperature, which triggers ALARM state, in tenths of degrees Celcius.
- **unsigned int Criticallusb**
Maximum USB current which triggers ALARM state, in mA.
- **unsigned int CriticalUusb**
Maximum USB voltage which triggers ALARM state, tens of mV.
- **unsigned int MinimumUusb**
Minimum USB voltage which triggers ALARM state, tens of mV.
- **unsigned int Flags**
Flags of secure settings.

6.48.1 Detailed Description

This structure contains raw analog data from ADC embedded on board.

These data used for device testing and deep recalibratlon by manufacturer only.

See Also

[get_secure_settings](#)
[set_secure_settings](#)
[get_secure_settings, set_secure_settings](#)

6.48.2 Field Documentation

6.48.2.1 unsigned int CriticalIppwr

Maximum motor current which triggers ALARM state, in mA.

6.48.2.2 unsigned int CriticalIusb

Maximum USB current which triggers ALARM state, in mA.

6.48.2.3 unsigned int CriticalT

Maximum temperature, which triggers ALARM state, in tenths of degrees Celcius.

6.48.2.4 unsigned int CriticalUpwr

Maximum motor voltage which triggers ALARM state, tens of mV.

6.48.2.5 unsigned int CriticalUusb

Maximum USB voltage which triggers ALARM state, tens of mV.

6.48.2.6 unsigned int Flags

[Flags of secure settings.](#)

6.48.2.7 unsigned int LowUpwrOff

Lower voltage limit to turn off the motor, tens of mV.

6.48.2.8 unsigned int MinimumUusb

Minimum USB voltage which triggers ALARM state, tens of mV.

6.49 serial_number_t Struct Reference

Serial number structure and hardware version.

Data Fields

- unsigned int [SN](#)

New board serial number.

- uint8_t [Key](#) [32]

Protection key (256 bit).

- unsigned int [Major](#)

The major number of the hardware version.

- unsigned int [Minor](#)

Minor number of the hardware version.

- `unsigned int Release`
Number of edits this release of hardware.

6.49.1 Detailed Description

Serial number structure and hardware version.

The structure keep new serial number, hardware version and valid key. The SN and hardware version are changed and saved when transmitted key matches stored key. Can be used by manufacturer only.

See Also

[set_serial_number](#)

6.49.2 Field Documentation

6.49.2.1 `uint8_t Key[32]`

Protection key (256 bit).

6.49.2.2 `unsigned int Major`

The major number of the hardware version.

6.49.2.3 `unsigned int Minor`

Minor number of the hardware version.

6.49.2.4 `unsigned int Release`

Number of edits this release of hardware.

6.49.2.5 `unsigned int SN`

New board serial number.

6.50 set_position_calb_t Struct Reference

Position information which use user units.

Data Fields

- `float Position`
The position in the engine.
- `long_t EncPosition`
Encoder position.
- `unsigned int PosFlags`
Position setting flags.

6.50.1 Detailed Description

Position information which use user units.

Useful structure that contains position value in steps and micro for stepper motor and encoder steps of all engines.

See Also

[set_position](#)

6.50.2 Field Documentation

6.50.2.1 long_t EncPosition

Encoder position.

6.50.2.2 unsigned int PosFlags

[Position setting flags.](#)

6.50.2.3 float Position

The position in the engine.

6.51 set_position_t Struct Reference

Position information.

Data Fields

- int [Position](#)
The position of the whole steps in the engine.
- int [uPosition](#)
Microstep position is only used with stepper motors.
- long_t [EncPosition](#)
Encoder position.
- unsigned int [PosFlags](#)
[Position setting flags.](#)

6.51.1 Detailed Description

Position information.

Useful structure that contains position value in steps and micro for stepper motor and encoder steps of all engines.

See Also

[set_position](#)

6.51.2 Field Documentation

6.51.2.1 long_t EncPosition

Encoder position.

6.51.2.2 unsigned int PosFlags

Position setting flags.

6.51.2.3 int uPosition

Microstep position is only used with stepper motors.

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings).

6.52 stage_information_t Struct Reference

Stage information.

Data Fields

- char [Manufacturer](#) [17]
Manufacturer.
- char [PartNumber](#) [25]
Series and PartNumber.

6.52.1 Detailed Description

Stage information.

See Also

[set_stage_information](#)
[get_stage_information](#)
[get_stage_information](#), [set_stage_information](#)

6.52.2 Field Documentation

6.52.2.1 char Manufacturer[17]

Manufacturer.

Max string length: 16 chars.

6.52.2.2 char PartNumber[25]

Series and PartNumber.

Max string length: 24 chars.

6.53 stage_name_t Struct Reference

Stage user name.

Data Fields

- char [PositionerName](#) [17]

User positioner name.

6.53.1 Detailed Description

Stage user name.

See Also

[get_stage_name](#), [set_stage_name](#)

6.53.2 Field Documentation

6.53.2.1 char PositionerName[17]

User positioner name.

Can be set by user for his/her convinience. Max string length: 16 chars.

6.54 stage_settings_t Struct Reference

Stage settings.

Data Fields

- float [LeadScrewPitch](#)

Lead screw pitch (mm).

- char [Units](#) [9]

Units for MaxSpeed and TravelRange fields of the structure (steps, degrees, mm, ...).

- float [MaxSpeed](#)

Max speed (Units/c).

- float [TravelRange](#)

Travel range (Units).

- float [SupplyVoltageMin](#)

Supply voltage minimum (V).

- float [SupplyVoltageMax](#)

Supply voltage maximum (V).

- float [MaxCurrentConsumption](#)

Max current consumption (A).

- float [HorizontalLoadCapacity](#)

Horizontal load capacity (kg).

- float [VerticalLoadCapacity](#)

Vertical load capacity (kg).

6.54.1 Detailed Description

Stage settings.

See Also

[set_stage_settings](#)
[get_stage_settings](#)
[get_stage_settings](#), [set_stage_settings](#)

6.54.2 Field Documentation

6.54.2.1 float HorizontalLoadCapacity

Horizontal load capacity (kg).

Data type: float.

6.54.2.2 float LeadScrewPitch

Lead screw pitch (mm).

Data type: float.

6.54.2.3 float MaxCurrentConsumption

Max current consumption (A).

Data type: float.

6.54.2.4 float MaxSpeed

Max speed (Units/c).

Data type: float.

6.54.2.5 float SupplyVoltageMax

Supply voltage maximum (V).

Data type: float.

6.54.2.6 float SupplyVoltageMin

Supply voltage minimum (V).

Data type: float.

6.54.2.7 float TravelRange

Travel range (Units).

Data type: float.

6.54.2.8 char Units[9]

Units for MaxSpeed and TravelRange fields of the structure (steps, degrees, mm, ...).

Max string length: 8 chars.

6.54.2.9 float VerticalLoadCapacity

Vertical load capacity (kg).

Data type: float.

6.55 status_calb_t Struct Reference

Device state which use user units.

Data Fields

- unsigned int [MoveSts](#)
Flags of move state.
- unsigned int [MvCmdSts](#)
Move command state.
- unsigned int [PWRSts](#)
Flags of power state of stepper motor.
- unsigned int [EncSts](#)
Encoder state.
- unsigned int [WindSts](#)
Winding state.
- float [CurPosition](#)
Current position.
- long_t [EncPosition](#)
Current encoder position.
- float [CurSpeed](#)
Motor shaft speed.
- int [Ipwr](#)
Engine current, mA.
- int [Upwr](#)
Power supply voltage, tens of mV.
- int [Iusb](#)
USB current, mA.
- int [Uusb](#)
USB voltage, tens of mV.
- int [CurT](#)
Temperature in tenths of degrees C.
- unsigned int [Flags](#)
Status flags.
- unsigned int [GPIOFlags](#)
Status flags of the GPIO outputs.
- unsigned int [CmdBufFreeSpace](#)
This field is a service field.

6.55.1 Detailed Description

Device state which use user units.

Useful structure that contains current controller state, including speed, position and boolean flags.

See Also

[get_status_impl](#)

6.55.2 Field Documentation

6.55.2.1 unsigned int CmdBufFreeSpace

This field is a service field.

It shows the amount of free cells buffer synchronization chain.

6.55.2.2 float CurPosition

Current position.

Corrected by the table.

6.55.2.3 float CurSpeed

Motor shaft speed.

6.55.2.4 int CurT

Temperature in tenths of degrees C.

6.55.2.5 long_t EncPosition

Current encoder position.

6.55.2.6 unsigned int Encsts

[Encoder state](#).

6.55.2.7 unsigned int Flags

[Status flags](#).

6.55.2.8 unsigned int GPIOFlags

[Status flags of the GPIO outputs](#).

6.55.2.9 int Ipwr

Engine current, mA.

6.55.2.10 int lusb

USB current, mA.

6.55.2.11 unsigned int MoveSts

Flags of move state.

6.55.2.12 unsigned int MvCmdsts

Move command state.

6.55.2.13 unsigned int PWRSts

Flags of power state of stepper motor.

6.55.2.14 int Upwr

Power supply voltage, tens of mV.

6.55.2.15 int Uusb

USB voltage, tens of mV.

6.55.2.16 unsigned int Windsts

Winding state.

6.56 status_t Struct Reference

Device state.

Data Fields

- unsigned int [MoveSts](#)
Flags of move state.
- unsigned int [MvCmdsts](#)
Move command state.
- unsigned int [PWRSts](#)
Flags of power state of stepper motor.
- unsigned int [Encsts](#)
Encoder state.
- unsigned int [Windsts](#)
Winding state.
- int [CurPosition](#)
Current position.
- int [uCurPosition](#)
Step motor shaft position in microsteps.

- long_t [EncPosition](#)
Current encoder position.
- int [CurSpeed](#)
Motor shaft speed in steps/s or rpm.
- int [uCurSpeed](#)
Part of motor shaft speed in microsteps.
- int [Ipwr](#)
Engine current, mA.
- int [Upwr](#)
Power supply voltage, tens of mV.
- int [Iusb](#)
USB current, mA.
- int [Uusb](#)
USB voltage, tens of mV.
- int [Curt](#)
Temperature in tenths of degrees C.
- unsigned int [Flags](#)
Status flags.
- unsigned int [GPIOFlags](#)
Status flags of the GPIO outputs.
- unsigned int [CmdBufFreeSpace](#)
This field is a service field.

6.56.1 Detailed Description

Device state.

Useful structure that contains current controller state, including speed, position and boolean flags.

See Also

[get_status_impl](#)

6.56.2 Field Documentation

6.56.2.1 unsigned int CmdBufFreeSpace

This field is a service field.

It shows the amount of free cells buffer synchronization chain.

6.56.2.2 int CurPosition

Current position.

6.56.2.3 int CurSpeed

Motor shaft speed in steps/s or rpm.

6.56.2.4 int Curt

Temperature in tenths of degrees C.

6.56.2.5 long_t EncPosition

Current encoder position.

6.56.2.6 unsigned int EncSts

[Encoder state.](#)

6.56.2.7 unsigned int Flags

[Status flags.](#)

6.56.2.8 unsigned int GPIOFlags

[Status flags of the GPIO outputs.](#)

6.56.2.9 int Ipwr

Engine current, mA.

6.56.2.10 int Iusb

USB current, mA.

6.56.2.11 unsigned int MoveSts

[Flags of move state.](#)

6.56.2.12 unsigned int MvCmdSts

[Move command state.](#)

6.56.2.13 unsigned int PWRSts

[Flags of power state of stepper motor.](#)

6.56.2.14 int uCurPosition

Step motor shaft position in microsteps.

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings). Used only with stepper motor.

6.56.2.15 int uCurSpeed

Part of motor shaft speed in microsteps.

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings). Used only with stepper motor.

6.56.2.16 int Upwr

Power supply voltage, tens of mV.

6.56.2.17 int Uusb

USB voltage, tens of mV.

6.56.2.18 unsigned int WindSts

Winding state.

6.57 sync_in_settings_calb_t Struct Reference

Synchronization settings which use user units.

Data Fields

- unsigned int [SyncInFlags](#)
Flags for synchronization input setup.
- unsigned int [ClutterTime](#)
Input synchronization pulse dead time (mks).
- float [Position](#)
Desired position or shift.
- float [Speed](#)
Target speed.

6.57.1 Detailed Description

Synchronization settings which use user units.

This structure contains all synchronization settings, modes, periods and flags. It specifies behaviour of input synchronization. All boards are supplied with standard set of these settings.

See Also

[get_sync_in_settings_calb](#)
[set_sync_in_settings_calb](#)
[get_sync_in_settings](#), [set_sync_in_settings](#)

6.57.2 Field Documentation

6.57.2.1 unsigned int ClutterTime

Input synchronization pulse dead time (mks).

6.57.2.2 float Position

Desired position or shift.

6.57.2.3 float Speed

Target speed.

6.57.2.4 unsigned int SyncInFlags

Flags for synchronization input setup.

6.58 sync_in_settings_t Struct Reference

Synchronization settings.

Data Fields

- unsigned int [SyncInFlags](#)
Flags for synchronization input setup.
- unsigned int [ClutterTime](#)
Input synchronization pulse dead time (mks).
- int [Position](#)
Desired position or shift (full steps)
- int [uPosition](#)
The fractional part of a position or shift in microsteps.
- unsigned int [Speed](#)
Target speed (for stepper motor: steps/s, for DC: rpm).
- unsigned int [uSpeed](#)
Target speed in microsteps/s.

6.58.1 Detailed Description

Synchronization settings.

This structure contains all synchronization settings, modes, periods and flags. It specifies behaviour of input synchronization. All boards are supplied with standard set of these settings.

See Also

[get_sync_in_settings](#)
[set_sync_in_settings](#)
[get_sync_in_settings](#), [set_sync_in_settings](#)

6.58.2 Field Documentation

6.58.2.1 unsigned int ClutterTime

Input synchronization pulse dead time (mks).

6.58.2.2 unsigned int Speed

Target speed (for stepper motor: steps/s, for DC: rpm).

Range: 0..100000.

6.58.2.3 unsigned int SyncInFlags

Flags for synchronization input setup.

6.58.2.4 int uPosition

The fractional part of a position or shift in microsteps.

Is used with stepper motor. Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings).

6.58.2.5 unsigned int uSpeed

Target speed in microsteps/s.

Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings). Using with stepper motor only.

6.59 sync_out_settings_calb_t Struct Reference

Synchronization settings which use user units.

Data Fields

- unsigned int [SyncOutFlags](#)
Flags of synchronization output.
- unsigned int [SyncOutPulseSteps](#)
This value specifies duration of output pulse.
- unsigned int [SyncOutPeriod](#)
This value specifies number of encoder pulses or steps between two output synchronization pulses when SYNCOUT_ONPERIOD is set.
- float [Accuracy](#)
This is the neighborhood around the target coordinates (in encoder pulses or motor steps), which is getting hit in the target position and the momentum generated by the stop.

6.59.1 Detailed Description

Synchronization settings which use user units.

This structure contains all synchronization settings, modes, periods and flags. It specifies behaviour of output synchronization. All boards are supplied with standard set of these settings.

See Also

[get_sync_out_settings_calb](#)
[set_sync_out_settings_calb](#)
[get_sync_out_settings](#), [set_sync_out_settings](#)

6.59.2 Field Documentation

6.59.2.1 float Accuracy

This is the neighborhood around the target coordinates (in encoder pulses or motor steps), which is getting hit in the target position and the momentum generated by the stop.

6.59.2.2 unsigned int SyncOutFlags

[Flags of synchronization output.](#)

6.59.2.3 unsigned int SyncOutPeriod

This value specifies number of encoder pulses or steps between two output synchronization pulses when SYNCOUT_ONPERIOD is set.

6.59.2.4 unsigned int SyncOutPulseSteps

This value specifies duration of output pulse.

It is measured microseconds when SYNCOUT_IN_STEPS flag is cleared or in encoder pulses or motor steps when SYNCOUT_IN_STEPS is set.

6.60 sync_out_settings_t Struct Reference

Synchronization settings.

Data Fields

- unsigned int [SyncOutFlags](#)
Flags of synchronization output.
- unsigned int [SyncOutPulseSteps](#)
This value specifies duration of output pulse.
- unsigned int [SyncOutPeriod](#)
This value specifies number of encoder pulses or steps between two output synchronization pulses when SYNCOUT_ONPERIOD is set.
- unsigned int [Accuracy](#)
This is the neighborhood around the target coordinates, which is getting hit in the target position and the momentum generated by the stop.
- unsigned int [uAccuracy](#)
This is the neighborhood around the target coordinates in microsteps (only used with stepper motor).

6.60.1 Detailed Description

Synchronization settings.

This structure contains all synchronization settings, modes, periods and flags. It specifies behaviour of output synchronization. All boards are supplied with standard set of these settings.

See Also

[get_sync_out_settings](#)
[set_sync_out_settings](#)
[get_sync_out_settings, set_sync_out_settings](#)

6.60.2 Field Documentation

6.60.2.1 `unsigned int Accuracy`

This is the neighborhood around the target coordinates, which is getting hit in the target position and the momentum generated by the stop.

6.60.2.2 `unsigned int SyncOutFlags`

[Flags of synchronization output.](#)

6.60.2.3 `unsigned int SyncOutPeriod`

This value specifies number of encoder pulses or steps between two output synchronization pulses when `SYNCOUT_ONPERIOD` is set.

6.60.2.4 `unsigned int SyncOutPulseSteps`

This value specifies duration of output pulse.

It is measured microseconds when `SYNCOUT_IN_STEPS` flag is cleared or in encoder pulses or motor steps when `SYNCOUT_IN_STEPS` is set.

6.60.2.5 `unsigned int uAccuracy`

This is the neighborhood around the target coordinates in microsteps (only used with stepper motor).

Microstep size and the range of valid values for this field depend on selected step division mode (see `MicrostepMode` field in `engine_settings`).

6.61 `uart_settings_t` Struct Reference

UART settings.

Data Fields

- `unsigned int Speed`
UART speed (in bauds)
- `unsigned int UARTSetupFlags`
UART parity flags.

6.61.1 Detailed Description

UART settings.

This structure contains UART settings.

See Also

[get_uart_settings](#)
[set_uart_settings](#)
[get_uart_settings, set_uart_settings](#)

6.61.2 Field Documentation

6.61.2.1 `unsigned int UARTSetupFlags`

UART parity flags.

Chapter 7

File Documentation

7.1 ximc.h File Reference

Header file for libximc library.

Data Structures

- struct `calibration_t`
Calibration structure.
- struct `device_network_information_t`
Device network information structure.
- struct `feedback_settings_t`
Feedback settings.
- struct `home_settings_t`
Position calibration settings.
- struct `home_settings_calb_t`
Position calibration settings which use user units.
- struct `move_settings_t`
Move settings.
- struct `move_settings_calb_t`
Move settings which use user units.
- struct `engine_settings_t`
Movement limitations and settings, related to the motor.
- struct `engine_settings_calb_t`
Movement limitations and settings, related to the motor, which use user units.
- struct `entype_settings_t`
Engine type and driver type settings.
- struct `power_settings_t`
Step motor power settings.
- struct `secure_settings_t`
This structure contains raw analog data from ADC embedded on board.
- struct `edges_settings_t`
Edges settings.
- struct `edges_settings_calb_t`
Edges settings which use user units.
- struct `pid_settings_t`

- struct `sync_in_settings_t`
Synchronization settings.
- struct `sync_in_settings_calb_t`
Synchronization settings which use user units.
- struct `sync_out_settings_t`
Synchronization settings.
- struct `sync_out_settings_calb_t`
Synchronization settings which use user units.
- struct `extio_settings_t`
EXTIO settings.
- struct `brake_settings_t`
Brake settings.
- struct `control_settings_t`
Control settings.
- struct `control_settings_calb_t`
Control settings which use user units.
- struct `joystick_settings_t`
Joystick settings.
- struct `ctp_settings_t`
Control position settings(is only used with stepper motor).
- struct `uart_settings_t`
UART settings.
- struct `network_settings_t`
Network settings.
- struct `password_settings_t`
Network settings.
- struct `calibration_settings_t`
Calibration settings.
- struct `controller_name_t`
Controller user name and flags of setting.
- struct `nonvolatile_memory_t`
Userdata for save into FRAM.
- struct `emf_settings_t`
EMF settings.
- struct `engine_advansed_setup_t`
EAS settings.
- struct `extended_settings_t`
EST settings.
- struct `get_position_t`
Position information.
- struct `get_position_calb_t`
Position information.
- struct `set_position_t`
Position information.
- struct `set_position_calb_t`
Position information which use user units.
- struct `status_t`
Device state.

- struct [status.calb_t](#)
Device state which use user units.
- struct [measurements_t](#)
The buffer holds no more than 25 points.
- struct [chart_data_t](#)
Additional device state.
- struct [device_information_t](#)
Read command controller information.
- struct [serial_number_t](#)
Serial number structure and hardware version.
- struct [analog_data_t](#)
Analog data.
- struct [debug_read.t](#)
Debug data.
- struct [debug_write_t](#)
Debug data.
- struct [stage_name_t](#)
Stage user name.
- struct [stage_information_t](#)
Stage information.
- struct [stage_settings_t](#)
Stage settings.
- struct [motor_information_t](#)
motor information.
- struct [motor_settings.t](#)
Physical characteristics and limitations of the motor.
- struct [encoder_information_t](#)
Encoder information.
- struct [encoder_settings_t](#)
Encoder settings.
- struct [hallsensor_information_t](#)
Hall sensor information.
- struct [hallsensor_settings.t](#)
Hall sensor settings.
- struct [gear_information_t](#)
Gear information.
- struct [gear_settings_t](#)
Gear settings.
- struct [accessories_settings.t](#)
Additional accessories information.
- struct [init_random_t](#)
Random key.
- struct [globally_unique_identifier_t](#)
Globally unique identifier.

Macros

- `#define XIMC_API`
Library import macro.
- `#define XIMC_CALLCONV`
Library calling convention macros.
- `#define XIMC_RETTYPE void*`
Thread return type.
- `#define device_undefined -1`
Handle specified undefined device.

Result statuses

- `#define result_ok 0`
success
- `#define result_error -1`
generic error
- `#define result_not_implemented -2`
function is not implemented
- `#define result_value_error -3`
value error
- `#define result_nodevice -4`
device is lost

Logging level

- `#define LOGLEVEL_ERROR 0x01`
Logging level - error.
- `#define LOGLEVEL_WARNING 0x02`
Logging level - warning.
- `#define LOGLEVEL_INFO 0x03`
Logging level - info.
- `#define LOGLEVEL_DEBUG 0x04`
Logging level - debug.

Enumerate devices flags

This is a bit mask for bitwise operations.

- `#define ENUMERATE_PROBE 0x01`
Check if a device with OS name name is XIMC device.
- `#define ENUMERATE_ALL_COM 0x02`
Check all COM devices.
- `#define ENUMERATE_NETWORK 0x04`
Check network devices.

Flags of move state

This is a bit mask for bitwise operations. Specify move states.

See Also

`get_status`
`status_t::MoveSts`, `get_status_impl`

- `#define MOVE_STATE_MOVING 0x01`
This flag indicates that controller is trying to move the motor.
- `#define MOVE_STATE_TARGET_SPEED 0x02`
Target speed is reached, if flag set.
- `#define MOVE_STATE_ANTIPLAY 0x04`
Motor is playing compensation, if flag set.

Flags of internal controller settings

This is a bit mask for bitwise operations.

See Also

`set_controller_name`
`get_controller_name`
`controller_name.t::CtrlFlags`, `get_controller_name`, `set_controller_name`

- `#define EEPROM_PRECEDENCE 0x01`
If the flag is set settings from external EEPROM override controller settings.

Flags of power state of stepper motor

This is a bit mask for bitwise operations. Specify power states.

See Also

`get_status`
`status_t::PWRSts`, `get_status_impl`

- `#define PWR_STATE_UNKNOWN 0x00`
Unknown state, should never happen.
- `#define PWR_STATE_OFF 0x01`
Motor windings are disconnected from the driver.
- `#define PWR_STATE_NORM 0x03`
Motor windings are powered by nominal current.
- `#define PWR_STATE_REDUC 0x04`
Motor windings are powered by reduced current to lower power consumption.
- `#define PWR_STATE_MAX 0x05`
Motor windings are powered by maximum current driver can provide at this voltage.

Status flags

This is a bit mask for bitwise operations. Controller flags returned by device query. Contains boolean part of controller state. May be combined with bitwise OR.

See Also

`get_status`
`status_t::Flags`, `get_status_impl`

- `#define STATE_CONTR 0x0000003F`
Flags of controller states.
- `#define STATE_ERRC 0x00000001`
Command error encountered.
- `#define STATE_ERRD 0x00000002`
Data integrity error encountered.
- `#define STATE_ERRV 0x00000004`

- `#define STATE_EEPROM_CONNECTED 0x00000010`
EEPROM with settings is connected.
- `#define STATE_IS_HOMED 0x00000020`
Calibration performed.
- `#define STATE_SECUR 0x1B3FFC0`
Flags of security.
- `#define STATE_ALARM 0x00000040`
Controller is in alarm state indicating that something dangerous had happened.
- `#define STATE_CTP_ERROR 0x00000080`
Control position error(is only used with stepper motor).
- `#define STATE_POWER_OVERHEAT 0x0000100`
Power driver overheat.
- `#define STATE_CONTROLLER_OVERHEAT 0x0000200`
Controller overheat.
- `#define STATE_OVERLOAD_POWER_VOLTAGE 0x0000400`
Power voltage exceeds safe limit.
- `#define STATE_OVERLOAD_POWER_CURRENT 0x0000800`
Power current exceeds safe limit.
- `#define STATE_OVERLOAD_USB_VOLTAGE 0x0001000`
USB voltage exceeds safe limit.
- `#define STATE_LOW_USB_VOLTAGE 0x0002000`
USB voltage is insufficient for normal operation.
- `#define STATE_OVERLOAD_USB_CURRENT 0x0004000`
USB current exceeds safe limit.
- `#define STATE_BORDERS_SWAP_MISSET 0x0008000`
Engine stuck at the wrong edge.
- `#define STATE_LOW_POWER_VOLTAGE 0x0010000`
Power voltage is lower than Low Voltage Protection limit.
- `#define STATE_H_BRIDGEFAULT 0x0020000`
Signal from the driver that fault happened.
- `#define STATE_WINDING_RES_MISMATCH 0x0100000`
The difference between winding resistances is too large.
- `#define STATE_ENCODER_FAULT 0x0200000`
Signal from the encoder that fault happened.
- `#define STATE_ENGINE_RESPONSE_ERROR 0x0800000`
Error response of the engine control action.
- `#define STATE_EXTIO_ALARM 0x1000000`
The error is caused by the external EXTIO input signal.

Status flags of the GPIO outputs

This is a bit mask for bitwise operations. GPIO state flags returned by device query. Contains boolean part of controller state. May be combined with bitwise OR.

See Also

- `get_status`
`status_t::GPIOFlags`, `get_status_impl`
- `#define STATE_DIG_SIGNAL 0xFFFF`
Flags of digital signals.
 - `#define STATE_RIGHT_EDGE 0x0001`
Engine stuck at the right edge.
 - `#define STATE_LEFT_EDGE 0x0002`
Engine stuck at the left edge.
 - `#define STATE_BUTTON_RIGHT 0x0004`
Button "right" state (1 if pressed).

- `#define STATE_BUTTON_LEFT 0x0008`
Button "left" state (1 if pressed).
- `#define STATE_GPIO_PINOUT 0x0010`
External GPIO works as Out, if flag set; otherwise works as In.
- `#define STATE_GPIO_LEVEL 0x0020`
State of external GPIO pin.
- `#define STATE_BRAKE 0x0200`
State of Brake pin.
- `#define STATE_REV_SENSOR 0x0400`
State of Revolution sensor pin.
- `#define STATE_SYNC_INPUT 0x0800`
State of Sync input pin.
- `#define STATE_SYNC_OUTPUT 0x1000`
State of Sync output pin.
- `#define STATE_ENC_A 0x2000`
State of encoder A pin.
- `#define STATE_ENC_B 0x4000`
State of encoder B pin.

Encoder state

This is a bit mask for bitwise operations. Encoder state returned by device query.

See Also

`get_status`
`status_t::EncSts`, `get_status_impl`

- `#define ENC_STATE_ABSENT 0x00`
Encoder is absent.
- `#define ENC_STATE_UNKNOWN 0x01`
Encoder state is unknown.
- `#define ENC_STATE_MALFUNC 0x02`
Encoder is connected and malfunctioning.
- `#define ENC_STATE_REVERS 0x03`
Encoder is connected and operational but counts in other direction.
- `#define ENC_STATE_OK 0x04`
Encoder is connected and working properly.

Winding state

This is a bit mask for bitwise operations. Motor winding state returned by device query.

See Also

`get_status`
`status_t::WindSts`, `get_status_impl`

- `#define WIND_A_STATE_ABSENT 0x00`
Winding A is disconnected.
- `#define WIND_A_STATE_UNKNOWN 0x01`
Winding A state is unknown.
- `#define WIND_A_STATE_MALFUNC 0x02`
Winding A is short-circuited.
- `#define WIND_A_STATE_OK 0x03`
Winding A is connected and working properly.
- `#define WIND_B_STATE_ABSENT 0x00`
Winding B is disconnected.
- `#define WIND_B_STATE_UNKNOWN 0x10`
Winding B state is unknown.

- `#define WIND_B_STATE_MALFUNC 0x20`
Winding B is short-circuited.
- `#define WIND_B_STATE_OK 0x30`
Winding B is connected and working properly.

Move command state

This is a bit mask for bitwise operations. Move command (`command_move`, `command_movr`, `command_left`, `command_right`, `command_stop`, `command_home`, `command_loft`, `command_sstp`) and its state (`run`, `finished`, `error`).

See Also

- `get_status`
`status_t::MvCmdSts`, `get_status_impl`
- `#define MVCMD_NAME_BITS 0x3F`
Move command bit mask.
 - `#define MVCMD_UKNWN 0x00`
Unknown command.
 - `#define MVCMD_MOVE 0x01`
Command move.
 - `#define MVCMD_MOVR 0x02`
Command movr.
 - `#define MVCMD_LEFT 0x03`
Command left.
 - `#define MVCMD_RIGHT 0x04`
Command right.
 - `#define MVCMD_STOP 0x05`
Command stop.
 - `#define MVCMD_HOME 0x06`
Command home.
 - `#define MVCMD_LOFT 0x07`
Command loft.
 - `#define MVCMD_SSTP 0x08`
Command soft stop.
 - `#define MVCMD_ERROR 0x40`
Finish state (1 - move command have finished with an error, 0 - move command have finished correctly).
 - `#define MVCMD_RUNNING 0x80`
Move command state (0 - move command have finished, 1 - move command is being executed).

Flags of the motion parameters

This is a bit mask for bitwise operations. Specify motor shaft movement algorithm and list of limitations.
Flags returned by query of `get_move_settings`.

See Also

- `set_move_settings`
`get_move_settings`
`move_settings_t::MoveFlags`, `get_move_settings`, `set_move_settings`

- `#define RPM_DIV_1000 0x01`
This flag indicates that the operating speed specified in the command is set in milli rpm.

Flags of engine settings

This is a bit mask for bitwise operations. Specify motor shaft movement algorithm and list of limitations.
Flags returned by query of `engine_settings`. May be combined with bitwise OR.

See Also

[set_engine_settings](#)
[get_engine_settings](#)
[engine_settings_t::EngineFlags](#), [get_engine_settings](#), [set_engine_settings](#)

- #define **ENGINE_REVERSE** 0x01
Reverse flag.
- #define **ENGINE_CURRENT_AS_RMS** 0x02
Engine current meaning flag.
- #define **ENGINE_MAX_SPEED** 0x04
Max speed flag.
- #define **ENGINE_ANTIPLAY** 0x08
Play compensation flag.
- #define **ENGINE_ACCEL_ON** 0x10
Acceleration enable flag.
- #define **ENGINE_LIMIT_VOLT** 0x20
Maximum motor voltage limit enable flag(is only used with DC motor).
- #define **ENGINE_LIMIT_CURR** 0x40
Maximum motor current limit enable flag(is only used with DC motor).
- #define **ENGINE_LIMIT_RPM** 0x80
Maximum motor speed limit enable flag.

Flags of microstep mode

This is a bit mask for bitwise operations. Specify settings of microstep mode. Using with step motors.
Flags returned by query of engine settings. May be combined with bitwise OR

See Also

[engine_settings_t::flags](#)
[set_engine_settings](#)
[get_engine_settings](#)
[engine_settings_t::MicrostepMode](#), [get_engine_settings](#), [set_engine_settings](#)

- #define **MICROSTEP_MODE_FULL** 0x01
Full step mode.
- #define **MICROSTEP_MODE_FRAC_2** 0x02
1/2 step mode.
- #define **MICROSTEP_MODE_FRAC_4** 0x03
1/4 step mode.
- #define **MICROSTEP_MODE_FRAC_8** 0x04
1/8 step mode.
- #define **MICROSTEP_MODE_FRAC_16** 0x05
1/16 step mode.
- #define **MICROSTEP_MODE_FRAC_32** 0x06
1/32 step mode.
- #define **MICROSTEP_MODE_FRAC_64** 0x07
1/64 step mode.
- #define **MICROSTEP_MODE_FRAC_128** 0x08
1/128 step mode.
- #define **MICROSTEP_MODE_FRAC_256** 0x09
1/256 step mode.

Flags of engine type

This is a bit mask for bitwise operations. Specify motor type. Flags returned by query of engine settings.

See Also

`engine_settings_t::flags`
`set_entype_settings`
`get_entype_settings`
`entype_settings_t::EngineType, get_entype_settings, set_entype_settings`

- `#define ENGINE_TYPE_NONE 0x00`
A value that shouldn't be used.
- `#define ENGINE_TYPE_DC 0x01`
DC motor.
- `#define ENGINE_TYPE_2DC 0x02`
2 DC motors.
- `#define ENGINE_TYPE_STEP 0x03`
Step motor.
- `#define ENGINE_TYPE_TEST 0x04`
Duty cycle are fixed.
- `#define ENGINE_TYPE_BRUSHLESS 0x05`
Brushless motor.

Flags of driver type

This is a bit mask for bitwise operations. Specify driver type. Flags returned by query of engine settings.

See Also

`engine_settings_t::flags`
`set_entype_settings`
`get_entype_settings`
`entype_settings_t::DriverType, get_entype_settings, set_entype_settings`

- `#define DRIVER_TYPE_DISCRETE_FET 0x01`
Driver with discrete FET keys.
- `#define DRIVER_TYPE_INTEGRATE 0x02`
Driver with integrated IC.
- `#define DRIVER_TYPE_EXTERNAL 0x03`
External driver.

Flags of power settings of stepper motor

This is a bit mask for bitwise operations. Flags returned by query of engine settings. Specify power settings. Flags returned by query of power settings.

See Also

`get_power_settings`
`set_power_settings`
`power_settings_t::PowerFlags, get_power_settings, set_power_settings`

- `#define POWER_REDUCED_ENABLED 0x01`
Current reduction enabled after CurrReduceDelay, if this flag is set.
- `#define POWER_OFF_ENABLED 0x02`
Power off enabled after PowerOffDelay, if this flag is set.
- `#define POWER_SMOOTH_CURRENT 0x04`
Current ramp-up/down is performed smoothly during current_set_time, if this flag is set.

Flags of secure settings

This is a bit mask for bitwise operations. Flags returned by query of engine settings. Specify secure settings. Flags returned by query of secure settings.

See Also

[get_secure_settings](#)
[set_secure_settings](#)
[secure_settings_t::Flags](#), [get_secure_settings](#), [set_secure_settings](#)

- #define [ALARM_ON_DRIVER_OVERHEATING](#) 0x01
If this flag is set enter Alarm state on driver overheat signal.
- #define [LOW_UPWR_PROTECTION](#) 0x02
If this flag is set turn off motor when voltage is lower than LowUpwrOff.
- #define [H_BRIDGE_ALERT](#) 0x04
If this flag is set then turn off the power unit with a signal problem in one of the transistor bridge.
- #define [ALARM_ON_BORDERS_SWAP_MISSET](#) 0x08
If this flag is set enter Alarm state on borders swap misset.
- #define [ALARM_FLAGS_STICKING](#) 0x10
If this flag is set only a STOP command can turn all alarms to 0.
- #define [USB_BREAK_RECONNECT](#) 0x20
If this flag is set USB brake reconnect module will be enable.
- #define [ALARM_WINDING_MISMATCH](#) 0x40
If this flag is set enter Alarm state when windings mismatch.
- #define [ALARM_ENGINE_RESPONSE](#) 0x80
If this flag is set enter Alarm state on response of the engine control action.

Position setting flags

This is a bit mask for bitwise operations. Flags used in setting of position.

See Also

[get_position](#)
[set_position](#)
[set_position_t::PosFlags](#), [set_position](#)

- #define [SETPOS_IGNORE_POSITION](#) 0x01
Will not reload position in steps/microsteps if this flag is set.
- #define [SETPOS_IGNORE_ENCODER](#) 0x02
Will not reload encoder state if this flag is set.

Feedback type.

This is a bit mask for bitwise operations.

See Also

[set_feedback_settings](#)
[get_feedback_settings](#)
[feedback_settings_t::FeedbackType](#), [get_feedback_settings](#), [set_feedback_settings](#)

- #define [FEEDBACK_ENCODER](#) 0x01
Feedback by encoder.
- #define [FEEDBACK_EMF](#) 0x04
Feedback by EMF.
- #define [FEEDBACK_NONE](#) 0x05
Feedback is absent.
- #define [FEEDBACK_ENCODER_MEDIEDATED](#) 0x06
Feedback by encoder mediated by mechanical transmission (for example leadscrew).

Describes feedback flags.

This is a bit mask for bitwise operations.

See Also

`set_feedback_settings`
`get_feedback_settings`
`feedback_settings_t::FeedbackFlags, get_feedback_settings, set_feedback_settings`

- `#define FEEDBACK_ENC_REVERSE 0x01`
Reverse count of encoder.
- `#define FEEDBACK_ENC_TYPE_BITS 0xC0`
Bits of the encoder type.
- `#define FEEDBACK_ENC_TYPE_AUTO 0x00`
Auto detect encoder type.
- `#define FEEDBACK_ENC_TYPE_SINGLE_ENDED 0x40`
Single ended encoder.
- `#define FEEDBACK_ENC_TYPE_DIFFERENTIAL 0x80`
Differential encoder.

Flags for synchronization input setup

This is a bit mask for bitwise operations.

See Also

`sync_in_settings_t::SyncInFlags, get_sync_in_settings, set_sync_in_settings`

- `#define SYNCIN_ENABLED 0x01`
Synchronization in mode is enabled, if this flag is set.
- `#define SYNCIN_INVERT 0x02`
Trigger on falling edge if flag is set, on rising edge otherwise.
- `#define SYNCIN_GOTOPOSITION 0x04`
The engine is go to position specified in Position and uPosition, if this flag is set.

Flags of synchronization output

This is a bit mask for bitwise operations.

See Also

`sync_out_settings_t::SyncOutFlags, get_sync_out_settings, set_sync_out_settings`

- `#define SYNCOUT_ENABLED 0x01`
Synchronization out pin follows the synchronization logic, if set.
- `#define SYNCOUT_STATE 0x02`
When output state is fixed by negative SYNCOUT_ENABLED flag, the pin state is in accordance with this flag state.
- `#define SYNCOUT_INVERT 0x04`
Low level is active, if set, and high level is active otherwise.
- `#define SYNCOUT_IN_STEPS 0x08`
Use motor steps/encoder pulses instead of milliseconds for output pulse generation if the flag is set.
- `#define SYNCOUT_ONSTART 0x10`
Generate synchronization pulse when movement starts.
- `#define SYNCOUT_ONSTOP 0x20`
Generate synchronization pulse when movement stops.
- `#define SYNCOUT_ONPERIOD 0x40`
Generate synchronization pulse every SyncOutPeriod encoder pulses.

External IO setup flags

This is a bit mask for bitwise operations.

See Also

`get_extio_settings`
`set_extio_settings`
`extio_settings_t::EXTIOTSetupFlags, get_extio_settings, set_extio_settings`

- `#define EXTIO_SETUP_OUTPUT 0x01`
EXTIO works as output if flag is set, works as input otherwise.
- `#define EXTIO_SETUP_INVERT 0x02`
Interpret EXTIO states and fronts inverted if flag is set.

External IO mode flags

This is a bit mask for bitwise operations.

See Also

`extio_settings_t::extio_mode_flags`
`get_extio_settings`
`set_extio_settings`
`extio_settings_t::EXTIOModeFlags, get_extio_settings, set_extio_settings`

- `#define EXTIO_SETUP_MODE_IN_BITS 0x0F`
Bits of the behaviour selector when the signal on input goes to the active state.
- `#define EXTIO_SETUP_MODE_IN_NOP 0x00`
Do nothing.
- `#define EXTIO_SETUP_MODE_IN_STOP 0x01`
Issue STOP command, ceasing the engine movement.
- `#define EXTIO_SETUP_MODE_IN_PWOF 0x02`
Issue PWOF command, powering off all engine windings.
- `#define EXTIO_SETUP_MODE_IN_MOVR 0x03`
Issue MOVR command with last used settings.
- `#define EXTIO_SETUP_MODE_IN_HOME 0x04`
Issue HOME command.
- `#define EXTIO_SETUP_MODE_IN_ALARM 0x05`
Set Alarm when the signal goes to the active state.
- `#define EXTIO_SETUP_MODE_OUT_BITS 0xF0`
Bits of the output behaviour selection.
- `#define EXTIO_SETUP_MODE_OUT_OFF 0x00`
EXTIO pin always set in inactive state.
- `#define EXTIO_SETUP_MODE_OUT_ON 0x10`
EXTIO pin always set in active state.
- `#define EXTIO_SETUP_MODE_OUT_MOVING 0x20`
EXTIO pin stays active during moving state.
- `#define EXTIO_SETUP_MODE_OUT_ALARM 0x30`
EXTIO pin stays active during Alarm state.
- `#define EXTIO_SETUP_MODE_OUT_MOTOR_ON 0x40`
EXTIO pin stays active when windings are powered.

Border flags

This is a bit mask for bitwise operations. Specify types of borders and motor behaviour on borders. May be combined with bitwise OR.

See Also

`get_edges_settings`
`set_edges_settings`
`edges_settings_t::BorderFlags, get_edges_settings, set_edges_settings`

- `#define BORDER_IS_ENCODER 0x01`
Borders are fixed by predetermined encoder values, if set; borders position on limit switches, if not set.
- `#define BORDER_STOP_LEFT 0x02`
Motor should stop on left border.
- `#define BORDER_STOP_RIGHT 0x04`
Motor should stop on right border.
- `#define BORDERS_SWAP_MISSET_DETECTION 0x08`
Motor should stop on both borders.

Limit switches flags

This is a bit mask for bitwise operations. Specify electrical behaviour of limit switches like order and pulled positions. May be combined with bitwise OR.

See Also

`get_edges_settings`
`set_edges_settings`
`edges_settings_t::EnderFlags, get_edges_settings, set_edges_settings`

- `#define ENDER_SWAP 0x01`
First limit switch on the right side, if set; otherwise on the left side.
- `#define ENDER_SW1_ACTIVE_LOW 0x02`
1 - Limit switch connected to pin SW1 is triggered by a low level on pin.
- `#define ENDER_SW2_ACTIVE_LOW 0x04`
1 - Limit switch connected to pin SW2 is triggered by a low level on pin.

Brake settings flags

This is a bit mask for bitwise operations. Specify behaviour of brake. May be combined with bitwise OR.

See Also

`get_brake_settings`
`set_brake_settings`
`brake_settings_t::BrakeFlags, get_brake_settings, set_brake_settings`

- `#define BRAKE_ENABLED 0x01`
Brake control is enabled, if this flag is set.
- `#define BRAKE_ENG_PWROFF 0x02`
Brake turns off power of step motor, if this flag is set.

Control flags

This is a bit mask for bitwise operations. Specify motor control settings by joystick or buttons. May be combined with bitwise OR.

See Also

`get_control_settings`
`set_control_settings`
`control_settings_t::Flags, get_control_settings, set_control_settings`

- `#define CONTROL_MODE_BITS 0x03`
Bits to control engine by joystick or buttons.
- `#define CONTROL_MODE_OFF 0x00`

- `#define CONTROL_MODE_JOY 0x01`
Control by joystick.
- `#define CONTROL_MODE_LR 0x02`
Control by left/right buttons.
- `#define CONTROL_BTN_LEFT_PUSHED_OPEN 0x04`
Pushed left button corresponds to open contact, if this flag is set.
- `#define CONTROL_BTN_RIGHT_PUSHED_OPEN 0x08`
Pushed right button corresponds to open contact, if this flag is set.

Joystick flags

This is a bit mask for bitwise operations. Control joystick states.

See Also

`set_joystick_settings`
`get_joystick_settings`
`joystick_settings_t::JoyFlags, get_joystick_settings, set_joystick_settings`

- `#define JOY_REVERSE 0x01`
Joystick action is reversed.

Position control flags

This is a bit mask for bitwise operations. Specify settings of position control. May be combined with bitwise OR.

See Also

`get_ctp_settings`
`set_ctp_settings`
`ctp_settings_t::CTPFlags, get_ctp_settings, set_ctp_settings`

- `#define CTP_ENABLED 0x01`
Position control is enabled, if flag set.
- `#define CTP_BASE 0x02`
Position control is based on revolution sensor, if this flag is set; otherwise it is based on encoder.
- `#define CTP_ALARM_ON_ERROR 0x04`
Set ALARM on mismatch, if flag set.
- `#define REV_SENS_INV 0x08`
Sensor is active when it 0 and invert makes active level 1.
- `#define CTP_ERROR_CORRECTION 0x10`
Correct errors which appear when slippage if the flag is set.

Home settings flags

This is a bit mask for bitwise operations. Specify behaviour for home command. May be combined with bitwise OR.

See Also

`get_home_settings`
`set_home_settings`
`command_home`
`home_settings_t::HomeFlags, get_home_settings, set_home_settings`

- `#define HOME_DIR_FIRST 0x001`
Flag defines direction of 1st motion after execution of home command.
- `#define HOME_DIR_SECOND 0x002`
Flag defines direction of 2nd motion.
- `#define HOME_MV_SEC_EN 0x004`

- Use the second phase of calibration to the home position, if set; otherwise the second phase is skipped.
- #define **HOME_HALF_MV** 0x008
If the flag is set, the stop signals are ignored in start of second movement the first half-turn.
- #define **HOME_STOP_FIRST_BITS** 0x030
Bits of the first stop selector.
- #define **HOME_STOP_FIRST_REV** 0x010
First motion stops by revolution sensor.
- #define **HOME_STOP_FIRST_SYN** 0x020
First motion stops by synchronization input.
- #define **HOME_STOP_FIRST_LIM** 0x030
First motion stops by limit switch.
- #define **HOME_STOP_SECOND_BITS** 0x0C0
Bits of the second stop selector.
- #define **HOME_STOP_SECOND_REV** 0x040
Second motion stops by revolution sensor.
- #define **HOME_STOP_SECOND_SYN** 0x080
Second motion stops by synchronization input.
- #define **HOME_STOP_SECOND_LIM** 0x0C0
Second motion stops by limit switch.
- #define **HOME_USE_FAST** 0x100
Use the fast algorithm of calibration to the home position, if set; otherwise the traditional algorithm.

UART parity flags

This is a bit mask for bitwise operations.

See Also

[*uart_settings_t::UARTSetupFlags, get_uart_settings, set_uart_settings*](#)

- #define **UART_PARITY_BITS** 0x03
Bits of the parity.
- #define **UART_PARITY_BIT_EVEN** 0x00
Parity bit 1, if even.
- #define **UART_PARITY_BIT_ODD** 0x01
Parity bit 1, if odd.
- #define **UART_PARITY_BIT_SPACE** 0x02
Parity bit always 0.
- #define **UART_PARITY_BIT_MARK** 0x03
Parity bit always 1.
- #define **UART_PARITY_BIT_USE** 0x04
None parity.
- #define **UART_STOP_BIT** 0x08
If set - one stop bit, else two stop bit.

Motor Type flags

This is a bit mask for bitwise operations.

See Also

[*motor_settings_t::MotorType, get_motor_settings, set_motor_settings*](#)

- #define **MOTOR_TYPE_UNKNOWN** 0x00
Unknown type of engine.
- #define **MOTOR_TYPE_STEP** 0x01
Step engine.
- #define **MOTOR_TYPE_DC** 0x02
DC engine.

- #define `MOTOR_TYPE_BLDC` 0x03
BLDC engine.

Encoder settings flags

This is a bit mask for bitwise operations.

See Also

`encoder_settings_t::EncoderSettings, get_encoder_settings, set_encoder_settings`

- #define `ENCSET_DIFFERENTIAL_OUTPUT` 0x001
If flag is set the encoder has differential output, else single ended output.
- #define `ENCSET_PUSH_PULL_OUTPUT` 0x004
If flag is set the encoder has push-pull output, else open drain output.
- #define `ENCSET_INDEXCHANNEL_PRESENT` 0x010
If flag is set the encoder has index channel, else encoder hasn't it.
- #define `ENCSET_REVOLUTIONSENSOR_PRESENT` 0x040
If flag is set the encoder has revolution sensor, else encoder hasn't it.
- #define `ENCSET_REVOLUTIONSENSOR_ACTIVE_HIGH` 0x100
If flag is set the revolution sensor active state is high logic state, else active state is low logic state.

Magnetic brake settings flags

This is a bit mask for bitwise operations.

See Also

`accessories_settings_t::MBSettings, get_accessories_settings, set_accessories_settings`

- #define `MB_AVAILABLE` 0x01
If flag is set the magnetic brake is available.
- #define `MB_POWERED_HOLD` 0x02
If this flag is set the magnetic brake is on when powered.

Temperature sensor settings flags

This is a bit mask for bitwise operations.

See Also

`accessories_settings_t::LimitSwitchesSettings, get_accessories_settings, set_accessories_settings`

- #define `TS_TYPE_BITS` 0x07
Bits of the temperature sensor type.
- #define `TS_TYPE_UNKNOWN` 0x00
Unknown type of sensor.
- #define `TS_TYPE_THERMOCOUPLE` 0x01
Thermocouple.
- #define `TS_TYPE_SEMICONDUCTOR` 0x02
The semiconductor temperature sensor.
- #define `TS_AVAILABLE` 0x08
If flag is set the temperature sensor is available.
- #define `LS_ON_SW1_AVAILABLE` 0x01
If flag is set the limit switch connected to pin SW1 is available.
- #define `LS_ON_SW2_AVAILABLE` 0x02
If flag is set the limit switch connected to pin SW2 is available.
- #define `LS_SW1_ACTIVE_LOW` 0x04
If flag is set the limit switch connected to pin SW1 is triggered by a low level on pin.
- #define `LS_SW2_ACTIVE_LOW` 0x08

- `#define LS_SHORTED 0x10`
If flag is set the limit switch connected to pin SW2 is triggered by a low level on pin.

Flags of auto-detection of characteristics of windings of the engine.

This is a bit mask for bitwise operations.

See Also

`set_emf_settings`
`get_emf_settings`
`emf_settings_t::BackEMFFlags, get_emf_settings, set_emf_settings`

- `#define BACK_EMF_INDUCTANCE_AUTO 0x01`
Flag of auto-detection of inductance of windings of the engine.
- `#define BACK_EMF_RESISTANCE_AUTO 0x02`
Flag of auto-detection of resistance of windings of the engine.
- `#define BACK_EMF_KM_AUTO 0x04`
Flag of auto-detection of electromechanical coefficient of the engine.

Typedefs

- `typedef unsigned long long ulong_t`
- `typedef long long long_t`
- `typedef int device_t`
Type describes device identifier.
- `typedef int result_t`
Type specifies result of any operation.
- `typedef uint32_t device_enumeration_t`
Type describes device enumeration structure.
- `typedef struct calibration_t calibration_t`
Calibration structure.
- `typedef struct device_network_information_t device_network_information_t`
Device network information structure.

Functions

Controller settings setup

Functions for adjusting engine read/write almost all controller settings.

- `result_t XIMC_API set_feedback_settings (device_t id, const feedback_settings_t *feedback_settings)`
Feedback settings.
- `result_t XIMC_API get_feedback_settings (device_t id, feedback_settings_t *feedback_settings)`
Feedback settings.
- `result_t XIMC_API set_home_settings (device_t id, const home_settings_t *home_settings)`
Set home settings.
- `result_t XIMC_API set_home_settings_calb (device_t id, const home_settings_calb_t *home_settings_calb, const calibration_t *calibration)`
Set home settings which use user units.
- `result_t XIMC_API get_home_settings (device_t id, home_settings_t *home_settings)`
Read home settings.

- `result_t XIMC_API get_home_settings_calb (device_t id, home_settings_calb_t *home_settings_calb, const calibration_t *calibration)`
Read home settings which use user units.
- `result_t XIMC_API set_move_settings (device_t id, const move_settings_t *move_settings)`
Set command setup movement (speed, acceleration, threshold and etc).
- `result_t XIMC_API set_move_settings_calb (device_t id, const move_settings_calb_t *move_settings_calb, const calibration_t *calibration)`
Set command setup movement which use user units (speed, acceleration, threshold and etc).
- `result_t XIMC_API get_move_settings (device_t id, move_settings_t *move_settings)`
Read command setup movement (speed, acceleration, threshold and etc).
- `result_t XIMC_API get_move_settings_calb (device_t id, move_settings_calb_t *move_settings_calb, const calibration_t *calibration)`
Read command setup movement which use user units (speed, acceleration, threshold and etc).
- `result_t XIMC_API set_engine_settings (device_t id, const engine_settings_t *engine_settings)`
Set engine settings.
- `result_t XIMC_API set_engine_settings_calb (device_t id, const engine_settings_calb_t *engine_settings_calb, const calibration_t *calibration)`
Set engine settings which use user units.
- `result_t XIMC_API get_engine_settings (device_t id, engine_settings_t *engine_settings)`
Read engine settings.
- `result_t XIMC_API get_engine_settings_calb (device_t id, engine_settings_calb_t *engine_settings_calb, const calibration_t *calibration)`
Read engine settings which use user units.
- `result_t XIMC_API set_entype_settings (device_t id, const entype_settings_t *entype_settings)`
Set engine type and driver type.
- `result_t XIMC_API get_entype_settings (device_t id, entype_settings_t *entype_settings)`
Return engine type and driver type.
- `result_t XIMC_API set_power_settings (device_t id, const power_settings_t *power_settings)`
Set settings of step motor power control.
- `result_t XIMC_API get_power_settings (device_t id, power_settings_t *power_settings)`
Read settings of step motor power control.
- `result_t XIMC_API set_secure_settings (device_t id, const secure_settings_t *secure_settings)`
Set protection settings.
- `result_t XIMC_API get_secure_settings (device_t id, secure_settings_t *secure_settings)`
Read protection settings.
- `result_t XIMC_API set_edges_settings (device_t id, const edges_settings_t *edges_settings)`
Set border and limit switches settings.
- `result_t XIMC_API set_edges_settings_calb (device_t id, const edges_settings_calb_t *edges_settings_calb, const calibration_t *calibration)`
Set border and limit switches settings which use user units.
- `result_t XIMC_API get_edges_settings (device_t id, edges_settings_t *edges_settings)`
Read border and limit switches settings.
- `result_t XIMC_API get_edges_settings_calb (device_t id, edges_settings_calb_t *edges_settings_calb, const calibration_t *calibration)`
Read border and limit switches settings which use user units.
- `result_t XIMC_API set_pid_settings (device_t id, const pid_settings_t *pid_settings)`
Set PID settings.
- `result_t XIMC_API get_pid_settings (device_t id, pid_settings_t *pid_settings)`
Read PID settings.
- `result_t XIMC_API set_sync_in_settings (device_t id, const sync_in_settings_t *sync_in_settings)`
Set input synchronization settings.
- `result_t XIMC_API set_sync_in_settings_calb (device_t id, const sync_in_settings_calb_t *sync_in_settings_calb, const calibration_t *calibration)`
Set input synchronization settings which use user units.
- `result_t XIMC_API get_sync_in_settings (device_t id, sync_in_settings_t *sync_in_settings)`
Read input synchronization settings.

- `result_t XIMC_API get_sync_in_settings_calb (device_t id, sync_in_settings_calb_t *sync_in_settings_calb, const calibration_t *calibration)`
Read input synchronization settings which use user units.
- `result_t XIMC_API set_sync_out_settings (device_t id, const sync_out_settings_t *sync_out_settings)`
Set output synchronization settings.
- `result_t XIMC_API set_sync_out_settings_calb (device_t id, const sync_out_settings_calb_t *sync_out_settings_calb, const calibration_t *calibration)`
Set output synchronization settings which use user units.
- `result_t XIMC_API get_sync_out_settings (device_t id, sync_out_settings_t *sync_out_settings)`
Read output synchronization settings.
- `result_t XIMC_API get_sync_out_settings_calb (device_t id, sync_out_settings_calb_t *sync_out_settings_calb, const calibration_t *calibration)`
Read output synchronization settings which use user units.
- `result_t XIMC_API set_extio_settings (device_t id, const extio_settings_t *extio_settings)`
Set EXTIO settings.
- `result_t XIMC_API get_extio_settings (device_t id, extio_settings_t *extio_settings)`
Read EXTIO settings.
- `result_t XIMC_API set_brake_settings (device_t id, const brake_settings_t *brake_settings)`
Set settings of brake control.
- `result_t XIMC_API get_brake_settings (device_t id, brake_settings_t *brake_settings)`
Read settings of brake control.
- `result_t XIMC_API set_control_settings (device_t id, const control_settings_t *control_settings)`
Set settings of motor control.
- `result_t XIMC_API set_control_settings_calb (device_t id, const control_settings_calb_t *control_settings_calb, const calibration_t *calibration)`
Set settings of motor control which use user units.
- `result_t XIMC_API get_control_settings (device_t id, control_settings_t *control_settings)`
Read settings of motor control.
- `result_t XIMC_API get_control_settings_calb (device_t id, control_settings_calb_t *control_settings_calb, const calibration_t *calibration)`
Read settings of motor control which use user units.
- `result_t XIMC_API set_joystick_settings (device_t id, const joystick_settings_t *joystick_settings)`
Set settings of joystick.
- `result_t XIMC_API get_joystick_settings (device_t id, joystick_settings_t *joystick_settings)`
Read settings of joystick.
- `result_t XIMC_API set_ctp_settings (device_t id, const ctp_settings_t *ctp_settings)`
Set settings of control position(is only used with stepper motor).
- `result_t XIMC_API get_ctp_settings (device_t id, ctp_settings_t *ctp_settings)`
Read settings of control position(is only used with stepper motor).
- `result_t XIMC_API set_uart_settings (device_t id, const uart_settings_t *uart_settings)`
Set UART settings.
- `result_t XIMC_API get_uart_settings (device_t id, uart_settings_t *uart_settings)`
Read UART settings.
- `result_t XIMC_API set_network_settings (device_t id, const network_settings_t *network_settings)`
Set network settings.
- `result_t XIMC_API get_network_settings (device_t id, network_settings_t *network_settings)`
Read network settings.
- `result_t XIMC_API set_password_settings (device_t id, const password_settings_t *password_settings)`
Sets password settings.
- `result_t XIMC_API get_password_settings (device_t id, password_settings_t *password_settings)`
Read password settings.
- `result_t XIMC_API set_calibration_settings (device_t id, const calibration_settings_t *calibration_settings)`
Set calibration settings.

- `result_t XIMC_API get_calibration_settings (device_t id, calibration_settings_t *calibration_settings)`
Read calibration settings.
- `result_t XIMC_API set_controller_name (device_t id, const controller_name_t *controller_name)`
Write user controller name and flags of setting from FRAM.
- `result_t XIMC_API get_controller_name (device_t id, controller_name_t *controller_name)`
Read user controller name and flags of setting from FRAM.
- `result_t XIMC_API set_nonvolatile_memory (device_t id, const nonvolatile_memory_t *nonvolatile_memory)`
Write userdata into FRAM.
- `result_t XIMC_API get_nonvolatile_memory (device_t id, nonvolatile_memory_t *nonvolatile_memory)`
Read userdata from FRAM.
- `result_t XIMC_API set_emf_settings (device_t id, const emf_settings_t *emf_settings)`
Set electromechanical coefficients.
- `result_t XIMC_API get_emf_settings (device_t id, emf_settings_t *emf_settings)`
Read electromechanical settings.
- `result_t XIMC_API set_engine_advansed_setup (device_t id, const engine_advansed_setup_t *engine_advansed_setup)`
Set engine advansed settings.
- `result_t XIMC_API get_engine_advansed_setup (device_t id, engine_advansed_setup_t *engine_advansed_setup)`
Read engine advansed settings.
- `result_t XIMC_API set_extended_settings (device_t id, const extended_settings_t *extended_settings)`
Set extended settings.
- `result_t XIMC_API get_extended_settings (device_t id, extended_settings_t *extended_settings)`
Read extended settings.

Group of commands movement control

- `result_t XIMC_API command_stop (device_t id)`
Immediately stop the engine, the transition to the STOP, mode key BREAK (winding short-circuited), the regime "retention" is deactivated for DC motors, keeping current in the windings for stepper motors (with Power management settings).
- `result_t XIMC_API command_power_off (device_t id)`
Immediately power off motor regardless its state.
- `result_t XIMC_API command_move (device_t id, int Position, int uPosition)`
Upon receiving the command "move" the engine starts to move with pre-set parameters (speed, acceleration, retention), to the point specified to the Position, uPosition.
- `result_t XIMC_API command_move_calb (device_t id, float Position, const calibration_t *calibration)`
Move to position which use user units.
- `result_t XIMC_API command_movr (device_t id, int DeltaPosition, int uDeltaPosition)`
Move to offset.
- `result_t XIMC_API command_movr_calb (device_t id, float DeltaPosition, const calibration_t *calibration)`
Move to offset using user units.
- `result_t XIMC_API command_home (device_t id)`
The positive direction is to the right.
- `result_t XIMC_API command_left (device_t id)`
Start continuous moving to the left.
- `result_t XIMC_API command_right (device_t id)`
Start continuous moving to the right.
- `result_t XIMC_API command_loft (device_t id)`
Upon receiving the command "loft" the engine is shifted from the current point to a distance GENG :: Antiplay, then move to the same point.

- `result_t XIMC_API command_sstp (device_t id)`
Soft stop engine.
- `result_t XIMC_API get_position (device_t id, get_position_t *the_get_position)`
Reads the value position in steps and micro for stepper motor and encoder steps all engines.
- `result_t XIMC_API get_position_calb (device_t id, get_position_calb_t *the_get_position_calb, const calibration_t *calibration)`
Reads position value in user units for stepper motor and encoder steps all engines.
- `result_t XIMC_API set_position (device_t id, const set_position_t *the_set_position)`
Sets any position value in steps and micro for stepper motor and encoder steps of all engines.
- `result_t XIMC_API set_position_calb (device_t id, const set_position_calb_t *the_set_position_calb, const calibration_t *calibration)`
Sets any position value and encoder value of all engines which use user units.
- `result_t XIMC_API command_zero (device_t id)`
Sets the current position and the position in which the traffic moves by the move command and movr zero for all cases, except for movement to the target position.

Group of commands to save and load settings

- `result_t XIMC_API command_save_settings (device_t id)`
Save all settings from controller's RAM to controller's flash memory, replacing previous data in controller's flash memory.
- `result_t XIMC_API command_read_settings (device_t id)`
Read all settings from controller's flash memory to controller's RAM, replacing previous data in controller's RAM.
- `result_t XIMC_API command_save_robust_settings (device_t id)`
Save important settings (calibration coefficients and etc.) from controller's RAM to controller's flash memory, replacing previous data in controller's flash memory.
- `result_t XIMC_API command_read_robust_settings (device_t id)`
Read important settings (calibration coefficients and etc.) from controller's flash memory to controller's RAM, replacing previous data in controller's RAM.
- `result_t XIMC_API command_eesave_settings (device_t id)`
Save settings from controller's RAM to stage's EEPROM memory, which spontaneity connected to stage and it isn't change without its mechanical reconstruction.
- `result_t XIMC_API command_eeread_settings (device_t id)`
Read settings from controller's RAM to stage's EEPROM memory, which spontaneity connected to stage and it isn't change without its mechanical reconstruction.
- `result_t XIMC_API command_start_measurements (device_t id)`
Start measurements and buffering of speed, following error.
- `result_t XIMC_API get_measurements (device_t id, measurements_t *measurements)`
A command to read the data buffer to build a speed graph and a sequence error.
- `result_t XIMC_API get_chart_data (device_t id, chart_data_t *chart_data)`
Return device electrical parameters, useful for charts.
- `result_t XIMC_API get_serial_number (device_t id, unsigned int *SerialNumber)`
Read device serial number.
- `result_t XIMC_API get_firmware_version (device_t id, unsigned int *Major, unsigned int *Minor, unsigned int *Release)`
Read controller's firmware version.
- `result_t XIMC_API service_command_updf (device_t id)`
Command puts the controller to update the firmware.

Service commands

- `result_t XIMC_API set_serial_number (device_t id, const serial_number_t *serial_number)`
Write device serial number and hardware version to controller's flash memory.
- `result_t XIMC_API get_analog_data (device_t id, analog_data_t *analog_data)`
Read analog data structure that contains raw analog data from ADC embedded on board.
- `result_t XIMC_API get_debug_read (device_t id, debug_read_t *debug_read)`

Read data from firmware for debug purpose.

- `result_t XIMC_API set_debug_write (device_t id, const debug_write_t *debug_write)`
Write data to firmware for debug purpose.

Group of commands to work with EEPROM

- `result_t XIMC_API set_stage_name (device_t id, const stage_name_t *stage_name)`
Write user stage name from EEPROM.
- `result_t XIMC_API get_stage_name (device_t id, stage_name_t *stage_name)`
Read user stage name from EEPROM.
- `result_t XIMC_API set_stage_information (device_t id, const stage_information_t *stage_information)`
Set stage information to EEPROM.
- `result_t XIMC_API get_stage_information (device_t id, stage_information_t *stage_information)`
Read stage information from EEPROM.
- `result_t XIMC_API set_stage_settings (device_t id, const stage_settings_t *stage_settings)`
Set stage settings to EEPROM.
- `result_t XIMC_API get_stage_settings (device_t id, stage_settings_t *stage_settings)`
Read stage settings from EEPROM.
- `result_t XIMC_API set_motor_information (device_t id, const motor_information_t *motor_information)`
Set motor information to EEPROM.
- `result_t XIMC_API get_motor_information (device_t id, motor_information_t *motor_information)`
Read motor information from EEPROM.
- `result_t XIMC_API set_motor_settings (device_t id, const motor_settings_t *motor_settings)`
Set motor settings to EEPROM.
- `result_t XIMC_API get_motor_settings (device_t id, motor_settings_t *motor_settings)`
Read motor settings from EEPROM.
- `result_t XIMC_API set_encoder_information (device_t id, const encoder_information_t *encoder_information)`
Set encoder information to EEPROM.
- `result_t XIMC_API get_encoder_information (device_t id, encoder_information_t *encoder_information)`
Read encoder information from EEPROM.
- `result_t XIMC_API set_encoder_settings (device_t id, const encoder_settings_t *encoder_settings)`
Set encoder settings to EEPROM.
- `result_t XIMC_API get_encoder_settings (device_t id, encoder_settings_t *encoder_settings)`
Read encoder settings from EEPROM.
- `result_t XIMC_API set_hallsensor_information (device_t id, const hallsensor_information_t *hallsensor_information)`
Set hall sensor information to EEPROM.
- `result_t XIMC_API get_hallsensor_information (device_t id, hallsensor_information_t *hallsensor_information)`
Read hall sensor information from EEPROM.
- `result_t XIMC_API set_hallsensor_settings (device_t id, const hallsensor_settings_t *hallsensor_settings)`
Set hall sensor settings to EEPROM.
- `result_t XIMC_API get_hallsensor_settings (device_t id, hallsensor_settings_t *hallsensor_settings)`
Read hall sensor settings from EEPROM.
- `result_t XIMC_API set_gear_information (device_t id, const gear_information_t *gear_information)`
Set gear information to EEPROM.
- `result_t XIMC_API get_gear_information (device_t id, gear_information_t *gear_information)`
Read gear information from EEPROM.
- `result_t XIMC_API set_gear_settings (device_t id, const gear_settings_t *gear_settings)`
Set gear settings to EEPROM.
- `result_t XIMC_API get_gear_settings (device_t id, gear_settings_t *gear_settings)`
Read gear settings from EEPROM.

- `result_t XIMC_API set_accessories_settings (device_t id, const accessories_settings_t *accessories_settings)`
Set additional accessories information to EEPROM.
- `result_t XIMC_API get_accessories_settings (device_t id, accessories_settings_t *accessories_settings)`
Read additional accessories information from EEPROM.
- `result_t XIMC_API get_bootloader_version (device_t id, unsigned int *Major, unsigned int *Minor, unsigned int *Release)`
Read controller's firmware version.
- `result_t XIMC_API get_init_random (device_t id, init_random_t *init_random)`
Read random number from controller.
- `result_t XIMC_API get_globally_unique_identifier (device_t id, globally_unique_identifier_t *globally_unique_identifier)`
This value is unique to each individual die but is not a random value.
- `result_t XIMC_API goto_firmware (device_t id, uint8_t *ret)`
Reboot to firmware.
- `result_t XIMC_API has_firmware (const char *uri, uint8_t *ret)`
Check for firmware on device.
- `result_t XIMC_API command_update_firmware (const char *uri, const uint8_t *data, uint32_t data_size)`
Update firmware.
- `result_t XIMC_API write_key (const char *uri, uint8_t *key)`
Write controller key.
- `result_t XIMC_API command_reset (device_t id)`
Reset controller.
- `result_t XIMC_API command_clear_fram (device_t id)`
Clear controller FRAM.

Boards and drivers control

Functions for searching and opening/closing devices

- `typedef char * pchar`
Nevermind.
- `typedef void(XIMC_CALLCONV * logging_callback_t)(int loglevel, const wchar_t *message, void *user_data)`
Logging callback prototype.
- `device_t XIMC_API open_device (const char *uri)`
Open a device with OS uri uri and return identifier of the device which can be used in calls.
- `result_t XIMC_API close_device (device_t *id)`
Close specified device.
- `result_t XIMC_API load_correction_table (device_t *id, const char *namefile)`
Command of loading a correction table from a text file (this function is deprecated).
- `result_t XIMC_API set_correction_table (device_t id, const char *namefile)`
Command of loading a correction table from a text file.
- `result_t XIMC_API probe_device (const char *uri)`
Check if a device with OS uri uri is XIMC device.
- `result_t XIMC_API set_bindy_key (const char *keyfilepath)`
Set network encryption layer (bindy) key.
- `device_enumeration_t XIMC_API enumerate_devices (int enumerate_flags, const char *hints)`
Enumerate all devices that looks like valid.
- `result_t XIMC_API free_enumerate_devices (device_enumeration_t device_enumeration)`
Free memory returned by enumerate_devices.

- `int XIMC_API get_device_count (device_enumeration_t device_enumeration)`
Get device count.
- `pchar XIMC_API get_device_name (device_enumeration_t device_enumeration, int device_index)`
Get device name from the device enumeration.
- `result_t XIMC_API get_enumerate_device_serial (device_enumeration_t device_enumeration, int device_index, uint32_t *serial)`
Get device serial number from the device enumeration.
- `result_t XIMC_API get_enumerate_device_information (device_enumeration_t device_enumeration, int device_index, device_information_t *device_information)`
Get device information from the device enumeration.
- `result_t XIMC_API get_enumerate_device_controller_name (device_enumeration_t device_enumeration, int device_index, controller_name_t *controller_name)`
Get controller name from the device enumeration.
- `result_t XIMC_API get_enumerate_device_stage_name (device_enumeration_t device_enumeration, int device_index, stage_name_t *stage_name)`
Get stage name from the device enumeration.
- `result_t XIMC_API get_enumerate_device_network_information (device_enumeration_t device_enumeration, int device_index, device_network_information_t *device_network_information)`
Get device network information from the device enumeration.
- `result_t XIMC_API reset_locks ()`
Resets the error of incorrect data transmission.
- `result_t XIMC_API ximc_fix_usbser_sys (const char *device_uri)`
Fixing a USB driver error in Windows.
- `void XIMC_API msec_sleep (unsigned int msec)`
Sleeps for a specified amount of time.
- `void XIMC_API ximc_version (char *version)`
Returns a library version.
- `void XIMC_API logging_callback_stderr_wide (int loglevel, const wchar_t *message, void *user_data)`
Simple callback for logging to stderr in wide chars.
- `void XIMC_API logging_callback_stderr_narrow (int loglevel, const wchar_t *message, void *user_data)`
Simple callback for logging to stderr in narrow (single byte) chars.
- `void XIMC_API set_logging_callback (logging_callback_t logging_callback, void *user_data)`
Sets a logging callback.
- `result_t XIMC_API get_status (device_t id, status_t *status)`
Return device state.
- `result_t XIMC_API get_status_calb (device_t id, status_calb_t *status, const calibration_t *calibration)`
Return device state.
- `result_t XIMC_API get_device_information (device_t id, device_information_t *device_information)`
Return device information.
- `result_t XIMC_API command_wait_for_stop (device_t id, uint32_t refresh_interval_ms)`
Wait for stop.
- `result_t XIMC_API command_homezero (device_t id)`
Make home command, wait until it is finished and make zero command.

7.1.1 Detailed Description

Header file for libximc library.

7.1.2 Macro Definition Documentation

7.1.2.1 `#define ALARM_ON_DRIVER_OVERHEATING 0x01`

If this flag is set enter Alarm state on driver overheat signal.

7.1.2.2 `#define BACK_EMF_INDUCTANCE_AUTO 0x01`

Flag of auto-detection of inductance of windings of the engine.

7.1.2.3 `#define BACK_EMF_KM_AUTO 0x04`

Flag of auto-detection of electromechanical coefficient of the engine.

7.1.2.4 `#define BACK_EMF_RESISTANCE_AUTO 0x02`

Flag of auto-detection of resistance of windings of the engine.

7.1.2.5 `#define BORDER_IS_ENCODER 0x01`

Borders are fixed by predetermined encoder values, if set; borders position on limit switches, if not set.

7.1.2.6 `#define BORDER_STOP_LEFT 0x02`

Motor should stop on left border.

7.1.2.7 `#define BORDER_STOP_RIGHT 0x04`

Motor should stop on right border.

7.1.2.8 `#define BORDERS_SWAP_MISSET_DETECTION 0x08`

Motor should stop on both borders.

Need to save motor then wrong border settings is set

7.1.2.9 `#define BRAKE_ENABLED 0x01`

Brake control is enabled, if this flag is set.

7.1.2.10 `#define BRAKE_ENG_PWROFF 0x02`

Brake turns off power of step motor, if this flag is set.

7.1.2.11 `#define CONTROL_BTN_LEFT_PUSHED_OPEN 0x04`

Pushed left button corresponds to open contact, if this flag is set.

7.1.2.12 #define CONTROL_BTN_RIGHT_PUSHED_OPEN 0x08

Pushed right button corresponds to open contact, if this flag is set.

7.1.2.13 #define CONTROL_MODE_BITS 0x03

Bits to control engine by joystick or buttons.

7.1.2.14 #define CONTROL_MODE_JOY 0x01

Control by joystick.

7.1.2.15 #define CONTROL_MODE_LR 0x02

Control by left/right buttons.

7.1.2.16 #define CONTROL_MODE_OFF 0x00

Control is disabled.

7.1.2.17 #define CTP_ALARM_ON_ERROR 0x04

Set ALARM on mismatch, if flag set.

7.1.2.18 #define CTP_BASE 0x02

Position control is based on revolution sensor, if this flag is set; otherwise it is based on encoder.

7.1.2.19 #define CTP_ENABLED 0x01

Position control is enabled, if flag set.

7.1.2.20 #define CTP_ERROR_CORRECTION 0x10

Correct errors which appear when slippage if the flag is set.

It works only with the encoder. Incompatible with flag CTP_ALARM_ON_ERROR.

7.1.2.21 #define DRIVER_TYPE_DISCRETE_FET 0x01

Driver with discrete FET keys.

Default option.

7.1.2.22 #define DRIVER_TYPE_EXTERNAL 0x03

External driver.

7.1.2.23 #define DRIVER_TYPE_INTEGRATE 0x02

Driver with integrated IC.

7.1.2.24 #define EEPROM_PRECEDENCE 0x01

If the flag is set settings from external EEPROM override controller settings.

7.1.2.25 #define ENC_STATE_ABSENT 0x00

Encoder is absent.

7.1.2.26 #define ENC_STATE_MALFUNC 0x02

Encoder is connected and malfunctioning.

7.1.2.27 #define ENC_STATE_OK 0x04

Encoder is connected and working properly.

7.1.2.28 #define ENC_STATE_REVERS 0x03

Encoder is connected and operational but counts in other direction.

7.1.2.29 #define ENC_STATE_UNKNOWN 0x01

Encoder state is unknown.

7.1.2.30 #define ENDER_SW1_ACTIVE_LOW 0x02

1 - Limit switch connected to pin SW1 is triggered by a low level on pin.

7.1.2.31 #define ENDER_SW2_ACTIVE_LOW 0x04

1 - Limit switch connected to pin SW2 is triggered by a low level on pin.

7.1.2.32 #define ENDER_SWAP 0x01

First limit switch on the right side, if set; otherwise on the left side.

7.1.2.33 #define ENGINE_ACCEL_ON 0x10

Acceleration enable flag.

If it set, motion begins with acceleration and ends with deceleration.

7.1.2.34 #define ENGINE_ANTIPLAY 0x08

Play compensation flag.

If it set, engine makes backlash (play) compensation procedure and reach the predetermined position accurately on low speed.

7.1.2.35 #define ENGINE_CURRENT_AS_RMS 0x02

Engine current meaning flag.

If the flag is unset, then engine current value is interpreted as maximum amplitude value. If the flag is set, then engine current value is interpreted as root mean square current value (for stepper) or as the current value calculated from the maximum heat dissipation (bldc).

7.1.2.36 #define ENGINE_LIMIT_CURR 0x40

Maximum motor current limit enable flag(is only used with DC motor).

7.1.2.37 #define ENGINE_LIMIT_RPM 0x80

Maximum motor speed limit enable flag.

7.1.2.38 #define ENGINE_LIMIT_VOLT 0x20

Maximum motor voltage limit enable flag(is only used with DC motor).

7.1.2.39 #define ENGINE_MAX_SPEED 0x04

Max speed flag.

If it is set, engine uses maximum speed achievable with the present engine settings as nominal speed.

7.1.2.40 #define ENGINE_REVERSE 0x01

Reverse flag.

It determines motor shaft rotation direction that corresponds to feedback counts increasing. If not set (default), motor shaft rotation direction under positive voltage corresponds to feedback counts increasing and vice versa. Change it if you see that positive directions on motor and feedback are opposite.

7.1.2.41 #define ENGINE_TYPE_2DC 0x02

2 DC motors.

7.1.2.42 #define ENGINE_TYPE_BRUSHLESS 0x05

Brushless motor.

7.1.2.43 #define ENGINE_TYPE_DC 0x01

DC motor.

7.1.2.44 #define ENGINE_TYPE_NONE 0x00

A value that shouldn't be used.

7.1.2.45 #define ENGINE_TYPE_STEP 0x03

Step motor.

7.1.2.46 #define ENGINE_TYPE_TEST 0x04

Duty cycle are fixed.

Used only manufacturer.

7.1.2.47 #define ENUMERATE_PROBE 0x01

Check if a device with OS name name is XIMC device.

Be carefuyl with this flag because it sends some data to the device.

7.1.2.48 #define EXTIO_SETUP_INVERT 0x02

Interpret EXTIO states and fronts inverted if flag is set.

Falling front as input event and low logic level as active state.

7.1.2.49 #define EXTIO_SETUP_MODE_IN_ALARM 0x05

Set Alarm when the signal goes to the active state.

7.1.2.50 #define EXTIO_SETUP_MODE_IN_BITS 0x0F

Bits of the behaviour selector when the signal on input goes to the active state.

7.1.2.51 #define EXTIO_SETUP_MODE_IN_HOME 0x04

Issue HOME command.

7.1.2.52 #define EXTIO_SETUP_MODE_IN_MOVR 0x03

Issue MOVR command with last used settings.

7.1.2.53 #define EXTIO_SETUP_MODE_IN_NOP 0x00

Do nothing.

7.1.2.54 #define EXTIO_SETUP_MODE_IN_PWOFF 0x02

Issue PWOFF command, powering off all engine windings.

7.1.2.55 `#define EXTIO_SETUP_MODE_IN_STOP 0x01`

Issue STOP command, ceasing the engine movement.

7.1.2.56 `#define EXTIO_SETUP_MODE_OUT_ALARM 0x30`

EXTIO pin stays active during Alarm state.

7.1.2.57 `#define EXTIO_SETUP_MODE_OUT_BITS 0xF0`

Bits of the output behaviour selection.

7.1.2.58 `#define EXTIO_SETUP_MODE_OUT_MOTOR_ON 0x40`

EXTIO pin stays active when windings are powered.

7.1.2.59 `#define EXTIO_SETUP_MODE_OUT_MOVING 0x20`

EXTIO pin stays active during moving state.

7.1.2.60 `#define EXTIO_SETUP_MODE_OUT_OFF 0x00`

EXTIO pin always set in inactive state.

7.1.2.61 `#define EXTIO_SETUP_MODE_OUT_ON 0x10`

EXTIO pin always set in active state.

7.1.2.62 `#define EXTIO_SETUP_OUTPUT 0x01`

EXTIO works as output if flag is set, works as input otherwise.

7.1.2.63 `#define FEEDBACK_EMF 0x04`

Feedback by EMF.

7.1.2.64 `#define FEEDBACK_ENC_REVERSE 0x01`

Reverse count of encoder.

7.1.2.65 `#define FEEDBACK_ENC_TYPE_AUTO 0x00`

Auto detect encoder type.

7.1.2.66 `#define FEEDBACK_ENC_TYPE_BITS 0xC0`

Bits of the encoder type.

7.1.2.67 `#define FEEDBACK_ENC_TYPE_DIFFERENTIAL 0x80`

Differential encoder.

7.1.2.68 `#define FEEDBACK_ENC_TYPE_SINGLE_ENDED 0x40`

Single ended encoder.

7.1.2.69 `#define FEEDBACK_ENCODER 0x01`

Feedback by encoder.

7.1.2.70 `#define FEEDBACK_ENCODER_MEDIATED 0x06`

Feedback by encoder mediated by mechanical transmission (for example leadscrew).

7.1.2.71 `#define FEEDBACK_NONE 0x05`

Feedback is absent.

7.1.2.72 `#define H_BRIDGE_ALERT 0x04`

If this flag is set then turn off the power unit with a signal problem in one of the transistor bridge.

7.1.2.73 `#define HOME_DIR_FIRST 0x001`

Flag defines direction of 1st motion after execution of home command.

Direction is right, if set; otherwise left.

7.1.2.74 `#define HOME_DIR_SECOND 0x002`

Flag defines direction of 2nd motion.

Direction is right, if set; otherwise left.

7.1.2.75 `#define HOME_HALF_MV 0x008`

If the flag is set, the stop signals are ignored in start of second movement the first half-turn.

7.1.2.76 `#define HOME_MV_SEC_EN 0x004`

Use the second phase of calibration to the home position, if set; otherwise the second phase is skipped.

7.1.2.77 `#define HOME_STOP_FIRST_BITS 0x030`

Bits of the first stop selector.

7.1.2.78 #define HOME_STOP_FIRST_LIM 0x030

First motion stops by limit switch.

7.1.2.79 #define HOME_STOP_FIRST_REV 0x010

First motion stops by revolution sensor.

7.1.2.80 #define HOME_STOP_FIRST_SYN 0x020

First motion stops by synchronization input.

7.1.2.81 #define HOME_STOP_SECOND_BITS 0x0C0

Bits of the second stop selector.

7.1.2.82 #define HOME_STOP_SECOND_LIM 0x0C0

Second motion stops by limit switch.

7.1.2.83 #define HOME_STOP_SECOND_REV 0x040

Second motion stops by revolution sensor.

7.1.2.84 #define HOME_STOP_SECOND_SYN 0x080

Second motion stops by synchronization input.

7.1.2.85 #define HOME_USE_FAST 0x100

Use the fast algorithm of calibration to the home position, if set; otherwise the traditional algorithm.

7.1.2.86 #define JOY_REVERSE 0x01

Joystick action is reversed.

Joystick deviation to the upper values correspond to negative speeds and vice versa.

7.1.2.87 #define LOW_UPWR_PROTECTION 0x02

If this flag is set turn off motor when voltage is lower than LowUpwrOff.

7.1.2.88 #define MICROSTEP_MODE_FRAC_128 0x08

1/128 step mode.

7.1.2.89 #define MICROSTEP_MODE_FRAC_16 0x05

1/16 step mode.

7.1.2.90 #define MICROSTEP_MODE_FRAC_2 0x02

1/2 step mode.

7.1.2.91 #define MICROSTEP_MODE_FRAC_256 0x09

1/256 step mode.

7.1.2.92 #define MICROSTEP_MODE_FRAC_32 0x06

1/32 step mode.

7.1.2.93 #define MICROSTEP_MODE_FRAC_4 0x03

1/4 step mode.

7.1.2.94 #define MICROSTEP_MODE_FRAC_64 0x07

1/64 step mode.

7.1.2.95 #define MICROSTEP_MODE_FRAC_8 0x04

1/8 step mode.

7.1.2.96 #define MICROSTEP_MODE_FULL 0x01

Full step mode.

7.1.2.97 #define MOVE_STATE_ANTIPLAY 0x04

Motor is playing compensation, if flag set.

7.1.2.98 #define MOVE_STATE_MOVING 0x01

This flag indicates that controller is trying to move the motor.

Don't use this flag for waiting of completion of the movement command. Use MVCMD_RUNNING flag from the MvCmdSts field instead.

7.1.2.99 #define MOVE_STATE_TARGET_SPEED 0x02

Target speed is reached, if flag set.

7.1.2.100 #define MVCMD_ERROR 0x40

Finish state (1 - move command have finished with an error, 0 - move command have finished correctly).

This flags is actual when MVCMD_RUNNING signals movement finish.

7.1.2.101 #define MVCMD_HOME 0x06

Command home.

7.1.2.102 #define MVCMD_LEFT 0x03

Command left.

7.1.2.103 #define MVCMD_LOFT 0x07

Command loft.

7.1.2.104 #define MVCMD_MOVE 0x01

Command move.

7.1.2.105 #define MVCMD_MOVR 0x02

Command movr.

7.1.2.106 #define MVCMD_NAME_BITS 0x3F

Move command bit mask.

7.1.2.107 #define MVCMD_RIGHT 0x04

Command rigt.

7.1.2.108 #define MVCMD_RUNNING 0x80

Move command state (0 - move command have finished, 1 - move command is being executed).

7.1.2.109 #define MVCMD_SSTP 0x08

Command soft stop.

7.1.2.110 #define MVCMD_STOP 0x05

Command stop.

7.1.2.111 #define MVCMD_UKNWN 0x00

Unknown command.

7.1.2.112 #define POWER_OFF_ENABLED 0x02

Power off enabled after PowerOffDelay, if this flag is set.

7.1.2.113 #define POWER_REDUCED_ENABLED 0x01

Current reduction enabled after CurrReductDelay, if this flag is set.

7.1.2.114 #define POWER_SMOOTH_CURRENT 0x04

Current ramp-up/down is performed smoothly during current_set_time, if this flag is set.

7.1.2.115 #define PWR_STATE_MAX 0x05

Motor windings are powered by maximum current driver can provide at this voltage.

7.1.2.116 #define PWR_STATE_NORM 0x03

Motor windings are powered by nominal current.

7.1.2.117 #define PWR_STATE_OFF 0x01

Motor windings are disconnected from the driver.

7.1.2.118 #define PWR_STATE_REDUCED 0x04

Motor windings are powered by reduced current to lower power consumption.

7.1.2.119 #define PWR_STATE_UNKNOWN 0x00

Unknown state, should never happen.

7.1.2.120 #define REV_SENS_INV 0x08

Sensor is active when it 0 and invert makes active level 1.

That is, if you do not invert, it is normal logic - 0 is the activation.

7.1.2.121 #define RPM_DIV_1000 0x01

This flag indicates that the operating speed specified in the command is set in milli rpm.

Applicable only for ENCODER feedback mode and only for BLDC motors.

7.1.2.122 #define SETPOS_IGNORE_ENCODER 0x02

Will not reload encoder state if this flag is set.

7.1.2.123 #define SETPOS_IGNORE_POSITION 0x01

Will not reload position in steps/microsteps if this flag is set.

7.1.2.124 #define STATE_ALARM 0x0000040

Controller is in alarm state indicating that something dangerous had happened.

Most commands are ignored in this state. To reset the flag a STOP command must be issued.

7.1.2.125 #define STATE_BORDERS_SWAP_MISSET 0x0008000

Engine stuck at the wrong edge.

7.1.2.126 #define STATE_BRAKE 0x0200

State of Brake pin.

Flag "1" - if the pin state brake is not powered(brake is clamped), "0" - if the pin state brake is powered(brake is unclamped).

7.1.2.127 #define STATE_BUTTON_LEFT 0x0008

Button "left" state (1 if pressed).

7.1.2.128 #define STATE_BUTTON_RIGHT 0x0004

Button "right" state (1 if pressed).

7.1.2.129 #define STATE_CONTR 0x000003F

Flags of controller states.

7.1.2.130 #define STATE_CONTROLLER_OVERHEAT 0x0000200

Controller overheat.

7.1.2.131 #define STATE_CTP_ERROR 0x0000080

Control position error(is only used with stepper motor).

Flag is set when encoder position and step position are too far apart.

7.1.2.132 #define STATE_DIG_SIGNAL 0xFFFF

Flags of digital signals.

7.1.2.133 #define STATE_EEPROM_CONNECTED 0x0000010

EEPROM with settings is connected.

The built-in stage profile is uploaded from the EEPROM memory chip if the EEPROM_PRECEDENCE flag, allowing you to connect various stages to the controller with automatic setup.

7.1.2.134 #define STATE_ENC_A 0x2000

State of encoder A pin.

7.1.2.135 #define STATE_ENC_B 0x4000

State of encoder B pin.

7.1.2.136 #define STATE_ENGINE_RESPONSE_ERROR 0x0800000

Error response of the engine control action.

Motor control algorithm failure means that it can't define the correct decisions with the feedback data it receives. Single failure may be caused by mechanical problem. A repeating failure can be caused by incorrect motor settings.

7.1.2.137 #define STATE_ERRC 0x0000001

Command error encountered.

The command received is not in the list of controller known commands. Most possible reason is the outdated firmware.

7.1.2.138 #define STATE_ERRD 0x0000002

Data integrity error encountered.

The data inside command and its CRC code do not correspond, therefore data can't be considered valid. This error may be caused by EMI in UART/RS232 interface.

7.1.2.139 #define STATE_ERRV 0x0000004

Value error encountered.

The values in the command can't be applied without correction because they fall out the valid range. Corrected values were used instead of the orginal ones.

7.1.2.140 #define STATE_EXTIO_ALARM 0x1000000

The error is caused by the external EXTIO input signal.

7.1.2.141 #define STATE_GPIO_LEVEL 0x0020

State of external GPIO pin.

7.1.2.142 #define STATE_GPIO_PINOUT 0x0010

External GPIO works as Out, if flag set; otherwise works as In.

7.1.2.143 #define STATE_IS_HOMED 0x00000020

Calibration performed.

This meaning that relative position scale is calibrated against a hardware absolute position sensor like a limit switch. Drops after loss of calibration like harsh stop and possibly skipped steps.

7.1.2.144 #define STATE_LEFT_EDGE 0x0002

Engine stuck at the left edge.

7.1.2.145 #define STATE_LOW_USB_VOLTAGE 0x0002000

USB voltage is insufficient for normal operation.

7.1.2.146 #define STATE_OVERLOAD_POWER_CURRENT 0x0000800

Power current exceeds safe limit.

7.1.2.147 #define STATE_OVERLOAD_POWER_VOLTAGE 0x0000400

Power voltage exceeds safe limit.

7.1.2.148 #define STATE_OVERLOAD_USB_CURRENT 0x0004000

USB current exceeds safe limit.

7.1.2.149 #define STATE_OVERLOAD_USB_VOLTAGE 0x0001000

USB voltage exceeds safe limit.

7.1.2.150 #define STATE_POWER_OVERHEAT 0x0000100

Power driver overheat.

Motor control is disabled until some cooldown. This should not happen in boxed versions of controller. This may happen in bare board version of controller with a custom radiator. Redesign your radiator then.

7.1.2.151 #define STATE_REV_SENSOR 0x0400

State of Revolution sensor pin.

7.1.2.152 #define STATE_RIGHT_EDGE 0x0001

Engine stuck at the right edge.

7.1.2.153 #define STATE_SECUR 0x1B3FFC0

Flags of security.

7.1.2.154 #define STATE_SYNC_INPUT 0x0800

State of Sync input pin.

7.1.2.155 #define STATE_SYNC_OUTPUT 0x1000

State of Sync output pin.

7.1.2.156 #define STATE_WINDING_RES_MISMATCH 0x0100000

The difference between winding resistances is too large.

This usually happens with a damaged stepper motor with partially short-circuited windings.

7.1.2.157 #define SYNCIN_ENABLED 0x01

Synchronization in mode is enabled, if this flag is set.

7.1.2.158 #define SYNCIN_GOTOPOSITION 0x04

The engine is go to position specified in Position and uPosition, if this flag is set.

And it is shift on the Position and uPosition, if this flag is unset

7.1.2.159 #define SYNCIN_INVERT 0x02

Trigger on falling edge if flag is set, on rising edge otherwise.

7.1.2.160 #define SYNCOUT_ENABLED 0x01

Synchronization out pin follows the synchronization logic, if set.

It governed by SYNCOUT_STATE flag otherwise.

7.1.2.161 #define SYNCOUT_IN_STEPS 0x08

Use motor steps/encoder pulses instead of milliseconds for output pulse generation if the flag is set.

7.1.2.162 #define SYNCOUT_INVERT 0x04

Low level is active, if set, and high level is active otherwise.

7.1.2.163 #define SYNCOUT_ONPERIOD 0x40

Generate synchronization pulse every SyncOutPeriod encoder pulses.

7.1.2.164 #define SYNCOUT_ONSTART 0x10

Generate synchronization pulse when movement starts.

7.1.2.165 #define SYNCOUT_ONSTOP 0x20

Generate synchronization pulse when movement stops.

7.1.2.166 #define SYNCOUT_STATE 0x02

When output state is fixed by negative SYNCOUT_ENABLED flag, the pin state is in accordance with this flag state.

7.1.2.167 #define UART_PARITY_BITS 0x03

Bits of the parity.

7.1.2.168 #define WIND_A_STATE_ABSENT 0x00

Winding A is disconnected.

7.1.2.169 #define WIND_A_STATE_MALFUNC 0x02

Winding A is short-circuited.

7.1.2.170 #define WIND_A_STATE_OK 0x03

Winding A is connected and working properly.

7.1.2.171 #define WIND_A_STATE_UNKNOWN 0x01

Winding A state is unknown.

7.1.2.172 #define WIND_B_STATE_ABSENT 0x00

Winding B is disconnected.

7.1.2.173 #define WIND_B_STATE_MALFUNC 0x20

Winding B is short-circuited.

7.1.2.174 #define WIND_B_STATE_OK 0x30

Winding B is connected and working properly.

7.1.2.175 #define WIND_B_STATE_UNKNOWN 0x10

Winding B state is unknown.

7.1.2.176 #define XIMC_API

Library import macro.

Macros allows to automatically import function from shared library. It automatically expands to `dllimport` on msvc when including header file.

7.1.3 Typedef Documentation

7.1.3.1 `typedef void(XIMC_CALLCONV * logging_callback_t)(int loglevel, const wchar_t *message, void *user_data)`

Logging callback prototype.

Parameters

<i>loglevel</i>	a loglevel
<i>message</i>	a message

7.1.4 Function Documentation

7.1.4.1 `result_t XIMC_API close_device (device_t * id)`

Close specified device.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

Note

The *id* parameter in this function is a C pointer, unlike most library functions that use this parameter

7.1.4.2 `result_t XIMC_API command_clear_fram (device_t id)`

Clear controller FRAM.

Can be used by manufacturer only

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.3 `result_t XIMC_API command_eeread_settings (device_t id)`

Read settings from controller's RAM to stage's EEPROM memory, which spontaneously connected to stage and it isn't change without its mechanical reconstruction.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.4 **result_t XIMC_API command_eesave_settings (device_t id)**

Save settings from controller's RAM to stage's EEPROM memory, which spontaneity connected to stage and it isn't change without its mechanical reconstruction.

Can be used by manufacturer only.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.5 **result_t XIMC_API command_home (device_t id)**

The positive direction is to the right.

A value of zero reverses the direction of the flag, the set speed. Restriction imposed by the trailer, act the same, except that the limit switch contact does not stop. Limit the maximum speed, acceleration and deceleration function. 1) moves the motor according to the speed FastHome, uFastHome and flag HOME_DIR_FAST until limit switch, if the flag is set HOME_STOP_ENDS, until the signal from the input synchronization if the flag HOME_STOP_SYNC (as accurately as possible is important to catch the moment of operation limit switch) or until the signal is received from the speed sensor, if the flag HOME_STOP_REV_SN 2) then moves according to the speed SlowHome, uSlowHome and flag HOME_DIR_SLOW until signal from the clock input, if the flag HOME_MV_SEC. If the flag HOME_MV_SEC is reset skip this paragraph. 3) then move the motor according to the speed FastHome, uFastHome and flag HOME_DIR_SLOW a distance HomeDelta, uHomeDelta. description of flags and variable see in description for commands GHOM/SHOM

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

See Also

[home_settings.t](#)
[get_home_settings](#)
[set_home_settings](#)

7.1.4.6 **result_t XIMC_API command_homezero (device_t id)**

Make home command, wait until it is finished and make zero command.

This is a convenient way to calibrate zero position.

Parameters

	<i>id</i>	an identifier of device
<i>out</i>	<i>ret</i>	RESULT_OK if controller has finished home & zero correctly or result of first controller query that returned anything other than RESULT_OK.

7.1.4.7 **result_t XIMC_API command_left (device_t id)**

Start continuous moving to the left.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.8 **result_t XIMC_API command_loft (device_t id)**

Upon receiving the command "loft" the engine is shifted from the current point to a distance GENG :: Antiplay, then move to the same point.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.9 **result_t XIMC_API command_move (device_t id, int Position, int uPosition)**

Upon receiving the command "move" the engine starts to move with pre-set parameters (speed, acceleration, retention), to the point specified to the Position, uPosition.

For stepper motor uPosition sets the microstep, for DC motor this field is not used.

Parameters

<i>id</i>	an identifier of device
<i>Position</i>	position to move.
<i>uPosition</i>	part of the position to move, microsteps. Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine-settings).

7.1.4.10 **result_t XIMC_API command_move_calb (device_t id, float Position, const calibration_t * calibration)**

Move to position which use user units.

Upon receiving the command "move" the engine starts to move with pre-set parameters (speed, acceleration, retention), to the point specified to the Position.

Parameters

<i>id</i>	an identifier of device
<i>Position</i>	position to move.
<i>calibration</i>	user unit settings

Note

The parameter Position is adjusted by the correction table.

7.1.4.11 **result_t XIMC_API command_movr (device_t id, int DeltaPosition, int uDeltaPosition)**

Move to offset.

Upon receiving the command "movr" engine starts to move with pre-set parameters (speed, acceleration, hold), left or right (depending on the sign of DeltaPosition) by the number of pulses specified in the fields DeltaPosition, uDeltaPosition. For stepper motor uDeltaPosition sets the microstep, for DC motor this field is not used.

Parameters

<i>DeltaPosition</i>	shift from initial position.
<i>uDeltaPosition</i>	part of the offset shift, microsteps. Microstep size and the range of valid values for this field depend on selected step division mode (see MicrostepMode field in engine_settings).
<i>id</i>	an identifier of device

7.1.4.12 **result_t XIMC_API** command_movr_cab (**device_t id**, float DeltaPosition, const **calibration_t** * calibration)

Move to offset using user units.

Upon receiving the command "movr" engine starts to move with pre-set parameters (speed, acceleration, hold), left or right (depending on the sign of DeltaPosition) the distance specified in the field DeltaPosition.

Parameters

<i>DeltaPosition</i>	shift from initial position.
<i>id</i>	an identifier of device
<i>calibration</i>	user unit settings

Note

The end coordinate is calculated using DeltaPosition, is adjusted by the correction table. To calculate coordinates correctly, when using a correction table, you do not need to execute movr commands in batches.

7.1.4.13 **result_t XIMC_API** command_power_off (**device_t id**)

Immediately power off motor regardless its state.

Shouldn't be used during motion as the motor could be power on again automatically to continue movement. The command is designed for manual motor power off. When automatic power off after stop is required, use power management system.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

See Also

[get_power_settings](#)
[set_power_settings](#)

7.1.4.14 **result_t XIMC_API** command_read_robust_settings (**device_t id**)

Read important settings (calibration coefficients and etc.) from controller's flash memory to controller's RAM, replacing previous data in controller's RAM.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.15 **result_t XIMC_API command_read_settings (device_t id)**

Read all settings from controller's flash memory to controller's RAM, replacing previous data in controller's RAM.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.16 **result_t XIMC_API command_reset (device_t id)**

Reset controller.

Can be used by manufacturer only

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.17 **result_t XIMC_API command_right (device_t id)**

Start continuous moving to the right.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.18 **result_t XIMC_API command_save_robust_settings (device_t id)**

Save important settings (calibration coefficients and etc.) from controller's RAM to controller's flash memory, replacing previous data in controller's flash memory.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.19 **result_t XIMC_API command_save_settings (device_t id)**

Save all settings from controller's RAM to controller's flash memory, replacing previous data in controller's flash memory.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.20 **result_t XIMC_API command_sstp (device_t id)**

Soft stop engine.

The motor stops with deceleration speed.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.21 **result_t XIMC_API command_start_measurements (device_t id)**

Start measurements and buffering of speed, following error.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.22 **result_t XIMC_API command_stop (device_t id)**

Immediately stop the engine, the transition to the STOP, mode key BREAK (winding short-circuited), the regime "retention" is deactivated for DC motors, keeping current in the windings for stepper motors (with Power management settings).

When this command is called, the ALARM flag is reset.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.23 **result_t XIMC_API command_update_firmware (const char * uri, const uint8_t * data, uint32_t data_size)**

Update firmware.

Service command

Parameters

<i>uri</i>	a uri of device
<i>data</i>	firmware byte stream
<i>data_size</i>	size of byte stream

7.1.4.24 **result_t XIMC_API command_wait_for_stop (device_t id, uint32_t refresh_interval_ms)**

Wait for stop.

Parameters

	<i>id</i>	an identifier of device
	<i>refresh_interval_ms</i>	Status refresh interval. The function waits this number of milliseconds between get_status requests to the controller. Recommended value of this parameter is 10 ms. Use values of less than 3 ms only when necessary - small refresh interval values do not significantly increase response time of the function, but they create substantially more traffic in controller-computer data channel.
<i>out</i>	<i>ret</i>	RESULT_OK if controller has stopped and result of the first get_status command which returned anything other than RESULT_OK otherwise.

7.1.4.25 **result_t XIMC_API command_zero (device_t id)**

Sets the current position and the position in which the traffic moves by the move command and movr zero for all cases, except for movement to the target position.

In the latter case, set the zero current position and the target position counted so that the absolute position of the destination is the same. That is, if we were at 400 and moved to 500, then the command Zero makes the current position of 0, and the position of the destination - 100. Does not change the mode of movement that is if the motion is carried, it continues, and if the engine is in the "hold", the type of retention remains.

Parameters

<i>id</i>	an identifier of device
-----------	-------------------------

7.1.4.26 **device_enumeration_t XIMC_API enumerate_devices (int enumerate_flags, const char * hints)**

Enumerate all devices that looks like valid.

Parameters

in	<i>enumerate_flags</i>	enumerate devices flags
in	<i>hints</i>	extended information

hints is a string of form "key=value \n key2=value2". *Unrecognized key-value pairs are ignored*. Key list: *addr* - used together with ENUMERATE_NETWORK flag. Non-null value is a remote host name or a comma-separated list of host names which contain the devices to be found, absent value means broadcast discovery. *adapter_addr* - used together with ENUMERATE_NETWORK flag. Non-null value is a IP address of network adapter. Remote ximc device must be on the same local network as the adapter. When using the *adapter_addr* key, you **must set** the *addr* key. Example: "addr= \n adapter_addr=192.168.0.100".

7.1.4.27 **result_t XIMC_API free_enumerate_devices (device_enumeration_t device_enumeration)**

Free memory returned by *enumerate_devices*.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
----	---------------------------	--

7.1.4.28 **result_t XIMC_API get_accessories_settings (device_t id, accessories_settings_t * accessories_settings)**

Read additional accessories information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>accessories_settings</i>	structure contains information about additional accessories

7.1.4.29 **result_t XIMC_API** get_analog_data (**device_t id**, **analog_data_t * analog_data**)

Read analog data structure that contains raw analog data from ADC embedded on board.

This function used for device testing and deep recalibration by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
out	<i>analog_data</i>	analog data coefficients

7.1.4.30 **result_t XIMC_API** get_bootloader_version (**device_t id**, **unsigned int * Major**, **unsigned int * Minor**, **unsigned int * Release**)

Read controller's firmware version.

Parameters

	<i>id</i>	an identifier of device
out	<i>Major</i>	major version
out	<i>Minor</i>	minor version
out	<i>Release</i>	release version

7.1.4.31 **result_t XIMC_API** get_brake_settings (**device_t id**, **brake_settings_t * brake_settings**)

Read settings of brake control.

Parameters

	<i>id</i>	an identifier of device
out	<i>brake_settings</i>	structure contains settings of brake control

7.1.4.32 **result_t XIMC_API** get_calibration_settings (**device_t id**, **calibration_settings_t * calibration_settings**)

Read calibration settings.

This function fill structure with calibration settings.

See Also

[calibration_settings_t](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>calibration_settings</i>	calibration settings

7.1.4.33 **result_t XIMC_API** get_chart_data (**device_t id**, **chart_data_t * chart_data**)

Return device electrical parameters, useful for charts.

Useful function that fill structure with snapshot of controller voltages and currents.

See Also

[chart_data_t](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>chart_data</i>	structure with snapshot of controller parameters.

7.1.4.34 **result_t XIMC_API get_control_settings (device_t id, control_settings_t * control_settings)**

Read settings of motor control.

When choosing CTL_MODE = 1 switches motor control with the joystick. In this mode, the joystick to the maximum engine tends Move at MaxSpeed [i], where i = 0 if the previous use This mode is not selected another i. Buttons switch the room rate i. When CTL_MODE = 2 is switched on motor control using the Left / right. When you click on the button motor starts to move in the appropriate direction at a speed MaxSpeed [0], at the end of time Timeout [i] motor move at a speed MaxSpeed [i+1]. at Transition from MaxSpeed [i] on MaxSpeed [i +1] to acceleration, as usual.

Parameters

	<i>id</i>	an identifier of device
out	<i>control_settings</i>	structure contains settings motor control by joystick or buttons left/right.

7.1.4.35 **result_t XIMC_API get_control_settings_calb (device_t id, control_settings_calb_t * control_settings_calb, const calibration_t * calibration)**

Read settings of motor control which use user units.

When choosing CTL_MODE = 1 switches motor control with the joystick. In this mode, the joystick to the maximum engine tends Move at MaxSpeed [i], where i = 0 if the previous use This mode is not selected another i. Buttons switch the room rate i. When CTL_MODE = 2 is switched on motor control using the Left / right. When you click on the button motor starts to move in the appropriate direction at a speed MaxSpeed [0], at the end of time Timeout [i] motor move at a speed MaxSpeed [i+1]. at Transition from MaxSpeed [i] on MaxSpeed [i +1] to acceleration, as usual.

Parameters

	<i>id</i>	an identifier of device
out	<i>control_settings_calb</i>	structure contains settings motor control by joystick or buttons left/right.
	<i>calibration</i>	user unit settings

7.1.4.36 **result_t XIMC_API get_controller_name (device_t id, controller_name_t * controller_name)**

Read user controller name and flags of setting from FRAM.

Parameters

	<i>id</i>	an identifier of device
out	<i>controller_name</i>	structure contains previously set user controller name

7.1.4.37 **result_t XIMC_API** get_ctp_settings (**device_t id**, **ctp_settings_t * ctp_settings**)

Read settings of control position(is only used with stepper motor).

When controlling the step motor with encoder (CTP_BASE 0) it is possible to detect the loss of steps. The controller knows the number of steps per revolution (GENG :: StepsPerRev) and the encoder resolution (GFBS :: IPT). When the control (flag CTP_ENABLED), the controller stores the current position in the footsteps of SM and the current position of the encoder. Further, at each step of the position encoder is converted into steps and if the difference is greater CTPMinError, a flag STATE_CTP_ERROR. When controlling the step motor with speed sensor (CTP_BASE 1), the position is controlled by him. The active edge of input clock controller stores the current value of steps. Further, at each turn checks how many steps shifted. When a mismatch CTPMinError a flag STATE_CTP_ERROR.

Parameters

	<i>id</i>	an identifier of device
out	<i>ctp_settings</i>	structure contains settings of control position

7.1.4.38 **result_t XIMC_API** get_debug_read (**device_t id**, **debug_read_t * debug_read**)

Read data from firmware for debug purpose.

Its use depends on context, firmware version and previous history.

Parameters

	<i>id</i>	an identifier of device
out	<i>debug_read</i>	Debug data.

7.1.4.39 **int XIMC_API** get_device_count (**device_enumeration_t device_enumeration**)

Get device count.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
----	---------------------------	--

7.1.4.40 **result_t XIMC_API** get_device_information (**device_t id**, **device_information_t * device_information**)

Return device information.

All fields must point to allocated string buffers with at least 10 bytes. Works with both raw or initialized device.

Parameters

	<i>id</i>	an identifier of device
out	<i>device_information</i>	device information Device information.

See Also

[get_device_information](#)

7.1.4.41 **pchar XIMC_API** get_device_name (**device_enumeration_t** device_enumeration, **int** device_index)

Get device name from the device enumeration.

Returns *device_index* device name.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index

7.1.4.42 **result_t XIMC_API** get_edges_settings (**device_t** id, **edges_settings_t** * edges_settings)

Read border and limit switches settings.

See Also

[set.edges.settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>edges_settings</i>	edges settings, specify types of borders, motor behaviour and electrical behaviour of limit switches

7.1.4.43 **result_t XIMC_API** get_edges_settings_calb (**device_t** id, **edges_settings_calb_t** * edges_settings_calb, **const calibration_t** * calibration)

Read border and limit switches settings which use user units.

See Also

[set.edges.settings.calb](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>edges_settings_calb</i>	edges settings, specify types of borders, motor behaviour and electrical behaviour of limit switches
	<i>calibration</i>	user unit settings

Note

Attention! Some parameters of the edges_settings_calb structure are corrected by the coordinate correction table.

7.1.4.44 **result_t XIMC_API** get_emf_settings (**device_t id**, **emf_settings_t * emf_settings**)

Read electromechanical settings.

The settings are different for different stepper motors.

See Also

[set_emf_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>emf_settings</i>	EMF settings

7.1.4.45 **result_t XIMC_API** get_encoder_information (**device_t id**, **encoder_information_t * encoder_information**)

Read encoder information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>encoder_-information</i>	structure contains information about encoder

7.1.4.46 **result_t XIMC_API** get_encoder_settings (**device_t id**, **encoder_settings_t * encoder_settings**)

Read encoder settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>encoder_-settings</i>	structure contains encoder settings

7.1.4.47 **result_t XIMC_API** get_engine_advansed_setup (**device_t id**, **engine_advansed_setup_t * engine_advansed_setup**)

Read engine advansed settings.

See Also

[set_engine_advansed_setup](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>engine_-advansed_setup</i>	EAS settings

7.1.4.48 **result_t XIMC_API** get_engine_settings (**device_t id**, **engine_settings_t * engine_settings**)

Read engine settings.

This function fill structure with set of useful motor settings stored in controller's memory. These settings specify motor shaft movement algorithm, list of limitations and rated characteristics.

See Also

[set_engine_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>engine_settings</i>	engine settings

7.1.4.49 **result_t XIMC_API** get_engine_settings_calb (**device_t id**, **engine_settings_calb_t * engine_settings_calb**, **const calibration_t * calibration**)

Read engine settings which use user units.

This function fill structure with set of useful motor settings stored in controller's memory. These settings specify motor shaft movement algorithm, list of limitations and rated characteristics.

See Also

[set_engine_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>engine_settings_calb</i>	engine settings
	<i>calibration</i>	user unit settings

7.1.4.50 **result_t XIMC_API** get_entype_settings (**device_t id**, **entype_settings_t * entype_settings**)

Return engine type and driver type.

Parameters

	<i>id</i>	an identifier of device
out	<i>entype_settings</i>	structure contains settings motor type and power driver type

7.1.4.51 **result_t XIMC_API** get_enumerate_device_controller_name (**device_enumeration_t device_enumeration**, **int device_index**, **controller_name_t * controller_name**)

Get controller name from the device enumeration.

Returns *device_index* device controller name.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index
out	<i>controller_name</i>	controller name

7.1.4.52 **result_t XIMC_API** get_enumerate_device_information (**device_enumeration_t** device_enumeration, int device_index, **device_information_t** * device_information)

Get device information from the device enumeration.

Returns *device_index* device information.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index
out	<i>device_information</i>	device information data

7.1.4.53 **result_t XIMC_API** get_enumerate_device_network_information (**device_enumeration_t** device_enumeration, int device_index, **device_network_information_t** * device_network_information)

Get device network information from the device enumeration.

Returns *device_index* device network information.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index
out	<i>device_network_information</i>	device network information data

7.1.4.54 **result_t XIMC_API** get_enumerate_device_serial (**device_enumeration_t** device_enumeration, int device_index, uint32_t * serial)

Get device serial number from the device enumeration.

Returns *device_index* device serial number.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index
out	<i>serial</i>	device serial number

7.1.4.55 **result_t XIMC_API** get_enumerate_device_stage_name (**device_enumeration_t** device_enumeration, int device_index, **stage_name_t** * stage_name)

Get stage name from the device enumeration.

Returns *device_index* device stage name.

Parameters

in	<i>device_enumeration</i>	opaque pointer to an enumeration device data
in	<i>device_index</i>	device index
out	<i>stage_name</i>	stage name

7.1.4.56 **result_t XIMC_API** get_extended_settings (**device_t** id, **extended_settings_t** * extended_settings)

Read extended settings.

Currently not in use.

See Also

[set_extended_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>extended_settings</i>	EST settings

7.1.4.57 **result_t XIMC_API** get_extio_settings (**device_t** id, **extio_settings_t** * extio_settings)

Read EXTIO settings.

This function reads a structure with a set of EXTIO settings from controller's memory.

See Also

[set_extio_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>extio_settings</i>	EXTIO settings

7.1.4.58 **result_t XIMC_API** get_feedback_settings (**device_t** id, **feedback_settings_t** * feedback_settings)

Feedback settings.

Parameters

	<i>id</i>	an identifier of device
--	-----------	-------------------------

out	<i>IPS</i>	number of encoder counts per shaft revolution. Range: 1..65535. The field is obsolete, it is recommended to write 0 to IPS and use the extended CountsPerTurn field. You may need to update the controller firmware to the latest version.
out	<i>FeedbackType</i>	type of feedback
out	<i>FeedbackFlags</i>	flags of feedback
out	<i>CountsPerTurn</i>	number of encoder counts per shaft revolution. Range: 1..4294967295. To use the CountsPerTurn field, write 0 in the IPS field, otherwise the value from the IPS field will be used.

7.1.4.59 **result_t XIMC_API get_firmware_version (device_t id, unsigned int * Major, unsigned int * Minor, unsigned int * Release)**

Read controller's firmware version.

Parameters

	<i>id</i>	an identifier of device
out	<i>Major</i>	major version
out	<i>Minor</i>	minor version
out	<i>Release</i>	release version

7.1.4.60 **result_t XIMC_API get_gear_information (device_t id, gear_information_t * gear_information)**

Read gear information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>gear-information</i>	structure contains information about step gearhead

7.1.4.61 **result_t XIMC_API get_gear_settings (device_t id, gear_settings_t * gear_settings)**

Read gear settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>gear-settings</i>	structure contains step gearhead settings

7.1.4.62 **result_t XIMC_API get_globally_unique_identifier (device_t id, globally_unique_identifier_t * globally_unique_identifier)**

This value is unique to each individual die but is not a random value.

This unique device identifier can be used to initiate secure boot processes or as a serial number for USB or other end applications.

Parameters

	<i>id</i>	an identifier of device
out	<i>globally_unique_identifier</i>	the result of fields 0-3 concatenated defines the unique 128-bit device identifier.

7.1.4.63 **result_t XIMC_API** get_hallsensor_information (**device_t id, hallsensor_information_t * hallsensor_information**)

Read hall sensor information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>hallsensor_information</i>	structure contains information about hall sensor

7.1.4.64 **result_t XIMC_API** get_hallsensor_settings (**device_t id, hallsensor_settings_t * hallsensor_settings**)

Read hall sensor settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>hallsensor_settings</i>	structure contains hall sensor settings

7.1.4.65 **result_t XIMC_API** get_home_settings (**device_t id, home_settings_t * home_settings**)

Read home settings.

This function fill structure with settings of calibrating position.

See Also

[home_settings.t](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>home_settings</i>	calibrating position settings

7.1.4.66 **result_t XIMC_API** get_home_settings_calb (**device_t id, home_settings_calb_t * home_settings_calb, const calibration_t * calibration**)

Read home settings which use user units.

This function fill structure with settings of calibrating position.

See Also

[home_settings_calb.t](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>home_settings_- calb</i>	calibrating position settings
	<i>calibration</i>	user unit settings

7.1.4.67 **result_t XIMC_API get_init_random (device_t id, init_random_t * init_random)**

Read random number from controller.

Parameters

	<i>id</i>	an identifier of device
out	<i>init_random</i>	random sequence generated by the controller

7.1.4.68 **result_t XIMC_API get_joystick_settings (device_t id, joystick_settings_t * joystick_settings)**

Read settings of joystick.

If joystick position is outside DeadZone limits from the central position a movement with speed, defined by the joystick DeadZone edge to 100% deviation, begins. Joystick positions inside DeadZone limits correspond to zero speed (soft stop of motion) and positions beyond Low and High limits correspond MaxSpeed [i] or -MaxSpeed [i] (see command SCTL), where i = 0 by default and can be changed with left/right buttons (see command SCTL). If next speed in list is zero (both integer and microstep parts), the button press is ignored. First speed in list shouldn't be zero. The DeadZone ranges are illustrated on the following picture. !/attachments/download/5563/range25p.png! The relationship between the deviation and the rate is exponential, allowing no switching speed combine high mobility and accuracy. The following picture illustrates this: !/attachments/download/3092/ExpJoystick.png! The nonlinearity parameter is adjustable. Setting it to zero makes deviation/speed relation linear.

Parameters

	<i>id</i>	an identifier of device
out	<i>joystick_- settings</i>	structure contains joystick settings

7.1.4.69 **result_t XIMC_API get_measurements (device_t id, measurements_t * measurements)**

A command to read the data buffer to build a speed graph and a sequence error.

Filling the buffer starts with the command "start_measurements". The buffer holds 25 points, the points are taken with a period of 1 ms. To create a robust system, read data every 20 ms, if the buffer is completely full, then it is recommended to repeat the readings every 5 ms until the buffer again becomes filled with 20 points.

See Also

[measurements_t](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>measurements</i>	structure with buffer and its length.

7.1.4.70 **result_t XIMC_API** get_motor_information (**device_t** id, **motor_information_t** * motor_information)

Read motor information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>motor_information</i>	structure contains motor information

7.1.4.71 **result_t XIMC_API** get_motor_settings (**device_t** id, **motor_settings_t** * motor_settings)

Read motor settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>motor_settings</i>	structure contains motor settings

7.1.4.72 **result_t XIMC_API** get_move_settings (**device_t** id, **move_settings_t** * move_settings)

Read command setup movement (speed, acceleration, threshold and etc).

Parameters

	<i>id</i>	an identifier of device
out	<i>move_settings</i>	structure contains move settings: speed, acceleration, deceleration etc.

7.1.4.73 **result_t XIMC_API** get_move_settings_calb (**device_t** id, **move_settings_calb_t** * move_settings_calb, const **calibration_t** * calibration)

Read command setup movement which use user units (speed, acceleration, threshold and etc).

Parameters

	<i>id</i>	an identifier of device
out	<i>move_settings_calb</i>	structure contains move settings: speed, acceleration, deceleration etc.
	<i>calibration</i>	user unit settings

7.1.4.74 **result_t XIMC_API** get_network_settings (**device_t** id, **network_settings_t** * network_settings)

Read network settings.

This function returns current network settings.

See Also

[net_settings_t](#)

Parameters

<i>DHCP-Enabled[4]</i>	DHCP enabled (1) or not (0)
<i>IPv4Address[4]</i>	Array[4] with IP address
<i>SubnetMask[4]</i>	Array[4] with subnet mask address
<i>Default-Gateway[4]</i>	Array[4] with default gateway address

7.1.4.75 **result_t XIMC_API get_nonvolatile_memory (device_t id, nonvolatile_memory_t * nonvolatile_memory)**

Read userdata from FRAM.

Parameters

	<i>id</i>	an identifier of device
<i>out</i>	<i>nonvolatile_memory</i>	structure contains previously set userdata

7.1.4.76 **result_t XIMC_API get_password_settings (device_t id, password_settings_t * password_settings)**

Read password settings.

This function reads user password to the device web-page.

See Also

[pwd_settings_t](#)

Parameters

<i>User-Password[20]</i>	Password-string to web-page
--------------------------	-----------------------------

7.1.4.77 **result_t XIMC_API get_pid_settings (device_t id, pid_settings_t * pid_settings)**

Read PID settings.

This function fill structure with set of motor PID settings stored in controller's memory. These settings specify behaviour of PID routine for positioner. These factors are slightly different for different positioners. All boards are supplied with standard set of PID setting on controller's flash memory.

See Also

[set_pid_settings](#)

Parameters

	<i>id</i>	an identifier of device
<i>out</i>	<i>pid_settings</i>	pid settings

7.1.4.78 **result_t XIMC_API** get_position (**device_t** id, **get_position_t** * the_get_position)

Reads the value position in steps and micro for stepper motor and encoder steps all engines.

Parameters

	<i>id</i>	an identifier of device
out	<i>the_get_position</i>	structure contains move settings: speed, acceleration, deceleration etc.

7.1.4.79 **result_t XIMC_API** get_position_calb (**device_t** id, **get_position_calb_t** * the_get_position_calb, const **calibration_t** * calibration)

Reads position value in user units for stepper motor and encoder steps all engines.

Parameters

	<i>id</i>	an identifier of device
out	<i>the_get_position_calb</i>	structure contains move settings: speed, acceleration, deceleration etc.
	<i>calibration</i>	user unit settings

Note

Attention! Some parameters of the *the_get_position_calb* structure are corrected by the coordinate correction table.

7.1.4.80 **result_t XIMC_API** get_power_settings (**device_t** id, **power_settings_t** * power_settings)

Read settings of step motor power control.

Used with stepper motor only.

Parameters

	<i>id</i>	an identifier of device
out	<i>power_settings</i>	structure contains settings of step motor power control

7.1.4.81 **result_t XIMC_API** get_secure_settings (**device_t** id, **secure_settings_t** * secure_settings)

Read protection settings.

Parameters

	<i>id</i>	an identifier of device
out	<i>secure_settings</i>	critical parameter settings to protect the hardware

See Also

`status_t::flags`

7.1.4.82 **result_t XIMC_API** get_serial_number (**device_t** id, unsigned int * SerialNumber)

Read device serial number.

Parameters

	<i>id</i>	an identifier of device
out	<i>SerialNumber</i>	serial number

7.1.4.83 **result_t XIMC_API get_stage_information (device_t id, stage_information_t * stage_information)**

Read stage information from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>stage_information</i>	structure contains stage information

7.1.4.84 **result_t XIMC_API get_stage_name (device_t id, stage_name_t * stage_name)**

Read user stage name from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>stage_name</i>	structure contains previously set user stage name

7.1.4.85 **result_t XIMC_API get_stage_settings (device_t id, stage_settings_t * stage_settings)**

Read stage settings from EEPROM.

Parameters

	<i>id</i>	an identifier of device
out	<i>stage_settings</i>	structure contains stage settings

7.1.4.86 **result_t XIMC_API get_status (device_t id, status_t * status)**

Return device state.

Parameters

	<i>id</i>	an identifier of device
out	<i>status</i>	structure with snapshot of controller status Device state. Useful structure that contains current controller status, including speed, position and boolean flags.

See Also

[get_status](#)

7.1.4.87 **result_t XIMC_API** `get_status_calb (device_t id, status_calb_t * status, const calibration_t * calibration)`

Return device state.

Parameters

	<i>id</i>	an identifier of device
out	<i>status</i>	structure with snapshot of controller status
	<i>calibration</i>	user unit settings Calibrated device state. Useful structure that contains current controller status, including speed, position and boolean flags.

See Also

[get_status](#)

7.1.4.88 **result_t XIMC_API** `get_sync_in_settings (device_t id, sync_in_settings_t * sync_in_settings)`

Read input synchronization settings.

This function fill structure with set of input synchronization settings, modes, periods and flags, that specify behaviour of input synchronization. All boards are supplied with standard set of these settings.

See Also

[set_sync_in_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>sync_in_settings</i>	synchronization settings

7.1.4.89 **result_t XIMC_API** `get_sync_in_settings_calb (device_t id, sync_in_settings_calb_t * sync_in_settings_calb, const calibration_t * calibration)`

Read input synchronization settings which use user units.

This function fill structure with set of input synchronization settings, modes, periods and flags, that specify behaviour of input synchronization. All boards are supplied with standard set of these settings.

See Also

[set_sync_in_settings_calb](#)

Parameters

	<i>id</i>	an identifier of device
out	<i>sync_in_settings_calb</i>	synchronization settings
	<i>calibration</i>	user unit settings

7.1.4.90 **result_t XIMC_API** get_sync_out_settings (**device_t id**, **sync_out_settings_t * sync_out_settings**)

Read output synchronization settings.

This function fill structure with set of output synchronization settings, modes, periods and flags, that specify behaviour of output synchronization. All boards are supplied with standard set of these settings.

See Also

[set_sync_out_settings](#)

Parameters

	<i>id</i>	an identifier of device
out	sync_out_settings	synchronization settings

7.1.4.91 **result_t XIMC_API** get_sync_out_settings_calb (**device_t id**, **sync_out_settings_calb_t * sync_out_settings_calb**, **const calibration_t * calibration**)

Read output synchronization settings which use user units.

This function fill structure with set of output synchronization settings, modes, periods and flags, that specify behaviour of output synchronization. All boards are supplied with standard set of these settings.

See Also

[set_sync_in_settings_calb](#)

Parameters

	<i>id</i>	an identifier of device
out	sync_out_settings_calb	synchronization settings
	calibration	user unit settings

7.1.4.92 **result_t XIMC_API** get_uart_settings (**device_t id**, **uart_settings_t * uart_settings**)

Read UART settings.

This function fill structure with UART settings.

See Also

[uart_settings_t](#)

Parameters

	<i>Speed</i>	UART speed
out	uart_settings	UART settings

7.1.4.93 **result_t XIMC_API** goto_firmware (**device_t id**, **uint8_t * ret**)

Reboot to firmware.

Parameters

	<i>id</i>	an identifier of device
out	ret	RESULT_OK, if reboot to firmware is possible. Reboot is done after reply to this command. RESULT_NO_FIRMWARE, if firmware is not found. RESULT_ALREADY_IN_FIRMWARE, if this command was sent when controller is already in firmware.

7.1.4.94 **result_t XIMC_API** has_firmware (**const char * uri**, **uint8_t * ret**)

Check for firmware on device.

Parameters

	<i>uri</i>	a uri of device
out	ret	non-zero if firmware existed

7.1.4.95 **result_t XIMC_API** load_correction_table (**device_t * id**, **const char * namefile**)

Command of loading a correction table from a text file (this function is deprecated).

Use the function [set_correction_table\(device_t id, const char* namefile\)](#). The correction table is used for position correction in case of mechanical inaccuracies. It works for some parameters in _calb commands.

Parameters

	<i>id</i>	an identifier the device
in	namefile	- the file name must be fully qualified. If the short name is used, the file must be located in the application directory. If the file name is set to NULL, the correction table will be cleared. File format: two tab-separated columns. Column headers are string. Data is real, the point is a determiner. The first column is a coordinate. The second one is the deviation caused by a mechanical error. The maximum length of a table is 100 rows.

Note

The id parameter in this function is a C pointer, unlike most library functions that use this parameter

See Also

[command_move](#)
[get_position_calb](#)
[get_position_calb_t](#)
[get_status_calb](#)
[status_calb_t](#)
[get_edges_settings_calb](#)
[set_edges_settings_calb](#)
[edges_settings_calb_t](#)

7.1.4.96 void **XIMC_API** logging_callback_stderr_narrow (int loglevel, const wchar_t * message, void * user_data)

Simple callback for logging to stderr in narrow (single byte) chars.

Parameters

<i>loglevel</i>	a loglevel
<i>message</i>	a message

7.1.4.97 void **XIMC_API** logging_callback_stderr_wide (int loglevel, const wchar_t * message, void * user_data)

Simple callback for logging to stderr in wide chars.

Parameters

<i>loglevel</i>	a loglevel
<i>message</i>	a message

7.1.4.98 void **XIMC_API** msec_sleep (unsigned int msec)

Sleeps for a specified amount of time.

Parameters

<i>msec</i>	time in milliseconds
-------------	----------------------

7.1.4.99 **device_t XIMC_API** open_device (const char * uri)

Open a device with OS uri *uri* and return identifier of the device which can be used in calls.

Parameters

<i>in</i>	<i>uri</i>	- a device uri. Device uri has form "xi-com:port" or "xi-net://host/serial" or "xi-emu:///file". In case of USB-COM port the "port" is the OS device uri. For example "xi-com:\.\COM3" in Windows or "xi-com:/dev/tty.s123" in Linux/Mac. In case of network device the "host" is an IPv4 address or fully qualified domain uri (FQDN), "serial" is the device serial number in hexadecimal system. For example "xi-net://192.168.0.1/00001234" or "xi-net://hostname.com/89ABCDEF". In case of UDP protocol, use "xi-udp://<ip/host>:<port>". For example, "xi-udp://192.168.0.1:1818". Note: to open network device you must call set_bindy_key first. In case of virtual device the "file" is the full filename with device memory state, if it doesn't exist then it is initialized with default values. For example "xi-emu:///C:/dir/file.bin" in Windows or "xi-emu:///home/user/file.bin" in Linux/Mac.
-----------	------------	---

7.1.4.100 **result_t XIMC_API** probe_device (const char * uri)

Check if a device with OS uri *uri* is XIMC device.

Be carefuyl with this call because it sends some data to the device.

Parameters

in	<i>uri</i>	- a device uri
----	------------	----------------

7.1.4.101 **result_t XIMC_API reset_locks ()**

Resets the error of incorrect data transmission.

This function returns only 0 (OK). For example, sending the libximc command ends with an incorrect data transfer (error), any subsequent command always returns -1 (relevant for Windows).

7.1.4.102 **result_t XIMC_API service_command_updf (device_t id)**

Command puts the controller to update the firmware.

After receiving this command, the firmware board sets a flag (for loader), sends echo reply and restarts the controller.

7.1.4.103 **result_t XIMC_API set_accessories_settings (device_t id, const accessories_settings_t * accessories_settings)**

Set additional accessories information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>accessories_settings</i>	structure contains information about additional accessories

7.1.4.104 **result_t XIMC_API set_bindy_key (const char * keyfilepath)**

Set network encryption layer (bindy) key.

Parameters

in	<i>keyfilepath</i>	full path to the bindy keyfile When using network-attached devices this function must be called before enumerate_devices and open_device functions.
----	--------------------	---

7.1.4.105 **result_t XIMC_API set_brake_settings (device_t id, const brake_settings_t * brake_settings)**

Set settings of brake control.

Parameters

	<i>id</i>	an identifier of device
in	<i>brake_settings</i>	structure contains settings of brake control

7.1.4.106 **result_t XIMC_API** set_calibration_settings (**device_t** id, **const calibration_settings_t *** calibration_settings)

Set calibration settings.

This function send structure with calibration settings to controller's memory.

See Also

[calibration_settings_t](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>calibration_settings</i>	calibration settings

7.1.4.107 **result_t XIMC_API** set_control_settings (**device_t** id, **const control_settings_t *** control_settings)

Set settings of motor control.

When choosing CTL_MODE = 1 switches motor control with the joystick. In this mode, the joystick to the maximum engine tends Move at MaxSpeed [i], where i = 0 if the previous use This mode is not selected another i. Buttons switch the room rate i. When CTL_MODE = 2 is switched on motor control using the Left / right. When you click on the button motor starts to move in the appropriate direction at a speed MaxSpeed [0], at the end of time Timeout [i] motor move at a speed MaxSpeed [i+1]. at Transition from MaxSpeed [i] on MaxSpeed [i +1] to acceleration, as usual.

Parameters

	<i>id</i>	an identifier of device
in	<i>control_settings</i>	structure contains settings motor control by joystick or buttons left/right.

7.1.4.108 **result_t XIMC_API** set_control_settings_calb (**device_t** id, **const control_settings_calb_t *** control_settings_calb, **const calibration_t *** calibration)

Set settings of motor control which use user units.

When choosing CTL_MODE = 1 switches motor control with the joystick. In this mode, the joystick to the maximum engine tends Move at MaxSpeed [i], where i = 0 if the previous use This mode is not selected another i. Buttons switch the room rate i. When CTL_MODE = 2 is switched on motor control using the Left / right. When you click on the button motor starts to move in the appropriate direction at a speed MaxSpeed [0], at the end of time Timeout [i] motor move at a speed MaxSpeed [i+1]. at Transition from MaxSpeed [i] on MaxSpeed [i +1] to acceleration, as usual.

Parameters

	<i>id</i>	an identifier of device
in	<i>control_settings_calb</i>	structure contains settings motor control by joystick or buttons left/right.
	<i>calibration</i>	user unit settings

7.1.4.109 **result_t XIMC_API** set_controller_name (**device_t** id, **const controller_name_t *** controller_name)

Write user controller name and flags of setting from FRAM.

Parameters

	<i>id</i>	an identifier of device
in	<i>controller_name</i>	structure contains previously set user controller name

7.1.4.110 **result_t XIMC_API** set_correction_table (**device_t** id, **const char *** namefile)

Command of loading a correction table from a text file.

The correction table is used for position correction in case of mechanical inaccuracies. It works for some parameters in _calb commands.

Parameters

	<i>id</i>	an identifier the device
in	<i>namefile</i>	- the file name must be fully qualified. If the short name is used, the file must be located in the application directory. If the file name is set to NULL, the correction table will be cleared. File format: two tab-separated columns. Column headers are string. Data is real, the point is a determiner. The first column is a coordinate. The second one is the deviation caused by a mechanical error. The maximum length of a table is 100 rows.

See Also

[command_move](#)
[get_position_calb](#)
[get_position_calb_t](#)
[get_status_calb](#)
[status_calb_t](#)
[get_edges_settings_calb](#)
[set_edges_settings_calb](#)
[edges_settings_calb_t](#)

7.1.4.111 **result_t XIMC_API** set_ctp_settings (**device_t** id, **const ctp_settings_t *** ctp_settings)

Set settings of control position(is only used with stepper motor).

When controlling the step motor with encoder (CTP_BASE 0) it is possible to detect the loss of steps. The controller knows the number of steps per revolution (GENG :: StepsPerRev) and the encoder resolution (GFBS :: IPT). When the control (flag CTP_ENABLED), the controller stores the current position in the footsteps of SM and the current position of the encoder. Further, at each step of the position encoder is converted into steps and if the difference is greater CTPMinError, a flag STATE_CTP_ERROR. When controlling the step motor with speed sensor (CTP_BASE 1), the position is controlled by him. The active edge of input clock controller stores the current value of steps. Further, at each turn checks how many steps shifted. When a mismatch CTPMinError a flag STATE_CTP_ERROR.

Parameters

	<i>id</i>	an identifier of device
in	<i>ctp_settings</i>	structure contains settings of control position

7.1.4.112 **result_t XIMC_API set_debug_write (device_t id, const debug_write_t * debug_write)**

Write data to firmware for debug purpose.

Parameters

	<i>id</i>	an identifier of device
in	<i>debug_write</i>	Debug data.

7.1.4.113 **result_t XIMC_API set_edges_settings (device_t id, const edges_settings_t * edges_settings)**

Set border and limit switches settings.

See Also

[get_edges_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>edges_settings</i>	edges settings, specify types of borders, motor behaviour and electrical behaviour of limit switches

7.1.4.114 **result_t XIMC_API set_edges_settings_calb (device_t id, const edges_settings_calb_t * edges_settings_calb, const calibration_t * calibration)**

Set border and limit switches settings which use user units.

See Also

[get_edges_settings_calb](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>edges_settings_-calb</i>	edges settings, specify types of borders, motor behaviour and electrical behaviour of limit switches
	<i>calibration</i>	user unit settings

Note

Attention! Some parameters of the edges_settings_calb structure are corrected by the coordinate correction table.

7.1.4.115 **result_t XIMC_API set_emf_settings (device_t id, const emf_settings_t * emf_settings)**

Set electromechanical coefficients.

The settings are different for different stepper motors. Please download the new settings when you change the motor.

See Also

[get_emf_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>emf_settings</i>	EMF settings

7.1.4.116 **result_t XIMC_API** set_encoder_information (**device_t id**, **const encoder_information_t * encoder_information**)

Set encoder information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>encoder-information</i>	structure contains information about encoder

7.1.4.117 **result_t XIMC_API** set_encoder_settings (**device_t id**, **const encoder_settings_t * encoder_settings**)

Set encoder settings to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>encoder-settings</i>	structure contains encoder settings

7.1.4.118 **result_t XIMC_API** set_engine_advansed_setup (**device_t id**, **const engine_advansed_setup_t * engine_advansed_setup**)

Set engine advansed settings.

See Also

[get_engine_advansed_setup](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>engine-advansed-setup</i>	EAS settings

7.1.4.119 **result_t XIMC_API** set_engine_settings (**device_t** id, **const engine_settings_t *** engine_settings)

Set engine settings.

This function send structure with set of engine settings to controller's memory. These settings specify motor shaft movement algorithm, list of limitations and rated characteristics. Use it when you change motor, encoder, positioner etc. Please note that wrong engine settings lead to device malfunction, can lead to irreversible damage of board.

See Also

[get_engine_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>engine_settings</i>	engine settings

7.1.4.120 **result_t XIMC_API** set_engine_settings_calb (**device_t** id, **const engine_settings_calb_t *** engine_settings_calb, **const calibration_t *** calibration)

Set engine settings which use user units.

This function send structure with set of engine settings to controller's memory. These settings specify motor shaft movement algorithm, list of limitations and rated characteristics. Use it when you change motor, encoder, positioner etc. Please note that wrong engine settings lead to device malfunction, can lead to irreversible damage of board.

See Also

[get_engine_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>engine_settings_calb</i>	engine settings
	<i>calibration</i>	user unit settings

7.1.4.121 **result_t XIMC_API** set_entype_settings (**device_t** id, **const entype_settings_t *** entype_settings)

Set engine type and driver type.

Parameters

	<i>id</i>	an identifier of device
in	<i>entype_settings</i>	structure contains settings motor type and power driver type

7.1.4.122 **result_t XIMC_API** set_extended_settings (**device_t id**, **const extended_settings_t * extended_settings**)

Set extended settings.

Currently not in use.

See Also

[get_extended_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>extended_settings</i>	EST settings

7.1.4.123 **result_t XIMC_API** set_extio_settings (**device_t id**, **const extio_settings_t * extio_settings**)

Set EXTIO settings.

This function writes a structure with a set of EXTIO settings to controller's memory. By default input event are signalled through rising front and output states are signalled by high logic state.

See Also

[get_extio_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>extio_settings</i>	EXTIO settings

7.1.4.124 **result_t XIMC_API** set_feedback_settings (**device_t id**, **const feedback_settings_t * feedback_settings**)

Feedback settings.

Parameters

	<i>id</i>	an identifier of device
in	<i>IPS</i>	number of encoder counts per shaft revolution. Range: 1..65535. The field is obsolete, it is recommended to write 0 to IPS and use the extended CountsPerTurn field. You may need to update the controller firmware to the latest version.
in	<i>FeedbackType</i>	type of feedback
in	<i>FeedbackFlags</i>	flags of feedback
in	<i>CountsPerTurn</i>	number of encoder counts per shaft revolution. Range: 1..4294967295. To use the CountsPerTurn field, write 0 in the IPS field, otherwise the value from the IPS field will be used.

7.1.4.125 **result_t XIMC_API set_gear_information (device_t id, const gear_information_t * gear_information)**

Set gear information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>gear-information</i>	structure contains information about step gearhead

7.1.4.126 **result_t XIMC_API set_gear_settings (device_t id, const gear_settings_t * gear_settings)**

Set gear settings to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>gear-settings</i>	structure contains step gearhead settings

7.1.4.127 **result_t XIMC_API set_hallsensor_information (device_t id, const hallsensor_information_t * hallsensor_information)**

Set hall sensor information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>hallsensor-information</i>	structure contains information about hall sensor

7.1.4.128 **result_t XIMC_API set_hallsensor_settings (device_t id, const hallsensor_settings_t * hallsensor_settings)**

Set hall sensor settings to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>hallsensor-settings</i>	structure contains hall sensor settings

7.1.4.129 **result_t XIMC_API set_home_settings (device_t id, const home_settings_t * home_settings)**

Set home settings.

This function send structure with calibrating position settings to controller's memory.

See Also

[home_settings.t](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>home_settings</i>	calibrating position settings

7.1.4.130 **result_t XIMC_API** set_home_settings_calb (**device_t** id, **const home_settings_calb_t *** home_settings_calb, **const calibration_t *** calibration)

Set home settings which use user units.

This function send structure with calibrating position settings to controller's memory.

See Also

[home_settings.calb.t](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>home_settings_- calb</i>	calibrating position settings
	<i>calibration</i>	user unit settings

7.1.4.131 **result_t XIMC_API** set_joystick_settings (**device_t** id, **const joystick_settings_t *** joystick_settings)

Set settings of joystick.

If joystick position is outside DeadZone limits from the central position a movement with speed, defined by the joystick DeadZone edge to 100% deviation, begins. Joystick positions inside DeadZone limits correspond to zero speed (soft stop of motion) and positions beyond Low and High limits correspond MaxSpeed [i] or -MaxSpeed [i] (see command SCTL), where i = 0 by default and can be changed with left/right buttons (see command SCTL). If next speed in list is zero (both integer and microstep parts), the button press is ignored. First speed in list shouldn't be zero. The DeadZone ranges are illustrated on the following picture. !/attachments/download/5563/range25p.png! The relationship between the deviation and the rate is exponential, allowing no switching speed combine high mobility and accuracy. The following picture illustrates this: !/attachments/download/3092/ExpJoystick.png! The nonlinearity parameter is adjustable. Setting it to zero makes deviation/speed relation linear.

Parameters

	<i>id</i>	an identifier of device
in	<i>joystick_- settings</i>	structure contains joystick settings

7.1.4.132 **void XIMC_API** set_logging_callback (**logging_callback_t** logging_callback, **void *** user_data)

Sets a logging callback.

Call resets a callback to default (stderr, syslog) if NULL passed.

Parameters

<i>logging_callback</i>	a callback for log messages
-------------------------	-----------------------------

7.1.4.133 **result_t XIMC_API** set_motor_information (**device_t id**, **const motor_information_t * motor_information**)

Set motor information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>motor_information</i>	structure contains motor information

7.1.4.134 **result_t XIMC_API** set_motor_settings (**device_t id**, **const motor_settings_t * motor_settings**)

Set motor settings to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>motor_settings</i>	structure contains motor information

7.1.4.135 **result_t XIMC_API** set_move_settings (**device_t id**, **const move_settings_t * move_settings**)

Set command setup movement (speed, acceleration, threshold and etc).

Parameters

	<i>id</i>	an identifier of device
in	<i>move_settings</i>	structure contains move settings: speed, acceleration, deceleration etc.

7.1.4.136 **result_t XIMC_API** set_move_settings_calb (**device_t id**, **const move_settings_calb_t * move_settings_calb**, **const calibration_t * calibration**)

Set command setup movement which use user units (speed, acceleration, threshold and etc).

Parameters

	<i>id</i>	an identifier of device
in	<i>move_settings._calb</i>	structure contains move settings: speed, acceleration, deceleration etc.
	<i>calibration</i>	user unit settings

7.1.4.137 **result_t XIMC_API** set_network_settings (**device_t** id, **const network_settings_t *** network_settings)

Set network settings.

This function sets desired network settings.

See Also

[net_settings_t](#)

Parameters

<i>DHCPEnabled</i>	DHCP enabled (1) or not (0)
<i>IPv4Address[4]</i>	Array[4] with IP address
<i>SubnetMask[4]</i>	Array[4] with subnet mask address
<i>Default-Gateway[4]</i>	Array[4] with default gateway address

7.1.4.138 **result_t XIMC_API** set_nonvolatile_memory (**device_t** id, **const nonvolatile_memory_t *** nonvolatile_memory)

Write userdata into FRAM.

Parameters

	<i>id</i>	an identifier of device
<i>in</i>	<i>nonvolatile-memory</i>	structure contains previously set userdata

7.1.4.139 **result_t XIMC_API** set_password_settings (**device_t** id, **const password_settings_t *** password_settings)

Sets password settings.

This function sets user password to the device web-page.

See Also

[pwd_settings_t](#)

Parameters

<i>User-Password[20]</i>	Password-string to web-page
--------------------------	-----------------------------

7.1.4.140 **result_t XIMC_API** set_pid_settings (**device_t** id, **const pid_settings_t *** pid_settings)

Set PID settings.

This function send structure with set of PID factors to controller's memory. These settings specify behaviour of PID routine for positioner. These factors are slightly different for different positioners. All boards are supplied with standard set of PID setting on controller's flash memory. Please use it for loading new PID settings when you change positioner. Please note that wrong PID settings lead to device malfunction.

See Also

[get_pid_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>pid_settings</i>	pid settings

7.1.4.141 **result_t XIMC_API set_position (device_t id, const set_position_t * the_set_position)**

Sets any position value in steps and micro for stepper motor and encoder steps of all engines.

It means, that changing main indicator of position.

Parameters

	<i>id</i>	an identifier of device
out	<i>the_set_position</i>	structure contains move settings: speed, acceleration, deceleration etc.

7.1.4.142 **result_t XIMC_API set_position_calb (device_t id, const set_position_calb_t * the_set_position_calb, const calibration_t * calibration)**

Sets any position value and encoder value of all engines which use user units.

It means, that changing main indicator of position.

Parameters

	<i>id</i>	an identifier of device
out	<i>the_set_position_calb</i>	structure contains move settings: speed, acceleration, deceleration etc.
	<i>calibration</i>	user unit settings

7.1.4.143 **result_t XIMC_API set_power_settings (device_t id, const power_settings_t * power_settings)**

Set settings of step motor power control.

Used with stepper motor only.

Parameters

	<i>id</i>	an identifier of device
in	<i>power_settings</i>	structure contains settings of step motor power control

7.1.4.144 **result_t XIMC_API set_secure_settings (device_t id, const secure_settings_t * secure_settings)**

Set protection settings.

Parameters

<i>id</i>	an identifier of device
<i>secure_settings</i>	structure with secure data

See Also

`status_t::flags`

7.1.4.145 **result_t XIMC_API set_serial_number (device_t id, const serial_number_t * serial_number)**

Write device serial number and hardware version to controller's flash memory.

Along with the new serial number and hardware version a "Key" is transmitted. The SN and hardware version are changed and saved when keys match. Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>serial_number</i>	structure contains new serial number and secret key.

7.1.4.146 **result_t XIMC_API set_stage_information (device_t id, const stage_information_t * stage_information)**

Set stage information to EEPROM.

Can be used by manufacturer only.

Parameters

	<i>id</i>	an identifier of device
in	<i>stage-information</i>	structure contains stage information

7.1.4.147 **result_t XIMC_API set_stage_name (device_t id, const stage_name_t * stage_name)**

Write user stage name from EEPROM.

Parameters

	<i>id</i>	an identifier of device
in	<i>stage_name</i>	structure contains previously set user stage name

7.1.4.148 **result_t XIMC_API set_stage_settings (device_t id, const stage_settings_t * stage_settings)**

Set stage settings to EEPROM.

Can be used by manufacturer only

Parameters

	<i>id</i>	an identifier of device
in	<i>stage_settings</i>	structure contains stage settings

7.1.4.149 **result_t XIMC_API** set_sync_in_settings (**device_t** id, **const sync_in_settings_t *** sync_in_settings)

Set input synchronization settings.

This function send structure with set of input synchronization settings, that specify behaviour of input synchronization, to controller's memory. All boards are supplied with standard set of these settings.

See Also

[get_sync_in_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>sync_in_settings</i>	synchronization settings

7.1.4.150 **result_t XIMC_API** set_sync_in_settings_calb (**device_t** id, **const sync_in_settings_calb_t *** sync_in_settings_calb, **const calibration_t *** calibration)

Set input synchronization settings which use user units.

This function send structure with set of input synchronization settings, that specify behaviour of input synchronization, to controller's memory. All boards are supplied with standard set of these settings.

See Also

[get_sync_in_settings_calb](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>sync_in_settings_calb</i>	synchronization settings
	<i>calibration</i>	user unit settings

7.1.4.151 **result_t XIMC_API** set_sync_out_settings (**device_t** id, **const sync_out_settings_t *** sync_out_settings)

Set output synchronization settings.

This function send structure with set of output synchronization settings, that specify behaviour of output synchronization, to controller's memory. All boards are supplied with standard set of these settings.

See Also

[get_sync_out_settings](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>sync_out_settings</i>	synchronization settings

7.1.4.152 **result_t XIMC_API** set_sync_out_settings_calb (**device_t** id, const **sync_out_settings_calb_t** * sync_out_settings_calb, const **calibration_t** * calibration)

Set output synchronization settings which use user units.

This function send structure with set of output synchronization settings, that specify behaviour of output synchronization, to controller's memory. All boards are supplied with standard set of these settings.

See Also

[get_sync_in_settings_calb](#)

Parameters

	<i>id</i>	an identifier of device
in	<i>sync_out_settings_calb</i>	synchronization settings
	<i>calibration</i>	user unit settings

7.1.4.153 **result_t XIMC_API** set_uart_settings (**device_t** id, const **uart_settings_t** * uart_settings)

Set UART settings.

This function send structure with UART settings to controller's memory.

See Also

[uart_settings_t](#)

Parameters

	<i>Speed</i>	UART speed
in	<i>uart_settings</i>	UART settings

7.1.4.154 **result_t XIMC_API** write_key (const char * uri, uint8_t * key)

Write controller key.

Can be used by manufacturer only

Parameters

	<i>uri</i>	a uri of device
in	<i>key</i>	protection key. Range: 0..4294967295

7.1.4.155 **result_t XIMC_API** ximc_fix_usbser_sys (const char * device_uri)

Fixing a USB driver error in Windows.

The USB-COM subsystem in the Windows OS does not always work correctly. During operation, the following malfunctions are possible: All attempts to open the device fail. The device can be opened and data can be sent to it, but the response data is not received. These problems are fixed by reconnecting the device or reinitializing it in the Device Manager. The [ximc_fix_usbser_sys\(\)](#) function automates the deletion detection process.

7.1.4.156 void **XIMC_API** ximc_version (char * version)

Returns a library version.

Parameters

<i>version</i>	a buffer to hold a version string, 32 bytes is enough
----------------	---

Index

A1Voltage
 analog_data_t, 15
A1Voltage_ADC
 analog_data_t, 15
A2Voltage
 analog_data_t, 15
A2Voltage_ADC
 analog_data_t, 15
ACurrent
 analog_data_t, 16
ACurrent_ADC
 analog_data_t, 16
Accel
 move_settings_calb_t, 56
 move_settings_t, 57
accessories_settings_t, 12
 LimitSwitchesSettings, 13
 MBRatedCurrent, 13
 MBRatedVoltage, 13
 MBSSettings, 13
 MBTorque, 13
 MagneticBrakeInfo, 13
 TSGrad, 13
 TSMax, 13
 TSMIn, 13
 TSSettings, 14
 TemperatureSensorInfo, 13
Accuracy
 sync_out_settings_calb_t, 76
 sync_out_settings_t, 78
analog_data_t, 14
 A1Voltage, 15
 A1Voltage_ADC, 15
 A2Voltage, 15
 A2Voltage_ADC, 15
 ACurrent, 16
 ACurrent_ADC, 16
 B1Voltage, 16
 B1Voltage_ADC, 16
 B2Voltage, 16
 B2Voltage_ADC, 16
 BCurrent, 16
 BCurrent_ADC, 16
 FullCurrent, 16
 FullCurrent_ADC, 16
 H5, 16
 Joy, 16
Joy_ADC, 17
L, 17
L5, 17
L5_ADC, 17
Pot, 17
R, 17
SupVoltage, 17
SupVoltage_ADC, 17
Temp, 17
Temp_ADC, 17
Antiplay
 engine_settings_calb_t, 35
 engine_settings_t, 36
AntiplaySpeed
 move_settings_calb_t, 56
 move_settings_t, 57
B1Voltage
 analog_data_t, 16
B1Voltage_ADC
 analog_data_t, 16
B2Voltage
 analog_data_t, 16
B2Voltage_ADC
 analog_data_t, 16
BACK_EMF_KM_AUTO
 ximc.h, 105
BCurrent
 analog_data_t, 16
BCurrent_ADC
 analog_data_t, 16
BORDER_IS_ENCODER
 ximc.h, 105
BORDER_STOP_LEFT
 ximc.h, 105
BORDER_STOP_RIGHT
 ximc.h, 105
BRAKE_ENABLED
 ximc.h, 105
BRAKE_ENG_PWROFF
 ximc.h, 105
BackEMFFlags
 emf_settings_t, 31
BorderFlags
 edges_settings_calb_t, 29
 edges_settings_t, 30
brake_settings_t, 18
 BrakeFlags, 18

t1, 18
t2, 18
t3, 18
t4, 18
BrakeFlags
 brake_settings.t, 18

CONTROL_MODE_BITS
 ximc.h, 106
CONTROL_MODE_JOY
 ximc.h, 106
CONTROL_MODE_LR
 ximc.h, 106
CONTROL_MODE_OFF
 ximc.h, 106
CSS1_A
 calibration_settings.t, 19
CSS1_B
 calibration_settings.t, 19
CSS2_A
 calibration_settings.t, 19
CSS2_B
 calibration_settings.t, 19
CTP_ALARM_ON_ERROR
 ximc.h, 106
CTP_BASE
 ximc.h, 106
CTP_ENABLED
 ximc.h, 106
CTP_ERROR_CORRECTION
 ximc.h, 106
CTPFlags
 ctp_settings.t, 26
CTPMinError
 ctp_settings.t, 26
calibration_settings.t, 19
 CSS1_A, 19
 CSS1_B, 19
 CSS2_A, 19
 CSS2_B, 19
 FullCurrent_A, 19
 FullCurrent_B, 20
calibration_t, 20
chart_data_t, 20
 DutyCycle, 21
 Joy, 21
 Pot, 21
 WindingCurrentA, 21
 WindingCurrentB, 21
 WindingCurrentC, 21
 WindingVoltageA, 21
 WindingVoltageB, 22
 WindingVoltageC, 22
close_device
 ximc.h, 121
ClutterTime

sync_in_settings_calb_t, 74
sync_in_settings_t, 75
CmdBufFreeSpace
 status_calb_t, 70
 status.t, 72
command_clear_fram
 ximc.h, 121
command_eeread_settings
 ximc.h, 121
command_eesave_settings
 ximc.h, 121
command_home
 ximc.h, 122
command_homezero
 ximc.h, 122
command_left
 ximc.h, 122
command_loft
 ximc.h, 123
command_move
 ximc.h, 123
command_move_calb
 ximc.h, 123
command_movr
 ximc.h, 123
command_movr_calb
 ximc.h, 124
command_power_off
 ximc.h, 124
command_read_robust_settings
 ximc.h, 124
command_read_settings
 ximc.h, 124
command_reset
 ximc.h, 125
command_right
 ximc.h, 125
command_save_robust_settings
 ximc.h, 125
command_save_settings
 ximc.h, 125
command_sstp
 ximc.h, 125
command_start_measurements
 ximc.h, 126
command_stop
 ximc.h, 126
command_update_firmware
 ximc.h, 126
command_wait_for_stop
 ximc.h, 126
command_zero
 ximc.h, 126
control_settings_calb_t, 22
 Flags, 23
 MaxClickTime, 23

MaxSpeed, 23
Timeout, 23
control_settings_t, 23
Flags, 24
MaxClickTime, 24
MaxSpeed, 24
Timeout, 24
uDeltaPosition, 24
uMaxSpeed, 24
controller_name_t, 24
ControllerName, 25
CtrlFlags, 25
CountsPerTurn
 feedback_settings_t, 40
CriticallyPwr
 secure_settings_t, 63
CriticallyUsb
 secure_settings_t, 63
CriticalT
 secure_settings_t, 63
CriticalUpwr
 secure_settings_t, 63
CriticalUusb
 secure_settings_t, 63
ctp_settings_t, 25
 CTPFlags, 26
 CTPMInError, 26
CtrlFlags
 controller_name_t, 25
CurPosition
 status_calb_t, 70
 status_t, 72
CurSpeed
 status_calb_t, 70
 status_t, 72
CurT
 status_calb_t, 70
 status_t, 72
CurrReduceDelay
 power_settings_t, 61
CurrentSetTime
 power_settings_t, 61
DHCPEnabled
 network_settings_t, 59
DRIVER_TYPE_EXTERNAL
 ximc.h, 106
DeadZone
 joystick_settings_t, 50
debug_read_t, 26
 DebugData, 26
debug_write_t, 26
 DebugData, 27
DebugData
 debug_read_t, 26
 debug_write_t, 27
Decel
 move_settings_calb_t, 56
 move_settings_t, 58
DefaultGateway
 network_settings_t, 59
DetentTorque
 motor_settings_t, 53
device_information_t, 27
 Major, 27
 Minor, 27
 Release, 28
device_network_information_t, 28
DriverType
 entype_settings_t, 38
DutyCycle
 chart_data_t, 21
EEPROM_PRECEDENCE
 ximc.h, 107
ENC_STATE_ABSENT
 ximc.h, 107
ENC_STATE_MALFUNC
 ximc.h, 107
ENC_STATE_OK
 ximc.h, 107
ENC_STATE_REVERS
 ximc.h, 107
ENC_STATE_UNKNOWN
 ximc.h, 107
ENDER_SW1_ACTIVE_LOW
 ximc.h, 107
ENDER_SW2_ACTIVE_LOW
 ximc.h, 107
ENDER_SWAP
 ximc.h, 107
ENGINE_ACCEL_ON
 ximc.h, 107
ENGINE_ANTIPLAY
 ximc.h, 107
ENGINE_LIMIT_CURR
 ximc.h, 108
ENGINE_LIMIT_RPM
 ximc.h, 108
ENGINE_LIMIT_VOLT
 ximc.h, 108
ENGINE_MAX_SPEED
 ximc.h, 108
ENGINE_REVERSE
 ximc.h, 108
ENGINE_TYPE_2DC
 ximc.h, 108
ENGINE_TYPE_DC
 ximc.h, 108
ENGINE_TYPE_NONE

ximc.h, 108
ENGINE_TYPE_STEP
 ximc.h, 109
ENGINE_TYPE_TEST
 ximc.h, 109
ENUMERATE_PROBE
 ximc.h, 109
EXTIO_SETUP_INVERT
 ximc.h, 109
EXTIO_SETUP_OUTPUT
 ximc.h, 110
EXTIOModeFlags
 extio_settings_t, 39
EXTIOSetupFlags
 extio_settings_t, 39
edges_settings_calb_t, 28
 BorderFlags, 29
 EnderFlags, 29
 LeftBorder, 29
 RightBorder, 29
edges_settings_t, 29
 BorderFlags, 30
 EnderFlags, 30
 LeftBorder, 30
 RightBorder, 30
 uLeftBorder, 30
 uRightBorder, 30
Efficiency
 gear_settings.t, 41
emf_settings.t, 30
 BackEMFFlags, 31
 Km, 31
 L, 31
 R, 31
EncPosition
 get_position_calb_t, 43
 get_position_t, 43
 set_position_calb_t, 65
 set_position_t, 66
 status_calb_t, 70
 status_t, 72
EncSts
 status_calb_t, 70
 status_t, 73
encoder_information_t, 31
 Manufacturer, 32
 PartNumber, 32
encoder_settings.t, 32
 EncoderSettings, 33
 MaxCurrentConsumption, 33
 MaxOperatingFrequency, 33
 SupplyVoltageMax, 33
 SupplyVoltageMin, 33
EncoderSettings
 encoder_settings.t, 33
EnderFlags
edges_settings_calb_t, 29
 edges_settings_t, 30
engine_advanced_setup_t, 33
 stepcloseloop_Kp_high, 34
 stepcloseloop_Kp_low, 34
 stepcloseloop_Kw, 34
engine_settings_calb_t, 34
 Antiplay, 35
 EngineFlags, 35
 MicrostepMode, 35
 NomCurrent, 35
 NomSpeed, 35
 NomVoltage, 35
 StepsPerRev, 35
engine_settings_t, 36
 Antiplay, 36
 EngineFlags, 36
 MicrostepMode, 36
 NomCurrent, 37
 NomSpeed, 37
 NomVoltage, 37
 StepsPerRev, 37
 uNomSpeed, 37
EngineFlags
 engine_settings_calb_t, 35
 engine_settings_t, 36
EngineType
 entype_settings_t, 38
entype_settings_t, 37
 DriverType, 38
 EngineType, 38
enumerate_devices
 ximc.h, 127
Error
 measurements_t, 51
ExpFactor
 joystick_settings.t, 50
extended_settings_t, 38
extio_settings_t, 38
 EXTIOModeFlags, 39
 EXTIOSetupFlags, 39
FEEDBACK_EMF
 ximc.h, 110
FEEDBACK_ENC_REVERSE
 ximc.h, 110
FEEDBACK_ENCODER
 ximc.h, 111
FEEDBACK_NONE
 ximc.h, 111
FastHome
 home_settings_calb_t, 47
 home_settings_t, 48
feedback_settings_t, 39
 CountsPerTurn, 40
 FeedbackFlags, 40

FeedbackType, 40
IPS, 40
FeedbackFlags
 feedback_settings_t, 40
FeedbackType
 feedback_settings_t, 40
Flags
 control_settings_calb_t, 23
 control_settings_t, 24
 secure_settings_t, 63
 status_calb_t, 70
 status_t, 73
free_enumerate_devices
 ximc.h, 127
FullCurrent
 analog_data_t, 16
FullCurrent_A
 calibration_settings_t, 19
FullCurrent_ADC
 analog_data_t, 16
FullCurrent_B
 calibration_settings_t, 20

GPIOFlags
 status_calb_t, 70
 status_t, 73
gear_information_t, 40
 Manufacturer, 41
 PartNumber, 41
gear_settings_t, 41
 Efficiency, 41
 InputInertia, 41
 MaxOutputBacklash, 42
 RatedInputSpeed, 42
 RatedInputTorque, 42
 ReductionIn, 42
 ReductionOut, 42
get_accessories_settings
 ximc.h, 127
get_analog_data
 ximc.h, 127
get_bootloader_version
 ximc.h, 128
get_brake_settings
 ximc.h, 128
get_calibration_settings
 ximc.h, 128
get_chart_data
 ximc.h, 128
get_control_settings
 ximc.h, 129
get_control_settings_calb
 ximc.h, 129
get_controller_name
 ximc.h, 129
get_ctp_settings
 ximc.h, 130
get_debug_read
 ximc.h, 130
get_device_count
 ximc.h, 130
get_device_information
 ximc.h, 130
get_device_name
 ximc.h, 131
get_edges_settings
 ximc.h, 131
get_edges_settings_calb
 ximc.h, 131
get_emf_settings
 ximc.h, 131
get_encoder_information
 ximc.h, 132
get_encoder_settings
 ximc.h, 132
get_engine_advansed_setup
 ximc.h, 132
get_engine_settings
 ximc.h, 132
get_engine_settings_calb
 ximc.h, 133
get_entype_settings
 ximc.h, 133
get_enumerate_device_controller_name
 ximc.h, 133
get_enumerate_device_information
 ximc.h, 134
get_enumerate_device_network_information
 ximc.h, 134
get_enumerate_device_serial
 ximc.h, 134
get_enumerate_device_stage_name
 ximc.h, 134
get_extended_settings
 ximc.h, 135
get_extio_settings
 ximc.h, 135
get_feedback_settings
 ximc.h, 135
get_firmware_version
 ximc.h, 136
get_gear_information
 ximc.h, 136
get_gear_settings
 ximc.h, 136
get_globally_unique_identifier
 ximc.h, 136
get_hallsensor_information
 ximc.h, 137
get_hallsensor_settings
 ximc.h, 137
get_home_settings

ximc.h, 137
get_home_settings_calb
 ximc.h, 137
get_init_random
 ximc.h, 138
get_joystick_settings
 ximc.h, 138
get_measurements
 ximc.h, 138
get_motor_information
 ximc.h, 138
get_motor_settings
 ximc.h, 139
get_move_settings
 ximc.h, 139
get_move_settings_calb
 ximc.h, 139
get_network_settings
 ximc.h, 139
get_nonvolatile_memory
 ximc.h, 140
get_password_settings
 ximc.h, 140
get_pid_settings
 ximc.h, 140
get_position
 ximc.h, 140
get_position_calb
 ximc.h, 141
get_position_calb_t, 42
 EncPosition, 43
 Position, 43
get_position_t, 43
 EncPosition, 43
 uPosition, 43
get_power_settings
 ximc.h, 141
get_secure_settings
 ximc.h, 141
get_serial_number
 ximc.h, 141
get_stage_information
 ximc.h, 142
get_stage_name
 ximc.h, 142
get_stage_settings
 ximc.h, 142
get_status
 ximc.h, 142
get_status_calb
 ximc.h, 143
get_sync_in_settings
 ximc.h, 143
get_sync_in_settings_calb
 ximc.h, 143
get_sync_out_settings
 ximc.h, 144
get_sync_out_settings_calb
 ximc.h, 144
get_uart_settings
 ximc.h, 144
globally_unique_identifier_t, 44
 UniqueID0, 44
 UniqueID1, 44
 UniqueID2, 44
 UniqueID3, 44
goto_firmware
 ximc.h, 144

H5
 analog_data_t, 16
H_BRIDGE_ALERT
 ximc.h, 111
HOME_DIR_FIRST
 ximc.h, 111
HOME_DIR_SECOND
 ximc.h, 111
HOME_HALF_MV
 ximc.h, 111
HOME_MV_SEC_EN
 ximc.h, 111
HOME_STOP_FIRST_LIM
 ximc.h, 111
HOME_STOP_FIRST_REV
 ximc.h, 112
HOME_STOP_FIRST_SYN
 ximc.h, 112
HOME_USE_FAST
 ximc.h, 112
hallsensor_information_t, 44
 Manufacturer, 45
 PartNumber, 45
hallsensor_settings_t, 45
 MaxCurrentConsumption, 46
 MaxOperatingFrequency, 46
 SupplyVoltageMax, 46
 SupplyVoltageMin, 46
has_firmware
 ximc.h, 145
HoldCurrent
 power_settings_t, 62
home_settings_calb_t, 46
 FastHome, 47
 HomeDelta, 47
 HomeFlags, 47
 SlowHome, 47
home_settings_t, 47
 FastHome, 48
 HomeDelta, 48
 HomeFlags, 48
 SlowHome, 48
 uFastHome, 48

uHomeDelta, 48
 uSlowHome, 48

HomeDelta
 home_settings_calb_t, 47
 home_settings_t, 48

HomeFlags
 home_settings_calb_t, 47
 home_settings_t, 48

HorizontalLoadCapacity
 stage_settings_t, 68

IPS
 feedback_settings_t, 40

IPv4Address
 network_settings_t, 59

init_random_t, 49
 key, 49

InputInertia
 gear_settings_t, 41

Ipwr
 status_calb_t, 70
 status_t, 73

Iusb
 status_calb_t, 70
 status_t, 73

JOY_REVERSE
 ximc.h, 112

Joy
 analog_data_t, 16
 chart_data_t, 21

Joy_ADC
 analog_data_t, 17

JoyCenter
 joystick_settings_t, 50

JoyFlags
 joystick_settings_t, 50

JoyHighEnd
 joystick_settings_t, 50

JoyLowEnd
 joystick_settings_t, 50

joystick_settings_t, 49
 DeadZone, 50
 ExpFactor, 50
 JoyCenter, 50
 JoyFlags, 50
 JoyHighEnd, 50
 JoyLowEnd, 50

Key
 serial_number_t, 64

key
 init_random_t, 49

Km
 emf_settings_t, 31

L
 analog_data_t, 17
 emf_settings_t, 31

 L5
 analog_data_t, 17

 L5_ADC
 analog_data_t, 17

 LOW_UPWR_PROTECTION
 ximc.h, 112

 LeadScrewPitch
 stage_settings_t, 68

 LeftBorder
 edges_settings_calb_t, 29
 edges_settings_t, 30

 Length
 measurements_t, 51

 LimitSwitchesSettings
 accessories_settings_t, 13

 load_correction_table
 ximc.h, 145

 logging_callback_stderr_narrow
 ximc.h, 145

 logging_callback_stderr_wide
 ximc.h, 146

 logging_callback_t
 ximc.h, 121

 LowUpwrOff
 secure_settings_t, 63

 MBRatedCurrent
 accessories_settings_t, 13

 MBRatedVoltage
 accessories_settings_t, 13

 MBSettings
 accessories_settings_t, 13

 MBTorque
 accessories_settings_t, 13

 MICROSTEP_MODE_FULL
 ximc.h, 113

 MOVE_STATE_ANTIPLAY
 ximc.h, 113

 MOVE_STATE_MOVING
 ximc.h, 113

 MVCMD_ERROR
 ximc.h, 113

 MVCMD_HOME
 ximc.h, 113

 MVCMD_LEFT
 ximc.h, 114

 MVCMD_LOFT
 ximc.h, 114

 MVCMD_MOVE
 ximc.h, 114

 MVCMD_MOVR
 ximc.h, 114

 MVCMD_NAME_BITS
 ximc.h, 114

MVCMD_RIGHT
 ximc.h, 114
MVCMD_RUNNING
 ximc.h, 114
MVCMD_SSSTP
 ximc.h, 114
MVCMD_STOP
 ximc.h, 114
MVCMD_UKNWN
 ximc.h, 114
MagneticBrakeInfo
 accessories_settings_t, 13
Major
 device_information_t, 27
 serial_number_t, 64
Manufacturer
 encoder_information_t, 32
 gear_information_t, 41
 hallsensor_information_t, 45
 motor_information_t, 52
 stage_information_t, 66
MaxClickTime
 control_settings_calb_t, 23
 control_settings_t, 24
MaxCurrent
 motor_settings_t, 53
MaxCurrentConsumption
 encoder_settings_t, 33
 hallsensor_settings_t, 46
 stage_settings_t, 68
MaxCurrentTime
 motor_settings_t, 53
MaxOperatingFrequency
 encoder_settings_t, 33
 hallsensor_settings_t, 46
MaxOutputBacklash
 gear_settings_t, 42
MaxSpeed
 control_settings_calb_t, 23
 control_settings_t, 24
 motor_settings_t, 54
 stage_settings_t, 68
measurements_t, 50
 Error, 51
 Length, 51
 Speed, 51
MechanicalTimeConstant
 motor_settings_t, 54
MicrostepMode
 engine_settings_calb_t, 35
 engine_settings_t, 36
MinimumUusb
 secure_settings_t, 63
Minor
 device_information_t, 27
 serial_number_t, 64
motor_information_t, 51
 Manufacturer, 52
 PartNumber, 52
motor_settings_t, 52
 DetentTorque, 53
 MaxCurrent, 53
 MaxCurrentTime, 53
 MaxSpeed, 54
 MechanicalTimeConstant, 54
 MotorType, 54
 NoLoadCurrent, 54
 NoLoadSpeed, 54
 NominalCurrent, 54
 NominalPower, 54
 NominalSpeed, 54
 NominalTorque, 54
 NominalVoltage, 55
 Phases, 55
 Poles, 55
 RotorInertia, 55
 SpeedConstant, 55
 SpeedTorqueGradient, 55
 StallTorque, 55
 TorqueConstant, 55
 WindingInductance, 55
 WindingResistance, 56
MotorType
 motor_settings_t, 54
move_settings_calb_t, 56
 Accel, 56
 AntiplaySpeed, 56
 Decel, 56
 MoveFlags, 57
 Speed, 57
move_settings_t, 57
 Accel, 57
 AntiplaySpeed, 57
 Decel, 58
 MoveFlags, 58
 Speed, 58
 uAntiplaySpeed, 58
 uSpeed, 58
MoveFlags
 move_settings_calb_t, 57
 move_settings_t, 58
MoveSts
 status_calb_t, 71
 status_t, 73
msec_sleep
 ximc.h, 146
MvCmdSts
 status_calb_t, 71
 status_t, 73
network_settings_t, 58
 DHCPEnabled, 59

DefaultGateway, 59
IPv4Address, 59
SubnetMask, 59
NoLoadCurrent
 motor_settings_t, 54
NoLoadSpeed
 motor_settings_t, 54
NomCurrent
 engine_settings_calb_t, 35
 engine_settings_t, 37
NomSpeed
 engine_settings_calb_t, 35
 engine_settings_t, 37
NomVoltage
 engine_settings_calb_t, 35
 engine_settings_t, 37
NominalCurrent
 motor_settings_t, 54
NominalPower
 motor_settings_t, 54
NominalSpeed
 motor_settings_t, 54
NominalTorque
 motor_settings_t, 54
NominalVoltage
 motor_settings_t, 55
nonvolatile_memory_t, 59
 UserData, 60
open_device
 ximc.h, 146

POWER_OFF_ENABLED
 ximc.h, 114
POWER_REDUCT_ENABLED
 ximc.h, 114
POWER_SMOOTH_CURRENT
 ximc.h, 115
PWR_STATE_MAX
 ximc.h, 115
PWR_STATE_NORM
 ximc.h, 115
PWR_STATE_OFF
 ximc.h, 115
PWR_STATE_REDUCt
 ximc.h, 115
PWR_STATE_UNKNOWN
 ximc.h, 115
PWRSts
 status_calb_t, 71
 status_t, 73
PartNumber
 encoder_information_t, 32
 gear_information_t, 41
 hallsensor_information_t, 45
 motor_information_t, 52
 stage_information_t, 66

password_settings_t, 60
 UserPassword, 60
Phases
 motor_settings_t, 55
pid_settings_t, 60
Poles
 motor_settings_t, 55
PosFlags
 set_position_calb_t, 65
 set_position_t, 66
Position
 get_position_calb_t, 43
 set_position_calb_t, 65
 sync_in_settings_calb_t, 74
PositionerName
 stage_name_t, 67
Pot
 analog_data_t, 17
 chart_data_t, 21
power_settings_t, 61
 CurrReductDelay, 61
 CurrentSetTime, 61
 HoldCurrent, 62
 PowerFlags, 62
 PowerOffDelay, 62
PowerFlags
 power_settings_t, 62
PowerOffDelay
 power_settings_t, 62
probe_device
 ximc.h, 146

R
 analog_data_t, 17
 emf_settings_t, 31
REV_SENS_INV
 ximc.h, 115
RPM_DIV_1000
 ximc.h, 115
RatedInputSpeed
 gear_settings_t, 42
RatedInputTorque
 gear_settings_t, 42
ReductionIn
 gear_settings_t, 42
ReductionOut
 gear_settings_t, 42
Release
 device_information_t, 28
 serial_number_t, 64
reset_locks
 ximc.h, 147
RightBorder
 edges_settings_calb_t, 29
 edges_settings_t, 30
RotorInertia

motor_settings_t, 55
SN
 serial_number_t, 64
STATE_ALARM
 ximc.h, 115
STATE_BRAKE
 ximc.h, 116
STATE_BUTTON_LEFT
 ximc.h, 116
STATE_BUTTON_RIGHT
 ximc.h, 116
STATE_CONTR
 ximc.h, 116
STATE_CTP_ERROR
 ximc.h, 116
STATE_DIG_SIGNAL
 ximc.h, 116
STATE_ENC_A
 ximc.h, 116
STATE_ENC_B
 ximc.h, 117
STATE_ERRC
 ximc.h, 117
STATE_ERRD
 ximc.h, 117
STATE_ERRV
 ximc.h, 117
STATE_EXTIO_ALARM
 ximc.h, 117
STATE_GPIO_LEVEL
 ximc.h, 117
STATE_GPIO_PINOUT
 ximc.h, 117
STATE_IS_HOMED
 ximc.h, 117
STATE_LEFT_EDGE
 ximc.h, 118
STATE_POWER_OVERHEAT
 ximc.h, 118
STATE_REV_SENSOR
 ximc.h, 118
STATE_RIGHT_EDGE
 ximc.h, 118
STATE_SECUR
 ximc.h, 118
STATE_SYNC_INPUT
 ximc.h, 118
STATE_SYNC_OUTPUT
 ximc.h, 119
SYNCIN_ENABLED
 ximc.h, 119
SYNCIN_GOTOPOSITION
 ximc.h, 119
SYNCIN_INVERT
 ximc.h, 119
SYNCOUT_ENABLED
 ximc.h, 119
SYNCOUT_IN_STEPS
 ximc.h, 119
SYNCOUT_INVERT
 ximc.h, 119
SYNCOUT_ONPERIOD
 ximc.h, 119
SYNCOUT_ONSTART
 ximc.h, 119
SYNCOUT_ONSTOP
 ximc.h, 119
SYNCOUT_STATE
 ximc.h, 120
secure_settings_t, 62
 CriticallyPwr, 63
 CriticallyUsb, 63
 CriticalT, 63
 CriticalUpwr, 63
 CriticalUusb, 63
 Flags, 63
 LowUpwrOff, 63
 MinimumUusb, 63
serial_number_t, 63
 Key, 64
 Major, 64
 Minor, 64
 Release, 64
 SN, 64
service_command_updf
 ximc.h, 147
set_accessories_settings
 ximc.h, 147
set_bindy_key
 ximc.h, 147
set_brake_settings
 ximc.h, 147
set_calibration_settings
 ximc.h, 147
set_control_settings
 ximc.h, 148
set_control_settings_calb
 ximc.h, 148
set_controller_name
 ximc.h, 148
set_correction_table
 ximc.h, 149
set_ctp_settings
 ximc.h, 149
set_debug_write
 ximc.h, 150
set_edges_settings
 ximc.h, 150
set_edges_settings_calb
 ximc.h, 150
set_emf_settings

ximc.h, 150
set_encoder_information
 ximc.h, 151
set_encoder_settings
 ximc.h, 151
set_engine_advanced_setup
 ximc.h, 151
set_engine_settings
 ximc.h, 151
set_engine_settings_calb
 ximc.h, 152
set_entype_settings
 ximc.h, 152
set_extended_settings
 ximc.h, 152
set_extio_settings
 ximc.h, 153
set_feedback_settings
 ximc.h, 153
set_gear_information
 ximc.h, 153
set_gear_settings
 ximc.h, 154
set_hallsensor_information
 ximc.h, 154
set_hallsensor_settings
 ximc.h, 154
set_home_settings
 ximc.h, 154
set_home_settings_calb
 ximc.h, 155
set_joystick_settings
 ximc.h, 155
set_logging_callback
 ximc.h, 155
set_motor_information
 ximc.h, 156
set_motor_settings
 ximc.h, 156
set_move_settings
 ximc.h, 156
set_move_settings_calb
 ximc.h, 156
set_network_settings
 ximc.h, 156
set_nonvolatile_memory
 ximc.h, 157
set_password_settings
 ximc.h, 157
set_pid_settings
 ximc.h, 157
set_position
 ximc.h, 158
set_position_calb
 ximc.h, 158
set_position_calb_t, 64
EncPosition, 65
PosFlags, 65
Position, 65
set_position_t, 65
 EncPosition, 66
 PosFlags, 66
 uPosition, 66
set_power_settings
 ximc.h, 158
set_secure_settings
 ximc.h, 158
set_serial_number
 ximc.h, 159
set_stage_information
 ximc.h, 159
set_stage_name
 ximc.h, 159
set_stage_settings
 ximc.h, 159
set_sync_in_settings
 ximc.h, 159
set_sync_in_settings_calb
 ximc.h, 160
set_sync_out_settings
 ximc.h, 160
set_sync_out_settings_calb
 ximc.h, 160
set_uart_settings
 ximc.h, 161
SlowHome
 home_settings_calb_t, 47
 home_settings_t, 48
Speed
 measurements_t, 51
 move_settings_calb_t, 57
 move_settings_t, 58
 sync_in_settings_calb_t, 74
 sync_in_settings_t, 75
SpeedConstant
 motor_settings_t, 55
SpeedTorqueGradient
 motor_settings_t, 55
stage_information_t, 66
 Manufacturer, 66
 PartNumber, 66
stage_name_t, 67
 PositionerName, 67
stage_settings_t, 67
 HorizontalLoadCapacity, 68
 LeadScrewPitch, 68
 MaxCurrentConsumption, 68
 MaxSpeed, 68
 SupplyVoltageMax, 68
 SupplyVoltageMin, 68
 TravelRange, 68
 Units, 68

VerticalLoadCapacity, 69
StallTorque
 motor_settings_t, 55
status_calb_t, 69
 CmdBuffFreeSpace, 70
 CurPosition, 70
 CurSpeed, 70
 CurT, 70
 EncPosition, 70
 EncSts, 70
 Flags, 70
 GPIOFlags, 70
 Ipwr, 70
 Iusb, 70
 MoveSts, 71
 MvCmdSts, 71
 PWRSts, 71
 Upwr, 71
 Uusb, 71
 WindSts, 71
status_t, 71
 CmdBuffFreeSpace, 72
 CurPosition, 72
 CurSpeed, 72
 CurT, 72
 EncPosition, 72
 EncSts, 73
 Flags, 73
 GPIOFlags, 73
 Ipwr, 73
 Iusb, 73
 MoveSts, 73
 MvCmdSts, 73
 PWRSts, 73
 uCurPosition, 73
 uCurSpeed, 73
 Upwr, 73
 Uusb, 74
 WindSts, 74
stepcloseloop_Kp_high
 engine_advanced_setup_t, 34
stepcloseloop_Kp_low
 engine_advanced_setup_t, 34
stepcloseloop_Kw
 engine_advanced_setup_t, 34
StepsPerRev
 engine_settings_calb_t, 35
 engine_settings_t, 37
SubnetMask
 network_settings_t, 59
SupVoltage
 analog_data_t, 17
SupVoltage_ADC
 analog_data_t, 17
SupplyVoltageMax
 encoder_settings_t, 33
 hallsensor_settings_t, 46
 stage_settings_t, 68
SupplyVoltageMin
 encoder_settings_t, 33
 hallsensor_settings_t, 46
 stage_settings_t, 68
sync_in_settings_calb_t, 74
 ClutterTime, 74
 Position, 74
 Speed, 74
 SyncInFlags, 75
sync_in_settings_t, 75
 ClutterTime, 75
 Speed, 75
 SyncInFlags, 75
 uPosition, 76
 uSpeed, 76
sync_out_settings_calb_t, 76
 Accuracy, 76
 SyncOutFlags, 77
 SyncOutPeriod, 77
 SyncOutPulseSteps, 77
sync_out_settings_t, 77
 Accuracy, 78
 SyncOutFlags, 78
 SyncOutPeriod, 78
 SyncOutPulseSteps, 78
 uAccuracy, 78
SyncInFlags
 sync_in_settings_calb_t, 75
 sync_in_settings_t, 75
SyncOutFlags
 sync_out_settings_calb_t, 77
 sync_out_settings_t, 78
SyncOutPeriod
 sync_out_settings_calb_t, 77
 sync_out_settings_t, 78
SyncOutPulseSteps
 sync_out_settings_calb_t, 77
 sync_out_settings_t, 78
t1
 brake_settings_t, 18
t2
 brake_settings_t, 18
t3
 brake_settings_t, 18
t4
 brake_settings_t, 18
TGrad
 accessories_settings_t, 13
TMax
 accessories_settings_t, 13
TMin
 accessories_settings_t, 13
TSSettings

accessories_settings_t, 14
Temp
 analog_data_t, 17
Temp_ADC
 analog_data_t, 17
TemperatureSensorInfo
 accessories_settings_t, 13
Timeout
 control_settings_calb_t, 23
 control_settings_t, 24
TorqueConstant
 motor_settings_t, 55
TravelRange
 stage_settings.t, 68

UART_PARITY_BITS
 ximc.h, 120
UARTSetupFlags
 uart_settings.t, 79
uAccuracy
 sync_out_settings_t, 78
uAntiplaySpeed
 move_settings.t, 58
uCurPosition
 status_t, 73
uCurSpeed
 status_t, 73
uDeltaPosition
 control_settings_t, 24
uFastHome
 home_settings.t, 48
uHomeDelta
 home_settings.t, 48
uLeftBorder
 edges_settings.t, 30
uMaxSpeed
 control_settings_t, 24
uNomSpeed
 engine_settings.t, 37
uPosition
 get_position_t, 43
 set_position_t, 66
 sync_in_settings_t, 76
uRightBorder
 edges_settings.t, 30
uSlowHome
 home_settings.t, 48
uSpeed
 move_settings.t, 58
 sync_in_settings_t, 76
uart_settings.t, 78
 UARTSetupFlags, 79
UniqueID0
 globally_unique_identifier_t, 44
UniqueID1
 globally_unique_identifier_t, 44

UniqueID2
 globally_unique_identifier_t, 44
UniqueID3
 globally_unique_identifier_t, 44
Units
 stage_settings_t, 68
Upwr
 status_calb_t, 71
 status_t, 73
UserData
 nonvolatile_memory_t, 60
UserPassword
 password_settings_t, 60
Uusb
 status_calb_t, 71
 status_t, 74

VerticalLoadCapacity
 stage_settings_t, 69

WIND_A_STATE_ABSENT
 ximc.h, 120
WIND_A_STATE_OK
 ximc.h, 120
WIND_B_STATE_ABSENT
 ximc.h, 120
WIND_B_STATE_OK
 ximc.h, 120
WindSts
 status_calb_t, 71
 status_t, 74
WindingCurrentA
 chart_data_t, 21
WindingCurrentB
 chart_data_t, 21
WindingCurrentC
 chart_data_t, 21
WindingInductance
 motor_settings_t, 55
WindingResistance
 motor_settings.t, 56
WindingVoltageA
 chart_data_t, 21
WindingVoltageB
 chart_data_t, 22
WindingVoltageC
 chart_data_t, 22
write_key
 ximc.h, 161

XIMC_API
 ximc.h, 120
ximc.h, 80
 BACK_EMF_KM_AUTO, 105
 BORDER_IS_ENCODER, 105
 BORDER_STOP_LEFT, 105
 BORDER_STOP_RIGHT, 105

BRAKE_ENABLED, 105
BRAKE_ENG_PWROFF, 105
CONTROL_MODE_BITS, 106
CONTROL_MODE_JOY, 106
CONTROL_MODE_LR, 106
CONTROL_MODE_OFF, 106
CTP_ALARM_ON_ERROR, 106
CTP_BASE, 106
CTP_ENABLED, 106
close_device, 121
command_clear_fram, 121
command_eeread_settings, 121
command_eesave_settings, 121
command_home, 122
command_homezero, 122
command_left, 122
command_loft, 123
command_move, 123
command_move_calb, 123
command_movr, 123
command_movr_calb, 124
command_power_off, 124
command_read_robust_settings, 124
command_read_settings, 124
command_reset, 125
command_right, 125
command_save_robust_settings, 125
command_save_settings, 125
command_sstp, 125
command_start_measurements, 126
command_stop, 126
command_update_firmware, 126
command_wait_for_stop, 126
command_zero, 126
EEPROM_PRECEDENCE, 107
ENC_STATE_ABSENT, 107
ENC_STATE_MALFUNC, 107
ENC_STATE_OK, 107
ENC_STATE_REVERS, 107
ENC_STATE_UNKNOWN, 107
ENDER_SWAP, 107
ENGINE_ACCEL_ON, 107
ENGINE_ANTIPLAY, 107
ENGINE_LIMIT_CURR, 108
ENGINE_LIMIT_RPM, 108
ENGINE_LIMIT_VOLT, 108
ENGINE_MAX_SPEED, 108
ENGINE_REVERSE, 108
ENGINE_TYPE_2DC, 108
ENGINE_TYPE_DC, 108
ENGINE_TYPE_NONE, 108
ENGINE_TYPE_STEP, 109
ENGINE_TYPE_TEST, 109
ENUMERATE_PROBE, 109
EXTIO_SETUP_INVERT, 109
EXTIO_SETUP_OUTPUT, 110
enumerate_devices, 127
FEEDBACK_EMF, 110
FEEDBACK_ENCODER, 111
FEEDBACK_NONE, 111
free_enumerate_devices, 127
get_accessories_settings, 127
get_analog_data, 127
get_bootloader_version, 128
get_brake_settings, 128
get_calibration_settings, 128
get_chart_data, 128
get_control_settings, 129
get_control_settings_calb, 129
get_controller_name, 129
get_ctp_settings, 130
get_debug_read, 130
get_device_count, 130
get_device_information, 130
get_device_name, 131
get_edges_settings, 131
get_edges_settings_calb, 131
get_emf_settings, 131
get_encoder_information, 132
get_encoder_settings, 132
get_engine_advansed_setup, 132
get_engine_settings, 132
get_engine_settings_calb, 133
get_entype_settings, 133
get_enumerate_device_controller_name, 133
get_enumerate_device_information, 134
get_enumerate_device_network_information, 134
get_enumerate_device_serial, 134
get_enumerate_device_stage_name, 134
get_extended_settings, 135
get_extio_settings, 135
get_feedback_settings, 135
get_firmware_version, 136
get_gear_information, 136
get_gear_settings, 136
get_globally_unique_identifier, 136
get_hallsensor_information, 137
get_hallsensor_settings, 137
get_home_settings, 137
get_home_settings_calb, 137
get_init_random, 138
get_joystick_settings, 138
get_measurements, 138
get_motor_information, 138
get_motor_settings, 139
get_move_settings, 139
get_move_settings_calb, 139
get_network_settings, 139
get_nonvolatile_memory, 140
get_password_settings, 140
get_pid_settings, 140
get_position, 140

get_position_calb, 141
get_power_settings, 141
get_secure_settings, 141
get_serial_number, 141
get_stage_information, 142
get_stage_name, 142
get_stage_settings, 142
get_status, 142
get_status_calb, 143
get_sync_in_settings, 143
get_sync_in_settings_calb, 143
get_sync_out_settings, 144
get_sync_out_settings_calb, 144
get_uart_settings, 144
goto_firmware, 144
H_BRIDGE_ALERT, 111
HOME_DIR_FIRST, 111
HOME_DIR_SECOND, 111
HOME_HALF_MV, 111
HOME_MV_SEC_EN, 111
HOME_USE_FAST, 112
has_firmware, 145
JOY_REVERSE, 112
LOW_UPWR_PROTECTION, 112
load_correction_table, 145
logging_callback_stderr_narrow, 145
logging_callback_stderr_wide, 146
logging_callback_t, 121
MICROSTEP_MODE_FULL, 113
MOVE_STATE_ANTIPLAY, 113
MOVE_STATE_MOVING, 113
MVCMD_ERROR, 113
MVCMD_HOME, 113
MVCMD_LEFT, 114
MVCMD_LOFT, 114
MVCMD_MOVE, 114
MVCMD_MOVR, 114
MVCMD_NAME_BITS, 114
MVCMD_RIGHT, 114
MVCMD_RUNNING, 114
MVCMD_SSTP, 114
MVCMD_STOP, 114
MVCMD_UKNWN, 114
msec_sleep, 146
open_device, 146
POWER_OFF_ENABLED, 114
PWR_STATE_MAX, 115
PWR_STATE_NORM, 115
PWR_STATE_OFF, 115
PWR_STATE_REDUC, 115
PWR_STATE_UNKNOWN, 115
probe_device, 146
REV_SENS_INV, 115
RPM_DIV_1000, 115
reset_locks, 147
STATE_ALARM, 115
STATE_BRAKE, 116
STATE_BUTTON_LEFT, 116
STATE_BUTTON_RIGHT, 116
STATE_CONTR, 116
STATE_CTP_ERROR, 116
STATE_DIG_SIGNAL, 116
STATE_ENC_A, 116
STATE_ENC_B, 117
STATE_ERRC, 117
STATE_ERRD, 117
STATE_ERRV, 117
STATE_EXTIO_ALARM, 117
STATE_GPIO_LEVEL, 117
STATE_GPIO_PINOUT, 117
STATE_IS_HOMED, 117
STATE_LEFT_EDGE, 118
STATE_REV_SENSOR, 118
STATE_RIGHT_EDGE, 118
STATE_SECUR, 118
STATE_SYNC_INPUT, 118
STATE_SYNC_OUTPUT, 119
SYNCIN_ENABLED, 119
SYNCIN_GOTOPOSITION, 119
SYNCIN_INVERT, 119
SYNCOUT_ENABLED, 119
SYNCOUT_IN_STEPS, 119
SYNCOUT_INVERT, 119
SYNCOUT_ONPERIOD, 119
SYNCOUT_ONSTART, 119
SYNCOUT_ONSTOP, 119
SYNCOUT_STATE, 120
service_command_updf, 147
set_accessories_settings, 147
set_bindy_key, 147
set_brake_settings, 147
set_calibration_settings, 147
set_control_settings, 148
set_control_settings_calb, 148
set_controller_name, 148
set_correction_table, 149
set_ctp_settings, 149
set_debug_write, 150
set_edges_settings, 150
set_edges_settings_calb, 150
set_emf_settings, 150
set_encoder_information, 151
set_encoder_settings, 151
set_engine_advanced_setup, 151
set_engine_settings, 151
set_engine_settings_calb, 152
set_entype_settings, 152
set_extended_settings, 152
set_extio_settings, 153
set_feedback_settings, 153
set_gear_information, 153
set_gear_settings, 154

set_hallsensor_information, 154
set_hallsensor_settings, 154
set_home_settings, 154
set_home_settings_calb, 155
set_joystick_settings, 155
set_logging_callback, 155
set_motor_information, 156
set_motor_settings, 156
set_move_settings, 156
set_move_settings_calb, 156
set_network_settings, 156
set_nonvolatile_memory, 157
set_password_settings, 157
set_pid_settings, 157
set_position, 158
set_position_calb, 158
set_power_settings, 158
set_secure_settings, 158
set_serial_number, 159
set_stage_information, 159
set_stage_name, 159
set_stage_settings, 159
set_sync_in_settings, 159
set_sync_in_settings_calb, 160
set_sync_out_settings, 160
set_sync_out_settings_calb, 160
set_uart_settings, 161
UART_PARITY_BITS, 120
WIND_A_STATE_OK, 120
WIND_B_STATE_OK, 120
write_key, 161
XIMC_API, 120
ximc_fix_usbser_sys, 161
ximc_version, 161
ximc_fix_usbser_sys
 ximc.h, 161
ximc_version
 ximc.h, 161